

SERVICE MANUAL

TNC 351/355

Subject to Change/Further Developments

DR. JOHANNES HEIDENHAIN is constantly working on technically improving its units. It is therefore possible that details of your Control may differ slightly from those described herein. If that is the case please order a suitably revised issue of the Service Manual.

Copying/Duplication

This manual is provided subject to the condition that no part of it shall be reproduced in any form or by any means without our prior consent in writing.

Issue: 06/92

D-8225 Traunreut · Tel. (08669) 31-0

HEIDENHAIN

Kundendienst

Co	ntents				
	44	And Contraction of the Contracti		44	Page
1.	How to use the Servic	e Manual 🔊			3
2.	Error Messages				4
S.C.O.	2.1 Possible Causes f	or Error Message	\$S		7
3.	Fault Messages and th	eir Causes			8
4.	LOGIC Unit LE 351/355				13
	4.1 Designation of th	e LOGIC Unit			13
	4.2 Hardware Componen	ts of the LOGIC	Unit		14
	4.3 Connector Layout	LE 351/355			15
	4.4 PROCESSOR Board		~SUILO'		22
	4.5 CLP PROCESSOR Boa	rd			23
	4.6 Grounding Diagram	44		Are .	24
5.	External Supply				25
	5.1 Requirements of t	he External Supp	ply		25
	5.2 Supply for the NC	-Part			26
	5.3 Testing the POWER	SUPPLY Board A	ssembly		29
	5.4 24V-DC Supply for	the PLC-Part			32
	5.5 Buffer Battery				34
6.	KEYBOARD Unit TE 351/	355			35
	6.1 Overview				35
	6.2 Circuit Diagram o	of the KEYBOARD	Unit solution		36
	6.3 Testing the KEYBO	ARD Unit			37
	6.4 Key Matrix				38
7.	DISPLAY Unit BE 212/4	12			41
	7.1 Display for TNC 3				41
	7.2 Display for TNC	355			41
	7.3 Testing the Disp	lay 🖉			42
8.	Measuring Systems				44
	8.1 Error Messages				44
	8.2 Possible Error Ca	ause			44
	8.3 Testing the Measu	iring Systems			44
9 .	Handwheel				46
	9.1 Overview				46
	9.2 Testing the Hands	wheel			46
10.	3D-Touch Probe		Ś.		47
and a	10.1 Overview		~35/4°		47
	10.2 Error Messages				48
	and the second s				



Kundendienst

Contents

									Page
11.	RS-2	32-C Inter	face						49
	11.1	Operating	Modes ME-	-FE-EXT					A9
	11.2	Selecting	Baud-Rate	e					49
	11.3	Connectin	ng Cable an	nd Adapt	er for	the RS-2	232-C/V.2	4	50
	11.4	Machine H	Parameters	for the	RS-232	R-C/V.24-	-Interfac	e	51
	11.5	Connectio	ng Cable fo	or Print	er				52
	11.6	Error Mes	sages						52
12.	Exte	rnal Data	1/0						56
	12.1	External	Data Outpu	it N					56
	12.2	External	Data Inpu	ALION LAND					59
13.	Anal	og Outputs	5 - 4					All .	63
	13.1	Technical	Data						ob 63
	13.2	Measuring	the Analo	og Outpu	t Volta	iges			63
	13.3	Changing	Positional	L Display	y Mode				65
	13.4	Speed Ad	justment						65
	13.5	Offset Ad	ljustment						66
14.	PLC-	1/0							67
	14.1	Technical	Data						ల్ 67
	14.2	Control	of PLC- I/C	o sé					68
	14.3	Test for	PLC-Outpu	t "Contr	ol Read	ly" and :	its Ackno	wledgement	7Ø
	15. '	Test Units	5						72
	15.1	Test Unit	for the l	POWER SU	PPLY Bo	ard Asse	embly		72
	15.2	Test Unit	for the 2	Analog O	utputs				2 72
	15.3	Test Unit	ts for the	PLC-I/O					73
	15.4	Test Unit	t for the 1	KEYBOARD	Unit				74
	15.5	Test Ada	oters and i	Extensio	n Cable	es s			75
16.	Exch	ange Info	mation 🚽						76
	16.1	General							8 76
	16.2	Exchange	Procedure	for the	LOGIC	Unit			80
	16.3	Exchange	Procedure	for the	PROCES	SOR Boar	rd		82
	16.4	Exchange	Procedure	for the	CLP PI	ROCESSOR	Board		84
	16.5	Exchange	Procedure	for the	POWER	SUPPLY I	Board Ass	embly	. 86
	16.6	Exchange	Procedure	for the	PLC P	OWER I/O	Board PI	300	88
	16.7	Exchange	Procedure	for the	EPROM	3			్ 90
17.	Mach	ine Param	eter Listi	na 🖉					91



Kundendienst

<u>1. How to use the TNC 351/355</u> Service Manual

The TNC 351/355 Service Manual can be used for fault diagnosis, fault localisation and elimination of a TNC-controlled machine tool.

In order to determine the fault condition on an NC-machine, a fundamental knowledge of the machine and the servo amplifiers is necessary, as well as a knowledge of their interaction with the Control and measuring system. In addition, improper use of the Control, such as incorrect NC-programming or incorrect selection of machine parameters can lead to the occurrence of fault conditions. Further information in this respect can be found in the:

Machine Documentation of the Manufacturer Service Manual Handbook for the Machine Manufacturer

The handbook for the machine manufacturer is not enclosed with every control as the service manual.

It is generally only supplied to the machine manufacturer and is submitted to a "change service" by HEIDENHAIN, Traunreut. It is therefore absolutely necessary to consult the machine manufacturer in the case of errors concerning the machine parameters or the interface of the control. Support can also be obtained by the HEDIENHAIN service, Traunreut or by HEIDENHAIN agencies.

Telephone numbers or addresses and telex/telefax connections can be found on the inner side of the cover page and on the rear side of the service manual.



Kundendienst

2. Error Messages

The TNC 351/355 contains a comprehensive, integrated supervision system to avoid input or operating errors, to localize and diagnose faults of technical defects of the whole plant (TNC, measuring system, machine, cabling etc.). The supervision system is a fix component of the TNC-hardware and software and is always operative when the control is switched on. The recognition of a technical defect or an operating error is displayed in plain language on the screen.

Insignificant error messages can be erased with the |CE|-key.

The error messages listed are described more precisely in the following instructions:

- Service Manual, section:		44		
- TNC 355 Operating Manual		20.9		
- Handbook for the machine manufacturer, resp. machine documentation of the manufacturer	automat	2		
- FE 401 Operating Instructions		HM/ MD	OM	SI
ADDRESS LETTER ALREADY ASSIGNED			<u>x</u>	<u>ò</u>
SELECTED BLOCK NOT ADDRESSED	Nº.		x	3F
TOUCH POINT INACCESSIBLE	Ser.		<u>x</u>	10.2
ARITHMETICAL ERROR	30		X	
PATH OFFSET WRONGLY ENDED	\$ ⁷	2	s°	
PATH OFFSET WRONGLY STARTED			X	
OPERATION PARAMETERS ERASED		X		2.1
CC-BLOCK MISSING		<u> </u>	X	
CYCL INCOMPLETE	6		x	8
DATA MEDIUM MISSING	N°			11.6
DATA MEDIUM EMPTY	all and a second	<u> </u>	S.	111.6
DATA MEDIUM WRITE-PROTECTED	K.	L	30	11.6
PROGRAM INCOMPLETE	0	2	S.	11.6
BLK FORM DEFINITION INCORRECT	×	A.	X	
AXIS DOUBLE PROGRAMMED		18°	<u>x</u>	_
PLANE WRONGLY DEFINED		·	<u>x</u>	
FURTHER PROGRAM ENTRY IMPOSSIBLE	6	-	x	0
ENTRY VALUE INCORRECT	_X20		<u>x</u>	Nº"
LIMIT SWITCH X+	18 C. C.	x	S.	2.1
LIMIT SWITCH X-	<u> 19</u>	x	30	2.1
LIMIT SWITCH Y+	Ś	x	S°	2.1
LIMIT SWITCH Y-		X	2	2.1
LIMIT SWITCH Z+		X		2.1
LIMIT SWITCH Z-		X		2.1
LIMIT SWITCH AXIS IV +	6	<u>x</u>		2.1
LIMIT SWITCH AXIS IV-	Nº.	<u>x</u>		2.1
LIMIT SWITCH AXIS V+	S.	x	e de la constante de la consta	2.1
LIMIT SWITCH AXIS V-	10	x	10	2.1



Kundendienst

	2000			3°~	
		BA	HM/	OM	SI
	AND AND	FE	MD		
			1		
ERR: 001		х			11.6
ERR: 002		X			11.6
ERR: 003		X	L		11.6
ERR: 004	. S.	X		- 20-	11.6
ERR: 010		x		de la compañía de la	11.6
ERR: Ø11		x	<u></u>		11.6
ERR: Ø12		X	3		11.6
ERR: 013		X			11.6
ERR: 014		X			11.6
ERR: 100	-··· •. •.····	X	ļ		11.6
ERR: 102		X 🖄	.	S	11.6
ERR: 103	20,	X	_		11.6
ERR: 104		X	_	S.	11.6
ERR: 105	, Si	x	<u></u>	Ĩ	111.6
ERR: 106		X	25		11.6
ERR: 107	2.	x			11.6
ERR: 108		x			11.6
EXT. IN-/OUTPUT NOT READY					11.6
EMERGENCY-STOP		3	X	S	14.3
WRONG AXIS PROGRAMMED				X	
WRONG OPERATING MODE				6 ²⁵	11.6
WRONG RPM	S.		X	2	
WRONG POCKET NR.	and the second s		and a start	X	
CHAMFER NOT PERMITTED	24		-22	X	
WRONG PROGRAM DATA				X	11.6
PROTECTED PGM	<u></u>	20	_	X	<u></u>
G-CODE GROUP ALREADY ASSIGNED		St.		X	35
NO EDITING OF RUNNING PROGRAM				x	
CONTOUR PROGRAMMING ERROR		L		X	i
CONTOUR CANNOT BE PROCESSED			<u>s</u>	х	
CONTOUR TOO COMPLEX			524.	х	
CIRCLE END POS. INCORRECT	24		10	X	<u> </u>
CIRCLE CENTRE UNDEFINED			<u> </u>	X	1
SHORT CURRENT INTERRUPTION		S.	<u> </u>		2.1
LABEL NUMBER ALLOCATED		S.		X	35
LABEL NUMBER NOT ALLOCATED	<u></u>	L		X	
MACHINE PARAMETER INCOMPLETE		ļ	ļ	<u></u>	12.2
N-CODE MISSING			, Š	X	
ILLEGAL NC-BLOCK	Str.	ļ	Str.	X	
SLOT WIDTH TOO LARGE	19.		24	<u> </u>	
PGM-SECTION CANNOT BE SHOWN				X	_
PGM XXXXXXX MISSING		2		X	N.
POCKET Ø UNDEFINED		Y		X	<u> </u>
PLC: ERROR Ø			x	5	
·		ĺ		250	
. S' S'		l.	· .ð		
 Anti- Anti- 			and the second		
PLC: ERROR 99	Se .		x		⁻
POSITIONING ERROR			x		2.1
PROGRAM NUMBER ALLOCATED		6		x	0
PROGRAM NUMBER UNAVAILABLE		X°		x	<u>}</u>
PROGRAM MEMORY EXCEEDED				x	



Kundendienst

				HM/	OM	SI
			FE	MD		1
EXCHANGE BUFFER BATTERY					x	5.5
RADIUS COMP. UNDEFINED			128		x	10.2
ROUNDING-OFF UNDEFINED	25		25		X	35
ROUNDING-OFF NOT PERMITTED					X	
ROUNDING RADIUS TOO LARGE		- AL			X	
BLOCK FORMAT INCORRECT	S	Š.			<u> x</u>	
BLOCK NUMBER ALREADY ALLOCAT	ED			34	x	
BLOCK TOO LONG		24		20	х	
SPINDLE ROTATES MISSING					x	
JUMP TO LABEL Ø NOT PERMITTE	D		200		x	20
RELAY TOT. DC VOLTAGE MISSIN	G S		S.	X		14.3
POWER INTERRUPTED		6	С ^о	X	2	14.3
SEARCH ADDRESS MISSING	and the second s				X	
KEY NON FUNCTIONAL	S.	.8		X	82	
EXCHANGE TOUCH PROBE BATTERY	18	and the second s		and a start	x	10.2
STYLUS ALREADY IN CONTACT		20		20	x	10.2
PROBE SYSTEM NOT READY			· · ·		x	10.2
TOOL CALL MISSING	2.62		200		x	
TOOL DEF MISSING	25		S.		x	38
TOOL DEF Ø NOT PERMITTED			<u></u>		X	
ILLEGAL G-CODE	a guilte				x	\perp
PROGRAM-START UNDEFINED	S	<u></u>			Х	
WRONG SIGN PROGRAMMED	State -			Star.	X	<u> </u>
MIRROR IMAGE ON TOOL AXIS		24		10	x	
TOOL NUMBER ALLOCATED				<u> </u>	<u>x</u>	-
TOOL RADIUS TOO LARGE	20		20.		<u>x</u>	<u></u>
ANGLE REFERENCE MISSING			S.		X	A.
EXCESSIVE SUBPROGRAMMING	<u></u>		0		X	~
TOO MANY USER PARAMETER	and the second s			X	all'	
EXCESSIVE SUBCONTOURS	- 75		<u> </u>		X	
TWO TOOL DEF XXX WITH PGM CA	LL	and and	<u> </u>	Str.	<u>x</u>	
3D-INTERPOLATION NOT PERMITT	'ED			14	X	



2.1 Possible Causes for Brror Messages

OPERATING PARAMETERS ERASED

- The machine parameters are principally erased with new units and exchange units.
- Software exchange with different software updates
- Buffer batteries and rechargeable NiCd batteries defective
- RAM-error on PROCESSOR Board

LIMIT SWITCH X+

(e.g.)

"Manual" operating mode When traversing with directional keys the adjusted software limit switch or the additional limitation in the auxiliary operating modes was reached.

"Automatic" operating mode

The positioning path calculated with the current block lies out of the software limit switch or out of the additional limitation. The positioning is not carried out.

Machine parameters for software limit switches

MP 44	MP 45	MP 46	MP 47	MP 48	MP 49	MP 50	MP 51	MP 325	MP 326
X+	X-	¥+	¥-	Z+	Z-	IV+	IV-	V+	V-

SHORT CURRENT INTERRUPTION

- Short collapse of supply to TNC (approx. 120 150 ms)
- Important machine parameters were changed; e.g. MP 12, MP 20, MP 60, MP 72, MP 90, MP 170, MP 184, MP 217, MP 236 etc.

POSITIONING ERROR

- The position supervision entered in machine parameter 56 or 175 is effective (control approach behaviour of axis, optimize again, if required).



Kundendienst

<u>. Fault Messages</u> and their Causes

The integrated supervision system differentiates between insignificant and significant errors. Significant errors are displayed with a flashing display (e.g. erroneous functions of linear transducers, drives and errors in data processing).

The control opens the contact "Control ready" in the case of significant errors. This results in a EMERGENCY-STOP of the machine. The state "EMERGENCY-STOP" can only be eliminated again by switching off

the main switch provided that the error cause was eliminated before.

Flashing disp	lay	3	Possible fault cause				
FAULTY DATA	PROCESSING	Ø	PROCESSOR Board				
,	",2	1	n n n n n n n n n n n n n n n n n n n				
пар, н	tones?	2	A PACE IN A CRACK				
"	ранти	3	H H H H H				
н 48	"	4	n shin shirt				
()	",2.2	A	" wash wash				
с ^{абу} н	A COLORADO	В	CLP PROCESSOR Board				
"	Paul "	C					
	"	D	n shar n share				
	"	E	PROCESSOR or CLP PROCESSOR Board				
н 13	.onah	F	н н н н				
"	paul "	G	CLP PROCESSOR Board				
	н	Real H	PROCESSOR Board				
J.	"	I	n n n n n n n n n n n n n n n n n n n				
Rath H	ton and	ĸ	A THE ADDRESS AND ADDRESS				
н	paul u	Jost C	Machine Parameter *				

* Enable (selection) of a function via machine parameters which are not integrated in the software.

If the error message "FAULTY DATA PROCESSING " (= identification letter, see above!) occurs repeatedly return the compl. LOGIC UNIT to HEIDENHAIN for repair. Indicate also the error message and the identification letter. HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 9

Kundendienst

lashir	ng ć	lisplay	School	Fault cause	
ERROR	IN	PLC-PROGRAM	·····	Fault with non-erasable marker (see also PLC-Description)	
	н	MIGDRUMPIC	A	Start Key or incremental positioning X+	
11	н -	nat n	B	Rapid Traverse Key or incremental positioning X-	
H. Harr	"	. tomative	С	Direction Latch Key or incremental positioning Y+	
**	"	and the Content	D CO	Feed Release or incremental positioning Y-	
" Arand	н	"	E	Start PLC Positioning X-axis or incremental positioning Z+	
н	**	aballomats	F	Start PLC Positioning Y-axis or incremental positioning Z-	
ŧ	Ħ	AND THE REAL PROPERTY IN	G and the	Start PLC Positioning Z-axis or incremental positioning IV+	
Nº.?	н	"	H	Start PLC Positioning IV-axis or incremental positioning IV-	
1	"	M. Ghauton	I	Directional key X+ or incremental positioning V+	
	11 -	11 ²⁰⁰ 11	J	Directional key X- or incremental positioning V-	
H.	"	" Iomable	K	Directional key Y+ or start-PLC-positioning axis V	
I	"	MIGDOL .	L José	Directional key Y-	
6	11 -	19 ⁰⁰¹ 11	M	Directional key Z+ or directional key V+	
ALO.X	••	" nonacht	N	Directional key Z- or directional key V-	
Ŧ	11	and the state of t	0 John Go	Directional key IV+ or supplementary axis to be changed to M2590 and M2591	
H and	Ħ	n Alashe	Ρ	Directional Key IV- or Start PLC Positioning S-axis	
	11	- alter	Q	Non-defined macro called up via PLC markers	

Possible location of fault: PLC Program, PROCESSOR Board, PL 300 (PLC POWER I/O Board Assembly), external keys, switch or wiring DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

EIDENHA

SERVICE MANUAL TNC 351/355 Page 10

Kundendienst

		doalar			
lashing display	54	Fault cau	15e	AND CONTRACT	Second Contraction
GROSS POSITIONING	ERROR A	Position	(trailing error	r) supervision	
Man Charlon	and and a second	positic machine - Trailir Exceedi determ	on supervision of a parameter 57. ng error operat ing trailing er ined by machine	determined by ion: ror supervision parameter 174.	
GROSS POSITIONING	ERROR B	Supervisi	ion of analog v	oltage limit	
N ¹⁰ N ⁰	()	lated l volt li	inal value of by the control : imit (only with	reached the ± 10 speed precontrol)	. doautor
GROSS POSITIONING	ERROR C	Movement	supervision	a aslaulated by th	a same
-Hall	340 Å	control machine	l reached the 1 e parameter 234	imit programmed in	e
GROSS POSITIONING	ERROR D	Standstil	ll supervision	n from the nominal	
ware CO	4	position greater meter	on of an axis a r than programm 169.	t standstill is ed in machine para	- why will be
		- When po program position in mach	ositioning beyon nmed the value on is greater th hine parameter	nd the target poin of the nominal han programmed 169.	t "ó
GROSS POSITIONING	ERROR E	Supervis: - The off reached ment by	ion of offset v fset voltage lin d with an autom y machine param	oltage mit of 100 mV was atic offset adjust eter 252.	www.daur
		adka.e			
Possible location	of error w	ith the error m	message "GROSS	POSITIONING ERROR	

Possible location of error with the error message "GROSS POSITIONING ERROF A/B/C/D/E": With "Gross Positioning Error" the error can be due to any component of the closed loop.

e.g.: - control error (e.g. CLP PROCESSOR Board)

- excessive offset voltage at servo amplifier
- wrong speed adjustment at servo amplifier
- supervision of servo amplifier is effective (e.g. current supervision)
- electrical defect of servo amplifier
- motor defective, tacho, measuring system or cabling
- mechanical defect (bearing, spindle or guidance error)
- excessive mechanical forces on drive



Kundendienst

		~2	D.				
lashing disp	play	and in	Fault cause	8	and the second second		and the second
TRANSDUCER >	C DEFECTIVE	A	Fault code: A B	= signal = signal	amplitude : frequency	fault fault	6
<u> М</u> н – У	7 4	A	- Measuring sy	stem not	connected		
s " 2	Z SCH	A	- Cable damage	đ. S			
"]	EV"	A	Glass scale	dirty or	damaged 🔊		
" \	<u> Г</u> ОС Н	A S	- Scanning hea	d damaged			
		And and	- Measuring sy (CLP PROCESS	stem supe OR Board)	rvision de:	fective	
TRANSDUCER >	K DEFECTIVE	В	Supervision of	measurin	g systems,	see sectio	on 8.3
Con V	7	B	allar,				
· · · · · · · · · · · · · · · · · · ·	, 197 н	Ř –	3°°.				
" 7	- v "	B N	6.				
н " <u>т</u>	7 н	B	and the				
TNC OPERATIN EMERGENCY ST	IG TEMP. EXC TOP DEFECTIV	E	ducers having (counting erro or LOGIC Unit) Temperature in Unit greater t - Fault with t output "Cont	distance- r caused • the inne han +65°C he superv rol Ready	coded refer by measurin r side of f ision rout: " when swit	the LOGIC ine for the	AMARA COSTO
	N. Challer	and H. Bos	machine (see	section	14.3).		
EMERGENCY ST	NOP PLC	41	The error mess 2815 is set wi (M2924 - M3622	age only thout add	appears if itional man	marker ckers	
Carl Carl Carl Carl Carl Carl Carl Carl	anabha.		(11232 <u>4</u> - 113923				
PLC: ERROR ()0	1)	Marker 2924	pault	and the second		
to		as as a	το	and mark	er 2815 wa:	s set	
PLC: ERROR 9)9	1)	Marker 3023				
No.	A.		No.				

 Instead of PLC: ERROR ØØ ... 99, also another dialog may appear with a customized PLC-program. Detailled information can be obtained from the machine manufacturer.



Flashing d	isplay		Fault cause	Fault cause			Possible fault location		
	,ba ^{ute}	mathad		C-checksum * cation of fau rrect checksum	dit m		ballonatikan	, to autic	
CHECK-SUM	ERROR	XXØØ	CRC-checksu	m error with	EPROM	3	PROCESSOR	Board	
Carlyle ?	"	XX10	" naska d		 10.91	4	" (athart	"	
з ^{сог} н	" dante	XX20	WICDOUTON		++	5	Southor'	" "Highaute	
11	н	XX3Ø			n.	6	n		
KOMBRY P.P	"	XX31			sch ² .?	6	" anathad	" %	
	Marrie Hood	XX4Ø	and the second s		u	2	CLP PROCE	SSOR Board	
H	"	XX42	"		" Marta	2	" 	"	
Jonals "	" Maine	XX41	" mailenass		RAM		" nautornau	" "ballo	
"	ANNAL .	XX4 3	A CALL		н	And And	-) 11	" shad!"	
Carly and	н	XXE9	" naska p		" sta?		PROCESSOR	Board	
³⁰ H	doaute	XXEA	" dbauton"		11		Sparton'	" (jbajte	

* CRC = Cyclic Redundancy Check (cyclic block check when data is transmitted) If the error message "CHECKSUM ERROR XXXX" occurs repeatedly return the compl. LOGIC UNIT for repair and indicate the checksum error.



Kundendienst

4. LOGIC Unit LE 351/355

Logic Unit without PLC Power I/O Board Assembly (PL 300)



Logic Board with PLC Power I/O Board Assembly (PL 300)



4.1 Designation of the LOGIC Unit





Kundendienst

4.2 Hardware components of the LOGIC UNIT

The LOGIC UNIT consists of the following assemblies:

- POWER SUPPLY ASSEMBLY
- PLC PROCESSOR Board
- PROCESSOR Board
- PL 300 (= PLC-Power Supply Board, only with Q/W/S/Y-Version)

The following tables show the inserted assemblies for the various LOGIC UNITS.

4.2.1 TNC 355 Assembly Overview, new Hardware Version (connecting sockets marked with colours)

Logic Unit	TNC 355	(IV) + S	10 martine	TNC 355	(V) + S	tomatyle
Assembly	LE 355 B/F	LE 355 Q/W	LE 355 C/G	LE 355 S/Y	LE 355 CR/GR	LE 355 SR/YR
	254 581	254 582	254 819	254 820	249 516	249 517

PROCESSOR BOARD

	249 652	x	X	x	x	x	x
--	---------	---	---	---	---	---	---

CLP PROCESSOR BOARD

249 663			x	x		
249 820	2	·	a la construcción de la construc		x	x S
249 823	x	x	AN AN	, ŝ	<u>z</u>	and the

POWER SUPPLY ASSEMBLY

236 484 Ø7 x x x x x x	
------------------------	--

PL 300

	237 659 x x	x
--	-------------	---



Kundendienst

4.2.2 TNC 351/355 Assembly Overview, old Hardware Version

10 °					-	10		
Logic Unit	TNC 351	CNC 332	TNC 355	5 (IV) + S	IN	355 (V)	TNC 355	(V) + S
Assemblies	LE 351 B/F 243 992	LE 355 /E 236 482	LE 355 B/F 237 660	LE 355 Q/W 238 324	LE 355 B/F 242 408	LE 355 Q/W 242 407	LE 355 C/G 246 813	LE 355 S/Y 248 055
PROCESSOR BOAR	D	- - L						
235 635		x		2		S.		\$
237 930	x	all a	x	x	x	x	x	x
CLP PROCESSOR	BOARD	5	JUN		Jul		JON	··· I
235 769	8	x	8		8	<u> </u>	8	
238 289	584		x	x	320	54	(54
239 863	3		100	1	X	X		14
242 878	X							
245 922		à		à		à	x	x
POWER SUPPLY A	SSEMBLY	35		28 C	2	P.	and the	
236 484 02		x	x	x	x	x	10	
" Ø4	X		30		100		. A .	
" Ø7	34 ¹ 0	*		*	ALCO:	3	X	x
PL 300	22	.	200	32		200	· · · · · · · · · · · · · · · · · · ·	44
237 659		à		X		x x		×
- Sterio	<u> </u>		<u> </u>	N.		14	A.	

x = from first delivery * = from production code K7 (7/89)



SERVICE	MANUAL	TNC	351/355
Page 15			

4.3 LE 351/355 connector layout

4.3.1 Connector layout of LE 351/355 B/F/Q/W LOGIC UNITS





Kundendienst

4.3.2 Connector layout of LE 355 C/G/S/Y LOGIC UNITS





Kundendienst

4.3.3 Connector layout of LE 355.R LOGIC UNITS





4.3.4 Connector layout of the TNC 351/355 B/F/Q/W CLP PROCESSOR Board

X1,X2,X3,X4 encoder input 1, 2, 3, 4 Sine signal input X7 Touch Probe System Flanged socket with 9-pin female insert Flanged socket with 7-pin flanged socket Signal designation Connection no. Signal designation Connection no. QOI Ūĸ õo-Մե <u>5</u>00+ Start 90°-Trigger signal Standby signal Battery warning RI+ RI-<u>6</u> +5 V (Up) Inner shield (U_N) 7 0 V (UN) Outer shield connector housing Inner shield 9 Outer shield = connector housing X8 nominal value output for X,Y,Z,IV,V*,S X5 encoder input 5 Flanged socket with 15-pin female insert Square wave signal input Signal designation Anschluß-Nr. Analog output of X-axis Analog output of Y-axis Analog output of Z-axis Flanged socket with 12-pin female insert Signal designation Connection no. Analog out. of IVth-axis Analog output of Vth-axis Analog output of S-axis 4 <u>La1</u> La1 6 8 W X-axis W X-axis W Z-axis W Z-axis W IVth-axis W IVth-axis W S-axis Un 2 Un 2 $\frac{11}{13}$ 1 14 6 15 Δ Outer shield = connector housing 2,4,6,10,12 do not assign UaS not present UaS 7 * only with 5-axes controls +5 V (sensor line)* +5 V (Up) 2 <u>1</u>2 X9 BE 412 Visual Display Unit $\emptyset V (sensor line) * \\ \emptyset V (U_N)$ 11 Flanged socket with 15-pin female insert 10 Anschluß-Nr. Signal designation Shield = housing 9 (via spring) 1,8,11 Ø V V SYNC * The sensor line is connected in the unit with the pertinent supply line. 10 H SYNC BRIGHT/DARK 12VIDEO 13 Outer shield = connector housing 3 to 6,14,15 do not assign X6 Electronic Handwheel HR 150/250 Flanged socket with 9-pin female insert X10 reference pulse inhibit Signal designation Connection no. Flanged socket with 9-pin female insert ão-Connection no. 900+ Signal designation <u>900-</u> Shield Ref. pulse inhibit X1 +5 V (U_b) ØV (U_N) Ref. pulse inhibit X2 Ref. pulse inhibit X3 4 Inner shield (0 volt) Ref. pulse inhibit X4 5 Outer shield = connector housing Ref. pulse inhibit X5 +24 V (PLC)* Ø V (PLC) б 7.8 do not assign 7 do not assign * only with LE 351, id.no. 243 992 ..., LE 355, id.no. 237 660..., 238 324..., 242 407 ..., 242 408 ..



4.3.5 Connector layouts for LE 355 C/G/S/Y/.R CLP PROCESSOR BOARD

X1, X2, X3, X4 encoder input 1, 2, 3, 4 X12 TS120 Touch Probe System (TS 111/TS 511 only via cable adapter) see page 16 X1, X2, X3, X4 Flanged socket with 15-pin female/male insert Signal designation Connection no. X5, X6 encoder input 5, 6 ØV-shield 1 square-wave input Standby signal 3 Start 4 see page 16 X5 +15V 5 +15V (Up) 6 7 8 Battery warning ØV (U_N) X7 HR 150/250 Electronic Handwheel Trigger signal 9 Trigger signal²) 10 see page 16 X6 Do not assign 2, 11 to 15 X13 encoder 2, 3, 4 with square wave signal X8 nominal value output for X, Y, Z, IV, V, S input see page 16 X8 Flanged socket with 25-pin female insert <u>Signal designation</u> U_{a1} Connection no. X9 BE 412 Visual Display Unit Ua 2 2 U_{a Ø} 3 Uas see page 16 X9 4 encoder 4 Uai 14 15 16 Ue 2 Uaø X10 reference pulse inhibit 17, ØV 🛛 Uai 5 see page 16 X10 Ŭa 2 6 Uno 7 Ūas 8 -encoder 3 18 Ŭaı X11 Handwheel with axis switch-over keys Ua 2 19 20 Uae Flanged socket with 9-pin female/male insert ØV 21-Uai 9 Signal designation Connection no. Ua 2 10 ØV Vae 2 11 +5V Uas 12 encoder 2 3 22 +12VΔ Ua1 23 -15V 5 Ue 2 DTR 6 ป็อด 24 RxD ØV 25 7 1, 8, 9 13 Do not assign Do not assign

Outer shield housing



4.3.6 Connector layout of PROCESSOR BOARD

X21 PLC-output

Flange socket, female (37-pole)

Contact No.	Allocation	
1	A0 3)	
2	A1 3)	
3	A2 ³⁾	
4	A3 ³⁾	
5 👌	A4 ³	
6	A5 ³⁾	
7	A6 3)	- 2
8	A7 ³¹	50-
9	A8	
10	A9	<u>-</u>
11	A10	
12	A11	
13	A12	
14	A13	
15	A14 .0	<u>. 6</u>
16	A15	<u></u>
17	A16	
18	A17	
19	A18	
20 👌	A19	
21	A20	
22	A21	- 20
23	A22	300
24	A23	
25	A24 ²⁾	
26	A25 21	
27	A26 ²⁾	
28	A27 ²⁾	
29	A28 ²⁾	2
30	A29 2)	185
31	A30 ²⁾	<u> </u>
32, 33	do not assign	
34	Control operational	
35, 36, 37	24 V via external EMERGENCY STOP disconnectible (PLC ¹⁾)	
Housing	External screen	

¹⁷ If required, the supply <u>vol</u>tage for the disconnectible outputs can be assigned to connector X24, pin 1

²¹ not disconnectible via external EMERGENCY STOP A0 ... A23 are disconnectible via external EMERGENCY STOP

³⁹ A0 ... A7 duplicated on X27. Machine operating panel

X22 PLC-input

Flange socket, female (37-pole)

Contact No.	Allocation
100	EO
2	E1
3	E2
4	E3 Feedback signal for test "Control operational"
5	E4
6 🖉	E5 🔊
7 🔬	E6
80	E7
9	E8
10	E9
11	E10
12	E11
13	E12
14	E13
15	E14
16	E15
17	E16
18	E17
19	E18
20 🔬	E19
21	E20
22 🖉	E21
23	E22
24	E23
25	E24
26	E25
27	E26
28	E27
29	E28
30	E29
31	E30 0
32	E31
33, 34	do not assign
35, 36, 37	0 V (PLC)"
Housing	External screen

If required, the 0 V-connection can be assigned to connector X24, pin 3

DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

EIDENHAIN

Kundendienst

X23 KEYBOARD Unit TE 351/355

Flanged socket connector (37-pin)

Pin no.	Assignment	
1 25	RLØ	8
2	RL1	
3	RL2	
4	RL3	for key matrix
5	RL4	San.
6	RL5	
7	RL6	
8	RL7	
9	E128	100
10	E129	
11	E130	
12	E131	.8
13	E132	S.
14	E133	N
15	E134	
16	E135	200
17	E136	25
18	E137	
19	E138	and the second sec
20	OUTØ	Š
21	OUT1	
22	OUT2	
23	OUT 3	for kev matrix
24	OUT4	2
25	OUT5	
26	OUT6	
27	OUT7	
28	E139	8
29	E140	
30	+15V (suppl	v for kevs on
	Machine Ope	rating Panel)
31	E141	Ś.
32	E142	S.
33	E143	SC.
34	Spindle Ove	rride (wiper)
35	Feed Overri	de (wiper)
36	+12V Overri	de Potentiometer
37	ØV Override	Potentiometer
housing	outer shiel	d
0		Ś.

X24 PLC Supply

Terminal block

Terminal no.	Assignment
1 Jonadian	+24V disconnectable via external EMERGENCY-STOP ¹
2	+24V not disconnectable
3 ്	QV2 > ()

- The supply can be optionally assigned to connector X21, pin 35, 36, 37.
- 2) ØV can be optionally assigned to connector X22, pin 35, 36, 37.

X26 Data Interface RS-232-C

Flanged socket, connector (25-pin)

Pin no. 🚿	Assignment
1	shield
2	RxD
3 ്	TxD
4	CTS
5	RTS
6	DTR
7	GND
8 to 19 🔊	do not assign
20	DSR
21 to 25	do not assign
housing	outer shield

PLC-inputs E128...E140 from Machine Operating Panel

SERVICE MANUAL TNC 351/355 Page 18



Kundendienst

X27 Machine Operating Panel

Flanged socket, connector (37-pin)

This connection is used when the assigned inputs on the TE 355 are insufficient.

Pin no.	Assignment	1991 - 1992 - 19
1	E128	
2	E129	N
3	E130	······································
4	E131	L
5	E132	
6	E133	20
7	E134	100
8	E135	N.S.
9	E136	3
10	E137	
110	E138	
12	E139	26
13	E140	Sol
14	E141	.S ⁶
15	E142	. S
16	E143	. State.
17	E144	14
18	E145	
19	E146	
20	E147	10%
21	E148	30,
22	E149	and the second s
23	E150	<u></u>
24	E151	18 C
25	E152	
26	A0 🔊	
27	A1	N.
28	A2	Ser.
29	A3 🚫	
30	A4	
31	A5	AN .
32 📣	A6	Sec.
33	A7	
34	0 V (PLC)	~
35	0 V (PLC)	
36	+24 V (PLC)	100 M
37	+24 V (PLC)	S.

PLC outputs A# ... A7 to Machine Operating Panel

X31 Logic Supply (LE)





4.3.7 Connector Layout of the PLC POWER I/O Board Assembly PL 300



HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

Kundendienst

4.3.8 Connector Layouts of the TE 351/355 KEYBOARD Unit

X1 For connection of the machine operating panel

Flange socket, female (25-pole)

Contact No.	Allocation				
1	E140				
2	E139				
3	E138				
4	E137				
5 🚫	E136				
6	E135				
7	E134				
8	E133				
9	E132				
10	E131				
11	E130				
12	E129				
13 🖉	E128				
14 ¹⁾	0 V (override potentiometer)				
15 ¹⁾	+12 V (override potentiometer)				
16 ¹⁾	Feed rate override potentiometer (wiper)				
17 ¹⁾	Spindle override potentiometer (wiper)				
18 to 21	do not assign				
22	+15 V (Supply for buttons of machine operating panel)				
23	E143				
24	E142				
25	E141				

CautionI

Do not assign if the potentiometer on the TE is to be used.

X2 For connection of the logic unit LE 355

Flange socket, male (37-pole)

Contact No.	Allocation	<u></u>
1,8°	RLO	80
2	RL1	
3	RL2 🔊	
4	RL3	
5	RL4	for key matrix
6	RL5	
7	RL6	
3	RL7	
90	E128	<u> </u>
0	E129	L
1	E130	
2	E131	2
3	E132	1 Contraction of the second se
4	E133	J.
5	E134	
6	E135	10 ⁰
7	E136	·····
8	E137	
9	E138	
20	Ουτο	0
21	OUT1	
22	OUT2	
23	OUT3	
24	OUT4	for key matrix
25	OUT5	
26	OUT6	
27		
28	E139	
29 🔊	E140	20
30	+15 V (Supply f operating panel	or buttons of machine
310	E141	Š ²
32	E142	les
33	E143	
34	Spindle override	(wiper)
35	Feed rate overri	de (wiper)
36 🔊	+12 V Override	potentiometer
37	0 V Override po	tentiometer



4.4 PROCESSOR Board

4.4.1 Interface

- 57 PLC-inputs 32 PLC-outputs
- Keyboard Unit
- Machine Operating Panel
- V. 24-interface

4.4.2 Supervision

- Program memory
- Data Processing
- PLC-program
- Acknowledgement Emergency-stop

4.4.3 Storage

- NC-Programs
- PLC-Program
- Machine parameters
- List of compensation values
- Operating program

4.5 CLP PROCESSOR Board

4.5.1 Interface

- Encoder inputs
- Reference pulse inhibit
- Electronic Handwheel
- 3D-Touch Probe
- Analog outputs
- Display

4.5.2 Supervision

- Measuring systems
- Temperature
- Buffer battery
- Data processing
- Program memory
- Axis positions (closed loop)

4.5.3 Storage

- Operating program











Kundendienst





Kundendienst

5. External Supply

5.1 Requirements of the Ext. Supply

The LE 355 must not be supplied by the machine control voltage! The LE 355 needs its own, external, separately generated supply voltage to VDE 0551. 24 V DC-voltage with a permissible oscillated AC-component of 1.5 V_{PP} (recommended filter capacitor 10000 µF/40 V–).



The **PLC-part** (PLC-inputs and outputs of the LE 355 and PL 300) is operated on the **24 V control voltage of the machine** which is generated according to VDE 0550.

Superimposed oscillated AC components which derive from an uncontrolled three-phase non-filtered bridge circuit with a ripple factor (see DIN 40110/10.75, Section 1.2) of 5% are permitted. This results in a maximum absolute value of 33.4 V for the upper voltage limit and a minimum absolute value of 18.5 V for the lower limit.

U 33.4 V 31 V -				
20.4 V 18.5 V				
C. S.	e d'	matter		

The **O V-lines** of the two power sources must be connected together ($\emptyset \ge 6 \text{ mm}^2$) and to the central operating ground of the machine ($\div B$) via an earth ground ($\emptyset \ge 6 \text{ mm}^2$).

t

Unit Supply voltage Voltage range Max. current Power consumption Average DC voltage consumption NC 24 V Lower limit 1.5 A approx, 30 W 20.4 V (VDE 0551) LE 355 PLC 1.8 A approx. 6 W if half of the inputs if approx. 1/3 of the and outputs are inputs and outputs driven simultaneously are driven simultaneously 24 V PL 300 (VDE 0550) Upper limit 21 A approx. 25 W 31 V1) if half of the inputs if approx. 1/3 of the and outputs are inputs and outputs driven simultaneously are driven simultaneously

The voltages must comply with the definitions given below:



Kundendienst

The BE 412(B) Display is supplied with mains voltage (ac voltage). With the mains voltage selector two voltage ranges can be adjusted in the BE 412B and six in the BE 412. Please check whether the mains voltage selector is correctly set and whether the correct mains fuse is used.

BE 412

Voltage supply	Voltage range	Frequency range	Power consumption	Mains fuse
100/120/140 V ~	-15 % +10%	A2 62 H7	approx A0 M	T 0.630 A
200/220/240 V ~	10 % 110%	-10 02 112	approx. 40 W	T Ø.315 A



In case of 110 V supply voltage the mains voltage selector must be adjusted to 120 V.

BE 412B

Supply voltage	Voltage range	Frequency range	Power consumption	Mains fuse
110 V~	85 V~ - 132 V~	2°	approx. 40 W	M2A
220 V~	170 V~ - 264 V~			M 1.25 A



HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 26

Kundendienst

5.2 Supply for the NC-Part

The supply for the NC-part is connected to the X31 terminals.

The various voltages for the LE are converted in the "POWER SUPPLY Board Assembly" from the +24V- supplied (see Block Diagrams, page 27 and 28).

The on/off-condition of the output voltages are displayed by LEDs. The level of the individual voltages can only coarsely be displayed by LEDs. To make a precise statement about the single voltages they must be measured for accuracy and correspond to the following table:

Output	UNOML [V]	UMIN [V]	UMAX [V]	INOML [A]
+ 5 V -	+ 5.15	+ 5.05	+ 5.25	2.5
+ 12 V	+ 12	+ 11.4	+ 12.6	Ø.15
- 12 V	- 12	- 11.4	- 12.6	0.08
+ 15 V	+ 15	+ 14.2	+ 15.8	Ø.3
- 15 V	- 15	- 14.2	- 15.8	Ø.07 🚿
UBATT	+ 4.5	+ 3.7	2 2	~ 50 µA
+ 24 V BE	+ 24	+ 20.4	+ 31	onator -
+ 12 V BE 1)	+ 12	+ 11.5	+ 12.5	1.3
+ 5 y * 1)	+ 5	+ 4.75	+ 5.25	0.3 🐇

The red LED for the RESET signal illuminates briefly when switching the control on/off. (only applies for TNC 355; the TNC 351 does not have a RESET LED) RESET TNC 351 $U_{L MAX} = 0.4 V U_{H MIN} = 3.9 V t_{L} = 100-300ms$ RESET TNC 355 $U_{L MAX} = 0.4 V U_{H MIN} = 3.0 V t_{L} = 100-300ms$ 1) + 12 V BE (for BE 212) and +5V* (potential-free) only with the

power supply, id.no. 236 484 Ø4 for TNC 351.



Kundendienst

5.2.1 LE 351 NC POWER SUPPLY Board Assembly



The connector doesn't exist with new versions due to direct soldering of the insulated wires onto the power supply board.



Kundendienst

5.2.2 LE 355 NC POWER SUPPLY Board Assembly Fig. 4 PLC Adapter (Id. No. 224 873 ZY)



The connector doesn't exist with new versions due to direct soldering of the insulated wires onto the power supply board.



Kundendienst

5.3 Testing the POWER SUPPLY Board Assembly

The POWER SUPPLY Board Assembly is protected by two fine-wire fuses. The +24V BE output voltage is protected by a F 2.5A fuse, all other output voltages by F 4.0A (see Block Diagram, pages 27 and 28). If a fault is detected (all voltages are missing) check if the LE 24V supply is present, then the two fuses.

Safe and fast testing of the POWER SUPPLY Board Assembly is possible by means of the PSA LOAD UNIT. The plug connection to the boards at the POWER SUPPLY Board Assembly has to be disconnected and the PSA LOAD UNIT has to be connected in its place.

Various voltages can be measured with a voltmeter at the sockets of the PSA LOAD UNIT. The measured values and tolerances can be compared with the values in the table, page 26. If the values of the measurements do not coincide with the values of the table the POWER SUPPLY Board Assembly is defective.

If no PSA LOAD UNIT is available the voltages may also be measured at the test points on the PROCESSOR Board or on the CLP PROCESSOR Board (for location of test points, see section 5.3.2).

ATTENTION

When connecting (disconnecting, always switch off mains switch first!


Kundendienst

5.3.1 Measuring Circuit with PSA LOAD UNIT





Kundendienst

5.3.2 Test Points on the Boards





Kundendienst

5.4 Supply for the PLC-Part

The terminal supply of the internal PLC-part is normally connected to the X 24 terminal (1 = +24V disconnectable, 2 = +24V not disconnectable 3 = ØV). The Ø-volt line as well as the +24V disconnectable can optionally be connected via connector X 21 or X 22 (see PLC-Connection Diagram, page 33).

The supply for the PLC POWER Board Assembly PL 300 (only with Q/W/S/Y-versions) is connected to the X 12 terminal (0V), X 13 (+24V disconnectable) and the connector blocks X 3/12 (+24V not disconnectable). See PLC-Connection Diagram, page 33.

There are **no** fuses on the PLC POWER I/O Board Assembly (electronic current limitation).

The +24V which can be switched off are protected on all PROCESSOR boards with a F 2.5A fine-wire fuse and indicated with a green LED. The +24V which cannot be switched off are only protected with a F 1A fine-wire fuse on the PROCESSOR Board, id.no. 249 652 ..







Kundendienst

5.4.1 Connection Diagram for the PLC Supply





Kundendienst

5.5 Buffer Batteries

Change Buffer Battery

The buffer battery is the voltage source for the program memory with switched-off machine.

If the message

EXCHANGE BUFFER BATTERY

appears the batteries have to be exchanged within one week.

The buffer batteries are located behind a PG screwed connection in the POWER SUPPLY Board Assembly of the LE 351/355.

Apart from the batteries additional rechargeable NiCd batteries on the PROCESSOR Board were used to backup the program memory of TNC 351 and TNC355.

The mains voltage can be switched off to exchange the batteries. The rechargeable batteries store the contents without batteries for approx. 2 weeks.



The rechargeable NiCd batteries are only charged if the TNC is switched on.



IEC-designation "LRG" Recommendation: PHILIPS Type LR 6 1.5V



PROCESSOR Board

-rechargeable NiCd batteries

HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 35

Kundendienst

6. TE 351/355 KEYBOARD UNIT

6.1 Overview

TE	351	A	Id.no.	243 995	Ø2	1)4)
TE	355		н _К	237 661	Ø1	2)4)
TE	355	A	- H 30	*1	Ø2	4)
TE	355	С			Ø3	5)
TE	355		Id.no.	255 Ø15	01	2)3)4)
ΤE	355	A	е н	"	02	3)4)
TE	355	C	11	н	Ø3	3)5)

ΤE	355	B	Id.no.	241 964	Ø1	4)
TE	355	D	**	"	02	5)
TE	355	В	Id.no.	255 Ø16	01	3)4)
TE	355	D	п	а ^р . н	Ø2	3)5)



0000 0000 000 0 0000 00000 ٠ . O 00000 0000 00000 00000 00000 O 00000 00000 wide version

- high version
- 1) without graphic keys
- 2) without connector X 1 (connection to Machine Operating Panel)
- 3) with ground connection
- 4) IV-axes-version
- 5) V-axes-version

HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 36

Kundendienst







Kundendienst

6.3 Testing the KEYBOARD Unit

Safe and fast testing of the KEYBOARD Unit is possible by means of a KEYBOARD TEST UNIT. The KEYBOARD TEST UNIT is connected to the X 23 connection of the LE.

On the KEYBOARD TEST Unit the **key code**, the input states of the inputs **E 128** to **E 143** and +12V are displayed. In addition, the voltages for the inputs **E 128** to **E 143** as well as the wiper voltage for the override or spindle potentiometer (approx \emptyset - 11.5V) can be measured.

With switched-on LE and pressing a key the respective LEDs RL and Out illuminate. The key code can be compared to the tables, pages 38 to 40.

If no KEYBOARD TEST UNIT is available the contacts of the keys can also be measured with an ohmmeter at the connector.

6.3.1 KEYBOARD TEST UNIT Connection

KEYBOARD Unit



E 128 to **E 143** for the Machine Operating Panel

LOGIC Unit

X 23

 $R_{L} \overset{\circ}{\bullet} \overset{1}{\bullet} \overset{2}{\bullet} \overset{3}{\bullet} \overset{4}{\bullet} \overset{5}{\bullet} \overset{5}{\bullet} \overset{7}{\bullet}$ out $\overset{\circ}{\bullet} \overset{1}{\bullet} \overset{2}{\bullet} \overset{3}{\bullet} \overset{4}{\bullet} \overset{5}{\bullet} \overset{5}{\bullet} \overset{7}{\bullet}$ eut $\overset{\circ}{\bullet} \overset{1}{\bullet} \overset{2}{\bullet} \overset{3}{\bullet} \overset{4}{\bullet} \overset{5}{\bullet} \overset{5}{\bullet} \overset{7}{\bullet}$ I 28 129 130 131 132 133 134 135E $\overset{\circ}{\bullet} \overset{\circ}{\bullet} \overset{\circ$

KEYBOARD TEST UNIT

HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 38

Kundendienst

6.4 Key Matrix

X2 Pin	1	2	3	4	5	6	7	8	20	21	22	23	24	25	26	27
Кеу	RLØ	RL1	RL2	RL3	RL4	RL5	RL6	RL7	00	01	02	03	04	05	06	07
PGM NR		~	Sto.		1	Daute		€	1000			~	€			2020
CL PGM		And I.			Sala a		•	A	2.55	 		and the second	•		and a start	<u></u>
PGM CALL			-	8		•	6				2		Ð	8		<u></u>
S.			á	1			and the state			ante	X		á	1 ^{0×}		
4		x	SULCON .			100150		•	1000	e e		Ð	aller			20000
~		A ACAN !!			Rach		Ð	Å	24.5	<u> </u>		Ð		<u> </u>	A A A	<u></u>
			1	8			Ð				•			8		
<u></u>			á	3			and the	Ð		and the	Ð		, á	100	<u> </u>	
⊶		X	SHO			€			1000			Ð	all ^{on}			100,000
Jc		a de la			€			Å			1	Ð				<u>.</u>
	2			8	╺┻╍╌╌╌		3			1	~	1	1	8	.	
MOD			, á	3			Ð			20H	Ĩ		Å	K°	6	
BLK	;		S.HOT			102150	€		1005	pî -			J.HON			€
MAGN		and in the second	1					€	4 ¹		········	and and it				€
START				~		€	8									Ð
J.S.N.			్లు	No.1	1		and and	_L	4	Land Contraction		d	Å	Aro. Y	I	L
(P)	•		SUILON			1020 LO			10213	p.			JUICO'		•	102110
8		0	1			\$P.		. Sh	4.			Carah.			Ð	9
			•	8			8				2			~	Ð	
•			1	•			Selfer.			and the			Å		ŧ	
\odot			33101		Ð	Gallo			1000	5		x	auton		0	1020 LO
8	Ð	And Contraction				ço			h.C			and in				•
∍		•		~			~							~		€
MOD			•	300			Jelle .			and and			_5	Ser.		Ð
P		~	300	6		Call ^O		-	150 ¹⁵	5		~	ANON Y	1		
I		And C		1	Ð	Ş		Å	A.C.			and C		1	3	⊕



X2 Pin	1	2	3	4	5	6	7	8	2Ø	21	22	23	24	25	26	27
Key	RLØ	RL1	RL2	RL3	RL4	RL5	RL6	RL7	00	01	02	03	04	05	06	07
		1	ð	1	Ð		Ser Ser			S. S. S.			Ð			
TOUCH		x	3 ¹⁰	•		Calle		1	.			xó	NICOLO IN			10015C
		A.A.I.		€	54.44			3	4. C.C.			and in the second		6	444	<u> </u>
+	5		Ð	8			6			1	6			.		
Card Control	€		600				Server .			1. and the			S.	œ		
GOTO		x	Sec.			Calle	€		(Daul			x	5	e		20050
ł					54.44	€		34	8						•	
+				8			6	Ð			6			¢		
H			S.	10		€	alle a			Cardhe		1	Ĩ	•		
× → .		20	30	1		Calle		•	10aus	0		x	S. S.C.		Ð	100110
STOP					Ð			4	h.,		•	e and a second			5	
CYCL DEF	5			8			6	Ð		6	6			6		
			S.S.	1			Ð			•			J.	ter.		
LOL SET			300			•			, ionit	•		, co	5 ¹⁰			100 JE
		in the second						4	9	•					4hh	
		Ð		6			6				6					
TOOL DEF			and					•	•	Carthe			and	19		
TOOL			310			Callo	€		•			x	S ^{ILO}			Daillo
RĿ		in in in			S.S.A.	Ð		4	•			and in the second			444	
R₽				2	Ð	ł	~		6					8		



Kundendienst

						<u></u>										
X2 Pin	1	2	3	4	5	6	7	8	20	21	22	23	24	25	26	27
Key	RLØ	RL1	RL2	RL3	RL4	RL5	RL6	RL7	00	01	02	03	04	05	06	07
X			60	Ð			Je Star			Card Card			€			
7		.8	€.			Calle			doaut			, d	⊕			KORD C
8	1	•			44.44			14	¢			A.A.A.	•		444	
9	€			6			.0				ò		Ð	6		
Y			J.	Ð		ć	3 Stor			Cardeo		Ð	E.			
4		, de	Ð			(Daile			doaut			Ð	STO.			Sparter Start
5	~	Ð			444			4	2			•	1		4	
6	Ð			8			6				6	Ð		6		
Ζ			60	•			Je hou	1	1	Carles	6	<u> </u>	20	1		
1		×	€			Carlie Carlie	1		doauti		Ð	×	S.C.			20000
2		•			hun			H.	2		Ð	a sai			444	
3	Ð			6			6				€			8	•	
IV			a de la comercia de l	•			all a			•		1	a la	to.		
0			2 ⁵⁰			Calle			dout'	•		×	3 ²⁰			Daute
·			6		the second			4	1. N.	•		and a second			444	
₩.	Ð			8			8			•	6		ļ	6		
CE			J.S.	1	•		and a			Carle			J.	•		
*VQ	-	20	്⊕			Oalito			0	b.		20	SUIC.			Dauto
* Q Q DEF		•			And A			4	•			Caral C			444	
	€			~					Ð		_	<u> </u>		~		

* Key assignment for 5-axis-version



Kundendienst

7. DISPLAY Unit BE 212/412

7.1 DISPLAY Unit for TNC 351



7.2 DISPLAY Units for TNC 355

BE 412 Id.no. 237 657 Ø1

BE 412 B Id.no. 241 845 Ø1



discontinued type



current type



Kundendienst

7.3 Testing the DISPLAY Unit

BE 412

If the machine is switched on and the DISPLAY Unit remains dark check the mains fuse (mains fuse integrated with voltage selector at rear of **DISPLAY Unit**) and replace, if necessary.

If the fuse is in order you can check with the TNC 355 whether the fault is on the **DISPLAY Unit** or on the LE by disconnecting the plug-and-socket connection.

With disconnected plug and switched-on display a bright, rectangular field has to be displayed.



autonic autonic autonic

If the screen displays this field the CLP PROCESSOR Board in the LOGIC Unit might be defective.

If, however, the display remains dark with plug disconnected the display is defective and has to be exchanged.

BE 212

This test cannot be carried out with the TNC 351 since the DISPLAY Unit of this control does not have its own mains supply.

The voltage is supplied by the LOGIC Unit and can be checked with a voltmeter at connector X9 (pin 1, 8 and 11 $\emptyset V$, pin 2 and 4 +12V).

The control signals for the TNC 351 and the TNC 355 Display Unit can only be checked with an oscilloscope and must correspond to the following diagrams. With diagrams for VIDEO and BRIGHT/DARK, deviations may occur in the time base in the figures shown.

As to connector layout, see section 4.3.4.



7.3.1 Timing Diagrams LE 351 with BE 212

X 9 Connector Timing Diagrams



















5ms/DIV



Kundendienst

Measuring Systems

8.1 Error Messages



= signal amplitude fault

TRANSDUCER X DEFECT \mathbf{B} = signal frequency fault

8.2 Possible Fault Cause

- Glass scale dirty or damaged
- Scanning head damaged or defective
- Cable damaged
- Encoder input in the LOGIC Unit (LE) defective

8.3 Testing the Measuring Systems

Encoders can be interchanged with each other at the LOGIC Unit (X1...X5 refer to section 4.3.1 LOGIC Unit Connections) which allows you to determine whether the encoders or the encoder inputs of the LOGIC Unit is defective. In conjunction with the above procedure the respective machine parameters have to be changed when interchanging encoders at the LOGIC Unit (LE).

55	MP	Input value	
X	253	Ø ≜ standard allocation	5
Y	254	1 ≙ encoder input X1	
Z	255	2 ≙ encoder input X2	
IV	256	3 ≜ encoder input X3	
X	257	4 ≙ encoder input X4	
NO.X		5 ≙ encoder input X5	
5	2	6 ≑ encoder input X6 (only w	ith
	30	V-axes-	version)
	X Y Z IV V	MP X 253 Y 254 Z 255 IV 256 V 257	MPInput valueX253 $\emptyset \triangleq$ standard allocationY2541 \triangleq encoder input X1Z2552 \triangleq encoder input X2IV2563 \triangleq encoder input X3V2574 \triangleq encoder input X45 \triangleq encoder input X56 \triangleq encoder input X6 (only W V-axes-

Procedure with an error message e.g. "ENCODER X DEFECTIVE B"

- Switch off main switch
- Exchange X-axis of encoder, e.g. with the Y-axis at the LOGIC Unit
- Switch on main switch
- Call machine parameters with the error message "POWER INTERRUPTED" with key number 95148 and exchange the input values from machine parameter 253 and 254. If the input value for the machine parameters is 0 the machine parameter 253 has to be programmed with 2 and 254 with 1.
- Enter machine parameters and switch on machine as usual.

If the same error message "ENCODER X DEFECTIVE" appears the error is due to the encoders or the extension cable. If the error message changed from "X" to "Y", however, the encoder input of the LOGIC Unit is defective.

If the reference pulse inhibit (connector X10) is used and if positioning should occur with exchanged encoders also the reference pulse inhibit for the respective axes must be exchanged.



Kundendienst

8.3.1 Electrically Checking the Scanning Head of the Measuring System

To determine if the measuring system is at fault the following test equipment is used:

- phase angle measuring unit (PWM) with/without oscilloscope

- high-resistance short circuit tester

If no phase angle measuring unit is available an ohmmeter can be used to electrically test the state of the cable, the lamp and the photoelements of a measuring system by taking the following measurements at the connector of the measuring system:

- Connector housing of measuring system with machine housing $\leq 1 Q$ (outer shielding)
- Connector housing of measuring system with pin 9 (inner screen outer screen) R = •
- Connector housing of measuring system with pin 1 to 8 (outer screen signal lines) R = ••
- Pin 9 with pin 1 to pin 8 (inner screen signal lines) $R = \infty$

-	Pin	8	with	pin	7	RI 1)	(change	poles	of	ohmmeter)	
-	Pin	7	with	pin	8	RI 1)				35	mately the same.
-	Pin	6	with	pin	5	90°	(change	poles	of	ohmmeter	should be approxi-
-	Pin	5	with	pin	6	90°				- CO.	- The measured values
£	Pin	2	with	pin	1	0°	(change	poles	of	ohmmeter)	
Ξ.	Pin	1	WITH	pin	4	Ψ					

- Pin 3 with pin 4 La (approx. $5 30 \Omega$)
- 1) With measuring systems having an adjustable reference mark different values or no resistances are measured depending on the type of activation.

Diagram of measuring system with sine-wave output signals



Measuring systems with square-wave output signals can only be tested with a phase angle measuring unit (PWM).



Kundendienst

9. Handwheel

- 9.1 Overview
- 9.1.1 Handwheels with sine signal
 - HR 150 Id.no. 217 978 --



HR 250 Id.no. 217 977 -



9.1.2 Serial Handwheels

HR	130	Id.no.	254	Ø4Ø	
HR	130.001	Id.no.	249	371	

HR 330 Id.no. 251 534 --







Kundendienst

9.2 Checking the Handwheel

9.2.1 Handwheel with sine input

The HR 150, resp. the HR 250 Handwheel can be electrically checked as an encoder, but without reference pulse, however.

9.2.2 Seriel Handwheel

The serial HR 130, resp. the HR 330 Handwheel can only be checked with an oscilloscope. The control signals (X11 pin6 = DTR, pin 8 = RxD) must correspond to the following diagram.

The Handwheel is supplied by the Logic Unit (X11 pin $2 = \emptyset V$, pin 4 = +12V).



Diagram measured at the X11 Logic Unit.



Kundendienst

10. 3D-Touch Probe

10.1 Overview

10.1.1 Touch Probe with an external Interface Electronics (APE)



10.1.2 Touch Probe with integrated Interface Electronics (APE)

TS 120 Id.no. 243 614 --





Kundendienst

10.2 Brror Messages

1. TOUCH POINT INACCESSIBLE

After starting a probe the probing point was not reached within the measuring path determined in machine parameter 216.

2. EXCHANGE TOUCH PROBE BATTERY

The battery voltage of the touch probe with infrared transmission remains below admissible level.

3. STYLUS ALREADY IN CONTACT

When starting a probe function, the stylus is already deflected.

4. PROBE SYSTEM NOT READY

The infrared transmission path between the "Touch Probe" and the "Transmit-Receive Unit" is obstructed (e.g. coolant film on probe windows) or is interrupted completely. The touch probe side with two windows has to be adjusted in the direction of transmit-receive unit.



11. RS-232-C/V.24 - Interface

<u>11.1 Operating Modes ME-FE-EXT</u>

The TNC 355 can be switched to 3 operating modes for data transmission as follows:

- ME To connect the ME 101/ME 102 HEIDENHAIN Magnetic Tape Unit or other peripheral units. The data format (7 data bits, 1 stop bit, parity (even parity) and the baud rate (2400) are adapted to the ME.
- FE To connect the FE 401 HEIDENHAIN Floppy Disk Unit or other peripheral units. The data is transmitted with a special protocol (blockwise transfer) in order to backup data. The data format (7 data bits, 1 stop bit, parity (even parity), the baud rate (9600) and the transmission protocol is adapted to the FE.
- EXT To adapt data transmission in the standard data format and for blockwise transfer on external peripheral units. The interface for data transmission is adapted via the machine parameters, the baud rate is optional.

Peripheral units for the operating mode EXT:

Paper tape punch or paper tape reader Printer or matrix printer for graphic printout Mass storage or programming stations for "Blockwise Transfer" Programming stations and PCs' for external programming

11.1.1 Changing Operating Modes ME-FE-EXT

Select auxiliary operating mode "MOD" with the MOD-key. Press the 4-key or MOD several times until the RS-232-C/V.24-INTERFACE with the ME-, FE- or EXT-display appears.

Press the [m]-key until the required operating mode is displayed. Acknowledge the auxiliary operating mode with the $\begin{bmatrix} 0 \\ 0 \end{bmatrix}$ -key subsequently.

With graphic printout the operating mode **EXT** is automatically selected which is independent of the **ME** or **FE**-mode.

11.2 Selecting the Baud-Rate

Select auxiliary operating mode "MOD" with the |MOD|-key. Press the |MOD|-key or |MOD| several times until **BAUD-RATE** is displayed.

Input new value for **BAUD-RATE**, if required (possible values: 110, 150, 300, 600, 1200, 4800, 9600, Baud) and enter with the e^{-key} -key. Acknowledge the auxiliary operating mode with the e^{-key} key subsequently.



11.3 Connection Cable and Adapter for RS-232-C/V.24-Interface

Wiring diagram of the RS-232-C/V.24-Interface



The data lines and control lines of the cable between LE 351/355 and the RS-232-C/V.24-adapter block (id.no. 239 760 ..) are crossed. At connector X26 of the LE 351/355 the layout is carried out according to a DTU (Data Transmission Unit). Owing to the crossed data and control lines of the cable between LE 351/355 and RS-232-C/V.24-adapter the layout of the RS-232-C/V.24-adapter corresponds to the DTE (Data Terminal Equipment). Thus the external units can be connected to the standard data transmission cable (id.no. 242 869 01) of HEIDENHAIN.



11.4 Machine Parameters for the RS-232-C/V.24-Interface

A precise description of the single machine parameters can be taken from the TNC Handbook for Machine Manufacturers, resp. from the information regarding the RS-232-C/V.24-data interface.

11.4.1 Machine Parameters for "Standard interface"

MP	Input values	Function
71	3	sign for prgr. end = ETX
92	Bit Ø Ø	decimal point
222	168	7 data bits, transmission stop by DC3, parity bit (even parity), 1 stop bit
223	Ø	standard interface

11.4.2 Machine Parameters for "Blockwise transfer"

MP	Input values	Function	
71	515	sign for prgr. end = ETX	<u> </u>
	S.	sign for prgr. beginning = STX	
218	17736	H and E	
219	16712	H and A	
220	279	ETB and SOH	
221	5382	ACK and NAK	
222	168	7 data bits, transmission stop by DC3,	
	- Alle	parity bit (even parity), 1 stop bit	
223	1	Blockwise transfer	
224	<u>8</u> 4	EOT	

11.4.3 Machine Parameters for Graphic Printout

		l	E I	PSON	S.C.	1	BROTHER	819 🔊	MANNESMANN
2	MP	LQ500	LX800	LX85	FX100	FX800	S 15ø9	Thinkjet	Tally
	226	795	795	1819	1819	1819	1051	795	1819
	227	16648	13078	17217	17217	17224	12301	16648	17224
	228	Ø	Ø	6963	6963	6963	2560	Ø	6963
	229	Ø	Ø	6154	7424	5624	Ø	Ø	5642
	230	1546	1546	1546	1290	1546	1546	1546	1546
	231	3355	6954	6954	6987	6954	3355	3355 💉	6987
	232	19200	13312	1024	2	1024	19200	19200	1280
	233	512	512	512	Ø	512	512	512	512 👌

When printing graphics the control automatically switches the operating mode to EXT and the data format to 8 data bits.



11.5 Connection Cable for Printers

Simple wiring proved to be the right one for most printers (see page $5\emptyset$).

11.6 Brror Messages

11.6.1 Displayed Error Messages in the ME-Operating Mode

WRONG OPERATING MODE

No or wrong operating mode on external data storage unit.

WRONG PROGRAM DATA

During data transmission defective program data were found. Reading was repeated three times by the magnetic tape and aborted subsequently.

DATA MEDIUM MISSING

No disk inserted in drive.

DATA MEDIUM EMPTY

On the data carrier (diskette) no programs are stored.

DATA MEDIUM WRITE-PROTECTED

Write-enable pin of cassette is missing.

PROGRAM INCOMPLETE

Data transmission was aborted before the program was completely transmitted.

EXT. IN-/OUTPUT NOT READY

- DSR-signal of TNC is missing.
- ME not connected.
- defective transmission cable.



Kundendienst

11.6.2	Displayed	Error	Messages	of	the	TNC	in	the	FE-Operating	Mode
--------	-----------	-------	----------	----	-----	-----	----	-----	--------------	------

In this operating mode errors are output by the Floppy Disk Unit in the following form: ERR: (SP) (SP) XXX (CR) (XXX = error number)

The following errors can be displayed on the screen:

- ERR: 001 Wrong instruction code (e.g. wrong machine parameters for control character)
- ERR: 002 Illegal program name (monitor operation)
- ERR: 003 Faulty data transmission
- ERR: 004 Incomplete program on diskette
- ERR: 010 Program not on diskette
- ERR: 011 Program is protected against erasure
- ERR: Ø12 Program is being stored
- ERR: Ø13 Diskette directory is full
- ERR: 014 Diskette is full
- ERR: 100 Diskette not formatted
- ERR: 102 Drive not ready
- ERR: 103 Diskette is write-protected
- ERR: 104 Faulty data on diskette
- ERR: 105 Section cannot be found (e.g. unformatted diskette is to be described)

ERR: 106

ERR: 107 Electronic error in the FE

ERR: 108



Kundendienst

11.6.3 Error Messages at the ME

The ME-electronics as well as the external operating conditions are tested. Detected errors are displayed as flashing codes by the operating mode indicating lamps. Error descriptions can be found in the following table:

O LED - off	LED - flashing		
Indicating lamps	Error message	All and	All all
	Faulty data during transmission		
	Cassette is not inserted	Michaiton.	AL CON
	Write-protection pin in cassette i	s missing	N.a.
	Wrong operating mode selected	Lona He	
	Data from magnetic tape defective		WWWW CO
	Magnetic tape blank	Kody	
* 0 0 0 0 0 0 0	sallonac sallonac	nautomaci	
	water water		
	Floatronia fault in MF		
	Electronic ladit in ME		
$\begin{array}{c} \bullet \bullet \circ \circ \circ \circ \\ \circ \circ \circ \circ \circ \circ \circ \end{array}$	Andre Andre		Alan .
	a conathat		
	Tape end	and the second s	Sarah Ba

Peripheral unit is not connected

Data transfer between TNC and ME (or peripheral unit) interrupted by pressing the $\begin{bmatrix} DEL \\ D \end{bmatrix}$ -key

By pressing the stop -key the error messages can be erased.

0 🔆 🔆 🔆

0 $\dot{0}$ $\dot{0}$ $\dot{0}$

ا بنج 🛬 ک

0000

EIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

Kundendienst

indicating lamps. O LED - off	LED - on EED - flashing
Indicating lamps	Error messages
0 0 0 • 0 * 0 0	Diskette is missing or electronic error
000 * 00 * 00	Diskette cannot be formatted since diskette is accessed
♦ 0 0 ● ♦ 0 0 0	Diskette is missing or not formatted
* 0 0 * * 0 0 0	Diskette cannot be copied since writing and reading is active
$\bullet \circ \not = \bullet$	External unit not ready or not connected
★ 0 ● ● 0 0 0 0	Diskette is missing or not formatted
* 0 0 • 0 0 • 0	Diskette is missing or not formatted or no program available
* 0 • * 0 0 0 0	Program cannot be output since a transmission is active via a TNC-interface
	Program cannot be output since a transmission is active via a PRT-interface
	External unit not ready or not connected
	Diskette is missing or not formatted
0000 *000	Diskette is missing or not formatted
0 0 ● ★ ★ 0 0 0	Program cannot be stored since a transmission is active via a TNC-interface
	Program cannot be stored since a transmission is active via a PRT-interface
0 • 0 • 0 • • •	External unit not ready or not connected
	Diskette is missing or electronic error
	Directory cannot be output since a transmission is active via a PRT-interface
000¥ 00000	A coupling of the interfaces is not possible since a transmission is active via the TNC-interface
000* 0000	A coupling of the interfaces is not possible since a transmission is active via the PRT-interface

By pressing the stop -key the error messages can be erased.

External unit not ready or not connected

0000 00 🔆 🗨

0000



Kundendienst

<u>12. External Data I/O</u>

12.1 External Data Output

Connect external data storage unit (ME, FE or EXT) to the TNC.
Prepare external data storage unit for data transmission: with the ME by pressing the store, TNC and the +g-keys.
with the FE by pressing the store-key.
Select operating mode of the interface (ME, FE or EXT) at the TNC (see section 11.1.1). Also select baud rate with the operating mode EXT. (see section 11.2).

12.1.1 Output of Machine Parameters to the ME

Dialog display	Press key	
MANUAL OPERATION	MOD	are and the second
VACANT BLOCKS = XXXX	•	A
CODE NUMBER =	951	4 8 🕅
MACHINE PARAMETER PROGRAMMING MACHINE PARAMETER MP Ø ?		and the second
EXTERNAL DATA INPUT ?	NO	AN ANTA
EXTERNAL DATA OUTPUT	ha.	
MANUAL OPERATION	and the second	

12.1.2 Output of Machine Parameters to the FE

Dialog display	Press key
MANUAL OPERATION	MOD
VACANT BLOCKS = XXXX	
CODE NUMBER =	9 5 1 4 8
MACHINE PARAMETER PROGRAMMING MACHINE PARAMETER MP Ø ?	
EXTERNAL DATA INPUT ?	NO INI
PROGRAM NUMBER =	Input program number requested under which the machine parameters are to be output and acknowledge with the for -key.
EXTERNAL DATA OUTPUT	
MANUAL OPERATION	

HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut - Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 57

Kundendienst

12.1.3 Output of the PLC-Program to the M	E			
Dialog display	Press key			
MANUAL OPERATION	MOD			
VACANT BLOCKS = XXXX	+			
CODE NUMEBR =	9 5 1	026		
TABELLE E/A/Z/T/M	$\overline{}$		A ASA	
PC-EDITIER-FUNKTION		204	₿ 🐨 🐼) ^{2,}	
EXTERN EIN/AUS ? ENT/NO-ENT				
AUSGABE ASC/BIN ? ENT/NO-ENT			10000	
AUSGABE AB PGM-ZEILE = \emptyset	$\left(\mathbb{R}^{n}\right)^{n}$ (2)	048	\mathbb{P}	
AUSGABE BIS PGM-ZEILE = Ø	(204)	7 🔊) ^{1,} (3	071	
EXTERNAL DATA OUTPUT	onabl	- Charl		
QUERVERWEIS-LISTE ?		1. GDBUL		
PC-EDITIER-FUNKTION				
MANUAL OPERATION	No.?			

with output of 1st and 2nd kByte
 with output of 3rd kByte



Kundendienst

12.1.4 Output of the PLC-Program to the	FE M COS
Dialog display	Press key
MANUAL OPERATION	
VACANT BLOCKS = XXXX	
CODE NUMBER =	951026
TABELLE E/A/Z/T/M	
PC-EDITIER-FUNKTION	$(\textcircled{2})^{1}, (\textcircled{2})^{2}, (2$
EXTERN EIN/AUS ? ENT/NO-ENT	
AUSGABE ASC/BIN ? ENT/NO-ENT	ENT
	$(\mathbb{E})^{1}, (2048) \mathbb{E})^{2},$
AUSGABE AB $PGM-ZEILE = 0$	(2047) (307) (307)
AUSGABE BIS PGM-ZEILE = 0	
PROGRAM NUMBER =	Input program number requested under which the PLC-program is to be output
EXTERNAL DATA OUTPUT	and enter with the em-key.
PC-EDITIER-FUNKTION	
MANUAL OPERATION	sonation sonation sonation
	NISSON NISSON
 with output of 1st and 2nd kByte with output of 3rd kByte 	
12.1.5 Output of all NC-Programs to the	ME or the FE
Dialog display	Press key
MANUAL OPERATION	
PROGRAMMING AND EDITING	
PROGRAMMING AND EDITING SELECTION = ENT/END = NOENT	allomatike allomatike allomatike
READ-IN SELECTED PROGRAM	
READ-OUT SELECTED PROGRAM	
READ-OUT ALL PROGRAMS	
EXTERNAL DATA OUTPUT	Horran Horran Horran
PROGRAMMING AND EDITING	what the what the share the



Kundendienst

12.1.6 Output of the compensation value list to the ME

Dialog display	Press key
MANUAL OPERATION	MOD
VACANT BLOCKS = XXXX	
CODE NUMBER =	105296
COMPENSATION VALUE LIST DEFECTIVE AXIS ?	
EXTERNAL DATA INPUT ?	ENT.
EXTERNAL DATA OUTPUT	Statio. Salto.
COMPENSATION VALUE LIST	
MANUAL OPERATION	8 8 8

12.1.7 Output of the correction list to the FE

Dialog display	Press key
MANUAL OPERATION	COM
VACANT BLOCKS = XXXX	
CODE NUMBER =	105296
COMPENSATION VALUE LIST DEFECTIVE AXIS ?	
EXTERNAL DATA INPUT ?	NO ENT
PROGRAM NUMBER =	Enter the requested program number under which the compensation value list is to be output and acknow- ledge with the key [N].
EXTERNAL DATA OUTPUT	and they
COMPENSATION VALUE LIST	
MANUAL OPERATION	MALCORD MALCORD



SERVICE MANUAL TNC 351/355 Page 59

12.2 External Data Input

- Connect external data storage unit (ME, FE or EXT) to the TNC.
- Prepare external data storage unit for the data transmission: with the ME by pressing the respinsion, respin
- Adjust operating mode of the interface (ME, FE or EXT) at the TNC. (see section 11.1.1). Also select baud rate with the operating mode EXT. (see section 11.2).

12.2.1 Machine parameter input from the ME with erased memory

Dialog display	Press key	
OPERATING PARAMETERS ERASED	CE	John College
PLC: PROGRAM MEMORY ERASED	CE	
MACHINE PARAMETER PROGRAMMING MACHINE PARAMETER MP Ø ?		
EXTERNAL DATA INPUT	A OTTAINE	

12.2.2 Machine parameter input from the FE with erased memory

Dialog display	Press key	
OPERATING PARAMETERS ERASED	CE	. Kalina in initia init
PLC: PROGRAM MEMORY ERASED	CE	
MACHINE PARAMETER PROGRAMMING MACHINE PARAMETER MP Ø ?		
PROGRAM NUMBER =	Input program numb machine parameters transfer with the	ber under which the are stored and which key
EXTERNAL DATA INPUT		

15h

* After reading in the machine parameters "POWER INTERRUPTION" usually appears in the dialog display; if, however, the error message "MACHINE PARAMETERS IN-COMPLETE" appears, fewer machine parameters are stored on the external data storage unit than required by the TNC. In this case the remaining machine parameters have to be entered manually.

These machine parameters can be obtained by the machine manufacturer.



12.2.3 Input of Machine Parameters from the ME with not-erased Memory (the machine parameters in the memory are overwritten)

Dialog display	Press key
MANUAL OPERATION	ООМ
VACANT BLOCKS = XXXX	+ alone
CODE NUMBER =	95148
MACHINE PARAMETER PROGRAMMING MACHINE PARAMETER MP \emptyset ?	
EXTERNAL DATA INPUT ?	
EXTERNAL DATA INPUT	SWILL BALL

12.2.4 Input of Machine Parameters from the FE with non-erased Memory (the machine parameters in the memory are overwritten)

Dialog display	Press key
All Al	Μοο
MANUAL OPERATION	
VACANT BLOCKS = XXXX	t the second second
CODE NUMBER =	9 5 1 4 8 🕅
MACHINE PARAMETER PROGRAMMING MACHINE PARAMETER MP Ø ?	
EXTERNAL DATA INPUT ?	
PROGRAM NUMBER =	Input program number under which the machine parameters are stored and transfer with the EM -key

* After reading in the machine parameters "MANUAL OPERATION" usually appears in the dialog display; if, however, the error message "MACHINE PARAMETERS INCOMPLETE" appears fewer machine parameters are stored on the external data storage unit than required by the TNC. In this case the remaining machine parameters have to be entered manually.

These machine parameters can be interrogated by the machine manufacturer.

HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (086 69) 31-0

SERVICE MANUAL TNC 351/355 Page 61

Kundendienst

12.2.5 Input of the PLC-Program from the	ME			
Dialog display	Press ke	y 🦨		
MANUAL OPERATION	MOD	13.9	N.C.	
VACANT BLOCKS = XXXX	+ 1			
CODE NUMBER =	95	10	2 6	
TABELLE E/A/Z/T/M	$\widehat{\}$			
PC-EDITIER-FUNKTION	(🐼) ^{1,}		0 4 8	(N)
EXTERN EIN/AUS ? ENT/NO-ENT				
EINGABE AB PGM-ZEILE = Ø			4 8 🕅	
EXTERNAL DATA INPUT	-statut			
PC-EDITIER-FUNKTION		12.0		
MANUAL OPERATION				

12.2.6 Input of the PLC-Program from the FE

Dialog display	Press key	
MANUAL OPERATION	мор	
VACANT BLOCKS = XXXX	•	
CODE NUMBER =	95102	6
TABELLE E/A/Z/T/M	<u>ک</u>	
PC-EDITIER-FUNKTION	(∞) ^{1,} (2 0] 4 8 🕅 🐼) ² ,
EXTERN EIN/AUS ? ENT/NO-ENT	ENT	
EINGABE AB PGM-ZEILE = Ø	$(m)^{1}, (204$] 8 (1) ² ,
PROGRAM NUMBER =	Input program number the PLC-program is transfer with the	r under which stored and जो-key
PC-EDITIER-FUNKTION		
MANUAL OPERATION		
1) with input of 1st and 2nd kByte		
2) with input of 3rd kByte		



Kundendienst

12.2.7 Input of NC-Programs from the Dialog display	ME or FE	
MANUAL OPERATION	(
PROGRAMMING AND EDITING	\bigotimes	
PROGRAMMING AND EDITING SELECTION = ENT/END = NOENT	ALAN AL COC	
READ-IN SELECTED PROGRAM	•	
READ-IN PROGRAM OFFERED		
READ-IN ALL PROGRAMS	ENT	
EXTERNAL DATA INPUT	MARINE	
PROGRAMMING AND EDITING	àà.	

DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut • Tel. (08669) 31-0

EIDENHAIN

SERVICE MANUAL TNC 351/355 Page 62.1

Kundendienst

12.2.8 Input of compensation value list from the ME Dialog display Press key MANUAL OPERATION MOD VACANT BLOCKS = XXXX + 5 9 6 1 0 2 CODE NUMBER = \odot COMPENSATION VALUE LIST DEFECTIVE AXIS ? ENT EXTERNAL DATA INPUT ? EXTERNAL DATA INPUT ? COMPENSATION VALUE LIST MANUAL OPERATION

12.2.9 Input of the compensation value list from the FE

Dialog display	4	Press key
MANUAL OPERATION	12. Q.	
VACANT BLOCKS = XXXX	ACT MACH	+ souther souther
CODE NUMBER =	NI-Span	105296
COMPENSATION VALUE LIST DEFECTIVE AXIS ?	Aran .	
EXTERNAL DATA INPUT ?	ANY	
PROGRAM NUMBER =	www.chaiton	enter the program number under which the compensation value list is stored and ack- nowledge with the m-key.
EXTERNAL DATA INPUT	19.01	
COMPENSATION VALUE LIST	tomator	
MANUAL OPERATION		way of the way of the second s
DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut • Tel. (08669) 31-0 SERVICE MANUAL TNC 351/355 Page 63

Kundendienst

13. Analog Outputs

DENHAIN

<u>13.1 Technical Data</u>

5 or 6 outputs X, Y, Z, IV, V and S

Loading capacity: $R_L \min = 5 \text{ kQ}$ $C_L \max = 5 \text{ nF}$

 $\begin{array}{rcl} U_{a \ max} &= \pm \ 10 \ V \ \pm \ 0.25 \ V \\ U_{a \ min} &= & 0 \ V \ \pm & 1 \ mV \end{array}$

Resolution 12 Bit = 4095 steps

Smallest step = $\frac{U_{a max}}{4095 \text{ steps}} = \frac{10 \text{ V}}{4095} = 2.44 \text{ mV}$

13.2 Measuring the Analog Output Voltages

Proportional to the traversing speed the control outputs an analog voltage of $\emptyset V$ (axis standstill) to 9V (rapid traverse). This voltage can simply be measured with the ANALOG OUTPUT TEST ADAPTER directly at the LOGIC Unit or at the connecting terminals of the servo amplifier with a voltmeter.

If, however, no axis movement takes place due to a defect and if it is to be checked whether the error is due to the control or to an external unit proceed as follows:

- Switch off mains switch at machine.

- Connect ANALOG OUTPUT TEST ADAPTER to connector X8 (nominal value output) of the LE and connect voltmeter at the ANALOG OUTPUT TEST ADAPTER to the sockets of the defective axis. If no ANALOG OUTPUT TEST ADAPTER is available then connect voltmeter directly to the nominal value input of the servo amplifier.
- Switch on main switch and control voltage.
- Switch position display to LAG (trailing error).
- Check or adjust the following machine parameters (note original input values when changing machine parameters and input them after checking).

MP	Input value	Function		
174	100 (mm)	Trailing erro	or supervision	EMERGENCY-STOP
234	9.99 (V)	Movement sup	ervision	

- Sequentially traverse over those reference marks that have to be traversed over before that of the defective axis.

- Turn back completely override potentiometer of the KEYBOARD Unit and start reference mark approach for the defective axis.

- Check axis release for defective axis at servo amplifier.

- Check display (Control in operation) has to be on, F has to illuminate as usual with the feed display (not inverse F) and with the position display no point must illuminate after the axis designation (e.g. X.).

- Turn override potentiometer to the right and turn back again before the trailing error display reaches the position supervision limit (MP 174).



Kundendienst

The control outputs an analog voltage when turning the override potentiometer to the right and increases this voltage proportionally to the trailing error up to maximally 10V. If a voltage of $10V \pm 0.25V$ is measured with a voltmeter at the ANALOG OUTPUT TEST ADAPTER the control is in order. If, however, no voltage is measured then switch off mains switch, unplug connector X8 of the LE, remove the wire to the nominal value line at servo drive and check for short circuit. If the nominal value line is in order reconnect connector X8 to the LE (leave nominal value line at servo amplifier unconnected), switch on mains switch and repeat measurement by approaching the reference mark. If an analog voltage is measured the control is in order. If, however, no voltage is measured the analog output of the LE is probably defective.

13.2.1 Set-up for Measuring the Analog Outputs





Kundendienst

13.3 Changing Positional Display Mode

Select auxiliary operating mode "MOD" with the MOD -key. Press the or the MOD -key several times until the POSITION DISPLAY appears. Press the MOD -key, if necessary, until the requested display (ACTL, REF, LAG, NOML or DIST) appears.

Acknowledge the auxiliary operating mode with the $\begin{bmatrix} DEL \\ D \end{bmatrix}$ -key subsequently.

13.4 Speed Adjustment

Check and/or optimize machine parameters (note original input values when changing the machine parameters).

MP	Input value	Function	automo
60	0	Speed precontrol on	
65	0	Display step = $1\mu m$	

- Change positional display mode to LAG (trailing error display).

Input the following test program.

e.g. 1 LBL 1 2 X 100 R0 F2999 3 X 0 R F 4 CALL LBL 1 REP 10

0 R0 F29999 M (Select bigger traverse range if possible) R F M LBL 1 REP 10

Processing of test program in the operating mode "Program Run Full Sequence".

- Adjust speed at servo amplifier (tacho) such until the trailing error display possibly displays zero in both directions during positioning.
- Repeat adjustment for all axes.

Bring machine parameters and positional display to original state again.



Kundendienst

13.5 Offset Adjustment

13.5.1 Offset Adjustment with Key Number

- Select auxiliary operating mode "MOD" with the MOD -key and select key number with the h-key. Input key number 75368 and transfer with the -key.
- The converter steps (2.44mV) are now displayed for the offset on the display. If the m-key is now pressed the offset values are transferred into the offset memory and compensated. If instead of the m -key the key is pressed the offset memory is erased and the compensation is eliminated.
- Acknowledge the auxiliary operating mode with the $|{}_{\Box}^{\mathsf{PEL}}|$ -key.

13.5.2 Automatic Cyclic Offset Adjustment

In machine parameter 252 the cycle time (20 ms units) is determined according to an existing offset which is compensated by one converter step (2.44mV). If the automatic offset adjustment is to be switched off the machine parameter 252 has to be programmed with zero.

ATTENTION!

If with the automatic offset adjustment an offset voltage of 100 mV is reached the control switches off with the error message "GROSS POSITIONING ERROR E".

13.5.3 Offset Adjustment at the Servo Amplifier

- Check or adjust the following machine parameters (note the original values when changing machine parameters).

МР	Input value	Function
28, 29, 30, 31	0	Integral factor
32, 33, 34, 35, 332	> Ø.5	Differential factor
60	0	Speed precontrol on
65	0	Display step = 1 µm
252	Ø	Cycle time for automatic offset adjustment

- Switch position display to LAG (trailing error display).

- Erase offset memory with key number 75368 (see section 13.5.1).

Select operating mode \square or \square or \square .

Adjust offset at servo amplifier until the individual axes display zero or oscillate symmetrically around zero.

Bring machine parameters and position display to original state again.

HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 67

Kundendienst

14. PLC-I/O

14.1 Technical Data

14.1.1 PLC-Inputs of the LE

E0 up to E31 to X22 E128 up to E143 to X23 and X27 E144 up to E152 to X27

"0" Ue = - 20 V up to 3.2 V Ie = 1.5 mA with Ue = 3.2 V "1" Ue = 13 V up to 30.2 V Ie = 3.7 mA up to 9.1 mA

14.1.2 PLC-Outputs of the LE

A0 up to A7 to X21 and X27 A8 up to A30 and "control ready" to X21

"1" $U_{B min} = U_{B} - 3 V$ $I_{a NOM} = 0.1 A$

Connector layout, see section 4.3.3

14.1.3 PLC-inputs of the PL 300
E64 up to E126 to X4 up to X9
"0" Ue = - 20 V up to 4 V
Ie = 1.6 mA with Ue = 4 V
"1" Ue = 16.5 V up to 30 V
Ie = 6.2 mA up to 12.6 mA

14.1.4 PLC-outputs to the PL 300 A32 up to A62 and "control ready" to X1 up to X3 "1" U_{θ} min = U_{B} - 3 V I_{a} NOM = 1.2 A

Connector layout, see section 4.3.4



Kundendienst

14.2 Checking the PLC-I/O

3 test units are available for checking the PLC-inputs and outputs:

PLC TEST UNIT	X21, X22 and X27
KEYBOARD TEST UNIT	for X23
PL TEST ADAPTER	for PL Board

All inputs or outputs of a connector are simultaneously displayed with the PLC TEST UNIT and the KEYBOARD Unit and their voltages can be meaured. Only the inputs or outputs of one connector block of the PLC POWER I/O Board Assembly (PL 300) can be displayed at one time using the PL TEST ADAPTER. Taking measurements directly at the terminals is possible.

14.2.1 PLC-Inputs

The inputs can be controlled as follows:

- Connect TEST Unit to the LE or to the PLC POWER_ I/O Board Assembly PL 300.
- Select auxiliary operating mode "MOD" with the MOD -key and select key
- number with the *f*-key. Input code number **951026**, input with the *r*-key and look at the table (at the BE) of the inputs with the *f*-key subsequently.
- The logical states of the inputs are now displayed on the screen. The states displayed on the screen and on the test unit have to coincide. If there is a difference then measure the voltage level (as to the values, see Techn. Data) for this input at the TEST UNIT. If the input voltage is in order the respective input board is probably defective (EØ to E31 and E128 to E152 PROCESSOR Board, E64 to E126 PLC POWER I/O Board Assembly PL_300).

Acknowledge the auxiliary operating mode with the $\left| \stackrel{\text{DEL}}{\Box} \right|$ and $\left| \stackrel{\text{END}}{\Box} \right|$ -keys.

ATTENTION !

When connecting/disconnecting_always switch off mains switch first!



Kundendienst

14.2.2 PLC-Outputs

The outputs can be checked as follows:

- Connnect PLC I/O TEST UNIT between the LE and the interface or the PL 300 Interface.
- Select auxiliary operating mode "MOD" with the MOD -key and select key number with the + -key.
- Input key number "951026", enter with the m -key and call the table (at the BE) for outputs with the key subsequently.
- The logical states for the outputs are now displayed on the screen. The states displayed on the screen and on the test unit must coincide. If there is a difference then check the connecting cable for short circuit and measure output current for this output at the interface (max. 100mA for the LE or 1.2A for the PL-outputs). If the output current is not exceeded and the connecting cable is also in order the output board is probably defective (A0 to A30 PRO-CESSOR Board, A32 to A62 PLC POWER I/O Board Assembly PL 300)
- Acknowledge the auxiliary operating mode with the $\begin{bmatrix} \nabla E L \\ D \end{bmatrix}$ and the $\begin{bmatrix} E N D \\ D \end{bmatrix}$ -keys.

ATTENTION!

μl,

When connecting/disconnecting always switch off mains switch first!

14.2.3 Set-up for testing the PLC I/O





Kundendienst

<u>14.3 Output "Control Ready" and acknowledgement</u> for the test "Control ready"

Important functions are supervised with self-diagnosis by the TNC 351/355 control (electronic assemblies as microprocessors, read-only memory, read-write memory, positioning systems, encoders, etc.)

If an error is determined when checking a flashing error message appears in plain dialog in the dialog display. The output "control ready" is opened when outputting this error message. This state can be cancelled by switching the main switch off if the error cause has been eliminated before.

The output "Control ready" must switch off the 24 volt control voltage in the machine interface. Since this function is a very important safety feature the switch-off function of the output "Control Ready" is checked each time the machine is switched on via the input "Acknowledgement control ready".

The control has two supervision devices (CLP PROCESSOR Board and PROCESSOR Board). Both boards are checked one after another when switching the machine on.

If the +24V are missing at the input "Acknowledgement control Ready" during the switch-on test routine the error message "CONTROL VOLTAGE FOR RELAY MIS-SING" appears. If, however, the acknowledgement is switched off too late or not at all after switching the output off the **flashing** error message "EMER-GENCY-STOP DEFECTIVE" appears. Also if the supply is missing for the PLC-part a **flashing** error message "EMERGENCY-STOP DEFECTIVE" appears (Supply for the PLC-Part, see section 5.4).

If an error is determined by the control during the switch-on test routine it can be determined by inserting a bridge between the output "Control ready" and the input "Acknowledgement control ready" (separate connected wires) whether the defect is due to the control or to the interface. If after inserting the bridge and correct power supply for the PLC-part the error is still present the defect is due to the LOGIC Unit. If, however, after inserting the bridge the error no longer appears the defect can be found at the interface.



ATTENTION

After the check it is absolutely necessary to remove the bridge and to regenerate the operating state.



1

2

3

14.3.1 Switch on Test Routine Timing Diagram



Time Remarks Fault message

Wait for control voltage

After switching the output "Control Ready" off, the acknowledgement "control ready" must be switched off within 174 ms, resp. 124 ms; if not, the flashing error message appears.

If during the operation the acknowledgement is switched off appears. CURRENT INTERRUPTION

CONTROL VOLTAGE FOR RELAY IS MISSING

EMERGENCY-STOP DEFECTIVE

EXTERNAL EMERGENCY-STOP



Kundendienst

<u>15. Test Equipment</u>

15.1 Test Unit for the POWER SUPPLY Board Assembly

PSA LOAD UNIT Id.no. 247 358 01



The connector doesn't exist with newer versions. The insulated wired of the connection cables to processor and PLC board are soldered in directly. Measure voltages according to description 5.3.2!

15.2 Test Unit for the Keyboard Unit

KEYBOARD TEST UNIT, Id.no. 247 360 01



HEIDENHAIN DR. JOHANNES HEIDENHAIN GmbH D-8225 Traunreut · Tel. (08669) 31-0

SERVICE MANUAL TNC 351/355 Page 73

Kundendienst

15.3 Test Aids for the PLC-I/O

PL TEST ADAPTER Id.no. 247 359 Ø1



PLC TEST UNIT Id.no. 247 361 Ø1





15.4 Universal Test Unit for 15-37-pin Sub-D connector

Measuring adapter, id.no. 255 480 01



The measuring adapter is used to check the inputs and outputs of 15-37 pin Sub-D plug connections. A cable adapter described on the following page is required for each connector size.

The measuring adapter can also be inserted instead of the PLC- and the KEY-BOARD test units (without display, however) previously described.







9-pin cable adapter, id.no. 255 481 Ø1

15-pin cable adapter, id.no. 255 482 Ø1







37-pin cable adapter, id.no. 255 484 Ø1



Kundendienst

16. EXCHANGE INFORMATION

16.1 General

16.1.1 Auxiliaries required

1 external data storage unit, e.g. ME 101/102 or FE 401 with connecting cable

1 tool set (screwdriver, socket wrench etc.)

1 MOS-protection mat (only required when exchanging a board or the EPROMS).

16.1.2 MOS-Protection

When exchanging the **PROCESSOR** or the **CLP PROCESSOR** Boards and/or the **EPROMs** it is absolutely necessary that a MOS-protection mat is used since the **MOS-compo**nents on the board or the **EPROMs** may be damaged by electrostatic discharge.

Attention:

Any contact with the boards or the EPROMs with an electrostatically charged object (packing, storage, place of deposit) or careless handling must be avoided.

MOS-Protection Mat:

deal deal	Potential compensat	ting (
Ser and the second s	line with protection	on
www.chaite	resistor MOS-	R ⁻¹ R ⁻¹ Connection to ground (e.g. GROUND CONDUC- TOR socket) may be omitted when lying
	protection mat	a MOS-protection mat on the machine
wristlet	ballonac	table.
	1. St. St.	

16.1.3 Compatibility of Software

Exchange units (compl. Logic Units) are equipped on principle with the latest software.

Exchange boards are delivered without software and without software release modul.

Therefore EPROMs and software release modul have to be removed from the defective board and inserted to the exchange board. (see section 16.7) Please always send exchange boards back for repair without EPROMs and without software release modul.

When exchanging the boards it is convenient to exchange both boards (PROCESSOR and CLP PROCESSOR).

Thus an EPROM exchange is avoided and it is guaranteed that the software of your control is updated.



16.1.4 Backup of Machine Parameters and User Programs

EIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

D-8225 Traunreut · Tel. (08669) 31-0

Before exchanging the complete LOGIC Unit or the PROCESSOR Board, the machine parameters, the user programs and perhaps also the "PLC-program" and the "Compensation value list" have to be saved on an external data carrier. If machine parameter 77 is unequal 1 PLC program parts are processed from

the RAM and must be saved as well. The following table shows which program parts are processed from BAN in

The following table shows which program parts are processed from RAM in dependence of machine parameter 77:

Machine parameter	Input value	PLC-program from RAM
77	0	1st and 2nd kByte
and the second	2 3	1st, 2nd and 3rd kByte 3rd kByte

If the non-linear axis error compensation for one or for several axes is activated the "compensation value list" must also be saved. The following table shows the activation of the non-linear axis error compensation in dependence of machine parameter 20 to 23 and 330:

Machine parameter 🚿	In	put val	Lue	non-linear axis erro active in	r compensation
20 21 22	(4 to 7) or (1	l2 to 15)	X-axis Y-axis	and the fil
23 33Ø	ALC ROLL	14 74	Boalton	Z-axis IVth-axis Vth-axis	

The procedure for data backup is described in section 12.1. The programs do not have to be backed up if they are already present on an external data carrier.

Note:

The machine parameters, the compensation value list (if active) and the PLCprogram (MP 77 unequal 1) should be principally backed up on an external data carrier due to reasons of safety.



16.1.5 Data determination for Supplementary Operating Modes:

If the **PROCESSOR Board** or the complete **LOGIC Unit** is to be exchanged the preset values and the input values should be determined for supplementary operating modes to bring them to the previous state after the exchange.

Switch the main switch on and off again.

Dialog display	Press keys	Remarks
MEMORY TEST	è _	k k
POWER INTERRUPTED	CE	anaster . onaster . o
RELAY EXT. DC VOLTAGE MISSING	don'	Switch on control voltage.
MANUAL OPERATION	MOD	water water
PASS OVER X-REFERENCE MARK PASS OVER Y-REFERENCE MARK PASS OVER Z-REFERENCE MARK PASS OVER REFERENCE MARK AXIS 4		<u>Do not yet approach reference</u> <u>marks!</u>
VACANT BLOCKS	÷	and the second s
CHANGE MM/INCH	Ŧ	14° - 14°
	Q.	Mag Mag
POSITION DATA O O O O O ACTL REF LAG NOML DIST		Note position data (%) ad- justed and then switch over to ACTL with the m key.
VZ.	and the second second	water water
ACTL X	19	Note preset values. (Do not forget sign!)
ACTL Y	, i	international automatic
ACTL Z	WARANDOOC	www.chc www.chc
ACTL IV.	•	astrant astrant
ACTL V.		seal wichauton wichauto
POSDATA DISPLAY LARGE/SMALL	I	A MA A MA
BAUD-RATE =	↓	Note baud-rate.
RS-232-C-INTERFACE = ME O FE O EXT O		Note interface (SC) adju- sted and then switch over to ME, FE or EXT with the read here



Kundendienst

TNC dialog display		Press key	Remarks
	VZ		
LIMIT X+ =		Ŧ	Note limit values. (Do not forget sign!)
LIMIT X- =			A Gallo Migallo
LIMIT Y+ =		+	an ann
LIMIT Y- =		H	Norradian Roman
LIMIT Z+ =		Jan I	NAME CONTRACTION
LIMIT 2- = [I	14 ⁰ ,0
LIMIT IV+ =			abautomati
LIMIT IV- = [•	anna anna
LIMIT V+ * =		ł	ast of
LIMIT V- * = [I CONTRACTOR	Station
NC: SOFTWARE [an ann
PLC: SOFTWARE UMBER			utonadika.k
* only with V-axes	control		Leve Leve

16.1.6 Labelling of Connection Cables:

If the connection cables are incompletely or not at all labelled, they must be labelled in order to generate the right plug connection after exchanging the LOGIC UNIT or another assembly. Connector layout, see section 4.3



ATTENTION!

Incorrect connection may cause damage to the unit.



Kundendienst

16.2. Exchange Procedure for the LOGIC Unit

16.2.1 Backup and Cable Labelling (see section 1.4 to 1.6)

16.2.2 Demounting the LOGIC Unit

- a) Switch off mains switch.
- b) Unscrew and disconnect all plug and terminal connections of the LOGIC Unit.





c) Unscrew the 4 mounting screws for the LOGIC Unit.



d) Take out the LOGIC Unit and replace with an exchange unit.

16.2.2 Mounting the LOGIC Unit

The procedure for mounting the replacement LOGIC Unit is opposite to that of removal.

- a) Mount and secure LOGIC Unit.
- b) Reconnect plug, terminal and clamp connections.

Please pay attention that no connections are interchanged!

c) Switch on mains switch.

- d) Read machine parameters in again (machine parameter, PLC-program and compensation value list) which were saved before the exchange.
- e) Enter preset values and supplementary operating modes from the previous table (before approaching the reference marks).
- f) Read in user program.

Exchange completed.



Kundendienst

16.3. Exchange Procedure for the PROCESSOR Board

16.3.1 MOS-Protection Mat, Software, Backup and Cable Labelling (see section 16.1.2 to 16. 1.6)

16.3.2 Removal of PROCESSOR Board

- a) Switch off mains switch of the machine.
- b) Unscrew and disconnect all plugged connections and the terminal connection at the PROCESSOR Board (X21, X22, X23, X24, X26 and X27). As to connector layout, see section 4.3
- c) Loosen the 4 turn-lock fasteners and remove cover of LOGIC Unit.



Pull-off flat cable connector by pulling strap



Kundendienst

e) Unscrew fastening screws.



Loosen knurled screws

Loosen fastening screws

f) Take out PROCESSOR Board from the frame, exchange EPROMs, if necessary, (see section 1.3), insert new board.

16.3.3 Insertion of PROCESSOR Board

The procedure for inserting the replacement PROCESSOR Board is opposite to that of removal.

- a) Push in and secure PROCESSOR Board.
- b) Reconnect plug and terminal connections.

Please pay attention that no connections are interchanged!

- c) Refit LOGIC Unit cover.
- d) Switch on mains switch.
- e) Read machine parameters in again (machine parameters, PLC-program and compensation value list) which were saved before the exchange.
- Enter preset values and supplementary operating modes from the previous table (before approaching the reference marks).
- g) Read in user program.

Exchange completed.

<u>A T T E N T I O N</u>

Send or store the boards <u>only</u> in the **original package** which protects the boards against electrostatic discharge!

Never use ordinary plastic bags for packaging!



cable

Kundendienst

16.4. Exchange Procedure for the CLP Processor Board

- 16.4.1 MOS-protection set, Software, Backup and Cable Labelling (see section 1.2 to 1.6)
- 16.4.2 Removal of CLP PROCESSOR Board
- a) Switch off mains switch of the machine.
- b) Unscrew and disconnect plug connections at the CLP PROCESSOR Board
- (X1 X13) (connector layout, refer to section 4.3)
- c) Open LOGIC Unit



d) Disconnect internal plug connections.

Pull-off flat cable connector by pulling strap Pull-off flat cable connector by pulling strap Press snap lock connector inwards and pull-off flat



screws

Kundendienst

e) Unscrew mounting screws.

f) Take out CLP PROCESSOR Board from the frame, exchange EPROMs, if necessary, (see section 1.3), insert new board.

16.4.3 Insertion of CLP PROCESSOR Board

The procedure for inserting the replacement CLP PROCESSOR Board is opposite to that of removal.

- a) Insert and secure CLP PROCESSOR Board.
- b) Reconnect plug connection.

Please pay attention that no connections are interchanged!

- c) Close LOGIC Unit.
- d) Switch on mains switch.

Exchange completed.



Send or store the boards <u>only</u> in the original package which protects the boards against electrostatic discharge!

Do never use ordinary plastic material for packaging!



Kundendienst

16.5. Procedure for the POWER SUPPLY Board Assembly

- a) Switch off mains switch of the machine.
- b) Open LOGIC Unit

c) Disconnect terminal and multiplug connector.

Press strap lock connector inwards and pull-off plug X2.



With versions having no connector X2 the plug on the CLP processor board has to be disconnected. (see section 16.4.2)





Loosen terminal block screws and pull wires



d) Loosen fastening screws.

Take out POWER SUPPLY Board Assembly and insert replacement.



e) Tighten fastening screws, reconnect terminal and multiplug connection.

Please pay attention that no connections are interchanged!

f) Close LOGIC Unit, switch on mains switch.

Exchange completed.

吗

<u>ATTENTION</u>

Send or store the boards <u>only</u> in the **original package** which protects the boards against electrostatic discharge!

Never use ordinary plastic bags for packaging!



Kundendienst



c) Loosen the 4 turn-lock fasteners and remove cover of LOGIC Unit.





d) Disconnect flat cable connection on the PROCESSOR Board.



Press apart snap lock and pull-off flat cable

e) The procedure for mounting the replacement PL 300 is opposite to that of removal. - Reconnect PL 300 to PROCESSOR Board.

- Mount PL 300 onto the LOGIC Unit.
- Reconnect terminal and clamp connections.
- Switch on mains switch.

Exchange completed.



<u>ATTENTION</u>

Send or store the boards <u>only</u> in the **original package** which protects the boards against electrostatic discharge!

Never use ordinary plastic bags for packaging!



Kundendienst

16.7. Exchange Procedure for the BPROMs

16.7.1 MOS-protection

When exchanging the EPROMs it is absolutely necessary to use a MOS-protection mat. Otherwise they may be damaged by electrostatic discharge.

We recommend using an IC extraction/insertion tool to prevent damage to the board, IC socket or EPROM. Note the position no. and the package index of the EPROM for correct insertion.

e.g. IC extraction/insertion tool



16.7.2 Labelling of EPROMs

CLP PROCESSOR Board

basic software id. no.

position no. (e.g. IC-P1)



3				ŤA		
3				_ ` ¶		
52						
						III###################################
				2		
		<u></u>	N.	91 I I	بالمالية المالية المالية المالية	
1			and the second			
						こ見!見!!!!!
			1 25			
1			1			
6	52			•	Plaine Plaine	
			3		ப்பில் தில் பில் பில் பில் பில் பில் பில் பில் ப	vare Diate
- [\sim		• • • ~
				3×.		
						PIC-P6
			<u> </u>			PIC-PS
			P			
2	<u></u>		- 1			
		E PIC-P1]]	·		
			4	•		
				25		
			25		الم	
Ì						
		- 19 ⁵⁷	1. ST.			
2	<u></u>			E		

PROCESSOR Board



Kundendienst

17. Machine parameters

The machine parameters are listed for all software versions as follows: Since certain machine parameters are only applied for a certain software, resp. are active from a certain software version, columns with symbols after the parameter numbers are introduced for differentiation.

Meaning:

Column:

4	Ξ	standard	software	PGM-no.	237	300	••	to	237	339		for	IV-axes-controls
5	9	standard	l software	PGM-no.	237	340	••	to	237	359	2.	for	V-axes-controls
4*	=	special	software	PGM-no.	243	100	• •	to	243	139	•••	for	IV-axes-controls
5*	=	special	software	PGM-no.	243	140	••	to	243	159	••	for	V-axes-controls

Symbols

- = the machine parameter is active with all software versions.
- $\emptyset 4$ = the machine parameter is active from a certain software version (e.g. $\emptyset 4$ means from software version $\emptyset 4$).
- \emptyset = the machine parameter of this software has no function and must be programmed with \emptyset .
 - = the machine parameter is not present in this software.

Function	34	Parameter no.	4	5	4*	5*	Input range	ALACAN !!
Rapid course	X Y Z IV	¢ 1 2 3	<u>کې</u> ۲	+ + + +	* * *		8029998 [mm/min] angular axis: 8029998 [°/min]	10 ²¹⁰⁵
Manual feed	X Y Z IV	4 5 6 7		+ + 11 +	•	*	www.cot	Annah O'
Speed when approaching the reference marks	X Y Z IV	8 9 10 11	* * *	* * *	+ + + - + + + + + + + + + + + + + + + +	* • •	1959 Martin Charles Index.	AND REAL PROPERTY
Signal evaluation, input	X1 X2 X3 X4	12 13 14 15		+ + +	* * *	*	1 = 4-fold (max. traverse speed 39 [m/min] 2 = 2-fold (max. traverse speed 15 [m/min]	
Traverse direction when approaching the reference marks	X Y Z IV	16 17 18 19	*	h.	•/• •/•	€ • • •	<pre>\$ = plus direction 1 = minus direction (if parameters no. 20 to 27 are p correctly)</pre>	rogrammed



Function	14	Paraneter No.	4	5	4±	5*	Input range
Machine parameter with multiple function	X Y Z IV	20 21 22 23	3.9		6.	allo	ahan ahan ahan ahan ahan ahan
Counting direction	, And	bit Ø	+	•		•	+ Ø = positive counting direction + 1 = negative counting direction
Release for reference pulse inhib	bit	1 and	+	+	•	+	+ Ø = reference pulse inhibit inactive + 2 = reference pulse inhibit active
Release for non-linear axis error compensation	the second	2	\$ 9	64		•	+ © inactive + 4 = compensation active
Output of the smallest possible voltage steps of 2.44 mV		3 Romany	09	84	+	+ يە	 # Ø = 2.44 mV output if the nominal value calculated is equal/exceeds 1.22 mV. + 8 = 2.44 mV output if the nominal value calculated exceeds Ø.
Polarity of the nominal value voltage	X Y Z IV	24 25 26 27	*	+ + + +	•0		<pre></pre>
Integral factor	X Y Z IV	28 29 30 31		* * *	*		Ø65535
Differential factor	X Y Z IV	32 33 34 35		* * * *	* * *	* * *	Ø65536
Backlash compensation	X Y Z IV	36 37 38 39	* * *	* * *			- 1.000 + 1.000 [mm] angular axis - 1.000 + 1.000 [°]
Compensation factor for linear compensation	X Y Z IV	40 41 42 43		* * *	+ + +		- 1.000 + 1.000 [mm/m]



Punction	Parameter no.	4	5	4=	5*	Input range
Software limit switch ranges X+ X-	44 45		+	*	+	- 30000.000 + 30000.000 [mm]
ус Ү- Ү-	46 47	+	*	+	So to	AL GRAND
Z+ Z-	48 49	+	+*	+	+	· wa wa
IV+ IV-	50 51	+	+ +	*	+	angular axis: - 30000.000 + 30000.000 [°]
Analog voltage with rapid course, X-axis X, Y, Z, IVth-axis X-axis	52	¢ Ø5	\$ 3	1919-19 1919-1919 1919-1919	S ^o	+ 4.5 + 9 [V]
Approach speed	53	J.	+	+	+	0.1 10 [m/min]
Acceleration X, Y, Z, IVth-axis X-axis	54	\$ Ø5	+	+	Contra Contra	0.001 3.0 [m/s ²]
Radial acceleration	55	+	+	1	+	0.001 3.0 [m/s ²]
Position supervision in operation with speed precontrol erasable Emergency-stop	56 57		+	*	* *	0.901 30 [mm]
Positioning window X, Y, Z	58	+	+ -	¢3	# Ø3	Ø.001 2.000 [nm] Ø.001 55.535 [nm]
Axis sequence when approaching the reference marks	59	49.19	• 3			
		12.9	2	And!		
Speed precontrol	60	+	+	+.	ta t	Ø = on 1 = off
Output of tool numbers or allocation numbers	61	Jan D	•	*	+	<pre>\$ = no output 1 = output of tool number only if the tool number changes. 2 = output of the tool number with each tool call. 3 = output of allocation no. (if MP 225 >= 1)</pre>
Output of spindle speed	62	•	+		+	<pre> Ø = no output of spindle speeds </pre>



Function	Parameter no.	4	5	4	5±	Input range
Coded output of spindle speed	J. S.		• 107 daa uuraaa u			1 = code output only if the speed changes. 2 = code output with each tool call.
Analog output of spindle speed	62	•	•			 3 = gear switching signal only if the speed changes. 4 = gear switching signal with every tool call 5 = without gear switching signal
Rpm code limitation	63	€°+	+	+	+	Ø1991 = no limitation
Transient behaviour during acceleration	64	•	ŧ	+	60 ¹⁵⁰	Ø.Ø1 - Ø.999
Display step	65	•	+	1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 -	÷	Ø = 1 µm 1 = 5 µm
without function for the time being	66	Ø	Ø	Ø	Ø	enter Ø
Dwell time of rotating direction reverse Working spindle for cycle "Tapping"	67	¢,	+	ŧ	Salle	9 65.535 [s]
Memory function for directional keys	68	+	+	and i	+	Ø = off 1 = on
Reference mark approach	69		•		Saure	 \$ = after approaching the reference marks the axes automatically approach the software limit switches. 1 = after approaching the reference marks the axes automatically return to the reference marks. 2 = special procedure for the approach of the reference marks
Nominal value voltage for spindle drive when gear is changed	70	*	ŧ	•	•	Ø 9.999 [V]
Sign for end and beginning of program	71	•	¢	•	Sel S	Ø 65535
Selection of the axes inhibited for the control	72 bit		4		5	
X-axis	1	(a)	+	•	+	+ 9 = not inhibited + 1 = inhibited
Y-axis	1	•	+	+	parts	+ 🖗 = not inhibited + 2 = inhibited
2-axis	2	+	•4	•	•	+ Ø = not inhibited + 4 = inhibited
IVth-axis	3		+	 •	+	+ Ø = not inhibited + 8 = inhibited
Vth-axis	4	-	•	and it	~	+ 0 = not inhibited + 16 = inhibited



					0	<u> </u>
Function	Parameter no.	4	5	41	5±	Input range
Parameters with multiple function	73	2 ²	* · ·			Ø 65.535 [s]
MP 92 Bit 12 = 0 BCD-output of the spindle speed: Preswitch-off time of the spindle for cycle "Tapping"	and ballon a		+	A MIC	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	www.chastonet
MP 92 Bit 12 = 1 Analog output of the spindle speed: spindle tracking time after reaching the drilling depth with cycle "Tapping"	Hornard	0	-	62	Ø2	advant international
Feed and spindle override	74 bit			and C	50	
Feed override, if the rapid traverse key is pressed in the auto. operating modes	8		+	•	•	+ 9 = override not active + 1 = override active
Continuous feed override or 2%-stages feed override	1,000	•	+	•		+ Ø = 2%-stages + 2 = continuous
Feed override, if the rapid traverse key and the external directional keys are pressed in the operating mode "Manual"	2	+	+		+	+ Ø = override not active + 4 = override active
Continuous spindle override or 2%-stages spindle override	3 Lomai	•	•	•	+	+ Ø = 2%-stages + 8 = continuous
Reference signal evaluation for inhibited axes	75	• @\?	4		\$ ²⁰ •	 Ø = reference signal evaluation without display "Reference mark approach" 1 = reference signal evaluation with display "Reference mark approach" 2 = no reference signal evaluation
Position data and encoder supervision	76 bit			Š.	Sentico Sentico	
Position data and encoder supervision for inhibited axes	8	+	+3	×.	+	+ Ø = inactive + 1 = active
The supervision of the encoder inputs for each axis can be separately switched off with bit 2 up to bit 5. This is applied for inbibited axes and for	1		*	+		encoder input X + Ø = with supervision + 2 = no supervision
non-inhibited axes. The position data remains active if bit \$ = 1.	2	•	ł.	2	+	encoder input Y + Ø = with supervision + 4 = no supervision
Johnshan C	3		+	+		encoder input Z + Ø = with supervision + 8 = no supervision



Function	A. A. A.	Parameter no.	4	5	4*	5*	Input range
hattend utomaste	Q.	4 conastras	•	•	•	ona	encoder input IV + 0 = with supervision + 16 = no supervision
		5	•	• 10-10-10-10-10-10-10-10-10-10-10-10-10-1	¢\$	•	encoder input V + 0 = with supervision + 32 = no supervision
aska.ol	ģ	6	-	•	-	۰ ماریک	encoder input VI + 0 = with supervision + 64 = no supervision
PLC-Program from RAM or from	EPROM	77 bit		.3	E.		N Gro
-13 ⁶⁴	7 2 ¹ 22	0	•	104	٠	•	+ 0 = 1st a. 2nd K-commands from RAM + 1 = 1st a. 2nd K-commands from EPROM
ashe	ו••	1,10	05	•	•	S SS	+ 0 = 3rd K-commands from EPROM + 2 = 3rd K-commands from RAM
S-analog output Speed range Gear stages	0 1 2 3	78 79 80 81	••••	• *** •	• • •	* * *	0 99999.999 [rpm]
Speed range of gear stages or limit speed with supervision	4 5 6 7	82 83 84 85	* * *	* * *	••••	•	0 99999.999 [rpm]
S-analog voltage with S-override to 100%		86	•	•	٠	٠	0 9.999 [V]
S-analog voltage with S-override and max. output vo	oltage	87	٠	٠	٠	•**	0 9.999 [V]
Limitation of S-override	Maximum Minimum	88 89	• •	¢st. €	, Son	•	0 150 [%]
Axis designation for the IVth	-axis	90	•	٠	٠	•	0 = A 3 = U 1 = B 4 = V 2 = C 5 = W
Constant contouring speed at	corners	91	•	٠	J.	•	0 179.999 [°]
Parameters with multiple func	tion	92 bit	•	24 24	•	•	ANIAN ANA
Decimal characters	\$	0	•	•	•	•	+ 0 = decimal comma + 1 = decimal point
Dialog		apaulo 1	•	•		¢.	+ 0 = first dialog + 2 = second dialog (English)



Function	Parameter no.	4	5	4	5*	Input range
Memory test during switch-on (RAM)	2	Ĩ	+	+	+	+ 0 = memory test carried out + 4 = no memory test
Checksum test during switch-on (RAN + EPROM)	3	+	+		Sat	+ Ø = checksum test carried out + 8 = no checksum test
Change from program run block sequence to program run single block when pro- cessing continuous contours	4	• 	13		*	+ # = the precalculated contour is finished (up to 14 blocks) + 16 = Interruption in current block
Counting mode if the IVth-axis works as a position data for an angular axis	5	+	•	+	Calle	+ Ø = IVth axis counts Ø29999,99 [°] + 32 = IVth-axis counts Ø359.999 [°]->Ø
Activation of functions for the Hirth-toothing for the IVth-axis	6	Ø 7	84		•	+ Ø = no Hirth-toothing + 64 = Hirth-toothing active
Activation of functions for the Hirth-toothing for the Vth-axis	7	Ĩ	04	↓ ↓	+	+ Ø = no Hirth-toothing + 128 = Hirth-toothing active
With active Hirth-toothing MP 65 only determines the display step for the X, Y and Z-axes, MP 260 is applied for the IVth-axis and MP 342 for the Vth-axis.	AN CON	Jan Carl	4			Warmingor warmingor
Actual/nominal value transfer after external EMERGENCY-STOP	8	10	84	+	o ^{all} c	+ Ø = acknowledgement + 256 = no acknowledgement
Distribution of the central tool memory in tools with and without allocation numbers	9	(0		•	<pre>+ Ø = no subdivision + 512 = subdivision (MP 209) = number of tools with allocation numbers) (MP 225) - (NP 209) = number of tools without allocation numbers)</pre>
Manual insertion of tools without allocation numbers	10		Ø			<pre>+ # = no tool call without allocation numbers possible {that means error message "Wrong allocation number"} + 1#24= tool call without allocation numbers possible {that means no error message}</pre>
Automatic acknowledgement of the error message "Current interrupted"	11	4	1			 # # error message "Current interrupted" must be acknowledged manually # 2048= error message "Current interrupted" is automatically acknowledged after approx. 3 seconds
Ramp for the spindle speed when tapping		8	 0	•	-	<pre>+ Ø = spindle ramp is determined via the tool axis + 4096= spindle ramp is determined via MP 168/MP 316, resp. MP 317/NP 318 (dependent on marker M2816)</pre>



Function	Parameter no.	4	5	4=	5*	Input range
Editing inhibit for manufacturer cycles	13		0		Sauc	 + Ø = the editing of the manufacturer cycle is inhibited if the program number of the manufacturer cycle is already filed in the EPROM. + 8192= no editing inhibit, that means the program number of an existing manufacturer cycle is assigned to a new program.
"GOTO-function" with blockwise transfer and simultaneous processing	14	Î	0	02	0 2	+ Ø = GOTO-function not possible + 16384 = GOTO-function possible
Actual/nominal value display with/ without tool length correction when setting datums in the tool axis	15 AM	0	1	13 8	83	 # Ø = display without tool length correction + 32768 = display with tool length correction
Overlapping factor with pocket milling	93	+	+	٠	+	Ø. 1 1.414
PLC: counter preset value for counters Ø - 15	94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109			**********		Ø 65535
PLC: time of timer for timers Ø - 15	110 111 112 113 114 115 116 117 118 119 120 121 122 123			• • • • • • • • • • • • • • • • • • • •		0 65535 (in units of 20 ms)
	124 125		+	+	+	Kall Kall


Punction	Parameter no.	4	5	f:	5±	Input range	ANN CO
PLC: 31 positioning values for PLC-Positioning	126 127 128 129 130 131 132 133 134	*	*	* * * * * * * *		- 30000.000 + 30000.000 [mm]	And the second second
	135 136 137 138 139 140 141 142	*	*	* * * *	*	ashe www.contenter	
	143 144 145 146 147 148 149 150 151		*	* * * * * * * * * * * * *	*	ANG AN ANG ANG ANG ANG ANG ANG ANG ANG A	
Manna Manna Martin Chart	152 153 154 155 156	* * *	• •			en and and a second a	www.cool
Activation of the next tool number, programmable with TOOL CALL/ or with the following allocation number, programmable with TOOL DEF	157	en de	4	+	Paulo	<pre>9 = no output of next tool number 1 = output of next tool number on if tool number is changed (TOOL CALL/) 2 = output of next tool number with each tool call (TOOL CALL/) 3 = output of next tool allocation programmable with TOOL DEF (if NP 225 >= 1)</pre>	ly n number,
Setting of a binary number with 16 mar- kers (marker 2192 to 2207)	158	+	•	،		Ø 65535	, doald
Automatic lubrification after X programmed traverse path Y in Z IV	159 160 161 162	• • •	**	* * *	* * *	Ø 65535 (in units of 65536 µm	}



						dialle dial
Function	Paraneter no.	4	5	4±	5±	Input range
Feed speed X for parameter no. 126 Y to no. 156 Z IV	163 164 165 166		* + +	* * *		80 29998 [mm/min]
Actual feed display before the start in the manual operating modes (same feed in all axes, that means smallest programmable feed, that means from parameters 4 to 7 and 322)	167	Kall	•	1. 1. 1.	+	Ø = no display 1 = display
Ramp gradient foe S-analog voltage	168	+	+	+	S.	♦ 1.999 [V/ms]
Standstill supervision	169	+	+	e de la compañía de la	•	0.001 30 [nu]
Programming station	170	And A	+	*	+	 \$\$0\$ = control\$\$\$ 1 = programming station: PLC active\$\$\$ 2 = programming station: PLC inactive\$\$\$\$ 3 = analog outputs for plotter operation\$
Selection of the Handwheel and the probe system	171 bit Ø	ą	Ø	and a star	5	+ Ø HR 150/250 + 1 HR 130/330
and had	1		+	+	•	+ 0 = TS 511 + 2 = TS 111/120
Polarity of S-analog voltage	172	•	+			<pre>Ø = NØ3: positive voltage NØ4: negative voltage 1 = NØ3: negative voltage MØ4: positive voltage 2 = NØ3 and NØ4: positive voltage 3 = NØ3 and NØ4: negative voltage</pre>
Status display erasure and Q-parameters with NØ2, M39 and program end	173	•	+	+	Saute	<pre>Ø = status display is not erased 1 = status display is erased</pre>
Position supervision in trailing distance operation Emergency-Stop Erasable	174 175		+	+	+	Ø 190 [ma]
Multiplication factor for the Kv-factor	176	+	÷	+		8.891 1.888
Rv-factor for the trailing X operation Y Z IV	177 178 179 180	• • •	+ + ~ +		* * *	9.100 10.000
Characteristic kink	181	+	+	+	+	0 100.000 [%]
Minimum for feed override when tapping Maximum for feed override when tapping	182 183	*	•7		*	0 150 [%] 0 150 [%]



					32		
Function	Parameter no.	4	5	(1	5*	Input range	30 Martin
Minimum voltage for S-analog output	184	Ì	+	+	+	Ø 9.999 [V]	
Waiting time to switch-off the residual nominal value voltage when the error message "Positioning error" appears	185	+	+	+	South	Ø 65.535 [s]	ALCODOL
Datums for positioning blocks with M92: X Y Z IV	186 187 188 189		* * * *	*	*	- 30000.000 + 30000.000 [mm] resp. - 30000.000 + 30000.000 [°]	19
Programming of speed S=0 permitted (voltage value of MP 184 can be very low)	190	•	•	- in Mar	S. •	<pre>Ø = S=Ø permitted 1 = S=Ø not permitted</pre>	A. C.
Display of current spindle speed before the spindle start	191	e.	+	+	•	<pre>\$ = off 1 = on</pre>	
Positioning window for the IVth-axis	192	+ -	+ -	+ Ø3	Ø 3	0.001 2.000 [mm or °] 0.001 65.535 [mm or °]	A CONTRACT
PLC: time of timers for timer 16-31	193	•	• 3	+	+	0 65535 (in units of 20 ms)	2
	174	~					
	195	@ ^K	•		!	NO XOX	
	190		7		1	18 M 19 M	
	100				- 10		
	190		, i		Ser.		100 M
	200		÷	38			3450
	201		-	15	•	44	3
	202		•	•	+		
	203		+	•	+	\$ \$	
	204	÷	+	+	+	No. No.	
	205	•	+	+	+	Co. Co.	
	206	+	+	+		and the second se	Ň
	207	•	•		\$~ •	, B	S.
and a start of the	208	•	•	1	•	A AND A	. Share
Function dependent on M92, bit 9	209	~			1		
MP92 bit 9 = 0: activation of PLC macro commands	tomar		+	+	+	Cardina Contraction	
M92 Bit 9 = 1: number of tools with allocation number	AMIC DOL	-	-	+0; 53	\$° +	Ø 99 tools	Sanni (Bob
Activation of PLC-macro commands	210	•	•	•		0 9999	
(Setting of markers 3200 3263)	211	ð	•	+	+	6 6	
Stor Stor	212	24	+	+	+	No. No.	
Cycle "Scaling" is active on 2 axes or on 3 axes	213	•	+	+		<pre>Ø = 3 axes (spacial) 1 = 2 axes (operating plane)</pre>	, 150 ⁰¹⁵



Function	Parameter no.	4	5	4=	5*	Input range
Output of M- and S-function	214 bit	9 ⁹				and the Real Property
Programmed stop with M#6	0	•	•		•	+ Ø = programmed stop with MØ6 + 1 = no programmed stop with MØ6
Output of M89	1	•	•	+	•	+ Ø = normal output at beginning of block + 2 = modal cycle call at end of block
Axis standstill if only one new spindle speed is output with a TOOL CALL	2	÷	•	+	+ 	+ Ø = axis standstill + 4 = no axis standstill
Axis stands still when M-function is output Ecceptions: axis stands still with M-functions which result in a pro- grammed stop (as NØØ, NØ2) or if a STOP or a CYCL-CALL block occurs	3	+ /0.	4	barne.	° ∙	+ Ø = axis standstill + 8 = no axis standstill
Reserved	4	•	Ø	0		+ 0
Axis stands still if a tool numnber, a tool axis or a spindle speed was programmed with a TOOL CALL	5	¢	0	<u>i</u>	•	+ ∮ = axis standstill + 32 = no axis standstill
Nominal/actual value acknowledgement during M/S/T-strobe if marker 2552 ff was set	6	6	\$	•	Saltion Saltion	 # # = during N/S/T-strobe the actual value is acknowledged as nominal value + 64 = during N/S/T-strobe the actual value is not acknowledged as nominal value
Probe system: feed for probing	215	٠	13	+	+	80 3000 [mm/min]
Probe system: measuring path	216	<u>م</u>	+	+	ŧ	Ø 19999.999 [mm]
Switch-over from HEIDENHAIN dialog programming to DIN/ISO-programming	217	*	+	+	a to	Ø = HEIDENHAIN-dialog 1 = DIN/ISO
"Blockwise transfer" ASCII-character for data input	218	•	+ "	e f	•	0 65535
"Blockwise transfer" ASCII-character for data output	219		+	•	+	Ø 65535
"Blockwise transfer" ASCII-character for the beginning the end of the command block	220	*	•	10.14	50.00	Ø 12079
"Blockwise transfer" ASCII-character for pos. acknowledge- ment, resp. negative acknowledgement	221	* /Q	•	•	•	0 12079



Function	Parameter no.	4	5	4=	5*	Input range
Data format and transmission stop for V.24-data interface	222 bit	30				LEYKE D LEYKE D
7 or 8 data bit	MODAL	•	4	and C.		<pre>+ Ø = 7 data bit (ASCII-code with 8th bit</pre>
Block-check character	1	<u> </u>	+	•	•	<pre>+ Ø = any BCC-character (also control sign) + 2 = BCC-character, no control sign</pre>
Transmission stop by RTS	2	•	+		\$° +	+ Ø = inactive + 4 = active
Transmission stop by DC3	3	*	+	•	*	+ Ø = inactive + 8 = active
Even or odd character parity	4	*	+	•	Gautic	+ # = even + 16 = odd
Requested character parity	5	*	•		• •	+ # = not required + 32 = required
Number of stop bits	6/7	(* (*	•		paulo	7 6 8 8 1½ stop bits 9 1 2 stop bits 1 8 1 stop bit 1 1 1 stop bit Setting bit 6: + 64 Setting bit 7: + 128
Operating mode V.24-data interface	223	•	+	•		<pre>Ø = "standard data interface" 1 = "blockwise transfer"</pre>
"Blockwise transfer" ASCII-character for end of data transmission	224	+	+ 4		+	0 12079
Central tool memory	225	÷	•	•	+	<pre>Ø = no central tool memory 1 99 = central tool memory input value = number of tool stations</pre>
Graphic printout Number of control characters to set the printer interface + 1 control character	226	•	+		•	Ø 65535
Graphic printout 2 control characters to set the printer interface	227 228 229		+ + +	* * *	+	Ø 65535



Function	Parameter no.	4	5	4=	5*	Input range
Graphic printout Number of control characters before each printer line + 1 control character	230	e P	•	• •	•	\$ 65535
Graphic printout 2 control charcaters before each printer line	231 232 +	* * *	+ + +		\$` • •	\$ 65535
Movement supervision	234	<u>e</u>	+	•	+	Ø.03 10 [V]
Touch probe system: safety distance via measuring point for autom. measurement	235	+	+	+	60000	Ø 19999.999 [mm]
Graphics	236 bit			asan'i		
Switch-over to "View in three planes"	0		+	•	+	+ Ø = German standard + 1 = American standard
Turning the coordinate system by 90° in the working plane	1,00	+	+	+		+ Ø = no rotation + 2 = coordinate system turned
Activation of the S-axis for spindle orientation	237		•		+	<pre>Ø = axis inactive 1 = axis is used to orientate the main spindle, without position data 2 = as input value 1, with position data, however (displayed instead of the IVth-, resp. the Vth-axis)</pre>
Kv-factor for S-axis (spindle)	238	+	+	•	S.	0.100 10.0000
Counting direction and handwheel input inhibit for axis of spindle orientation	239 bit		3			
Counting direction	8	Ĩ	+	+ 	+	<pre>+ Ø = positive counting direction + 1 = negative counting direction</pre>
Not assigned	1			-	0	
Not assigned	2	+	- 3	0	0	
Not assigned	3	à	-	8	0	
Encoder input X5 as Handwheel input for the X-axis	4	-	-	•	Salle	 + 9 = encoder input X5 corresponds to the standard input + 16 = encoder input X5 corrresponds to the Handwheel input for the X-axis
Positioning value to the reference value for the S-axis (spindle)	240	+	+	•	•	4 360.010



Function	Parameter no.	4	5	4=	5±	Input range
Cycles to mill pockets of any contour	241 bit	A.S.				AND REAL REAL
Cycle "Reaming": milling direction to premill contour	Ø		•			 # Ø = counterclockwise premilling of the contour with pockets, clockwise premilling with islands + 1 = clockwise premilling of the contour with pockets, counterclockwise premilling with islands
Cycle "Reaming": sequence for reaming and premilling	1	+	•		Spanne	 # # = mill a channel round the contour first, ream the pocket subsequently + 2 = ream the pocket first, mill a channel round the contour subsequently
Combining corrected or uncorrected contours	2	-0. 2	+	+	•	<pre>+ Ø = combining corrected contours + 4 = combining uncorrected contours</pre>
Reference mark distance for distance-coded encoders X Y Z IV	242 243 244 245	* * *	+ + + +	+		 65535 no distance-coded reference marks 1000 = linear encoder with 20 µm grating pitch or angular encoder with 36 reference marks and 18000 lines
Positioning window for S-axis (spindle)	246	<u>ر او</u>	+	+	+	1 65535 (incrementals)
Hysteresis for Electronical Handwheel	247	+	ŧ	+	+	Ø 65535 [incrementals]
Spindle speed for spindle orientation	248	+	+	1	S.	Ø 99999.999 [rpm]
Setting a binary number with 16 markers (marker 2208 to 2223)	249	•	•		•	¥ 65535
Setting a binary number with 16 markers (marker 2224 to 2239)	250		ŧ	•	+	¢ 65535
Touch probe: rapid traverse for probing	251	•	÷	+	Soot.	80 29998 [mm/min]
Automatic, cyclic offset adjustment	252	•	+ -	+	+	1 65535 [in unist of 20 ms] Ø = no automatic adjustment
Allocation of the axes to X the encoder inputs Y Z IV V	253 254 255 256 257	++++0	* * * *	+++++		<pre>\$\$\$ = standard allocation 1 = encoder input X1 2 = encoder input X2 3 = encoder input X3 4 = encoder input X4 5 = encoder input X5 6 = encoder input X6</pre>
Analog output of the speed for the spindle if marker 2501 is set	258		•	+	•	<pre> Ø 99999.999 [rpm] the rotating direction is always positive </pre>



			• ••	<u></u>	<u>×</u>		
Function	Parameter no.	4	5	4=	5±	Input range	-Starter.
Change-over dialogs for manufacturer cycles: difference between dialog numbers of the second (English) and the first dialog	259	\$ \$	•	+	Daito	Ø 50	.20015
Prescribed step for the IVth-axis if the Hirth-toothing is activated via MP 92	269	8	84	19 19	•	<pre>\$ 9.999 [°] Input value \$ is treated as \$.\$\$1.</pre>	the second second
Displacement for the IVth-axis if the Hirth-toothing is activated via MP 92	261	98	04	+	+ Dautico	- 30009.000 + 30000.000 [°]	
Number of global Q-parameters which are transferred from a manufacturer cycle to the calling program	262	Ø5	+	s.	•	Ø 50 When entering 40 the Q-parameters Q60 Q99 are global	Surger Contraction
Difference between Q-parameter numbers for "DLG-DEF"-block and "DLG-CALL"-block in the user cycle	263	•	•	•	+ Salito	Ø 50 Ø if "DLG-CALL"-blocks only	a control
PLC: time of timers for timers 32 - 47	264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279	\$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$	* * * * * * * * * * *			Ø 65535 (in units of 20 ms)	And the second s
PLC: counter preset value for counters 16 - 31	280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295	\$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$5 \$	$\begin{array}{c} \bullet \\ \bullet $				



Function	. caral	Parameter	4	5	4*	5*	Input range
44°	4	no.		24			4 4
Limitation of the feed override		296	05	٠	•	•	0 150 [%]
in % if marker 2509 is set		Carolt				S.	The second s
Acceleration	Y	297	05	٠	S	€ ♦	0.001 3.0 [m/s ²]
	z	298	05	•	Š`∳	•	(B) (B)
	IV	299	05		•	•	de la companya de la
The acceleration for the X-axis is determined by MP 54.	4	à		54			
Analog voltage with rapid	Y	300	08	03	•	•	+ 4.5 + 9 [V]
traverse	Z	301	08	03	•		
	IV	302	08	03	٠	₹ ♦	and the second second
The analog voltage for the X-ax:	Le 🧹	8°-			00		8
is determined by MP 52.	- And And			and a start			all and a second se
Input values for the datum shift	τ,						
activated via markers 2816, 2817	7, 2819		1		l	[
1. datm shift	х	303	08	04	•		- 30000.000 + 30000.000 [mm]
2. datum shift	х	304	08	04	•	. (*	office off
3. datum shift	x	305	08	04	. S ⁵	ĕ ♦	
1. datum shift	Y S	306	08	04		٠	- 30000.000 + 30000.000 [mm]
2. datum shift	Y	307	08	04	•	•	A
3. datum shift	Y	308	08	04	٠	•	
1. datm shift	z	309	08	04	٠	•	- 30000.000 + 30000.000 [mm]
2. datm shift	z	310	08	04	•		and and a set
3. datum shift	Z	311	08	04		•	nauto.
1. datum shift	IV	312	08	04	S. ♦	٠	- 30000.000 + 30000.000 [mm]
2. datum shift	IV	313	08	04	•	•	resp.
3. datum shift	IV	314	08	04	٠	•	- 30000.000 30000.000 [°]
%-factor for tha analog spindle		315	08	04	٠	•	0 150 [%]
voltage if marker 2822 is set		xor ar				5500	10 ¹⁰
Ramp gradient -		316	09	04		٠	0 1.999 [V/ms]
S-analog voltage to stop the spi	indle						0 = acceleration and braking from MP 168
Ramp gradient for the S-analog		Ś					e e
voltage if M 2816 is set	<u></u>		ļ			_8	· · · · · · · · · · · · · · · · · · ·
Acceleration		317	09	04		o st i	0 1.999 [V/ms]
Braking	aral.	318	09	04	⊗	•	0 1.999 [V/ms]
M 90 modal		319	0	0	•	•	0 = M 90 not modal
		6					1 89 (except for 2, 3, 4, 5, 6, 8, 9,
		No.					13, 14, 30)= M-function which is active
		and and a second				2	as M 90, but not modal



Function	Parameter no.	4	5	4±	5*	Input range
Axis designation for the Vth-axis	320	e ^{lo}	•	0	+	Ø = A 3 = U 1 = B 4 = V 2 = C 5 = W
Rapid traverse for the Vth-axis	321	-	•	80	+	80 29998 [mm/min] angular axis: 80 29998 [°/min]
Nanual feed for the Vth-axis	322	ŝ	+	Ø	+	80 29998 [mm/min]
Speed when approaching the reference marks	323	-	+	1	all o	- angular axis: 80 29998 [°/min]
Feed for PLC-positioning of Vth-axis	324	-	+	Ø	+	Arrand Land Arrand Land
Software limit switch ranges V +	325	\$	+	Ø	٠	- 30000.000 + 30000.000 [nm]
V -	326	2	+	Ø	+	- 30000.000 + 30000.000 [°]
Signal evaluation, input X5	327	-	h.	6 	50 ⁴⁰	1 = 4-fold 2 = 2-fold (max. traverse speed limited by the EXE-input frequency)
Reference mark distance for distance-coded encoders Axis V	328	6	•	8	Paulo	9 65535 9 = no distance-coded reference marks 1000 = linear encoders with 20µm grating pitch or angular encoder with 36 reference marks and 18000 lines
Traverse direction when approaching the referenec marks	329	- 102	•	0	•	<pre> Ø = plus direction 1 = minus direction (if machine parameters 330 and 331 are correctly programmed)</pre>
Nachine parameters with multiple function	330 bit			, id	pauto	MIGD ^{allo}
Counting direction for the Vth-axis	0	-	+4	9	+	+ Ø = positive counting direction + 1 = negative counting direction
Reference pulse inhibit for the Vth-axis	1	<u> </u>	+	0	+ .0	+ Ø = inactive + 2 = active
Release for non-linear axis error compensation for the Vth-axis	2		\$4	00	1	+ Ø = inactive + 4 = compensation active
Output of the smallest possible voltage step of 2.44 mV for the Vth-axis	3	10.	04	0	- auto	 + Ø = 2.44 mV output if the nominal value calculated is equal or exceeds 1.22 mV. + 8 = 2.44 mV output if the nominal value calculated exceeds Ø.



Function	Parameter no.	4	5	4*	5*	Input range
Polarity of the nominal value voltage	331	-	•	o	•	<pre>0 = positive with positive traverse direction 1 = negative with positive traverse direction</pre>
Differential factor for the speed precontrol	332	-	•	0	•	0 65.535
Kv-factor for the trailing operation V	333	-	- S -	0	٠	0.100 10.000
Datum setting via axis key V	334	-	•	0	ofnå	<pre>0 = inactive, datum is acknowledged from MP 337 1 = active</pre>
Acceleration for the Vth-axis	335	-	•	So	٠	0.001 3.0 [m/s ²]
Positioning window for the Vth-axis	336	-	-	0 -	• 03	0.001 2.000 [mm or °] 0.001 65.535 [mm or °]
Datum for the Vth-axis	337	-	•	0	•3	- 30000.000 + 30000.000 [mm]
Analog voltage with rapid traverse, axis V	338	-	03	0	¢.	+ 4.5 + 9 [V]
Input values for the datum shift of the Vth-axis, activated via marker 2816, 2817, 2819 1. datum shift V 2. datum shift V 3. datum shift V	339 340 341	-	04 04 04	000	•**	- 30000.000 + 30000.000 [mmm] resp. - 30000.000 + 30000.000 [°]
Prescribed step for the Vth-axis if the Hirth-toothing is activated via MP 92	342	-	04	0	•	0 9.999 [°] input value 0 is treated as 0.001
Displacement for the Vth-axis if the Hirth-toothing is activated via MP 92	343	-	04	o	•. 50	- 30000.000 + 30000.000 [°]
Compensation factor for linear compensation of the Vth-axis	344	-	04	0	•	- 1.000 + 1.000 [mm/m]



Function	A and	Parameter no.	4	3 ⁵	4*	5*	Input range
2nd group: software limit switch	5+	345	- 1	-	0	•	linear axis:
ranges for the 5th-axis;	5-	346	-	- 1	0	●3	- 30000.000 + 30000.000 mm
selectable via markers M2816/M281	17	. 56				5	rotational axis:
		10915			100	5	- 30000.000 + 30000.000°
3rd group: software limit switch	5+	347	_		•		linear avia
ranges for the 5th-avie	12	340		25			20000 000 + 20000 000
selectable via marker M2815/M2817	, ,	340			ľ		
Beiecable via marker M2010/M201/	ſ		2				- 30000 000 + 30000 0009
<u></u>		and the second second					- 30000.000 + 30000.000
Datum for positioning blocks		349	-	-	0	02	- 30000.000 + 30000.000 [mm]
with M 92 ax	cis 5	war -]		1	2	resp.
		05		3	S.		~ 30000.000 + 30000.000 [°]
Reserved	2220	350	_	324	0	0	
		351	_	_	0		
		352	2 -	_	0		
		353	_	_	0		No. No.
		354	_	_	0		Clark A
		355	_	_	0	n a	
		356	_	_	Š	l õ	
		357	_	_3	0		and the second se
		358	-	32	ő		4
		359	_	-	o o	ů	
			2				<u></u>
Minimum spindle speed		360	-	-	٠	.	0 99999.999 rpm
Spindle speed, %-deviation		361	_	-	•		0 99 %
of nominal value output		80			S		8
				- 52	1. C		
2nd spindle speed for spindle		362	-	2-	•	•	0 99999.999 rpm
orientation; active if the MP317/	MP318						
ramps were selected via marker 28	323	10	5				10 ^{.2} 10 ^{.2}
and the second s						- A	
2nd group: software limit switch	<u>к</u> + 	202	_			0	110000 000 1 20000 000
ranges; selectable via markers	X-	304		_	200		- 30000.000 + 30000.000 mm
M2010/M2014	¥+ 4	365	_	-	× •	•	rotational axis:
	Y-	366	-	25	٠	•	- 30000.000 30000.000°
				<u> </u>			~ ~ ~
	Z+	367	F -	-	•	•	Wax Wax
	Z-	368	_	_	. ♦		S. Alexandre a
	IV+	369	_	_	•		Otto Otto
	IV-	370	- 1	_	. 8	•	· 35. · 35.
			1			I .	



Function	A acad	Parameter no.	4	5	4*	5*	Input range:
3rd group: software limit switch ranges; selectable via M2816/M2817 markers	X+ X-	371 372	-	-	• •	•	linear axis: - 30000.000 + 30000.000 mm
	¥+ ¥-	373 374	- -	-		•	rotational axis: - 30000.000 + 30000.000° 375 377
	Z+ Z-	375 376	-		•	•	
	IV+ IV-	377 378	-	-	•		
Non-volatile storage of Q-paramet (8 parameters)	ers	379	-	144	j.	•	0 = no non-volatile storage of Q-parameters 1 92 = number of the first Q-parameter out of eight (non-volatile storage)
Multiple definition of tools in the centrol tool memory		380		-	•		<pre>0 = no multiple definition per tools 1 = 2 various definitions per tool 2 = 3 various definitions per tool 3 = 4 various definitions per tool 4 = 5 various definitions per tool 5 = 6 various definitions per tool</pre>
Size of NC-buffer memroy with "Blockwise transfer" with simultaneous processing		381		-	02	02	<pre>0 = reload continuous blocks 1 3000 = minimum number of NC-blocks in the block memory. After remai- ning below this limit data are reloaded via the interface.</pre>
Overlap voltage for positive analog voltage of the spindle (only active if analog voltage >	0)	362	-	4 <u>4</u>	02	02	- 9.999 + 9.999 [V]
Overlap voltage for negative analog voltage for the spindle (only active if analog voltage <	0)	383	_		02	02	- 9.999 + 9.999 [V]