

SIEMENS

Technical Description

Order number: 6AR1943-4AA00-2CA0

December 1999

SICOMP IMC01

Compact Process Computer

Order number: 6AR1025-1XXxx-0AA0

IMC01-BSP, Version 1.0

Basic software for the SICOMP IMC01 compact process computer

SICOMP Industrial Microcomputer

(4)J31069-D2094-U001-A0-7618

Product History of the Technical Description

Revision ¹⁾	Record of Changes	Date
A0	First edition	12/99

1) Corresponds to the 4th block of digits of the drawing number in the footer

Explanation of Notation

- * An asterisk behind the signal name indicates a low-active signal (e.g., IOR*).
 - / A slash between two signal names separates two level-dependent functions of one signal. Example: C/D* means Command for high level and Data for low level.
 - Connections indicated with a dash in a connector assignment table are reserved (i.e., bus or I/O interface).
- Signal** Special signals not included in these specifications are indicated in bold print in the signal assignment tables and then explained (e.g., **AMSEOP**).

Notes:

SICOMP® is a registered trademark of Siemens AG.

IBM AT® and IBM PC® are registered trademarks of the International Business Machines Corp.

INTEL® is a registered trademark of the INTEL Corp.

MS-DOS®, Windows® and Windows NT® are registered trademarks of Microsoft.

All other designations used in this documentation may be trademarks whose use by third parties for their own purposes may violate the rights of the owner.

Passing on and reproduction of this document, as well as utilization and communication of its contents is prohibited unless expressly authorized. Offenders will be liable for damages. All rights reserved, particularly in the event a patent is granted or a utility model is registered.

No responsibility is assumed for circuits, descriptions and tables contained in this document concerning freedom from rights of third parties. Information in the technical descriptions specifies products but does not guarantee characteristics. The product described in this documentation may require licensing. Questions should be directed to your local Siemens office.

Availability and technical modifications subject to change without prior notice.

ES43/Ka/WW8.0/VS5.0/A4

Safety Notes for SICOMP Boards

ESD protection measures



Caution

When handling boards and other components carrying this symbol, always adhere to ESD protection guidelines (**E**lectrostatic **S**ensitive **D**evelopments).

- Never touch the boards unless required work makes this absolutely necessary.
- When working with the boards, use a conductive and grounded work surface.
- Wear a grounding bracelet.
- Never touch the pins, connections or printed circuits of the boards.
- Never permit the boards or components to be touched by chargeable objects (e.g., synthetic materials).
- Keep the boards or components at least 10 cm away from CRT units and television sets.
- Leave the boards in their special packaging until they are needed. When registering boards, etc. do not remove the boards from their packaging or touch them.
- Boards may only be installed or removed when the voltage is off.

Related SICOMP Literature

For more information on installing and handling SICOMP boards, see the SICOMP IMC system manual.



Caution:

Danger of injury (e.g., sharp edges of housing components) when performing service and maintenance work!

Notes on the CE Seal

EC guidelines EMC 89/336/EEC

Products bearing the CE seal meet the requirements of EC guideline 89/336/EEC "electromagnetic compatibility" and the harmonized European standards (EN) listed below.

The EC declarations of conformity are retained for responsible authorities at the address below in accordance with article 10 of the above stated EC guideline.

Siemens Aktiengesellschaft
Bereich Automatisierungstechnik
A&D SE QTD QM
Postfach 2355
D-90713 Fuerth

Area of use

The products described are designed for use in industrial applications. They meet the following requirements.

Area of Use	Requirements for	
	Interference Emission	Interference Immunity
Industrial	EN 50081-2: 1993	EN 50082-2 : 1995

When an individual approval is granted, the products described can be used in Germany in residential areas (i.e., residential zones, trade and commerce zones and small business areas).

Area of Use	Requirements for	
	Interference Emission	Interference Immunity
Residential	Individual approval	EN 50082-1: 1992

Individual approval is granted by the "Bundesamt für Post und Telekommunikation" and its branch offices.

Installation guidelines

The products fulfill the requirements under the following conditions.

1. The installation guidelines and the notes on safety in this manual have been adhered to.
2. In addition, the following rules have been complied with.

Data/signal lines

All signal lines which leave the device must be provided with shielding. The shields of the signal lines must be attached on both sides in shielded plug connectors or with the metallic HF clamps provided for this purpose.

Other notes

Since the device is designed for installation in cabinet panels, the interfaces on the back of the device are not provided with additional protection.

Service work on switching cabinets

To protect the boards from static electrical discharge, technicians must discharge themselves electro-statically before touching the back of the device or the components on the back.

Updated technical data

Contrary to the information contained in the "Technical Data" of the technical description, the following specifications on electromagnetic compatibility apply to boards/devices which carry the CE seal.

These specifications apply to devices which have been installed as described by the stated installation guidelines.

Specifications for Electromagnetic Compatibility	Test Values
Interference immunity against the discharge of static electricity ¹⁾	
Tested in accordance with EN 61000-4-2	Air discharge 8 kV Contact discharge 4 kV
Interference immunity against fast transient interference voltages (bursts)	
Tested in accordance with EN 61000-4-4 Supply lines for 120/230 V AC Signal lines (I/O and bus lines)	2 kV 2 kV ²⁾
Interference immunity against electromagnetic fields ¹⁾	
Tested in accordance with EN V 50140 (amplitude-modulated HF)	80 to 1000 MHz 10 V/m 80% AM (1 kHz)
Tested in accordance with EN V 50140 (pulse-modulated HF)	900 MHz 10 V/m 50% ED, 200 Hz repetition frequency
Interference immunity against high frequency emission	
Tested in accordance with EN V 50141	0.15 to 80 MHz 10 V 80% AM (1 kHz) Source impedance 150 Ω
Interference emission ¹⁾	
Tested in accordance with EN 55011 Emission of electromagnetic fields Interference emission over power lines	Limit value class A, group 1 Limit value class A, group 1

1) *With closed metal housing on front of device*

2) *Signal lines which are not used for process control (e.g., cables to external printers: 1 kV)*

Table of Contents

1	Introduction	11
1.1	Product Structure	12
1.1.1	Block Diagram of the Hardware Components (Basic Configuration)	12
1.1.2	Software Structure	13
1.2	System Prerequisites and Accessories	14
1.3	Required Commissioning Steps	15
1.3.1	STEP 5 Programming for Compact PLC	15
1.3.2	C or IMC0x-PLC Programming	15
1.4	Scope of Delivery	16
2	Device Description	17
2.1	Features	17
2.1.1	Physical Components	18
2.1.2	Power Supply	18
2.1.3	Processor and Memory Configuration	19
2.1.4	Interfaces	20
2.2	Interface Signals	21
2.2.1	Serial Interfaces	21
2.2.2	Interfaces of the I/O Card	23
2.2.3	Interfaces of the Expansion Card	25
2.3	Technical Data	27
2.3.1	Operational Values	27
2.3.2	Physical Values	28
2.3.3	Environmental Requirements	28
3	Commissioning with STEP 5 Programming for Compact PLC	29
3.1	Connecting the Power Supply and the PG to the IMC01	29
3.2	Installing the IMC01-BSP on the PG	30
3.3	Creating the Program with the PG	30
3.4	Setting the Type of Measurement for the Analog Inputs	30
3.5	Installation in a Front Panel	32
3.6	Connecting the I/O Devices	33
3.6.1	Installation Guidelines	33
3.6.2	Grounding Concept	34
3.6.3	Connection Cable from PG to IMC01 (Zero Modem Cable)	35
3.7	Parameterizing PROFIBUS	35
4	Commissioning with C or IMC0x-PLC Programming	36
4.1	Connecting the Power Supply and the Development Computer to the IMC01	36
4.2	Installing the IMC01-BSP on the Development Computer	37
4.3	Preparing the Program and Generating the System	37
4.3.1	Using the Sample Applications	39

4.3.2	Using the Coprocessor Emulation	39
4.4	Loading and Testing the RMOS System and the User Program	40
4.4.1	Behavior during Booting/Reset	40
4.4.2	Establishing the Connection	41
4.4.3	Deleting Software from the IMC01	41
4.4.4	Loading an RMOS System or a User Program	42
4.4.5	Starting the System or User Program	43
4.4.6	Testing and Loading User Programs with the Debugger	43
4.5	Setting the Type of Measurement for the Analog Inputs	44
4.6	Installation in a Front Panel	45
4.7	Connecting the I/O Devices	46
4.7.1	Installation Guidelines	46
4.7.2	Grounding Concept	47
4.7.3	Connection Cable from PC to IMC01 (Zero Modem Cable)	48
4.8	Parameterizing PROFIBUS	48
5	Compact PLC	49
5.1	Reloading the Compact PLC to User FLASH Memory	49
5.2	Data Block Interfaces for the Peripherals	50
5.2.1	Character Output on the Display (FB_DIS)	50
5.2.2	Using the HW Peripherals (FB_IN, FB_OUT)	52
5.2.3	Configuration in DB_CONFIG	59
6	BIOS Functions	61
6.1	Call Back Functions	62
6.2	Functions for Analog Input	63
6.2.1	bai_get	63
6.2.2	bai_getmode	65
6.2.3	bai_init	66
6.2.4	bai_read	67
6.2.5	bai_setmode	69
6.2.6	bai_strtconv	70
6.3	Functions for Analog Output	72
6.3.1	bao_init	72
6.3.2	bao_set	73
6.3.3	bao_setmode	74
6.4	Real Time Clock Functions	75
6.4.1	bc_init_rtc	75
6.4.2	bc_stime	76
6.4.3	bc_time	77
6.5	Functions for Digital Input	79
6.5.1	bdi_get	80
6.5.2	bdi_getblock	81
6.5.3	bdi_getmbit	82
6.5.4	bdi_getmirror	83
6.5.5	bdi_init	84
6.5.6	bdi_mirror	84
6.5.7	bdi_resetmbit	85

6.5.8	bdi_setmbit	85
6.5.9	bdi_setmirror	86
6.6	Functions for Digital Output	87
6.6.1	bdo_flush	88
6.6.2	bdo_getmbit	89
6.6.3	bdo_getmirror	90
6.6.4	bdo_init	91
6.6.5	bdo_mflush	91
6.6.6	bdo_reset	92
6.6.7	bdo_resetmbit	92
6.6.8	bdo_set	93
6.6.9	bdo_setmbit	93
6.6.10	bdo_setmirror	94
6.6.11	bdo_status	95
6.7	Display Functions	96
6.7.1	bg_cleardevice	96
6.7.2	bg_getmaxx	97
6.7.3	bg_getmaxy	97
6.7.4	bg_gotoxy	98
6.7.5	bg_init	99
6.7.6	bg_outchar	99
6.7.7	bg_outtext	100
6.7.8	bg_screensaver	101
6.7.9	bg_setcursor	102
6.7.10	bg_setcursortype	103
6.7.11	bg_wherex	104
6.7.12	bg_wherey	104
6.8	General Functions	105
6.8.1	bgen_battstat	106
6.8.2	bgen_crc	107
6.8.3	bgen_init	107
6.8.4	bgen_version	108
6.9	Keyboard Functions	109
6.9.1	bk_getchar	109
6.9.2	bk_keybinit	110
6.9.3	bk_LEDflush	111
6.9.4	bk_setkeytab	111
6.10	Functions for Temperature Measurement	112
6.10.1	bpt_calibrate	112
6.10.2	bpt_gettemp	113
6.10.3	bpt_init	114
6.10.4	bpt_sel_chnum	114
6.11	Functions for Watchdog Processing	115
6.11.1	bwd_init	115
6.11.2	bwd_trigger	116
6.12	Functions for DP Slave Programming	117
6.12.1	dp_GetErrorState	117
6.12.2	dp_GetShortDPVersion	118
6.12.3	dp_GetStationAddress	118
6.12.4	dp_Init	119
6.12.5	dp_ReadOutputBuffer	120
6.12.6	dp_WriteInputBuffer	121

6.12.7	Structure of DP_ERROR_STATE	122
6.13	Functions of the Hardware Configuration	123
6.13.1	imc01ReadHwStatus	124
7	Appendix	125
7.1	Key Codes	125
7.2	Error Messages during the Loading Procedure	126
8	Abbreviations and Terms	127

1 Introduction

Application areas of the device

The SICOMP-IMC01 is a compact computer recommended for the following applications when RMOS is used.

- Process monitoring and operator control on the floor
- Control via digital and analog inputs and outputs




Figure 1.1 Front view of the IMC01 with display and operator control elements

1.1 Product Structure

1.1.1 Block Diagram of the Hardware Components (Basic Configuration)

The following block diagram shows a summary of the layout of the IMC01.




Figure 1.2 Block diagram of the hardware components (basic configuration)

1.1.2 Software Structure

The following figures show a summary of the software structure of the IMC01 and the developer's computer for Compact PLC and C or IMC0x-PLC programming.




Figure 1.3 Structure of the software components for Compact PLC on delivery




Figure 1.4 Structure of the software components for C or IMC0x-PLC programming

1.2 System Prerequisites and Accessories

Required Operational Accessories	Recommended by Siemens
Power supply with 24 V DC, at least 2 A continuous current	SITOP Power Standard ²⁾ basic E24/2 (2 A) 6EP1331-1SL11 basic E24/5 (5 A) 6EP1333-1SL11 basic E24/10 (10 A) 6EP1334-1SL11
Required Developmental Accessories For Compact PLC	
PG with STEP 5 software	STEP 5, version 6.65 or starting with version 7.12
Required Developmental Accessories for C/IMC0x-PLC programming	
IBM-AT-compatible computer with 3½" floppy disk drive Installed on this: - RMOS3 V3.20 ¹⁾ - Compiler: CADUL CC386, starting with V700 O - Linker: CADUL LINK386, starting with V207 - Assembler: CADUL AS386, starting with V300 I - Debugger: CADUL XDB386, starting with V401 A (not mandatory)	
Zero modem cable (shielded) for transmission from development computer to the IMC01	See chapter 3.6.3 or 4.7.3.
Other Accessories	Order No.
IMC0x-PLC (including English documentation) STEP 5 software	6AR1403-3AD00-2AA0

- 1) *Creating a system using this description requires a basic knowledge of RMOS. Training courses are offered by Siemens. Contact your local Siemens office for details.*
- 2) *See KT 10 catalog (combination technology).*

1.3 Required Commissioning Steps

Before commissioning the IMC01, perform the following steps.

1.3.1 STEP 5 Programming for Compact PLC

1. Connect the power supply and the PG to the IMC01.
2. Install the IMC01-BSP on the PG.
3. Create the program with the PG.
4. Set the type of measurement for the analog inputs.
5. Install in the front panel.
6. Connect the I/O devices.
7. Parameterize PROFIBUS.

These steps are described in detail in chapter 3.

Note:

After repairs, the device is returned in its original status on delivery (i.e., steps 3 to 7 must be repeated).

1.3.2 C or IMC0x-PLC Programming

1. Connect the power supply and the development computer to the IMC01.
2. Install the IMC01-BSP on the development computer.
3. Prepare program and generate system.
4. Load and test the RMOS system and the user program.
5. Set the type of measurement for the analog inputs.
6. Install in the front panel.
7. Connect the I/O devices.
8. Parameterize PROFIBUS.

These steps are described in detail in chapter 4.

Note:

After repairs, the device is returned in its original status on delivery (i.e., steps 4 to 8 must be repeated).

1.4 Scope of Delivery

Device

- IMC01 basic model or with expansion card
- 2 or 4 plug connectors, inserted with I/O card or expansion card
- Assembly kit
 - 6 M4 nuts with washers and spring rings for mounting the device
 - 1 M5 nut with washer, spring ring and contact disk for connection of ground

Documentation

- Technical Description
- Product floppy disk IMC01-BSP
- Software product slip
- Customer Support Service Fax (Software Registration Fax)
- IMC0x-PLC reference manual

2 Device Description

2.1 Features

The IMC01 consists of the following components.

- LC display, 16 x 4 characters
- Sealed keyboard with 24 keys, 8 of which are equipped with an LED
- Front plate with sealing frame for protection class IP65
- Metal housing with ventilation openings
- Computer unit with 80386EX processor
- FLASH memories with BIOS and user memory, can be programmed on-board
- SRAM work memory
- Serial interfaces for loading an RMOS system from the development computer and for use as desired
- Number of digital and analog inputs/outputs depends on the model.
- DP slave bus connection
- Extensive BIOS functions for input/output operations via keyboard, display, digital and analog inputs/outputs, and much more

These components will now be described in detail.

2.1.1 Physical Components

- Front plate** The IMC01 is designed for installation in switching cabinets or consoles. Sealing on all sides provides a protection rating of IP65 on the front.
The accessories required for installation are included with the device.
- LC display** The alphanumeric LC display has LED backlighting and can represent four lines with 16 characters each.
- Sealed keyboard** Each key activation (i.e., pressing or releasing) triggers a call-back function.
Two labeling strips can be inserted in openings on the bottom of the device to label keys S0 to S9 (e.g., the tens block).
- Metal housing** The housing of the IMC01 is made of refined stainless steel.
Ventilation openings on the top and bottom permit operation without a fan within a certain specified temperature range. See chapter 2.3.3.
All connection elements can be accessed on the bottom of the device.

2.1.2 Power Supply

The device is powered by a single 24 Volt direct current power supply. All required voltages (e.g., 5 V for the processor) are generated internally from this voltage.

2.1.3 Processor and Memory Configuration

Processor	80386EX from INTEL, clock frequency currently 24.576 MHz, integrated controller functions
Watchdog	Can be enabled and disabled via software. Hardware reset after approx. 250 msec when the trigger command is not issued.
Working memory	1-Mbyte SRAM (2 x 512 Kbytes) Saved data are protected against power failure by gold capacitor and extra backup battery.
Program memory	2-Mbyte FLASH memory divided into 128-Kbyte sectors The first sector contains the boot loading program and is not available to the user. All other sectors can be cleared on-board and rewritten.

Address (Hex)	Configuration	Use
03FF FFFF	Flash memory	Boot loader program
03FE 0000		User program
03FD FFFF		
03E0 0000		
000F FFFF	RAM	Working storage and reloadable tasks
0000 0000		

Figure 2.1 Organization of memory

2.1.4 Interfaces

The IMC01 is equipped with the following interfaces. IMC01-BSP contains BIOS functions for processing the interfaces. See chapter 6.

Basic model

Digital inputs and outputs	12 digital inputs (24 V, non-floating)
	2 digital outputs (24 V, P-switching, non-floating)
	6 relay outputs, floating
Analog inputs/outputs	2 analog inputs (can be set individually with plug-in jumpers for measuring voltage or temperature)
	2 analog inputs (can be set individually with plug-in jumpers for measuring voltage or temperature (PT100))
Serial interfaces	1 RS 232 (COM1), maximum of 38,400 baud
	1 RS 485 (COM2), semi-duplex, maximum of 38,400 baud
PROFIBUS-DP interface	PROFIBUS interface with SPC3 ASIC, DP slave function, maximum of 1.5 Mbaud, floating

Interfaces on the expansion card

The optional expansion card provides the following additional interfaces.

Digital inputs and outputs	12 digital inputs (24 V, non-floating)
	2 digital outputs (24 V, P-switching, non-floating)
	6 relay outputs, floating
Analog inputs/outputs	2 analog inputs, can be set individually with plug-in jumpers for measuring voltage or temperature
	2 analog inputs, can be set individually with plug-in jumpers for measuring voltage or temperature (PT100)
	1 analog output (floating)

2.2 Interface Signals

2.2.1 Serial Interfaces

Serial interface COM1 (RS 232): 1X7

9-pin
sub D plug
connector




Table 2.1 Allocation of the COM1 serial interface (RS 232)

Connection	Signal	Meaning
1	–	
2	RxD	Receiving data
3	TxD	Sending data
4	Reserved	Used internally. Do not connect.
5	GND	Signal ground
6	–	
7	RTS	Request to send
8	CTS	Ready to send
9	–	

– = Not used

COM2 (RS 485) serial interface: 1X8

9-pin
sub D socket




Table 2.2 Allocation of the COM2 (RS 485) serial interface

Connection	Signal	Meaning
1	RA	Terminating resistors for signal line A
2	RS485_B	Signal line B of the RS 485 differential signal
3	RS485_B	Signal line B of the RS 485 differential signal
4	Reserved	Used internally. Do not connect.
5	RTS	Request to send (TTL signal)
6	GND	Signal ground
7	RB	Terminating resistors for signal line B
8	RS485_A	Signal line A of the RS 485 differential signal
9	RS485_A	Signal line A of the RS 485 differential signal

– = Not used

Note:

The terminating resistors can be activated by connecting pin 1 with pin 8/9 or pin 7 with pin 2/3.


PROFIBUS-DP interface: 1X9**9-pin
sub D socket**

Table 2.3 Allocation of the PROFIBUS-DP interface

Connection	Signal	Meaning
1	–	
2	–	
3	RS485_B	Signal line B of the RS 485 differential signal
4	RTS	Request to send (TTL signal)
5	GND1	Signal ground ¹⁾
6	VCC1	+5 V voltage supply ¹⁾
7	–	
8	RS485_A	Signal line A of the RS 485 differential signal
9	–	

– = Not used


1) Only for bus terminating resistors

2.2.2 Interfaces of the I/O Card

Digital and analog inputs: 1X1

25-pin sub D socket

Table 2.4 Allocation of 1X1



Connection	Signal	Meaning
1	I0.0	Digital input 1
2	I0.1	Digital input 2
3	I0.2	Digital input 3
4	I0.3	Digital input 4
5	I0.4	Digital input 5
6	I0.5	Digital input 6
7	M24	Reference potential for digital inputs
8	AGND1	Analog ground of the inputs
9	AGND1	Analog ground of the inputs
10	AGND1	Analog ground of the inputs
11	AGND1	Analog ground of the inputs
12	AGND1	Analog ground of the inputs
13	-	
14	I0.6	Digital input 7
15	I0.7	Digital input 8
16	I1.0	Digital input 9
17	I1.1	Digital input 10
18	I1.2	Digital input 11
19	I1.3	Digital input 12
20	P18	Sensor voltage, 18 V
21	AI 1	Analog input 1
22	AI 2	Analog input 2
23	AI 3	Analog input 3
24	AI 4	Analog input 4
25	-	

- = Not used

Relay outputs: 1X2

12-pin Combicon plug connector

Table 2.5 Allocation of 1X2

Connection	Signal	Meaning
1	O0.0	Make-contact, digital output 1
2	O0.0	Make-contact, digital output 1
3	O0.1	Make-contact, digital output 2
4	O0.1	Make-contact, digital output 2
5	O0.2	Make-contact, digital output 3
6	O0.2	Make-contact, digital output 3
7	O0.3	Make-contact, digital output 4
8	O0.3	Make-contact, digital output 4
9	O0.4	Make-contact, digital output 5
10	O0.4	Make-contact, digital output 5
11	O0.5	Make-contact, digital output 6
12	O0.5	Make-contact, digital output 6

Power supply and digital outputs: 1X3

4-pin Combicon plug connector


Table 2.6 Allocation of 1X3

Connection	Signal	Meaning
1	P24	Supply voltage
2	O0.6	Digital output 7
3	O0.7	Digital output 8
4	M24	Reference potential

2.2.3 Interfaces of the Expansion Card

Digital inputs, analog inputs and outputs: 1X4

25-pin sub D socket Table 2.7 Allocation of 1X4



Connection	Signal	Meaning
1	I2.0	Digital input 13
2	I2.1	Digital input 14
3	I2.2	Digital input 15
4	I2.3	Digital input 16
5	I2.4	Digital input 17
6	I2.5	Digital input 18
7	M24	Reference potential for digital inputs
8	AGND1	Analog ground of the inputs
9	AGND1	Analog ground of the inputs
10	AGND1	Analog ground of the inputs
11	AGND1	Analog ground of the inputs
12	AGND1	Analog ground of the inputs
13	AO1	Analog output 1
14	I2.6	Digital input 19
15	I2.7	Digital input 20
16	I3.0	Digital input 21
17	I3.1	Digital input 22
18	I3.2	Digital input 23
19	I3.3	Digital input 24
20	P18	Sensor voltage, 18 V
21	AI 1	Analog input 5
22	AI 2	Analog input 6
23	AI 3	Analog input 7
24	AI 4	Analog input 8
25	AGND2	Analog ground of the outputs

Relay outputs: 1X5**12-pin Combicon
plug connector**

Table 2.8 Allocation of 1X5

Connection	Signal	Meaning
1	O1.0	Make-contact, digital output 9
2	O1.0	Make-contact, digital output 9
3	O1.1	Make-contact, digital output 10
4	O1.1	Make-contact, digital output 10
5	O1.2	Make-contact, digital output 11
6	O1.2	Make-contact, digital output 11
7	O1.3	Make-contact, digital output 12
8	O1.3	Make-contact, digital output 12
9	O1.4	Make-contact, digital output 13
10	O1.4	Make-contact, digital output 13
11	O1.5	Make-contact, digital output 14
12	O1.5	Make-contact, digital output 14

Power supply and digital outputs: 1X6**4-pin Combicon
plug connector**

Table 2.9 Allocation of 1X6

Connection	Signal	Meaning
1	P24	Supply voltage
2	O1.6	Digital output 15
3	O1.7	Digital output 16
4	M24	Reference potential

2.3 Technical Data

2.3.1 Operational Values

Power Supply	Typical	Permissible/Maximum
Supply voltage (P24)	24 V DC	20.4 to 28.8 V
Supply voltage fluctuation	18.5 to 30.2 V	In acc. w. DIN 19240
Current consumption (with outputs) Without expansion card With expansion card	1.3 A 2.4 A	
Current consumption (without outputs) Without expansion card With expansion card	0.3 A 0.4 A	
External fuses (must be provided by you)		Rapid-action, max. of 2.5 A per feeder line
Voltage drop at 24 V / 0.9 A (without external buffering)		1 msec ¹⁾
Data retention with uninterrupted buffering	3 years	

1) When this time is exceeded, an NMI is triggered followed by a RESET 0.5 msec later.

Digital Inputs and Outputs	Typical	Permissible/Maximum
Input voltage H signal L signal	24 V 0 V	15 to 30 V -3 to +5 V
Input current H signal L signal	1.5 mA 0 mA	15 mA 15 mA
Filter time constant	1 msec	
Output voltage H L	Depends on load (open output)	Min. of P24 – 3 V
Output current H L		0.5 A 0.4 mA

Relay Outputs	Typical	Permissible/Maximum
Type of contact	Make-contact	
Switching voltage		250 V AC
Switching current		8 A
Switching capacity DC AC		270 W 2000 W
Contact resistance (initial value)	≤ 100 mΩ at 24 V/1 A	
Test voltage, contact/winding		4000 V AC
Switching frequency		0.1 Hz
Life span at max. switching capacity	10 ⁵ switching cycles	2 x 10 ⁷ switching cycles
Fuses	Must be provided by you	
Protection against capacitive or inductive loads	Must be provided by you	

Analog Inputs	Typical	Permissible/Maximum
Voltage measuring ranges	0 to 5 V, 0 to 10 V, ± 5 V, ± 10 V	
Current measuring range	0 to 20 mA	
Temperature measuring range	-200° C to +230° C (PT100)	
Impedance during voltage measurement		Min. of 5 k Ω
Load during current measurement	200 Ω	
Resolution	12 bits	Min. of 10 bits
Conversion time	200 μ sec	
Channel switchover		
During temperature measurement	3 msec	
Other	200 μ sec	

Analog Output (on Expansion Card)	Typical	Permissible/Maximum
Output range	0 to 20 mA	
Load		300 Ω
Resolution	10 bits	
Conversion time	2.5 msec	
Potential isolation	Only functional isolation due to EMC No safety-relevant isolation	

2.3.2 Physical Values

Dimensions and Weight	Typical	Permissible/Maximum
Front plate without seal (width x height x thickness)	200 x 133 x 6 mm	
Mounting depth with front plate	118 mm	120 mm
Weight		
Basic model	1.35 kg	1.50 kg
With expansion card	1.50 kg	1.65 kg

2.3.3 Environmental Requirements

	Operation	Transportation and Storage
Ambient temperature	-20° to 60° C ¹⁾	-40° to 70° C
Relative humidity at 25° C	5 to 80%	5 to 95%
Permissible operating altitude	2500 m above sea level	No restrictions
Permissible temperature changes	10° C/30 min. (without condensation) or 0.5° C/min.	
Vibration In acc. w. IEC 68-2-6, 10 cycles on 3 axes	10 Hz to 58 Hz: 0.075 mm amplitude 58 Hz to 500 Hz: 1 g	5 Hz to 9 Hz: 3.5 mm amplitude 9 Hz to 500 Hz: 1 g
Shock	IEC 68-2-29 Test E/A 3 times per axis 2 directions per axis Total of 18 shocks 15 g/11 msec	

1) These specifications are valid for free convection and vertical mounting position.

3 Commissioning with STEP 5 Programming for Compact PLC

To commission the IMC01, proceed exactly as described below.



Caution:

Commissioning, installation and wiring may only be performed by qualified personnel who are familiar with and observe the general rules of technology and the applicable regulations and standards.

Before connecting the I/O devices and starting your user application, make sure that persons or systems will not be endangered by execution of the program.

1. Connect the power supply and the PG to the IMC01.
2. Install the IMC01-BSP on the PG.
3. Create the program with the PG.
4. Set the type of measurement for the analog inputs.
5. Install in the front panel.
6. Connect the I/O devices.
7. Parameterize PROFIBUS.

3.1 Connecting the Power Supply and the PG to the IMC01

The device is powered by the 4-pin pin strips on the I/O card (1X3, see chapter 2.2.2) and, if present, on the expansion card (1X6, see chapter 2.2.3).



Caution:

Suitable fuses (see chapter 2.3.1) must be installed in the feeder lines of the supply voltage, and, if necessary, an on/off switch.

Before turning on the supply voltage, make sure that all other connections are wired correctly.

Do not plug or unplug connection cables while the power is on. To do so may damage the device.

The PG is connected to the IMC01 with a zero modem cable on COM1. See chapter 3.6.3.

Note:

Remember that COM1 of the IMC01 is an RS 232 interface and not a 20 mA interface.

3.2 Installing the IMC01-BSP on the PG

If you are using only the Compact PLC, the IMC01-BSP can be installed without first installing RMOS V3.20. Cf. chapter 4.2.

Installation

1. Turn on the PG, and start MS-DOS.
2. Place the product floppy disk in the floppy disk drive.
3. Set up a new directory (e.g., C:\IMC01).
4. Copy the PRODUCT.EXE file to the new directory.
5. Unpack the files with the command:

```
product -d
```

3.3 Creating the Program with the PG

The STEP 5 software developed with the PG is stored on the buffered RAM where it is retained even after the device is turned off.

Before the user program can be stored in flash memory, it must be converted to binary format with the CVSTEPV.EXE program. Use the GEN_BIN.BAT batch file in directory SYSIMC1\COMPACT.PLC\STEP5 for this.

The user program can now be transferred to flash memory.

To do this, perform the following steps.

1. Switch the IMC01 off.
2. Start the LD_MC5.BAT batch file in directory SYSIMC1\COMPACT.PLC\LOADER.
3. Turn on the IMC01 again.

Use the LD_SYS.BAT batch file in directory SYSIMC1\COMPACT.PLC\LOADER to restore the status on delivery again.

3.4 Setting the Type of Measurement for the Analog Inputs

Plug-in jumpers are available on the I/O card and, if present, on the expansion card to set the type of measurement for the analog inputs. These jumpers are accessible from the top on the opened device. The figure below shows a view of the top of the opened device with the plug-in jumpers as preset at the factory.




Figure 3.1 Location and pre-sets of the plug-in jumpers (view of the top)

Table 3.1 Settings on the I/O card

Jumper Position	Default Setting	
Analog input 1	Current measurement (pins 9-10)	Voltage measurement (pins 1-2)
Analog input 2	Current measurement (pins 11-12)	Voltage measurement (pins 3-4)
Analog input 3	Temperature measurement (pins 13-14)	Voltage measurement (pins 5-6)
Analog input 4	Temperature measurement (pins 15-16)	Voltage measurement (pins 7-8)

Table 3.2 Settings on the expansion card

Jumper Position	Default Setting	
Analog input 5	Current measurement (pins 9-10)	Voltage measurement (pins 1-2)
Analog input 6	Current measurement (pins 11-12)	Voltage measurement (pins 3-4)
Analog input 7	Temperature measurement (pins 13-14)	Voltage measurement (pins 5-6)
Analog input 8	Temperature measurement (pins 15-16)	Voltage measurement (pins 7-8)

3.5 Installation in a Front Panel

The device is installed from the front in the front panel of switching cabinets or consoles and secured on the back with 6 nuts. A mounting cutout and 6 bored holes for the mounting bolts must be provided for the front panel.




Figure 3.2 Mounting cutout and bored holes

The front panel may not exceed 8 mm in thickness. The mounting depth of the device is 112 mm. Remember to leave sufficient space under the device for the connection plugs. For the size of the front plate, see chapter 2.3.2.

Note:

To prevent the device from overheating during operation, adhere to the following points.

- Do not expose the front plate to direct sunlight.
- Make sure that the ventilation openings in the device housing are not obstructed after installation.
- The standard installation position is vertical with the plug connectors pointing down.

Note:

The following conditions must be met to achieve a protection rating of IP65.

- Levelness of the front plate: Maximum of 0.5 mm
- Correct positioning of the sealing around the front plate
- Typical moment of torsion of the nuts: 1.5 Nm

3.6 Connecting the I/O Devices

The following figure shows the bottom of the IMC01 with the connection elements.




Figure 3.3 Bottom of the device with connection elements

3.6.1 Installation Guidelines

- The housing must be connected to the protective conductor with the threaded bolts on the back of the device.
- If you want to use the relay outputs with both SELV (Safety Extra Low Voltage) and higher voltages (e.g., alternating current power networks), one relay each must be left uncircuited between the SELV outputs and the power network outputs to ensure secure isolation of the SELV current circuit from the power network voltage.
- Do not plug or unplug connection cables while the power is on. To do so may damage the device.
- Do not plug or unplug the counter plugs while the power is on when voltages of ≥ 48 V DC are being used.
- When connecting the cables, ensure that any disconnected connections do not cause parasitic voltages (e.g., between 230 V outputs and the other connections of the controller).
- Unconnected power lines can destroy the device (e.g., feed-in on the digital outputs but no voltage supply on the device).
- With the electronic outputs, no countervoltage (i.e., external power source due to wire jumper or similar) may be applied to the plug connector.
- Protection against pole reversal of the supply voltages only exists in connection with an external fuse.
- A short circuit of the voltage supply pins of the PROFIBUS interface which lasts longer than one second may destroy the interface.
- There is a stud bolt on the back for connection of the shield. Ensure good conductivity (HF) when connecting the shield to cabinet ground.
- The galvanic connection of cabinet ground and M24 of the 24 V voltage supplies is made at the central grounding point outside the device.
- To the extent possible, all cables must be shielded.

- All ground potentials which enter and exit the device are galvanically connected with each other internally.
- All 24 V voltage lines entering the device are connected to the shield potential with capacitors (22 nF/500 V).

3.6.2 Grounding Concept

The figure below shows how the ground potentials of the board are connected to each other.





Figure 3.4 Grounding potentials of the board

Designation	Reference Potential for
AGND1	Analog Inputs
GND	Serial interfaces
M24	24 V voltage supply, digital inputs/outputs
GND1	PROFIBUS
AGND2	Analog output

The signal ground potentials are galvanically connected with each other. They are high-ohmic and capacitively coupled with the housing ground.

3.6.3 Connection Cable from PG to IMC01 (Zero Modem Cable)

Serial interfaces Connection from PG to IMC01



The connections indicated by broken lines are not absolutely necessary but do not interfere with data communication either.

3.7 Parameterizing PROFIBUS

The IMC01 has already been parameterized. Only the bus address still has to be set. See chapter 5.2.3.

Parameter files are available in directory DPS/GSD to enter the IMC01 in the master configuration (COM PROFIBUS).

Transfer these files to the appropriate directories of COM PROFIBUS.

4 Commissioning with C or IMC0x-PLC Programming

To commission the IMC01, proceed exactly as described below.

**Caution:**

Commissioning, installation and wiring may only be performed by qualified personnel who are familiar with and observe the general rules of technology and the applicable regulations and standards.

Before connecting the I/O devices and starting your user application, make sure that persons or systems will not be endangered by execution of the program.

1. Connect the power supply and the development computer to the IMC01.
2. Install the IMC01-BSP on the development computer.
3. Prepare program and generate system.
4. Load and test the RMOS system and the user program.
5. Set the type of measurement for the analog inputs.
6. Install in the front panel.
7. Connect the I/O devices.
8. Parameterize PROFIBUS.

4.1 Connecting the Power Supply and the Development Computer to the IMC01

The device is powered by the 4-pin pin strips on the I/O card (1X3, see chapter 2.2.2) and, if present, on the expansion card (1X6, see chapter 2.2.3).

**Caution:**

Suitable fuses (see chapter 2.3.1) must be installed in the feeder lines of the supply voltage, and, if necessary, an on/off switch.

Before turning on the supply voltage, make sure that all other connections are wired correctly.

Do not plug or unplug connection cables while the power is on. To do so may damage the device.

The development computer is connected to the IMC01 with a zero modem cable. See chapter 4.7.3.

4.2 Installing the IMC01-BSP on the Development Computer

Prerequisites

RMOS3 V3.20 must be installed on the development computer before you can begin installing the included software.

Installation

1. Turn on the development computer, and start MS-DOS.
2. Change to the RMOS master directory. For example:

```
cd \RM3DEV
```

3. Place the product floppy disk in the floppy disk drive.
4. Start the installation program:

```
a:install
```

For the directories and files which are set up, see the **READIMC1.1P0** file on the product floppy disk. If you change the directory structure, you will also have to adjust the entries in the batch files.

4.3 Preparing the Program and Generating the System

The procedure for program preparation and system generation depends on whether you start your user task with the RMOS system, or you want to load it during running operation.

Subdirectories APLSTART, APLBIOS and APLLOAD contain sample applications to illustrate the preliminary steps used in preparing the program.

Before calling GENSYSC.BAT, the paths of the development tools must be set (e.g., via search path or configuration variables).

How to proceed for system generation

Step	Files Required	Files Generated
Compile the IMC01-specific RMOS source files if you made changes to them.	GENBIOS.BAT and *.C in SYSIMC1\BIOS	*.OBJ
Edit the program sources	*.C in SYSIMC1\APLSTART or SYSIMC1\APLBIOS	
Compile ¹⁾	*.C in SYSIMC1\APLSTART or SYSIMC1\APLBIOS, IMC01BAS.H in SYSIMC1\BIOS	*.OBJ
Link and locate ¹⁾	SYSIMC1\APLSTART, SYSIMC1\APLBIOS or SYSIMC1\APLLOAD IMC01BAS.LIB in SYSIMC1\BIOS	RM3_PC1.LOC RM3_PC1.MAP RM3NUC.GAT
Generate the system file ¹⁾	QCOFTS	RM3_PC1.SYS

1) *Compiling, linking and locating, and generating the system file are performed with GENSYS.C.BAT.*

Transferring the system file is described in chapter 4.4.

How to proceed for loadable tasks

Step	Files Required	Files Generated
Generate a suitable system for loadable tasks with coprocessor emulation enabled (e.g., SYSIMC5\APLLOAD).	GENSYSC.BAT in SYSIMC1\APLLOAD	RM3_PC1.SYS
Edit the user task	*.C in EXPIMC1\APLSTART	
Compile the user task ¹⁾	*.C in EXPIMC1\APLSTART IMC01BAS.H in SYSIMC1\BIOS	*.OBJ
Link the user task ¹⁾	BIOSAPI.OBJ in SYSIMC1\BIOS	APLSTART.386

1) *Compiling and linking are performed with APLSTART.BAT.*

If you are going to use the system file and the user task from this example without changes, the same effect is produced on the IMC01 as with the example from SYSIMC1\APLSTART.

Transferring the system file and loading user tasks are described in chapter 4.4.

Note:
RMOS 3.20 always requires a coprocessor or a coprocessor emulation for the execution of tasks which were loaded with LOADRM.EXE or the Cadul HLL Debugger XDB. Since the IMC01 does not have a coprocessor, it is essential to include the coprocessor emulation here. This has already been done in our APLLOAD example.

4.3.1 Using the Sample Applications

APLSTART	Simple beginner's example with text outputs on the display
APLLOAD	Generation of an RMOS system to which tasks can be loaded via the HLL Debugger or LOADRM.EXE. Since there are no outputs to the I/O devices in the first task in this example, the user task is not interrupted.
APLBIOS	Extensive example containing executable sample programs as individual tasks in addition to the BIOS functions. You can use the TEST.H header file to control which tasks you want to start.

Task	Meaning	File Name (.C or .OBJ)
UTSK_AO	Processing of the analog outputs	UTSKAO
UTSK_AI	Processing of the analog inputs	UTSKAI
UTSK_DO	Processing of the digital outputs	UTSKDO
UTSK_DI	Processing of the digital inputs	UTSKDI
UTSK_KEYB	Processing of the keyboard (call interface)	UTSKKEYB
UTSK_Dummy	Dummy task, no function	UTSKDUMM

Using the sample task APLBIOS on the IMC01

When keyboard processing is active, you can perform the following actions.

Key	Effect
F1	Indicates analog inputs 0 to 3
F2	Indicates analog inputs 8 to 11
F3	Indicates the digital inputs
RESET	Triggers a system reset after expiration of the watchdog

4.3.2 Using the Coprocessor Emulation

To be able to use the numeric coprocessor emulation, the following entries must be made before system generation.

1. Remove the commentary characters from the following line in the RMCONF.C file.
#define FPU_EMULATOR
2. In the CCAPL.INP file, add the -VNDP option to all compiler calls. This option has already been set when the IMC01 is delivered. The CCAPL.INP file contains the compiler options and is called from the CCAPL.BAT file. This makes it easy to compile a single file.

Note:

Use of the coprocessor emulation is described in the READIMC1.1P0 file.

4.4 Loading and Testing the RMOS System and the User Program

The steps required to load the RMOS system and your user program to the IMC01 and test them there are described below.

Preparations

Copy the RM3_PC1.SYS system file to subdirectory UTILIMC1. One of the examples included in subdirectory SYSIMC1 can also be used.

Loading and starting

1. Establish connection.
2. Clear entire user FLASH memory if necessary.
3. Transfer RMOS system and user program.
4. Start the system.
5. Load user tasks if necessary.

These steps are explained in chapters 4.4.2 to 4.4.6.

Note:

The first four steps are executed by the FLASH.BAT batch file and documented there. The COM1 interface of the development computer is used. If you want to use another interface, you will have to change the appropriate settings in this file.

4.4.1 Behavior during Booting/Reset

After the power is turned on or after a hardware reset (e.g., triggered by the watchdog), the processor begins executing the boot program.

First, it initializes its internal registers and then checks to determine whether a serial connection to the development computer exists and software must be loaded. See chapter 4.4.2. If not, the RMOS operating system is started and execution of the user program begins.

Note:

It is the responsibility of the user to ensure that executable program code is located at the start address of the user program. See chapter 2.1.3.

4.4.2 Establishing the Connection

Proceed as follows to establish the connection between the IMC01 and the development computer.

1. Plug a zero modem cable into COM1 of the IMC01 and a free serial interface on your development computer.

2. Enter the following command after the MS-DOS prompt. Be sure to use the correct upper and lower case letters.

```
synchro COMx 19200
```

(COMx is the COM1 or COM2 computer interface used.)

3. Turn on the power supply of the IMC01.

The FLASH load program is started on the IMC01. The development computer indicates whether the connection was established successfully.

The IMC01 start screen shows the following information.

- "Flashloader"
The screen remains until the next reset. The display of the IMC01 also shows the function currently being executed by the loader.
- "starting System..."
After approx. two seconds the RMOS application is started. The monitor is cleared. If the screen remains, no valid system is loaded.

4.4.3 Deleting Software from the IMC01

New software can only be loaded correctly in the user FLASH memory of the IMC01 when the required sectors have been deleted before the transfer.

Proceed as follows to delete the entire user FLASH memory or individual sectors from it.

1. Make sure that the connection between the IMC01 and the development computer is established. See chapters 4.4.1 and 4.4.2.

2. Enter the following command after the MS-DOS prompt.

```
send COMx 19200 Configuration-file
```

Configuration-file is the complete file name (including path) of an ASCII file (e.g., DELFW.CFG) with the following contents.

Line No.	Contents (Hex) ¹⁾	Meaning
1	7	Number of valid entries in the file
2	0	Reserved
3	14	"Delete FLASH memory" command
4	0	Delete entire user FLASH memory or sector with the specified number (1 to n_{max} ²⁾)
5	0	Reserved
6	0	Reserved
7	9600	Baud rate for commands which follow (hexadecimal, 38,400 = 0x9600)
From 8	Any	Examples: Commentary or remarks

1) All numerical values are hexadecimal numbers.

2) $n_{max} = (\text{Size of the user FLASH memory (in kbytes)} / 128) - 1$

4.4.4 Loading an RMOS System or a User Program

Proceed as follows to load a new RMOS system or a user program to the IMC01.

1. Make sure that the connection between the IMC01 and the development computer is established and the clear command was executed. See chapters 4.4.1 and 4.4.2.
2. Enter the following command after the MS-DOS prompt.

```
send COMx 38400 Configuration-file, , Binary-file
```

Configuration-file is the complete file name (including path) of an ASCII file (e.g., LOADFW.CFG) with the following contents.

Line No.	Contents (Hex) ¹⁾	Meaning
1	7	Number of valid entries in the file
2	0	Reserved
3	16	"Load FLASH memory" command
4	0	Reserved
5	0	Transfer entire binary file or the number (hexadecimal) of bytes to be transferred from the binary file
6	0	Byte offset for the start address of the user FLASH memory (hexadecimal)
7	0	Baud rate for commands which follow unchanged or new baud rate (hexadecimal)
From 8	Any	Examples: Commentary or remarks

1) All numerical values are hexadecimal numbers.

Binary file is the complete file name (including path) of the RMOS system file or user program file to be loaded (e.g., RM3_PC1.SYS).

Note:

This procedure cannot be used to reload a user task. See chapter 4.4.6.

4.4.5 Starting the System or User Program

To terminate the connection between the IMC01 and the development computer and to start the RMOS system with your user task, enter the following command after the MS-DOS prompt.

```
send COMx 19200 Configuration-file
```

Configuration-file is the complete file name (including path) of an ASCII file (e.g., STARTFW.CFG) with the following contents.

Line No.	Contents (Hex) ¹⁾	Meaning
1	7	Number of valid entries in the file
2	0	Reserved
3	17	"Start application" command
4	0	Reserved
5	0	Reserved
6	0	Reserved
7	0	Reserved
From 8	Any	Examples: Commentary or remarks

1) All numerical values are hexadecimal numbers.

This concludes data transfer to the IMC01, deletes the contents of the SRAM, and restarts the device with a hardware reset triggered by the watchdog. Since the program for connection establishment on the development computer is not active, the IMC01 boots with the RMOS system and starts the user program.

Note:

The parameters of the COM1 interface are set to the following values.
 Baud rate of 19200 (default setting after startup)
 No parity bit
 8 data bits
 1 stop bit

4.4.6 Testing and Loading User Programs with the Debugger

To test a user program, you can use the low-level Debugger included with RMOS or the XDB from Organon. Proceed as described in the applicable manuals. You must use the COM1 serial interface on the IMC01.

Note:

Since the RMOS system file is loaded in the FLASH memory, you can only use hardware breaks here. The XDB.INI file under subdirectory SYSIMC1\APLSTART already contains an appropriate setting. Copy this file to the directory of XDB.

Reloadable tasks are loaded in work memory (SRAM), and software breaks can be used.

During the testing phase, you should work with reloadable tasks so that the entire system does not have to be transferred again when errors occur. The example from subdirectory APLLOAD can be used as the system file, and added step-by-step to your already tested user modules.

When generating a reloadable task, the included BIOSAPI.OBJ file must be linked. The APLSTART.BAT batch file in subdirectory EXPIMC1\APLSTART\CADUL contains an example of this.

Note:

As with every RMOS system, the RMRS232C device driver must be linked in before tasks can be reloaded with LOADRM.EXE. Use the following entry in the CONFIG.SYS file.

```
Device=<RMOS path>\UTIL\ RMRS232C.EXE SSDEV {COM1|COM2} 19200
```

4.5 Setting the Type of Measurement for the Analog Inputs

Plug-in jumpers are available on the I/O card and, if present, on the expansion card to set the type of measurement for the analog inputs. These jumpers are accessible from the top on the opened device. The figure below shows a view of the top of the opened device with the plug-in jumpers as preset at the factory.




Figure 4.1 Location and presettings of the plug-in jumpers (view of the top)

Table 4.1 Settings on the I/O card

Jumper Position	Default Setting	
Analog input 1	Current measurement (pins 9-10)	Voltage measurement (pins 1-2)
Analog input 2	Current measurement (pins 11-12)	Voltage measurement (pins 3-4)
Analog input 3	Temperature measurement (pins 13-14)	Voltage measurement (pins 5-6)
Analog input 4	Temperature measurement (pins 15-16)	Voltage measurement (pins 7-8)

Table 4.2 Settings on the expansion card

Jumper Position	Default Setting	
Analog input 5	Current measurement (pins 9-10)	Voltage measurement (pins 1-2)
Analog input 6	Current measurement (pins 11-12)	Voltage measurement (pins 3-4)
Analog input 7	Temperature measurement (pins 13-14)	Voltage measurement (pins 5-6)
Analog input 8	Temperature measurement (pins 15-16)	Voltage measurement (pins 7-8)

4.6 Installation in a Front Panel

The device is installed from the front in the front panel of switching cabinets or consoles and secured on the back with 6 nuts. A mounting cutout and 6 bored holes for the mounting bolts must be provided for the front panel.




Figure 4.2 Mounting cutout and bored holes

The front panel may not exceed 8 mm in thickness. The mounting depth of the device is 112 mm. Remember to leave sufficient space under the device for the connection plugs. For the size of the front plate, see chapter 2.3.2.

Note:

To prevent the device from overheating during operation, adhere to the following points.

- Do not expose the front plate to direct sunlight.
- Make sure that the ventilation openings in the device housing are not obstructed after installation.
- The standard installation position is vertical with the plug connectors pointing down.

Note:

The following conditions must be met to achieve a protection rating of IP65.

- Levelness of the front plate: Maximum of 0.5 mm
- Correct positioning of the sealing around the front plate
- Typical moment of torsion of the nuts: 1.5 Nm

4.7 Connecting the I/O Devices

The following figure shows the bottom of the IMC01 with the connection elements.




Figure 4.3 Bottom of the device with connection elements

4.7.1 Installation Guidelines

- The housing must be connected to the protective conductor with the threaded bolts on the back of the device.
- If you want to use the relay outputs with both SELV (Safety Extra Low Voltage) and higher voltages (e.g., alternating current power networks), one relay each must be left uncircuited between the SELV outputs and the power network outputs to ensure secure isolation of the SELV current circuit from the power network.
- Do not plug or unplug connection cables while the power is on. To do so may damage the device.
- Do not plug or unplug the counter plugs while the power is on when voltages of ≥ 48 V DC are being used.
- When connecting the cables, ensure that any disconnected connections do not cause parasitic voltages (e.g., between 230 V outputs and the other connections of the controller).
- Unconnected power lines can destroy the device (e.g., feed-in on the digital outputs but no voltage supply on the device).
- With the electronic outputs, no countervoltage (i.e., external power source due to wire jumper or similar) may be applied to the plug connector.
- Protection against pole reversal of the supply voltages only exists in connection with an external fuse.
- A short circuit of the voltage supply pins of the PROFIBUS interface which lasts longer than one second may destroy the interface.
- There is a stud bolt on the back for connection of the shield. Ensure good conductivity (HF) when connecting the shield to cabinet ground.
- The galvanic connection between cabinet ground and M24 of the 24 V voltage supplies is made at the central grounding point outside the device.
- To the extent possible, all cables must be shielded.

- All ground potentials which enter and exit the device are galvanically connected with each other internally.
- All 24 V voltage lines entering the device are connected to the shield potential with capacitors (22 nF/500 V).

4.7.2 Grounding Concept

The figure below shows how the ground potentials of the board are connected to each other.





Figure 4.4 Grounding potentials of the board

Designation	Reference Potential for
AGND1	Analog inputs
GND	Serial interfaces
M24	24 V voltage supply, digital inputs/outputs
GND1	PROFIBUS
AGND2	Analog output

The signal ground potentials are galvanically connected with each other. They are high-ohmic and capacitively coupled with the housing ground.

4.7.3 Connection Cable from PC to IMC01 (Zero Modem Cable)

Serial interfaces Connection from PC to IMC01



The connections indicated by broken lines are not absolutely necessary but do not interfere with data communication either.

4.8 Parameterizing PROFIBUS

The IMC01 has already been parameterized. Only the bus address still has to be set. See chapter 6.12.4.

Parameter files are available in directory DPS/GSD to enter the IMC01 in the master configuration (COM PROFIBUS).

Transfer these files to the appropriate directories of COM PROFIBUS.

5 Compact PLC

The Compact PLC has already been loaded in the device and can be used immediately after power-on. The Compact PLC is a preconfigured RMOS system with the following components.

- RMOS3.20
- IMC01 PLC
- DP slave coupling (32 bytes of digital inputs, 32 bytes of digital outputs)
- I/O interface in STEP 5 data blocks

A data block interface can be used to manipulate the following peripherals from the STEP 5 program.

- 24 digital inputs, 16 digital outputs
- 8 analog inputs (current, voltage and PT100 temperature)
- 1 analog output
- DP slave
- Keys and LEDs of the operator panel
- LCD display
- Hardware clock

HLL function blocks are used to couple the STEP 5 and RMOS worlds. If used, these blocks must be added to OB1 for the applicable interface functionality.

- | | | |
|--------------|--------|---------------------------------|
| • HLL FB 208 | FB_DIS | Character output on the display |
| • HLL FB 210 | FB_IN | Read in the peripherals |
| • HLL FB 211 | FB_OUT | Output to the peripherals |

5.1 Reloading the Compact PLC to User FLASH Memory

When needed, the Compact PLC can be reloaded to the IMC01 with the FLASH loader. The software for this is located in directory SYSIMC1\COMPACT.PLC. Here you will find, among others, a finished RM3_PC1.SYS system, a sample STEP 5 program and a batch file for downloading with the FLASH loader.

Directory SYSIMC1\COMPACT.PLC\LOADER contains the following batch files for the reload.

LD_SYS.BAT Reload the system, including the STEP 5 program image.bin from the SYSIMC1\COMPACT.PLC\STEP5 directory

LD_MC5.BAT Reload the STEP 5 program SYSIMC1\COMPACT.PLC\STEP5\image.bin.

The system is not loaded again.

5.2 Data Block Interfaces for the Peripherals

5.2.1 Character Output on the Display (FB_DIS)

The function block for character output on the display (FB_DIS) permits specific texts to be displayed with the STEP 5 application. The data block must contain at least 64 data words.

Function block FB_DIS uses data block DB_DIS whose values are indicated on the display.

Structure of DB_DIS

	15	0	
DW 0 to DW 7	Character code	Character code	1st line
DW 8 to DW 15	Character code	Character code	2nd line
DW 16 to DW 23	Character code	Character code	3rd line
DW 24 to DW 31	Character code	Character code	4th line

Call interface of FB_DIS (FB208)

The function block must be set up by the STEP 5 programmer. Remember, however, that no instructions at all are permitted in the function block.

STL

FB208

Name: FB_DIS

BEZ : DBNR E/A/D/B/T/Z: E BI/BY/W/D: W

: BE

Example

Call in OB1

Description

L	DB_DIS	Load number of data block DB_DIS
T	MB 8	Transfer to flag byte 8
SPA	FB_DIS	Call HLL function block FB_DIS
DBNR:	MW 8	Transfer number of DB_DIS as formal operand

....

**Caution**

The formal operand must be transferred in a flag word. Otherwise the function block will not be processed.

The data block number is transferred to the function block in the left-hand half of the flag word.

A status is returned in the right-hand half of the flag word.

- FFh = The referenced data block cannot be used. It either does not exist or is too small. The function block was not processed.
- 00h = The referenced data block could be used.

5.2.2 Using the HW Peripherals (FB_IN, FB_OUT)

The IMC0x-PLC controls the digital inputs/outputs with the conventional standard mechanisms (external I/O). The other HW peripherals are handled by the HLL function blocks.

The function blocks for reading in (FB_IN) and reading out (FB_OUT) the peripherals both use the same DB_PER data block to store their data. The data block must be set up by the STEP 5 programmer. The data block has a length of 132 DWs.

Structure of DB_PER

	15	0	
DW 0	Analog input AI1		Input area
DW 1	Analog input AI2		
DW 2	Analog input AI3		
DW 3	Analog input AI4		
DW 4	Analog input AI5		
DW 5	Analog input AI6		
DW 6	Analog input AI7		
DW 7	Analog input AI8		
DW 8	Configuration of the analog inputs		
DW 9	Current LED status		
DW 10	Reserved		
DW 11	Free	Hours	Current time
DW 12	Minutes	Seconds	
DW 13	Day of the week	Day	Current date
DW 14	Month	Year	
DW 15	Results of the background test		
DW 16	Analog output		Output area
DW 17	Current LED status		
DW 18	Reserved		
DW 19	Status	Hours	Set new time
DW 20	Minutes	Seconds	
DW 21	Day of the week	Day	Set new date
DW 22	Month	Year	
DW 23 to DW 24	Free		
DW 25	Second key	First key	Key codes
DW 26 to DW 28	Free		
DW 29	Station address		DP
DW 30 to DW 45	DP "input" area		
DW 46 to DW 99	Reserved		
DW 100 to DW 115	DP "output" area		
DW 116 to DW 131	Reserved		

DW 0 to DW 7

The analog inputs are 12 bits in length. The entered values are raw ADC data which require interpretation by the PLC program. The analog inputs have different interface options whose settings can be determined with DW 6.

When channels AI3, AI4, AI7 und AI8 are configured for temperature measurement, the values are specified in tenths of a degree.

When the jumper setting is "voltage," the voltage measuring range (unipolar/bipolar, 5 V/10 V) can be set for these channels in DB_CONFIG.

- AI1 Voltage or current
- AI2 Voltage or current
- AI3 Voltage or temperature
- AI4 Voltage or temperature
- AI5 Voltage or current *)
- AI6 Voltage or current *)
- AI7 Voltage or temperature *)
- AI8 Voltage or temperature *)

*) FFFFh is always entered if there is no expansion PCB.

DW 8

The configuration of the analog inputs can be determined with this data word.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							EXT	AI8	AI7	AI6	AI5	AI4	AI3	AI2	AI1
							nv=0 v = 1	U=0 T = 1	U=0 T = 1	U=0 I = 1	U=0 I = 1	U=0 T = 1	U=0 T = 1	U=0 I = 1	U=0 I = 1

EXT: Info bit showing whether expansion module is installed

Not present (nv) = 0

Present (v) = 1

DW 9

The current status of the LEDs can be determined with this data word.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
								LED 8	LED 7	LED 6	LED 5	LED 4	LED 3	LED 2	LED 1
								Off= 0 On= 1	Off= 0 On= 1	Off= 0 On= 1	Off= 0 On= 1	Off= 0 On= 1	Off= 0 On= 1	Off= 0 On= 1	Off= 0 On= 1

DW 11 to DW 12

The time is displayed as shown below.

- Hours: 0 to 23 hr
- Minutes: 0 to 59 min
- Seconds: 0 to 59 sec

DW 13 to DW 14

The date is displayed as shown below.

- Day of the week: 1 to 7, whereby 1 = Monday, ... , 6 = Saturday, 7 = Sunday
- Day: 1 to 31
- Month: 1 to 12
- Year: 0 to 99

DW 15

The data word contains the states of the test results of a test task running cyclically in the background.

The following are tested.

Backup battery	Load test at intervals of approx. 6 hours
RAM	Dynamic read/write test
Configuration	Plausibility test of the configuration data (driver switchover, interface parameters, and so on) on the EEPROM
Short circuit	Tests the electronic digital outputs for short circuit IO: Both bits are set when there is a short circuit on one of the electronic digital outputs of the basic board. EXT: Both bits are set when there is a short circuit on one of the electronic digital outputs of the expansion board.
DP	Checks status of the DP bus'
Trap	Checks for excessive interrupt load on the system since last power-on

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Trap							DP	EXT	EXT	IO	IO		RAM	FLSH	BATT
OK=0							OK=0	OK=0	OK=0	OK=0	OK=0		OK=0	OK=0	OK=0
Hit=1							Def=1	ks=1	ks=1	ks=1	ks=1		Def=1	Def=1	Def=1

OK = Okay, no error

Def = Not okay, defect, or no master detected for DP

ks = Short circuit

Hit = System load too high

DW 16

The resolution of the analog output is 10 bits. The entered values are raw ADC data which require evaluation by the PLC program. Values greater than 2^{10} are reduced to the maximum value of 2^{10} .

DW 17

The indication status of the LEDs can be set with this data word.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
								LED 7	LED 6	LED 5	LED 4	LED 3	LED 2	LED 1	LED 0
								Off=0	Off=0	Off=0	Off=0	Off=0	Off=0	Off=0	Off=0
								On=1	On=1	On=1	On=1	On=1	On=1	On=1	On=1

DW 19 to DW 22

The time/date of the real-time clock cannot only be read. It can also be set. For permissible formats, see DW 9 to DW 12. The value to be set is entered in the appropriate data byte. The individual values (e.g., seconds, day of the week, and so on) can also be set. After the function block is called, all entered values are reset to FFh. DL 19 contains the results (status) which were set.

- 00h = All values were accepted in the real-time clock.
- Value range of one of the values violated
 - 01h Erroneous value for hours
 - 02h Erroneous value for minutes
 - 04h Erroneous value for seconds
 - 10h Erroneous value for day of the week
 - 20h Erroneous value for day
 - 40h Erroneous value for month
 - 80h Erroneous value for year

If there are several errors, the error values are or-linked with each other.

Note:

No check is made for relationship when the clock block is set. For example, 02.30.97 is a legal value. The value is not automatically corrected until the next change.

The contents of DW 19 to DW 22 should be preset to FFFFh since otherwise the time/date would be changed when FB_OUT is called for the first time.

DW 25

The key codes of the keys currently being pressed are read out in this data word. The right-hand data byte (DR25) contains the key which was pressed first, and the left-hand data byte (DL25) contains the key which was pressed second. Only two simultaneously pressed keys can be detected. A second simultaneously activated key cannot be detected for keys S0 to S7.

The key codes correspond to the "special keycodes" described in IMC01BAS.H. See chapter 7.1.

DW 29

This data word contains the currently valid station address. This address is taken from DB_CONFIG during startup. See chapter 5.2.3. The DP master can change the configured station address.

DW 30 to DW 45


The IMC0x-PLC can write the DP "input" area (i.e., from the viewpoint of the DP master) as desired. This area is used to store the data which are to be indicated to the DP master as the process image. The area has a length of 64 data words.

DW 100 to DW 115

The DP master can write the DP "output" area (i.e., the output area as seen from the viewpoint of the DP master) as desired. This area is used to store the data which the IMC0x-PLC is to use as control data. The area has length of 32 data words.

Call interface of FB_IN (FB210)

The function block must be set up by the STEP 5 programmer. Remember, however, that no instructions are permitted at all for this function block.



STL

FB210

Name: FB_IN

BEZ : DBNR E/A/D/B/T/Z: E BI/BY/W/D: W

: BE

Example

Call in OB1

Description

L	DB_PER	Load number of the I/O data block
T	FW10	Transfer to flag word 10
SPA	FB_IN	Call HLL function block FB_IN
DBNR:	FW 10	Transfer the number of DB_PER as formal operand
....		

Call interface of FB_OUT (FB211)

The function block must be set up by the STEP 5 programmer. Remember, however, that no instructions are permitted at all for this function block.



STL

FB211

Name: FB_OUT

BEZ : DBNR E/A/D/B/T/Z: E BI/BY/W/D: W

: BE

Example

Call in OB1

Description

L	DB_PER	Load number of the I/O data block
T	FW10	Transfer to flag word 10
SPA	FB_OUT	Call HLL function block FB_OUT
DBNR:	FW 10	Transfer the number of DB_PER as formal operand
. . . .		



Caution

The following applies to both function blocks.

The formal operand must be transferred in a flag word. Otherwise the function block will not be processed.

The data block number is transferred to the function block in the left-hand half of the flag word.

A status is returned in the right-hand half of the flag word.

- FFh = The referenced data block cannot be used. It either does not exist or is too small. The function block was not processed.
- FEh = The data block referenced in FB_OUT is not the same as the one in FB_IN. The function block was not processed.
- 00h = The referenced data block could be used.

5.2.3 Configuration in DB_CONFIG

The following settings can be made in the configuration data block.

- DP slave bus address
- Priority of the DP communication task
- Pause time of the DP communication task
- Configuration of the analog inputs (unipolar/bipolar, 5 V/10 V measuring range)

The DB number is permanently set to 2.

Structure of DB_CONFIG

	15	0
DW 0	(Reserved)	DP bus address
DW 1	(Reserved)	Priority of DP task
DW 2	(Reserved)	Pause time of DP task
DW 3	DP status	
DW 4	DP reason (extra info on DP status)	
DW 5	Configuration of analog input AI1	
DW 6	Configuration of analog input AI2	
DW 7	Configuration of analog input AI3	
DW 8	Configuration of analog input AI4	
DW 9	Configuration of analog input AI5	
DW 10	Configuration of analog input AI6	
DW 11	Configuration of analog input AI7	
DW 12	Configuration of analog input AI8	

DL 0

Specification of the DP slave address. Values from 1 to 127 can be used. Enter 0 if no DP slave is to be configured.

DL 1, DL_2

The DP is processed in a system task. This task processes the DP slave cyclically in an endless loop. A pause is provided after each pass to give lower-priority tasks computing time.

The priority of the DP task and the pause time in msec can be set in DL1 and DL2. Standard values are set if you enter 0 (the default value). This permits you to optimize the entire system.

Note:

Although the entire system can be optimized, we strongly recommend leaving the standard settings (default value 0) as is. Incorrect settings will endanger the stability of the system.

DW 3

Return messages of the DP slave. The current status of the DP instance is returned here. The values are identical to the return message of the `dp_Init` function. See chapter 6.12.7.

DW 4

The reason for the status message in DW 3 is entered here. The values are identical to the return message of the `dp_Init` function. See chapter 6.12.7.

DW 5 to DW 12

The analog inputs are configured here. The setting is not valid unless the jumper is inserted on "voltage measurement." With current measurement, the measuring range is permanently set to 0 to 20 mA. With temperature measurement, the measuring range is permanently set to 0.1 degrees.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
														Bipolar	5 V
														Bip = 1	5V = 1
														Uni = 0	10V = 0

Examples

- AQ1 = 0 to 10 V, unipolar → DW5 = 0x0000
- AQ2 = 0 to 5 V, unipolar → DW6 = 0x0001
- AQ3 = -10 to 10 V bipolar → DW7 = 0x0002
- AQ4 = -5 to 5 V, bipolar → DW8 = 0x0003

6 BIOS Functions

The IMC1BIOS.LIB library file of the IMC01-BSP contains functions which allow you to access the hardware of the device.

Note:

Do not confuse the **basic input-output system** of the IMC01 with the boot BIOS of a PC.

The following description of these functions is organized by groups of hardware to be processed.

Function Groups	Call ¹⁾	Page
Functions for Analog Input	bai_...	63
Functions for Analog Output	bao_...	72
Real Time Clock Functions	bc_...	75
Functions for Digital Input	bdi_...	79
Functions for Digital Output	bdo_...	87
Display Functions	bg_...	96
General Functions	bgen_...	105
Keyboard Functions	bk_...	109
Functions for Temperature Measurement	bpt_...	112
Functions for Watchdog Processing	bwd_...	115
Functions for DP Slave Programming	dp_...	117
Functions of the Hardware Configuration	imc01...	123

1) ... = function-specific name

The examples in the descriptions are only provided for better comprehension of the particular function. Subdirectory SYSIMC1\APLBIOS offers an executable example.

Note:

Interface compatibility with the IMC05 requires fixed parameters for the IMC01 for some of the BIOS functions. For example, CHARACTER must always be entered for the coord_class parameter of the bg_gotoxy function.

6.1 Call Back Functions

When called, various initialization functions are provided with a pointer to a user function. This so-called call back function is then called by the applicable RMOS interrupt routine when a certain event occurs.

A call back function does not contain transfer parameters and must be programmed so that it can be executed within the time available to the interrupt routine. If necessary, extensive processing must be transferred to an additional processing function in S status, or to a task.

Note:
 Identical type BIOS routines generally do not have "reentrant" capability. For more details, see the READIMC1.1P0 file.

A call back function is specified for the following initialization functions.

Table 6.1 Initialization functions with transfer of a call back function

Call	Function	Event	RMOS Proc. Status
bk_keybinit	Initialize keyboard	Key control (i.e., press and release)	S
bai_strtconv	Start AD conversion of an analog input	After conclusion of AD conversion	S

If you transfer the value 0 instead of a pointer, no user function is performed.

Note:
 When a dynamic task is deleted from work memory, all initialization functions should be called with NULL pointers at the end to disable the appropriate interrupts.

6.2 Functions for Analog Input

Table 6.2 Functions for analog input

Call	Function	Page
<code>bai_get</code>	Read last conversion result of an analog input	63
<code>bai_getmode</code>	Read configuration of an analog input	65
<code>bai_init</code>	Initialize analog inputs and set voltage ranges	66
<code>bai_read</code>	Start AD conversion and read result in a function call	67
<code>bai_setmode</code>	Set operating mode of the analog inputs	69
<code>bai_strtconv</code>	Start AD conversion of an analog input	70

6.2.1 `bai_get`

Function Read result of the last AD conversion started with `bai_strtconv` for the specified analog input

Syntax

```
#include <imc01bas.h>
unsigned int bai_get(unsigned int number);
```

Parameters

Parameter Name	Meaning
<code>number</code>	Number of the analog input to be read 0 to 3: Analog inputs 1 to 4 on I/O card 4 to 7: Used internally 8 to 11: Analog inputs 5 to 8 on expansion card 12 to 15: Used internally

Return value

Function Value	Meaning
<code>0xFFFF</code>	Invalid
Other	Result of the AD conversion

Description

The function reads the result of the last AD conversion of the specified analog input. It should be called in the call back function specified when `bai_strtconv` was called.

The conversion result has a resolution of 12 bits.

Conversion result for the "voltage measurement" jumper setting

Setting 0 to +10 V

0x0000	0 Volt
0x0FFF	+10 Volt

Setting 0 to +5 V

0x0000	0 Volt
0x0FFF	+5 Volt

Setting -10 V to +10 V

0x0000	0 Volt
0x07FF	+10 Volt
0x0800	-10 Volt

Setting -5 V to +5 V

0x0000	0 Volt
0x07FF	+5 Volt
0x0800	-5 Volt

Conversion result for the "current measurement" jumper setting

0x0000	0 mA
0x0CCC	+20 mA

Note:

When the "temperature measurement" jumper setting is used, inputs AI3, AI4, AI7 and AI8 must be read by the `bpt_...` BIOS functions. See chapter 6.10.

Example

```
#include <imc01bas.h>
unsigned int value;
void testfunction(void)
{
    value = bai_get(1);
}
```

See also

`bai_strtconv`

6.2.2 bai_getmode

Function Read configuration (jumper setting) of an analog input

Syntax

```
#include <imc01bas.h>
unsigned char bai_getmode(unsigned int number);
```

Parameters

Parameter Name	Meaning
number	Number of the analog input 0 to 3: Analog inputs 1 to 4 on I/O card 8 to 11: Analog inputs 5 to 8 on expansion card

Return value

Function Value	Meaning
0	Jumper is set to voltage measurement.
0xFF	Jumper is set to current measurement (AI1, AI2, AI5 and AI6) or temperature measurement (AI3, AI4, AI7 and AI8).

Description

The function reads the position of the plug-in jumper with which the specified analog input is set to voltage or current or temperature measurement.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    int muster = 0;
    for (i=0;i<16;i++)
    {
        if (bai_getmode (i))
            muster |= 1<<i;
        else
            muster &= ~(1<<i);
    }
    printf ("AI-Konfigmuster = %x\n", muster);
}
```

See also

bai_read, bai_get, bai_strtconv, bpt_...

6.2.3 bai_init

Function Initialize analog inputs and set voltage ranges

Syntax

```
#include <imc01bas.h>
void bai_init(unsigned char volt_range_bitmsk);
```

Parameters

Parameter Name	Meaning																																																																																	
volt_range_bitmsk	Bit pattern for setting the voltage range of analog inputs Bit = 0: $U_{max} = 10\text{ V}$ Bit = 1: $U_{max} = 5\text{ V}$																																																																																	
Bit	<table border="1"> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> <td>Analog input</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A11 on I/O card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A12 on I/O card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A13 on I/O card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A14 on I/O card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A15 on expansion card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A16 on expansion card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A17 on expansion card</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>A18 on expansion card</td> </tr> </table>	7	6	5	4	3	2	1	0	Analog input									A11 on I/O card									A12 on I/O card									A13 on I/O card									A14 on I/O card									A15 on expansion card									A16 on expansion card									A17 on expansion card									A18 on expansion card
7	6	5	4	3	2	1	0	Analog input																																																																										
								A11 on I/O card																																																																										
								A12 on I/O card																																																																										
								A13 on I/O card																																																																										
								A14 on I/O card																																																																										
								A15 on expansion card																																																																										
								A16 on expansion card																																																																										
								A17 on expansion card																																																																										
								A18 on expansion card																																																																										

Return value None

Description The routine initializes processing of the analog inputs and assigns 0xFFFF (invalid) to their conversion results. The voltage range is set for the inputs set to voltage measurement.

BIOS calls the routine during startup, and sets all voltage ranges to 10 V.

The bai_setmode function sets the operating mode (unipolar/bipolar).

Setting of the voltage range is irrelevant to inputs which are set to current or temperature measurement.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    unsigned char voltrange_bitmask = 0; /* range 10 V */
    bai_init(voltrange_bitmask);
}
```

See also bai_setmode, bai_get, bai_strtconv,

6.2.4 bai_read

Function Start AD conversion of an analog input, wait for conclusion of AD conversion, and read result

Syntax

```
#include <imc01bas.h>
unsigned int bai_get(unsigned int number);
```

Parameters

Parameter Name	Meaning
number	Number of the analog input to be converted 0 to 3: Analog inputs 1 to 4 on I/O card 8 to 11: Analog inputs 5 to 8 on expansion card

Return value

Function Value	Meaning
0xFFFF	Invalid
Other	Result of the AD conversion

Description

The function starts the AD conversion of an analog input, waits until it has been concluded, and reads the conversion result. In comparison to the `bai_strtconv` and `bai_get` functions, this is an easier but slower method of reading an analog input.

Conversion result for the "voltage measurement" jumper setting

Setting 0 to +10 V

0x0000 0 Volt
0x0FFF +10 Volt

Setting 0 to +5 V

0x0000 0 Volt
0x0FFF +5 Volt

Setting -10 V to +10 V

0x0000 0 Volt
0x07FF +10 Volt
0x0800 -10 Volt

Setting -5 V to +5 V

0x0000 0 Volt
0x07FF +5 Volt
0x0800 -5 Volt

Conversion result for the "current measurement" jumper setting

0x0000 0 mA
0x0CCC +20 mA

Note:

Mixed use of `bai_read` and `bai_strtconv/bai_get` is permitted but must be decoupled in time by the user.

Example

```
#include <imc01bas.h>
unsigned int value 1;
unsigned int value 2;
void testfunction(void)
{
    value 1 = bai_read(0); /* convert ADC channel 1, read value*/
    value 2 = bai_read(1); /* convert ADC channel 2, read value*/
}
```

See also

bai_get, bai_strtconv, bpt_read

6.2.5 bai_setmode

Function Configuring analog inputs for functions `bai_strtconv` and `bai_get`

Syntax

```
#include <imc01bas.h>
int bai_setmode(unsigned int number,
               unsigned char mode);
```

Parameters

Parameter Name	Meaning
number	Number of the input to be configured 0 to 3: Analog inputs 1 to 4 on I/O card 8 to 11: Analog inputs 5 to 8 on expansion card
mode	Operating mode of the analog input AI_BIPOLAR Bipolar mode AI_UNIPOLAR: Unipolar mode

Return value

Function Value	Meaning
BAI_NO_ERROR	Function executed successfully.
BAI_INV_PARAM	Parameter invalid

Description

The function sets the operating mode of an analog input.

Bipolar mode $-U_{\max}$ to $+U_{\max}$

Unipolar mode 0 to $+U_{\max}$

The function is called by BIOS during startup and sets all inputs to unipolar mode.

Function `bai_init` sets the voltage range U_{\max} .

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bai_setmode (0, AI_BIPOLAR);
}
```

See also

`bai_init`

6.2.6 bai_strtconv

Function Start AD conversion of an analog input

Syntax

```
#include <imc01bas.h>
int bai_strtconv(unsigned int number,
                 void (*call_back_fct)());
```

Parameters

Parameter Name	Meaning
number	Number of the analog input to be converted 0 to 3: Analog inputs 1 to 4 on I/O card 4 to 7: Used internally 8 to 11: Analog inputs 5 to 8 on expansion card 12 to 15:Used internally
*call_back_fct	Pointer to function which is called after AD conversion has been concluded

Return value

Function Value	Meaning
0	Function executed successfully
-1	Invalid parameter (number too large)
-2	Call not permitted since an AD conversion is still in progress
-3	Analog inputs in shutdown mode

Description The function starts the AD conversion of an analog input.

When the AD conversion has been completed, the call back function specified is called. The converted analog value should be read there. See bai_get function.

Note:
 The call back function must be specified. A new conversion cannot be started until the call back function has been executed.
 The bai_strtconv function is required when bai_get is used. When bai_read is used, bai_strtconv may not be called.
 Since inputs AI3,4,7,and 8 must be read out by the bpt_... BIOS functions when the "temperature" jumper setting is used, bai_strtconv may not be called for temperature channels. When mixed operation (temperature inputs and voltage/current) is used, make sure that more than one conversion is never triggered simultaneously. For example, bpt_read may not be called for a temperature channel until a conversion (of a current/voltage channel) started with bai_strtconv has been concluded.

To trigger the conversion of several analog inputs at the same time, set bit 15 in `number`. This starts the AD conversion of all inputs from 0 to the input number specified.

Example: `number = 0x8003`: inputs 0 to 3

The call back function is not called until all conversions have been completed.

Example

```
#include <imc01bas.h>
extern _FIXED _FAR void test_fct(void);
void testfunction(void)
{
    bai_strtconv(1, test_fct);
}
```

See also

`bai_get`, `bai_read`

6.3 Functions for Analog Output

Table 6.3 Functions for analog output

Call	Function	Page
bao_init	Initialize analog output	72
bao_set	Output value to analog output	73
bao_setmode	Configure analog output (with IMC01 dummy for compatibility with IMC05)	74

6.3.1 bao_init

Function Initialize analog output

Syntax

```
#include <imc01bas.h>
void bao_init();
```

Return value None

Description The routine initializes processing of the analog output and resets this to 0 Volt.
The routine is called by BIOS during startup. It does not need to be called by the user.

6.3.2 bao_set

Function Output value to analog output

Syntax

```
#include <imc01bas.h>
unsigned char bao_set(unsigned int number,
                     unsigned int value);
```

Parameters

Parameter Name	Meaning
number	Number of the analog output (always 0)
value	Value to be output

Return value

Function Value	Meaning
0xFF	Output performed successfully
0	Output not performed (value or number too large or output deactivated)

Description

The function writes a value to the analog output specified.

00 Approx. 0 mA
1000 (0x3e8) Approx. 20 mA

Only 0 is permitted as the output number since only one output is available with IMC01.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bao_init();
    bao_set(0, 1000);     /* output 20 mA */
}
```

6.3.3 bao_setmode

Function Dummy function for IMC01. The output must always be set permanently to 0 to 20 mA and cannot be configured.

Syntax

```
#include <imc01bas.h>
int bao_setmode(unsigned int number,
                unsigned char mode);
```

Parameters

Parameter Name	Meaning
number	Dummy
mode	Dummy

Return value

Function Value	Meaning
BAO_NO_ERROR	Function executed successfully

Description

This is a dummy function for IMC01. It is included for interface compatibility with the IMC05 and should not be used for the IMC01. The function sets the operating mode of the analog outputs for the IMC05.

6.4 Real Time Clock Functions

Table 6.4 Real time clock functions

Call	Function	Page
bc_init_rtc	Initialize real time clock	75
bc_stime	Set date and time	76
bc_time	Read date and time	77

6.4.1 bc_init_rtc

Function Initialize real time clock

Syntax `#include <imc01bas.h>`
`void bc_init_rtc(void);`

Return value None

Description The routine starts processing of the real time clock. This does not change the previously valid date and time.

The routine is called by BIOS during startup. It does not need to be called by the user.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bc_init_rtc();
}
```

See also bc_stime, bc_time, RmSetHWClockTime, RmGetHWClockTime

6.4.2 bc_stime

Function Set date and time

Syntax

```
#include <imc01bas.h>
void bc_stime(RTC_TIME *time,
             RTC_DATE *date,
             unsigned char day);
```

Parameters

Parameter Name	Meaning
*time	Pointer to structure with the time
*date	Pointer to structure with the date
day	Day of the week

Return value None

Description This routine sets the time, date and day of the week for the real time clock. The structures for the values are described under the routine `bc_time` in chapter 6.4.3.

If one of the pointers contains the value `NULL` or a value is invalid, the real time clock is not set with this value.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    RTC_TIME time;
    RTC_DATE date;

    /* Set time to Monday, 18:02:00 */
    time.H1 = 8;
    time.H10 = 1;
    time.M1 = 2;
    time.M10 = 0;
    time.S1 = 0;
    time.S10 = 0;
    bc_stime(&time, NULL, MONDAY);
}
```

See also `bc_time`

6.4.3 bc_time

Function Read date and time

Syntax

```
#include <imc01bas.h>
void bc_time(RTC_TIME *time,
             RTC_DATE *date,
             unsigned char *day);
```

Parameters

Parameter Name	Meaning
*time	Pointer to structure for the time
*date	Pointer to structure for the date
*day	Pointer to a byte for the day of the week

Return value None

Description This routine reads the time, date and the day of the week from the real time clock.

The time is stored in the following structure.

Structure Element	Type	Meaning	Values
.S1	unsigned char	Seconds, ones position	0 to 9
.S10	unsigned char	Seconds, tens position	0 to 5
.M1	unsigned char	Minutes, ones position	0 to 9
.M10	unsigned char	Minutes, tens position	0 to 5
.H1	unsigned char	Hour, ones position	0 to 9
.H10	unsigned char	Hour, tens position	0 to 2

The date is stored in the following structure.

Structure Element	Type	Meaning	Values
.D1	unsigned char	Day, ones position	0 to 9
.D10	unsigned char	Day, tens position	0 to 3
.M1	unsigned char	Month, ones position	0 to 9
.M10	unsigned char	Month, tens position	0 to 1
.Y1	unsigned char	Year, ones position	0 to 9
.Y10	unsigned char	Year, tens position	0 to 9

The day of the week is stored in the following structure.

Constant	Meaning	Value
SUNDAY	Sunday	0
MONDAY	Monday	1
TUESDAY	Tuesday	2
WEDNESDAY	Wednesday	3
THURSDAY	Thursday	4
FRIDAY	Friday	5
SATURDAY	Saturday	6

Example

```
#include <imc01bas.h>

void testfunction(void)
{
    RTC_TIME time;
    RTC_DATE date;
    unsigned char dayoftheweek;

    bc_time(&time, &date, &dayoftheweek);
}
```

See also

bc_stime

6.5 Functions for Digital Input

Table 6.5 Functions for digital input (DI = digital input)

Call	Function	Page
bdi_get	Read digital input	80
bdi_getblock	Read block of digital inputs	81
bdi_getmbit	Read bit from DI image	82
bdi_getmirror	Read DI image	83
bdi_init	Initialize digital inputs	84
bdi_mirror	Update DI image	84
bdi_resetmbit	Reset bit in DI image	85
bdi_setmbit	Set bit in DI image	85
bdi_setmirror	Overwrite DI image	86

The following diagram shows the accesses which can be performed with these functions and the use of the image of the digital inputs (DI image).




Figure 6.1 Use of the DI image

The DI image can be used for test purposes (e.g., to simulate I/O devices which have not been connected yet).

6.5.1 bdi_get

Function Read digital input

Syntax

```
#include <imc01bas.h>
unsigned char bdi_get(unsigned int di_num);
```

Parameters

Parameter Name	Meaning
di_num	Number of the digital input to be read

Return value

Function Value	Meaning
0	Input is reset.
0xFF	Input is set.

Description

The function reads the status of a digital input directly and bypasses the image of the digital inputs.

If di_num contains an invalid value, 0 is returned as the result.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_gotoxy(0,1, CHARACTER);
    bg_outtext((bdi_get(3) == 0) ?
        `DI = set` : `DI = reset`);
}
```

See also

bdi_getmirror

6.5.2 bdi_getblock

Function Read block of digital inputs

Syntax

```
#include <imc01bas.h>
void bdi_getblock(unsigned int from_di,
                 unsigned int to_di,
                 unsigned short *dptr);
```

Parameters

Parameter Name	Meaning
from_di	Number of the first digital input to be read
to_di	Number of the last digital input to be read
*dptr	Pointer to the result

Note:

In principle, any values can be used for `from_di` and `to_di`. However, using values for `from_di` and `to_di` which are divisible by 8 speeds up processing considerably.

Return value None

Description The routine reads a block of digital inputs and stores the result by bit in the integer variables referenced.

Bit 0: DI0
Bit 23: DI23

The image of the digital inputs is not affected.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    int de_abbild; /* image for max. of 24 dig. inputs */

    bdi_getblock(0, 23, (unsigned short *) &de_abbild);
    /* read inputs 0 to 23 */
}
```

See also `bdi_get`, `bdi_mirror`

6.5.3 bdi_getmbit

Function Read bit from DI image

Syntax

```
#include <imc01bas.h>
unsigned char bdi_getmbit(unsigned int di_num);
```

Parameter Name	Meaning
di_num	Number of the bit to be read

Function Value	Meaning
0	Bit is reset.
0xFF	Bit is set.

Description The function reads a bit from the image of the digital inputs. If di_num contains an invalid value, 0 is returned as the result.

Example

```
#include <imc01bas.h>

void testfunction(void)
{
    bdi_mirror();
    bit_1 = bdi_getmbit(1);
    bdi_resetmbit(3);
    bit_3 = bdi_getmbit(3);
    bdi_setmbit(3);
    bit_3_ = bdi_getmbit(3);

    bg_gotoxy(0, 0, CHARACTER);
    bg_outtext(bit_1 ? " set" : "reset");
}
```

See also bdi_setmbit

6.5.4 bdi_getmirror

Function Read DI image

Syntax

```
#include <imc01bas.h>
unsigned int bdi_getmirror(unsigned char *pdi,
                          unsigned int bitcnt);
```

Parameters

Parameter Name	Meaning
*pdi	Pointer to variable in which the result is stored
bitcnt	Number of bits to be processed

Return value Number of bits which were processed

Description The function reads the first `bitcnt` bits from the image of the digital inputs and writes the result in the character string referenced.

Only the maximum number of bits actually contained in the image of the digital inputs is stored.

Example

```
#include <stdlib.h>
#include <imc01bas.h>

void testfunction(void)
{
    unsigned int pattern = {0x12};
    unsigned int result;
    unsigned int number;

    number = bdi_init();
    bdi_setmirror(&pattern, 16);
    number = bdi_getmirror(&result, 16);

    bg_gotoxy(0,1,CHARACTER);
    bg_outtext(itoa(number));
}
```

See also `bdi_mirror`, `bdi_setmirror`

6.5.5 bdi_init

Function Initialize digital inputs

Syntax

```
#include <imc01bas.h>
unsigned int bdi_init();
```

Return value Number of digital inputs available

Description The function resets all digital inputs and initializes their processing.

The function is called by BIOS during startup. It does not need to be called by the user.

Example

```
#include <stdlib.h>
#include <imc01bas.h>

void testfunction(void)
{
    unsigned int number;

    number = bdi_init();
    bg_gotoxy(0,1,CHARACTER);
    bg_outtext(itoa(number));
}
```

6.5.6 bdi_mirror

Function Update DI image

Syntax

```
#include <imc01bas.h>
void bdi_mirror();
```

Return value None

Description The routine reads all digital inputs and updates the internal BIOS DI image.

See also bdi_get, bdi_getmbit, bdi_setmbit, bdi_resetmbit

6.5.7 bdi_resetbit

Function Reset bit in DI image

Syntax

```
#include <imc01bas.h>
void bdi_resetbit(unsigned int di_num);
```

Parameter Name	Meaning
di_num	Number of the bit to be reset

Return value None

Description The routine resets the specified bit in the image of the digital inputs. If di_num contains an invalid value, processing is not performed.

See also bdi_get, bdi_getmbit, bdi_resetbit

6.5.8 bdi_setmbit

Function Set bit in DI image

Syntax

```
#include <imc01bas.h>
void bdi_setmbit(unsigned int di_num);
```

Parameter Name	Meaning
di_num	Number of the bit to be set

Return value None

Description The routine sets the specified bit in the image of the digital inputs. If di_num contains an invalid value, processing is not performed.

See also bdi_get, bdi_getmbit, bdi_resetbit

6.5.9 bdi_setmirror

Function Overwrite DI image

Syntax

```
#include <imc01bas.h>
void bdi_setmirror(unsigned char *pdi,
                  unsigned int bitcnt);
```

Parameters

Parameter Name	Meaning
*pdi	Pointer to variable containing the bit pattern to be written
bitcnt	Number of bits to be processed

Return value None

Description The routine overwrites the first `bitcnt` bits in the image of the digital inputs with the bit pattern specified.

Example

```
#include <imc01bas.h>
static unsigned char de_abbild[8];
/* Digital inputs and outputs */
void testfunction(void)
{
    bdi_setmirror (&de_abbild[0], 1);
}
```

See also `bdi_mirror`, `bdi_getmirror`

6.6 Functions for Digital Output

Table 6.6 Functions for digital output (DO = digital output)

Call	Function	Page
bdo_flush	Output block of digital outputs	88
bdo_getmbit	Read bit from DO image	89
bdo_getmirror	Read DO image	90
bdo_init	Initialize digital outputs	91
bdo_mflush	Output DO image	91
bdo_reset	Reset digital output	92
bdo_resetmbit	Reset bit in DO image	92
bdo_set	Set digital output	93
bdo_setmbit	Set bit in DO image	93
bdo_setmirror	Overwrite DO image	94
bdo_status	Read group error status of the output drivers	95

The output drivers are always processed in groups of 8 outputs. To circumvent this restriction, BIOS maintains an image of the digital outputs which you can also access by bit.

The following diagram shows the accesses which can be performed with these functions and the use of the image of the digital outputs (DO image).




Figure 6.2 Use of the DO image

6.6.1 bdo_flush

Function Output block of digital outputs

Syntax

```
#include <imc01bas.h>
void bdo_flush(unsigned int from_do,
               unsigned int to_do,
               unsigned char *dptr);
```

Parameters

Parameter Name	Meaning
from_do	Number of the first digital output
to_do	Number of the last digital output
*dptr	Pointer to the bit pattern to be written

Note:
 In principle, any values can be used for `from_do` and `to_do`.
 However, using values for `from_do` and `to_do` which are divisible by 8 speeds up processing considerably.

Return value None

Description The routine outputs the referenced bit pattern to the specified block of digital outputs.

Bit 0: DO0
 Bit 15: DO15

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    int do_mask = 0x15;
    /* specify bit mask for outputs */
    bdo_flush(6, 10, &do_mask);
    /* Set DO 6, 8, 10; reset DO 7, 9 */
}
```

See also bdo_set, bdo_reset, bdo_mflush

6.6.2 bdo_getmbit

Function Read bit from DO image

Syntax

```
#include <imc01bas.h>
unsigned char bdo_getmbit(unsigned int do_num);
```

Parameters

Parameter Name	Meaning
do_num	Number of the bit to be read

Return value

Function Value	Meaning
0	Bit is reset.
0xFF	Bit is set.

Description

The function reads a bit from the image of the digital outputs. A result of 0 is returned when do_num contains an invalid value.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bdo_setmbit(3);
    bit_3 = bdo_getmbit(3);

    bg_gotoxy(0,0,CHARACTER);
    bg_outtext(bit_3 ? "set" : "reset");
}
```

See also

bdo_setmbit

6.6.3 bdo_getmirror

Function Read DO image

Syntax

```
#include <imc01bas.h>
unsigned int bdo_getmirror(unsigned char *pdo,
                          unsigned int bitcnt);
```

Parameters

Parameter Name	Meaning
*pdo	Pointer to variable in which the result is stored
bitcnt	Number of bits to be processed

Return value Number of bits which were processed

Description The function reads the first `bitcnt` bits from the image of the digital outputs and writes the result in the character string referenced.

Only the maximum number of bits actually contained in the image of the digital outputs is stored.

Example

```
#include <stdlib.h>
#include <imc01bas.h>

void testfunction(void)
{
    unsigned int pattern = {0x12};
    unsigned int result;
    unsigned int number;
    char temp_string [10];

    number = bdo_init();
    bdo_setmirror(&pattern, 16);
    number = bdo_getmirror(&result, 16);

    bg_gotoxy(0,1,CHARACTER);
    bg_outtext(itoa(number, temp_string, 10));
}
```

See also `bdo_mflush`, `bdo_setmirror`

6.6.4 bdo_init

Function Initialize digital outputs

Syntax

```
#include <imc01bas.h>
unsigned int bdo_init(void (*call_back_fct)());
```

Parameters

Parameter Name	Meaning
*call_back_fct	Pointer to call back function which is called when the group error status of the output drivers changes

Return value Number of digital outputs available

Description The function initializes processing of the digital outputs by BIOS and installs the call back function for processing error interrupts.

All bits are reset in the image of the digital outputs (DO image).

The function is called by BIOS during startup (without pointer to a call back function). The function does not need to be called by the user unless the call back function is to be installed.

Example

```
#include <stdlib.h>
#include <imc01bas.h>

void testfunction(void)
{
    unsigned int number;

    number = bdo_init(NULL);
    bg_gotoxy(0,1,CHARACTER);
    bg_outtext(itoa(number));
}
```

See also bdo_status

6.6.5 bdo_mflush

Function Output DO image

Syntax

```
#include <imc01bas.h>
void bdo_mflush();
```

Return value None

Description The routine outputs the image of the digital outputs to the output drivers.

See also bdo_set

6.6.6 bdo_reset

Function Reset digital output

Syntax

```
#include <imc01bas.h>
void bdo_reset(unsigned int do_num);
```

Parameters

Parameter Name	Meaning
do_num	Number of the digital output to be reset

Return value None

Description The routine resets a bit in the DO image and outputs the corresponding group to the digital outputs. No processing is performed when do_num contains an invalid value.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bdo_reset(2);
}
```

See also bdo_setmirror, bdo_setmbit

6.6.7 bdo_resetmbit

Function Reset bit in DO image

Syntax

```
#include <imc01bas.h>
void bdo_resetmbit(unsigned int do_num);
```

Parameters

Parameter Name	Meaning
do_num	Number of the bit to be reset

Return value None

Description The routine resets the specified bit in the image of the digital outputs. No processing is performed when do_num contains an invalid value.

See also bdo_setmbit, bdo_getmbit

6.6.8 bdo_set

Function Set digital output

Syntax

```
#include <imc01bas.h>
void bdo_set(unsigned int do_num);
```

Parameters

Parameter Name	Meaning
do_num	Number of the digital output to be set

Return value None

Description The routine sets a bit in the DO image and outputs the corresponding group to the digital outputs. No processing is performed when do_num contains an invalid value.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bdo_set(2);
}
```

See also bdo_setmirror, bdo_setmbit

6.6.9 bdo_setmbit

Function Set bit in DO image

Syntax

```
#include <imc01bas.h>
void bdo_setmbit(unsigned int do_num);
```

Parameters

Parameter Name	Meaning
do_num	Number of the bit to be set

Return value None

Description The routine sets the specified bit in the image of the digital outputs. No processing is performed when do_num contains an invalid value.

See also bdo_set, bdo_getmbit

6.6.10 bdo_setmirror

Function Overwrite DO image

Syntax

```
#include <imc01bas.h>
void bdo_setmirror(unsigned char *pdo,
                  unsigned int bitcnt);
```

Parameters

Parameter Name	Meaning
*pdo	Pointer to variable containing the bit pattern to be written
bitcnt	Number of bits to be processed

Return value None

Description The routine overwrites the first `bitcnt` bits of the image of the digital outputs with the bit pattern transferred.

Example

```
#include <imc01bas.h>
static unsigned char do_mirror[2];
void testfunction(void)
{
    bdo_setmirror (&do_mirror[0], 1);
}
```

See also `bdo_mflush`, `bdo_getmirror`

6.6.11 bdo_status

Function Read group error status of the output drivers

Syntax

```
#include <imc01bas.h>
unsigned char bdo_status();
```

Return value When one of the following bits is set (= 1) in the return value, this indicates that an error has occurred.

Bit	7	6	5	4	3	2	1	0	Meaning
									Error in group 0 (DO0 to DO7)
									Error in group 1 (DO8 to DO15)
									Reserved
									Reserved

Description This function determines the group error status of the output drivers of all digital outputs.

The error bit of an output group is set under the following conditions.

- Overcurrent (short circuit) or thermal overload
- Undervoltage on one of the outputs

For example, the function can be used in the call back function of the `bdo_init` function.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    unsigned char result;

    result = bdo_status();
}
```

See also `bdo_init`

6.7 Display Functions

Table 6.7 Display functions

Call	Function	Page
bg_cleardevice	Clear display	96
bg_getmaxx	x dimension of display	97
bg_getmaxy	y dimension of display	97
bg_gotoxy	Position cursor (cursor becomes invisible)	98
bg_init	Initialize display	99
bg_outchar	Output character	99
bg_outtext	Output character string	100
bg_screensaver	Screen saver	101
bg_setcursor	Position cursor (cursor attributes are retained)	102
bg_setcursortype	Specify cursor attributes	103
bg_wherex	x position of text cursor	104
bg_wherey	y position of text cursor	104

6.7.1 bg_cleardevice

Function Clear display

Syntax

```
#include <imc01bas.h>
void bg_cleardevice();
```

Return value None

Description After deletion, blanks are output in all text positions. The cursor position is shifted to 0, 0.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_cleardevice();
}
```

See also bg_setcolor

6.7.2 **bg_getmaxx**

Function Determine maximum x dimension of the display (in characters)

Syntax

```
#include <imc01bas.h>
int bg_getmaxx();
```

Return value Integer value, depends on the hardware used:
currently always 16

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    char temp_string [10];

    bg_cleardevice();
    bg_outtext(itoa(bg_getmaxx(), temp_string, 10));
}
```

See also `bg_getmaxy`

6.7.3 **bg_getmaxy**

Function Determine maximum y dimension of the display (in characters)

Syntax

```
#include <imc01bas.h>
int bg_getmaxy();
```

Return value Integer value, depends on the hardware used:
to date, always 4

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    char temp_string [10];

    bg_cleardevice();
    bg_outtext(itoa(bg_getmaxy(), temp_string, 10));
}
```

See also `bg_getmaxx`

6.7.4 bg_gotoxy

Function Position text cursor

Syntax

```
#include <imc01bas.h>
unsigned char bg_gotoxy(unsigned int x_pos,
                        unsigned int y_pos,
                        unsigned int coord_class);
```

Parameter Name	Meaning
x_pos	x position of the text cursor (0 = left)
y_pos	y position of the text cursor (0 = top)
coord_class	Type of position specified CHARACTER Character position

Function Value	Meaning
0xFF	Positioning performed successfully
0	No positioning performed

Description The function positions the cursor for the text output but does not indicate it at its new position. Positioning is not performed when an invalid position is specified.

When the IMC01 is used, only CHARACTER may be specified for coord_class.

Example

```
#include <ctype.h>
#include <imc01bas.h>
void testfunction(void)
{
    int length, i;
    char *string = "TOLOWER";
    length = strlen(string);
    for (i=0; i<length-1; i++)
        string[i] = tolower(string [i]);
    bg_gotoxy(0, 1, CHARACTER);
    bg_outtext(string);
}
```

See also bg_setcursor, bg_setcursortype

6.7.5 **bg_init**

Function Initialize display

Syntax

```
#include <imc01bas.h>
void bg_init();
```

Return value None

Description This routine sets the display controller with the standard values.

- Text attribute = BG_NORM
- Cursor attribute: BG_NOCURSOR and BG_AUTOCURSOR
- Display cleared

The routine is called by BIOS during startup. It does not need to be called by the user.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_init();
    bg_outtext("Initialization performed");
}
```

6.7.6 **bg_outchar**

Function Output character

Syntax

```
#include <imc01bas.h>
void bg_outchar(char _character);
```

Parameters

Parameter Name	Meaning
_character	Character to be output

Return value None

Description The routine outputs the character at the position of the text cursor.

The text cursor is shifted to the right of the output text.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_cleardevice();
    bg_gotoxy(0,1, CHARACTER);
    bg_outchar(`A`);
    bg_outchar(`B`);
}
```

See also `bg_outtext`, `bg_settextattr`, `bg_setcursortype`,

6.7.7 **bg_outtext**

Function Output character string

Syntax

```
#include <imc01bas.h>
void bg_outtext(char *stringptr);
```

Parameters

Parameter Name	Meaning
*stringptr	Pointer to character string to be output

Return value None

Description The routine outputs the character string referenced by the pointer at the position of the text cursor.

The text cursor is shifted to the right of the output text.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_cleardevice();
    bg_gotoxy(0,1, CHARACTER);
    bg_outtext("Output a");

    bg_gotoxy(0,2, CHARACTER);
    bg_outtext("character string");
}
```

See also [bg_outchar](#), [bg_setcursortype](#),

6.7.8 bg_screensaver

Function Screen saver

Syntax

```
#include <imc01bas.h>
void bg_screensaver(unsigned char state);
```

Parameters

Parameter Name	Meaning
state	0x01: Activate screen saver 0x00: Deactivate screen saver

Return value None

Description The function turns the backlight of the display on or off. Correct use of this routine can extend the life of the backlight significantly.

Note:

Switching the backlight on and off too frequently damages the backlight just as much as leaving it on for unnecessarily long periods of time.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_screensaver(0x01);
}
```

6.7.9 **bg_setcursor**

Function Indicate text cursor at new position

Syntax

```
#include <imc01bas.h>
unsigned char bg_setcursor(unsigned int x_pos,
                           unsigned int y_pos,
                           unsigned int coord_class);
```

Parameter Name	Meaning
x_pos	x position of the text cursor (0 = left)
y_pos	y position of the text cursor (0 = top)
coord_class	Type of position specified CHARACTER Character position

Function Value	Meaning
0xFF	Positioning performed successfully
0	No positioning performed

Description The function positions the cursor for text output and indicates it at the new position with the cursor attributes set. Positioning is not performed when an invalid position is specified.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    unsigned char dummy;

    bg_gotoxy(0,2, CHARACTER);
    bg_outtext("Curspos. = 2,3");
    dummy = bg_setcursor(2,3,CHARACTER);
}
```

See also bg_gotoxy, bg_setcursortype

6.7.10 **bg_setcursortype**

Function Specify cursor attributes

Syntax

```
#include <imc01bas.h>
void bg_setcursortype(unsigned int cur_type,
                     unsigned int auto_cursor);
```

Parameters

Parameter Name	Meaning
cur_type	Type of cursor indication BG_NOCURSOR Cursor is invisible. BG_BLINKCURSOR Flashing block cursor BG_UNDERLINECURSOR Underline cursor
auto_cursor	BG_AUTOCURSOR_RIGHT Cursor positioned to right next to output text

Return value None

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_cleardevice();
    bg_setcursor(0,1, CHARACTER);
    bg_setcursortype(BG_BLINKCURSOR, BG_AUTOCURSOR_RIGHT);
}
```

See also `bg_setcursor`

6.7.11 **bg_wherex**

Function Determine current x position of the text cursor (in characters)

Syntax
`#include <imc01bas.h>`
`int bg_wherex();`

Return value

Function Value	Meaning
0	Cursor on left edge of display
...	
X _{max}	Cursor on right edge of display

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    int x_pos;
    char temp_string [10];

    bg_cleardevice();
    bg_gotoxy(10, 3, CHARACTER);
    x_pos = bg_wherex();
    bg_outtext(itoa(x_pos, temp_string, 10));
}
```

See also `bg_getmaxx`, `bg_wherey`, `bg_gotoxy`

6.7.12 **bg_wherey**

Function Determine current y position of the text cursor (in characters)

Syntax
`#include <imc01bas.h>`
`int bg_wherey();`

Return value

Function Value	Meaning
0	Cursor on top edge of display
...	
Y _{max}	Cursor on bottom edge of display

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    int y_pos;
    char temp_string [10];

    bg_cleardevice();
    bg_gotoxy(0, 1, CHARACTER);
    y_pos = bg_wherey();
    bg_outtext(itoa(y_pos, temp_string, 10));
}
```

See also `bg_getmaxy`, `bg_wherex`, `bg_gotoxy`

6.8 General Functions

Table 6.8 General BIOS functions

Call	Function	Page
bgen_battstat	Read battery status	106
bgen_crc	Generate CMOS checksum for a specified memory area	107
bgen_init	Initialize BIOS functions	107
bgen_version	Read BIOS version	108

6.8.1 bgen_battstat

Function Read battery status

Syntax `#include <imc01bas.h>`
`unsigned char bgen_battstat(unsigned int function);`

Parameters

Parameter Name	Meaning
function	Subfunction: 0 Battery not under load 1 Battery under load 2 Read battery status

Return value

Function Value	Meaning
0xFF	Battery is okay.
0	Battery is defective.

Description

The function switches test loading of the battery on or off and reads the battery status.

The battery must be under load prior to measurement. How long the battery must be under load depends on when the last measurement was made.

Notes:

- Battery status can only be checked when the battery is under load.
- An erroneous measurement will result when the battery has not been under load for quite some time. Ensure that the battery is under load before testing it. How long the battery must be placed under load depends on when the battery was placed under load last. We recommend placing the battery under load once a day for 15 minutes and then checking the battery status at the end.

Example

```
#include <imc01bas.h>

void waittime(void)
{...
}

void testfunction(void)
{
    bgen_battstat(1)
    waittime ();
    if (!bgen_battstat(2))
        outtext("battery defective");
    bgen_battstat(0)
}
```

6.8.2 bgen_crc

Function Generate CMOS checksum for a specified memory area

Syntax

```
#include <imc01bas.h>
unsigned int bgen_crc(unsigned int init,
                    unsigned long linadr,
                    unsigned int lng);
```

Parameters

Parameter Name	Meaning
init	Starting value for checksum calculation
linadr	Linear starting address for checksum calculation
lng	Area length in bytes

Return value CRC checksum calculated

Description The function calculates the CRC checksum of the specified memory area and adds it to the starting value.

Start addresses (see Figure 2.1)

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    unsigned int crc;
    /* Checksum of 1-Mbyte Flash memory */
    crc = bgen_crc(0, 0x3e00000, 0x100000);
}
```

6.8.3 bgen_init

Function Initialize general BIOS functions

Syntax

```
#include <imc01bas.h>
void bgen_init();
```

Return value None

Description The system already executes this initialization routine for general BIOS functions during startup. It does not need to be called by the user.

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bgen_init();
}
```

6.8.4 bgen_version

Function Read BIOS version

Syntax

```
#include <imc01bas.h>
unsigned char *bgen_version();
```

Return value Pointer to a string containing the version of BIOS (in accordance with C convention with 0x00 as end identifier)

Layout: "V xx.yy"

Example

```
#include <imc01bas.h>
void testfunction(void)
{
    bg_gotoxy(0,1, CHARACTER);
    bg_outtext(bgen_version());
}
```

6.9 Keyboard Functions

Table 6.9 Keyboard functions

Call	Function	Page
bk_getchar	Read character from keyboard	109
bk_keybinit	Initialize keyboard	110
bk_LEDflush	Control keyboard LEDs	111
bk_setkeytab	Load new keyboard table	111

6.9.1 bk_getchar

Function Read character from keyboard

Syntax

```
#include <imc01bas.h>
unsigned int bk_getchar();
```

Return value Character read in:

1st (low) byte: Character code
 2nd (high) byte: State:
 0xFF: Pressed
 0: Released

Description This call can be used to read the last keyboard character recognized. The function should be used within the call back function (see initialization) if you do not want to lose key activations.

Constants for the key codes are defined in header file IMC01BAS.H.

Example

```
#include <imc01bas.h>

void testfunction(void);
{
    union
    {
        int bios_char;
        struct
        {
            char code;
            unsigned char pressed;
        } character;
    } char_union;

    char_union.bios_char = bk_getchar();
    bg_gotoxy(0,0,CHARACTER);
    bg_outchar(char_union.character.code);
}
```

See also bk_setkeytab

6.9.2 bk_keybinit

Function Initialize keyboard

Syntax

```
#include <imc01bas.h>
void bk_keybinit(void (*call_back_fct)());
```

Parameters

Parameter Name	Meaning
*call_back_fct	Pointer to function to be called when keyboard is activated. The call back function does not receive transfer parameters. If you specify a NULL pointer, no function is called when the keyboard is activated.

Return value None

Description The routine initializes keyboard processing and loads the standard keyboard table. It generates a task which cyclically reads the keyboard and calls the specified call back function when a change in status is detected.

BIOS keyboard processing only holds (internally) the last character pressed or released. This character can be read during the call back function with `bk_getchar`.

Note:

The task which processes the keyboard calls the call back function. To maintain interface compatibility with the IMC05, no parameter is provided to set the task priority. Although the system sets this to a fixed value of 10 for the IMC01, it can be changed later by the application with RMOS function `RmSetTaskPriority`. The task ID required by `RmSetTaskPriority` can be determined by the `RmGetEntry` function. File `APLBIOSFIRSTTSK.C` contains an example. For additional information on using these RMOS functions, see the RMOS reference manual.

The call back function which was specified last is always used. This is particularly important to keep in mind when several tasks are to be executed simultaneously.

Example

```
#include <imc01bas.h>
unsigned int key;
void keyprocessing()
{
    key = bk_getchar();
}
void testfunction(void)
{
    bk_keybinit(keyprocessing);
    bg_outtext("keyboard initialized");
}
```

6.9.3 bk_LEDflush

Function Control keyboard LEDs

Syntax

```
#include <imc01bas.h>
void bk_LEDflush(unsigned char value);
```

Parameters

Parameter Name	Meaning																																																																																										
value	Bit pattern for controlling the 8 LEDs Bit = 1: LED is on. Bit = 0: LED is off.																																																																																										
<table border="1"> <thead> <tr> <th>Bit</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> <th>0</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S0</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S1</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S2</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S3</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S4</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S5</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S6</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>LED on key S7</td> </tr> </tbody> </table>		Bit	7	6	5	4	3	2	1	0	Meaning										LED on key S0										LED on key S1										LED on key S2										LED on key S3										LED on key S4										LED on key S5										LED on key S6										LED on key S7
Bit	7	6	5	4	3	2	1	0	Meaning																																																																																		
									LED on key S0																																																																																		
									LED on key S1																																																																																		
									LED on key S2																																																																																		
									LED on key S3																																																																																		
									LED on key S4																																																																																		
									LED on key S5																																																																																		
									LED on key S6																																																																																		
									LED on key S7																																																																																		

Return value None

Example

```
#include <imc01bas.h>
void testfunction(void);
{
    bk_LEDflush(0x01);          /* LED on S3 on. All others off. */
}
```

6.9.4 bk_setkeytab

Function Dummy function for IMC01

Syntax

```
#include <imc01bas.h>
void bk_setkeytab(unsigned char *keybtabs);
```

Parameters

Parameter Name	Meaning
*keybtabs	Pointer to keyboard table

Return value None

Description This is a dummy function for IMC01. It is included for interface compatibility with the IMC05.
This call is used with the IMC05 to provide BIOS with a new keyboard table for converting scan codes to character codes.
Since the scan codes, unlike the key codes, are dependent on the hardware, you should only use the key codes and execute any conversions yourself in your application.

6.10 Functions for Temperature Measurement

Table 6.10 Functions for temperature measurement

Call	Function	Page
bpt_calibrate	Calibrate analog inputs for temperature measurement	112
bpt_gettemp	Determine temperature	113
bpt_init	Initialize analog inputs for temperature measurement	114
bpt_sel_chnum	Switch the temperature channel	114

6.10.1 bpt_calibrate

Function Calibrate temperature inputs

Syntax

```
#include <imc01bas.h>
unsigned int bpt_calibrate(void)
```

Return value

Function Value	Meaning
0	Calibration failed
0xFF	Calibration successful

Description

The function determines the reference voltages of the temperature channels.

These reference voltages are used to generate a so-called temperature equation with which a measured voltage can be converted later on the PT100 to an appropriate temperature.

The function uses `bpt_select` to electrify the reference channels on the basic and expansion board in succession.

While the function is running, no other analog value conversion may be taking place.

The function is called by BIOS during startup. It does not need to be called by the user.

6.10.2 bpt_gettemp

Function Determines temperature of the transferred temperature channel

Syntax

```
#include <imc01bas.h>
unsigned int bpt_gettemp(unsigned int channel)
```

Parameters

Parameter Name	Meaning
Channel	Number of the temperature channel 2 and 3 for the basic board and 6 and 7 for the expansion board (if present)

Return value

Function Value	Meaning
0xFFFF	Invalid
Other	Temperature value in 0.1 degrees

Description

The function switches the PT100 measuring input to the selected channel and waits for a fixed reloading time. It starts the conversion and waits for it to be concluded. The function then returns the temperature value as a return value.

The reloading time is permanently set to 3 msec. Although the calling task is blocked during this time, the system provides computing time for lower-priority tasks.

As an alternative, the reloading time can also be managed by the application itself. If the `bpt_sel_chnum` function is called for the same channel before `bpt_gettemp` is called, `bpt_gettemp` starts the conversion immediately and no longer automatically waits for the reloading time to expire.

Note:

Remember that, when a switch is made between two channels with different potentials, a reload occurs which requires a sufficient waiting period. 3 msec are required for the maximum possible voltage difference.

6.10.3 bpt_init

Function Initialize analog inputs for temperature measurement

Syntax

```
#include <imc01bas.h>
void bpt_init(void);
```

Return value None

Description This function initializes the complete functionality of temperature measurement. Since this function is called already during system startup, it does not need to be called again by the application.

6.10.4 bpt_sel_chnum

Function Switching the temperature channel. The function is only required to speed up processing of bpt_gettemp by disabling a wait time in bpt_gettemp and permitting the application to implement this instead.

Syntax

```
#include <imc01bas.h>
unsigned int bpt_gettemp(unsigned int channel)
```

Parameters

Parameter Name	Meaning
Channel	Number of the temperature channel 2 and 3 for the basic board and 6 and 7 for the expansion board (if present)

Return value

Function Value	Meaning
_TRUE	OK. Function was executed.
_FALSE	Error. Function couldn't be executed.

Description

As an alternative, the reloading time can also be managed by the application itself. If the bpt_sel_chnum function is called for the same channel before bpt_gettemp is called, bpt_gettemp starts the conversion immediately and no longer automatically waits for the reload time to expire.

Note:

Remember that, when a switch is made between two channels with different potentials, a reload occurs which requires a sufficient waiting period. 3 msec are required for the maximum possible voltage difference.

6.11 Functions for Watchdog Processing

Table 6.11 Functions for watchdog processing

Call	Function	Page
bwd_init	Activate/deactivate hardware watchdog	115
bwd_trigger	Trigger hardware watchdog	116

6.11.1 bwd_init

Function Activate/deactivate hardware watchdog

Syntax

```
#include <imc01bas.h>
void bwd_init(unsigned char activate);
```

Parameters

Parameter Name	Value/Meaning
activate	0: Deactivate 1: Activate

Return value None

Description This routine activates or deactivates the hardware watchdog of the IMC01.

If, after activation, the watchdog is not reset cyclically, a hardware reset is triggered.

Example

```
#include <imc01bas.h>
void testtask(void)
{
    bwd_init(1);    /* Watchdog activated */
    while(1)
    {
        bwd_trigger(); /* Trigger watchdog cyclically */
        RmPauseTask(100); /* Wait 100 msec */
    }
}
```

See also bwd_trigger

6.11.2 bwd_trigger

Function Trigger hardware watchdog

Syntax

```
#include <imc01bas.h>
void bwd_trigger();
```

Return value None

Description This routine resets the hardware watchdog of the IMC01. A hardware reset is triggered if this routine is not called within approx. 250 msec after the watchdog was activated.

See also bwd_init

6.12 Functions for DP Slave Programming

Table 6.12 Functions for DP slave programming

Call	Function	Page
dp_GetErrorState	Scan current status of the DP slave	117
dp_GetShortDPVersion	Scan software version	118
dp_GetStationAddress	Scan station address	118
dp_Init	Initialize and start complete DP subunit	119
dp_ReadOutputBuffer	Call output data of DP master	120
dp_WriteInputBuffer	Transfer input data to DP master	121

6.12.1 dp_GetErrorState

Function Scan current status of the DP slave

Syntax

```
void _FIXED _FAR dp_GetErrorState(
    DP_ERROR_STATE _FIXED _FAR *psErrorState)
```

Parameters

Parameter Name	Meaning
psErrorState	Pointer to a structure of type DP_ERROR_STATE (See chapter 6.12.7.)

Return value None

Description This function supplies the current status of the DP slave (IMC01).
The status of a DP slave is primarily of interest if a data transmission has failed.

Example

```
typedef struct
{
    unsigned short wL2dpState;
    /* Current status of the L2DP unit */
    ...unsigned short wL2dpReason;
    /* Reason for the particular status */
} DP_ERROR_STATE;

struct DP_ERROR_STATE dp_status;

dp_GetErrorState(&dp_status);
```

See also dp_ReadOutputBuffer, dp_WriteInputBuffer

6.12.2 dp_GetShortDPVersion

Function Scan software version

Syntax unsigned short _FIXED _FAR dp_GetShortDPVersion(void)

Return value Version identifier:
High byte: Version
Low byte: Release

Description This function supplies the current software version of the DP slave (IMC01).

6.12.3 dp_GetStationAddress

Function Scan station address

Syntax unsigned char _FIXED _FAR dp_GetStationAddress(void)

Return value Current station address of the IMC01 in PROFIBUS-DP system

Description This function supplies the currently set station address of the IMC01. If the master does not assign a new address, the slave address set with dp_Init is used.

6.12.4 dp_Init

Function Initialize and start complete DP subunit

Syntax

```
unsigned short _FIXED _FAR dp_Init (
    unsigned char bParamStationAddress,
    unsigned char bParamTaskPriority,
    unsigned int bParamPauseTime)
```

Parameters

Parameter Name	Meaning
bParamStationAddress	Initial station address of the IMC01 on the PROFIBUS-DP system
bParamTaskPriority	Priority of the DP communication task in the system
bParamPauseTime	Wait time in the endless loop of the DP task This provides computing time for lower-priority tasks.

Return value

Function Value	Meaning
DP_NO_ERR	Function executed successfully
DP_ERR_OUT_OF_MEM	Not enough work memory to set up the DP task
DP_ERR_INVALID_SIZE	Invalid value for stack size of the DP task
DP_ERR_INVALID_STRING	Invalid string for catalog name of the DP task
DP_ERR_INVALID_TASK_ENTRY	Invalid jump address for the DP task
DP_ERR_INVALID_PTR	Character string for the DP task name would trigger a protection violation.
DP_ERR_INVALID_ID	Invalid ID for the DP task
DP_ERR_INVALID_TYPE	Invalid task priority
DP_ERR_TASK_NOT_DORMANT	DP task was not started from the DORMANT state.
DP_ERR_TASK_KILLED	DP task was already killed before being started.
DP_UNKNOWN_ERROR	Unknown error

Description

This function initializes and starts the complete DP subunit. This generates and starts the communication task.

6.12.5 dp_ReadOutputBuffer

Function Call output data of DP master

Syntax `_BOOL _FIXED _FAR dp_ReadOutputBuffer(
 unsigned char _FIXED _FAR *pbReadBuffer)`

Parameter Name	Meaning
pbReadBuffer	Pointer to a buffer with a minimum size of 32 bytes

Function Value	Meaning
_TRUE	Function executed successfully
_FALSE	No valid data stored in the buffer

Description This function calls the output data transferred by the DP master and stores the data in the specified buffer.

During one cycle, the master can transfer 32 bytes to the slave for use as desired.

The received data are only stored in the buffer when the slave is in "data exchange" status.

Note:
 The size of the buffer is not checked. A wrong size may cause the system to crash.

Example

```
#define DP_PERIPH_OUT_LEN      32
    /* Output data from the master's viewpoint */
unsigned char dp_ReadOutBuf[DP_PERIPH_OUT_LEN];
    /**** Read in output data of the DP master */

if (dp_ReadOutputBuffer (&dp_ReadOutBuf[0]) != OK)
    printf ("Error l2dp_ReadOutputBuffer\n");
```

See also dp_GetErrorState

6.12.6 dp_WriteInputBuffer

Function Transfer input data to DP master

Syntax `_BOOL _FIXED _FAR dp_WriteInputBuffer(
unsigned char _FIXED _FAR *pbWriteBuffer)`

Parameter Name	Meaning
pbWriteBuffer	Pointer to a buffer with a minimum size of 32 bytes

Function Value	Meaning
_TRUE	Function executed successfully
_FALSE	No data transferred to the master

Description This function transfers the input data in the specified buffer to the DP master. During one cycle, the master can receive 32 bytes from a slave. The data in the buffer are only transferred to the master when the slave is in "data exchange" status.

Note:
The size of the buffer is not checked. A wrong size may cause the system to crash.

Example

```
#define DP_PERIPH_IN_LEN      32
/* Input data from the master's viewpoint */
unsigned char dp_WriteInBuf[DP_PERIPH_IN_LEN];
/****** Send input I/O to the DP master ***/
if (dp_WriteInputBuffer (&dp_WriteInBuf[0]) != OK)
    printf ("Error l2dp_WriteInputBuffer\n");
```

See also dp_GetErrorState

6.12.7 Structure of DP_ERROR_STATE

Syntax

```
typedef struct
{
    unsigned short wdpState;
    unsigned short wdpReason;
}DP_ERROR_STATE;
```

Structure elements

Name	Meaning
wdpState	Current status of the DP unit
wdpReason	Reason for the status transition

Constants for wdpState

Constant	Meaning
DP_STATE_NO_INIT	Not initialized (original state)
DP_STATE_WAIT_PRM	Slave is waiting to be parameterized by the master.
DP_STATE_WAIT_CFG	Slave is waiting to be configured by the master.
DP_STATE_DATA_EXCHG	Data exchange
DP_STATE_ERROR	Unknown error state

Constants for wdpReason

Constant	Meaning
DP_REASON_NO_INIT	Initialization has still not been performed.
DP_REASON_INIT_DONE	Initialization was performed successfully.
DP_REASON_INIT_FAULT	Error during initialization
DP_REASON_PRM_OK	Parameterization was successful.
DP_REASON_PRM_FALSE	Parameterization failed.
DP_REASON_CFG_OK	Configuration was successful.
DP_REASON_CFG_FALSE	Configuration failed.
DP_REASON_CARRIER_LOST	Transmission medium lost
DP_REASON_MASTER_LOST	Master was concluded.

6.13 Functions of the Hardware Configuration

Table 6.13 Functions of the hardware configuration

Call	Function	Page
imc01ReadHwStatus	Read hardware configuration	124

6.13.1 imc01ReadHwStatus

Function Read hardware configuration

Syntax `#include <imc01bas.h>
IMC1_HW_CONFIG* imc01ReadHwStatus();`

Return value Pointer to a structure of type IMC1_HW_CONFIG

Description The function returns a pointer to a global data field in BIOS which describes the hardware configuration of the device. The structure of the data field is defined in IMC01BAS.H as shown below.

```
typedef struct _IMC1_HW_CONFIG
{
    IMC1_MAINBOARD    mboard;        /* main board */
} IMC1_HW_CONFIG;
```

Example

```
#include <imc01bas.h>
IMC1_HW_CONFIG* pHw;
int i;
i = 0;
while(1)
{
    i++;
    pHw = imc01ReadHwStatus();
    printf ("\n\nmainboard hardware version= %d",
            pHw->mboard.hw_version);
    printf ("\n0: IO-board not present, 1:present = %x",
            pHw->mboard.base_periph);
    printf ("\n0: EXT-board not present, 1:present= %x",
            pHw->mboard.ext_periph);
    printf ("\nRam memory start address= %xh",
            pHw->mboard.sram_linadr);
    printf ("\nRam memory size (only mainboard)= %xh",
            pHw->mboard.sram_size);
    printf ("\nFeprom memory start address= %xh",
            pHw->mboard.feprom_linadr);
    printf ("\nflash eprom memory size in byte= %xh",
            pHw->mboard.feprom_size);
    printf ("\nnumber of digital inputs= %d",
            pHw->mboard.numof_di);
    printf ("\nnumber of digital outputs= %d",
            pHw->mboard.numof_do);
    printf ("\nnumber of analog inputs= %d",
            pHw->mboard.numof_ai);
    printf ("\nnumber of analog outputs= %d",
            pHw->mboard.numof_ao);
    printf ("\nnumber of digital inputs with interrupt= %x",
            pHw->mboard.numof_int_di);
}
```

Structure elements

Element name	Meaning
mboard	Configuration of the basic device. The setup is described in IMC01BAS.H.

7 Appendix

7.1 Key Codes




Figure 7.1 View of the front of the IMC01 with key designations

Key Code	Key
00h	No key
01h	HOME
02h	Arrow up
03h	Arrow down
04h	Arrow to left
05h	Arrow to right
07h	SHIFT
0Ah	// (RESET)
0Eh	ESC
10h	Enter
11h	+/-
2Eh	.

Key Code	Key
30h	S0
31h	S1
32h	S2
33h	S3
34h	S4
35h	S5
36h	S6
37h	S7
38h	S8
39h	S9
41h	F1
42h	F2
43h	F3

7.2 Error Messages during the Loading Procedure

The error messages listed below can be indicated on the development computer during the loading procedure. Commentary is not provided for self-explanatory messages.

```
Error 100: file command.txt not found !
```

```
Error 101: Illegal baud rate
```

Only standard baud rates can be used (e.g., 9600, 19200, and so on).

```
Error 105: Function called with wrong number of parameter !
```

Too many or too few call parameters

```
Error 106: Configuration file not found !
```

The configuration file (e.g., DELFW.CFG) specified for SEND.EXE does not exist.

```
Error 107: Binary file not found !
```

The binary file specified for SEND.EXE does not exist.

```
Error 108: RS232 communication error !
```

Block checksum error of the XMODEM protocol after block was repeated three times

```
Error 109: Illegal 'offset' in configuration file !
```

The specified file offset is larger than the total length of the binary file.

```
Error 110: Illegal 'netto data length' in configuration file !
```

The specified number of bytes to be transferred is greater than the total length of the binary file.

```
Error 112: Key pressed to abort data transfer !
```

Data transmission was terminated by pressing a key.

```
Error 113: Illegal COM channel !
```

Only the COM1 and COM2 interfaces can be used.

8 Abbreviations and Terms

AC	Alternating Current
AD	Analog → Digital
AD conversion	Conversion of analog voltage to a digital value
ASCII	American Standard Code for Information Interchange
BIOS	Basic Input/Output System
BK	Pin terminal
BSP	Board Support Package (i.e., software package with board-related software)
COM1, COM2	Serial interfaces of the development computer
CRC	Determination of a checksum (Cyclic Redundancy Check)
DA	Digital → Analog
DA conversion	Conversion of a digital value into an analog voltage
DC	Direct Current
DI	Digital Input
DIL	Dual in Line
DO	Digital Output
DP	Distributed Periphery
ED	Switch-on duration (percentage)
EMC	Electro-Magnetic Compatibility
EN	European standard
ESD	Electrostatic Sensitive Device
FLASH memory	Non-volatile memory which can be deleted in blocks
FPU	Floating Point Unit, used by the coprocessor
HF	High Frequency
HLL	High Level Language (e.g., C language, in contrast to machine languages such as Assembler)
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LSB	Least Significant Bit
MSB	Most Significant Bit
NMI	Non Maskable Interrupt
PLC	Programmable Logic Controller
PROFIBUS	Process Field Bus
PS	Power Supply
RDC	Direction discriminator
RMOS	Real-time Multitasking Operating System

RTC	Real-Time Clock
SDI	Serial Data Input, signal of an absolute value encoder
Soft-PLC	Software-implemented programmable logic controller
SRAM	Static Random Access Memory
STEP 5	Machine language for programming programmable logic controllers
Zero modem cable	For serial data transfer from the development computer to the IMC01