


Terminal covers

The SZ-T type terminal cover conforms to DIN 57106 and VDE 0106 Teil 100 requirements regarding worker safety. The cover increases safety during maintenance and inspection.

Description	Type	Used with	
For contactor	SZ-T1	SC-03, 0, SH-4	
	SZ-T2	SC-05, SH5	
	SZ-T3	SC-4-0, 4-1	
	SZ-T4	SC-5-1, SJ-1SG	
	SZ-T22	SC-N1, N2	
	SZ-T23	SC-N2S, N3	
	SZ-N4T	SC-N4, N5A	
	SZ-N6T	SC-N6	
	SZ-N7T	SC-N7	
	SZ-N8T	SC-N8, N10	
	SZ-N11T	SC-N11, N12	
For starter	SZ-T1 SZ-T12	SW-03/3H, 0/3H	
	SZ-T2 SZ-T12	SW-05/3H	
	SZ-T3 SZ-T13	SW-4-0/3H, 4-1/3H SJ-1SWG	
	SZ-T4 SZ-T13	SW-5-1/3H	
	SZ-T22 SZ-T16	SW-N1/3H, N2/3H	
	SZ-T23 SZ-T17	SW-N2S/3H, N3/3H	
	SZ-N4T SZ-WN4T	SW-N4/3H, N5A/3H	
	SZ-N6T SZ-WN6T	SW-N6/3H	
	SZ-N7T SZ-WN7T	SW-N7/3H	
	SZ-N8T SZ-WN8T	SW-N8/3H	
	SZ-N8T SZ-WN10T	SW-N10/3H	
	SZ-N11T SZ-WN11T	SW-N11/3H, N12/3H	
	For auxiliary contact block	SZ-T5	SZ-A40, A31, A22, A222 SZ-A40H, A31H, A22H
		SZ-T6 SZ-T7	SZ-A20, A11, A02, A111 SZ-AS1, AS2 SZ-AS1H, AS2H, AS3H
SZ-T12 SZ-T13 SZ-T16 SZ-T17		TR-0N, TK-0N TR-5-1N, TK-5-1N TR-N2, TK-N2 TR-N3, TK-N3	
For thermal overload relay on-contactor mounting	SZ-T14 SZ-T15 SZ-RN6T	TR-N2H, TK-N2H TR-N3H, TK-N3H TR-N6H, TK-N6H	
For thermal overload relay separate mounting	SZ-T10 SZ-T11	SZ-HB SZ-HC	
For coil drive unit	SZ-T7	SZ-CD5, SZ-CD6	



Description	Type	Used with	
For reversing contactor	SZ-T1 SZ-T2 SZ-T3 SZ-T4 SZ-T22 SZ-T23	SC-03RM, 0RM SC-05RM SC-4-0RM, 4-1RM SC-5-1RM SC-N1RM, N2RM SC-N2SRM, N3RM	
	SZ-N4RT1 SZ-N4RT2	SC-N4RM, N5ARM	
	SZ-N6RT1 SZ-N6RT2	SC-N6RM	
	SZ-N7RT1 SZ-N7RT2	SC-N7RM	
	SZ-N8RT1 SZ-N8RT2	SC-N8RM, N10RM	
	SZ-N11RT1 SZ-N11RT2	SC-N11RM, N12RM	
	For reversing starter	SZ-T1 SZ-T12	SW-03RM, 0RM
		SZ-T2 SZ-T12	SW-05RM
		SZ-T3 SZ-T13	SW-4-0RM, 4-1RM
		SZ-T4 SZ-T13	SW-5-1RM
		SZ-T22 SZ-T16	SW-N1RM, N2RM
SZ-T23 SZ-T17		SW-N2SRM, N3RM	

■ Contactors and starters with terminal cover

Contactors, starters, industrial relays, and thermal overload relays with a terminal cover are also available as the finger-protected type for the European market. Suffix the code /T at the end of the type number, when ordering, for this type.

Example

SC-03/T type: Contactor **SC-03**+Terminal cover **SZ-T1**
SW-03/3HT type: Starter **SW-03/3H**+Terminal cover **SZ-T1**+**SZ-T12**