


Dimensions


(Detailed dimension drawings are available for each model on request)

Smooth tube types (thermocouples T, J and K and PT100)


E52-ET_




E52-ELT_



E52-EP_




E52-ELP_




Bayonet mounting types (PT100)

E52-EP6-_-2-B-_-



Compensation connector 1 types (thermocouples J and K)

E52-ETJ-_-C1-_/E52-ETK-_-C1-_-





Note: compatible with female connectors E52-EACC-JF1-_/E52-EACC-KF1-_-


Enclosed terminal types (thermocouples J and K and PT100)

E52-E-_-T2-_-

Smooth tube


G $\frac{1}{2}$ " mounting

Clamp mounting




Surface temperature measurement types

E52-ETJS1-B




E52-ESTPCPAN_




Environment temperature measurement types

E52-EPE1-B





E52-EPE2-B




Non-contact – Infrared sensor types



ES1B



Mounting Lock Nuts (Two) (Provided)




ES1C




Accessories

Compression fittings


E52-EACF1/2_



E52-EACF1/4_




E52-EACFM20




Thermowells

E52-EATW_



Compensation connectors

E52-EACC-_M_-_



E52-EACC-_F_-_

