

# Fuses

## Fuses for Opto 22 Racks

Opto 22 PN	Description	Fuse
G4PB16	G4 16-channel I/O Module Rack	FUSEG4B
G4PB16H	G4 16-channel Rack with Header Connector	FUSE01B (logic) FUSEG4B (I/O)
G4PB16HC	G4 16-channel Rack with Header Connector and Extra Terminal Strip	FUSE01B (logic) FUSEG4B (I/O)
G4PB16I	G4 16-channel I/O Module Rack Isolated Control	FUSEG4B
G4PB16J	G4 DC Input 4–16 VDC 16-channel Integral	FUSE01G4B
G4PB16K	G4 DC Input 16–28 VDC 16-channel Integral	FUSE01G4B
G4PB16L	G4 DC Output 5–60 VDC 16-channel Integral	FUSE01G4B
G4PB16T	G4 16-channel I/O Module Rack Extra Terminal Strip	FUSEG4B
G4PB24	G4 24-channel I/O Module Rack	FUSEG4B
G4PB32DEC	G4 32-channel I/O Module Rack	FUSEG4B
G4PB32H	G4 32-channel Rack with Header Connector for B4 Brain	FUSE02B (logic) FUSEG4B (I/O)
G4PB32JY-IN	G4 32 Point Rack Inputs JYC-systems	FUSE01G4B (logic) FUSEG4B (I/O)
G4PB32JY-OUT	G4 32 Point Rack JYC-systems	FUSE01G4B (logic) FUSEG4B (I/O)
G4PB4	G4 4-channel I/O Module Rack	FUSEG4B
G4PB4R	G4 4-channel Output Module Rack	FUSEG4B
G4PB8	G4 8-channel I/O Module Rack	FUSEG4B
G4PB8H	G4 8-channel Rack with Header Connector	FUSE01B (logic) FUSEG4B (I/O)
G4PB16FB1	Foxboro G4PB16 Single Wetting	FUSE01B (logic) FUSEG4B (I/O)
G4PB16FB2	Foxboro G4PB16 Dual Wetting	FUSE01B (logic) FUSEG4B (I/O)
PB16A	16-channel I/O Module Rack	FUSE05B
PB16AH	16-channel Analog Mounting Rack	FUSE02B
PB16C	16-channel I/O Module Rack Extra Terminal Strip	FUSE05B
PB16H	16-channel Rack with Header Connector	FUSE01B (logic) FUSE05B (I/O)

Opto 22 PN	Description	Fuse
PB16HC	16-channel Rack with Header Connector and Extra Terminal Strip	FUSE01B (logic) FUSE05B (I/O)
PB16HQ	Quad 4-module Position Rack	FUSE01B (logic) FUSE05B (I/O)
PB16J	DC Input 4–16 VDC 16-channel Integral	FUSE01B
PB16K	DC Input 16–28 VDC 16-channel Integral	FUSE01B
PB16L	DC Output 5–60 VDC 16-channel Integral	FUSE01B
PB16P1	Pamux 1	FUSE01B (logic) FUSE05B (I/O)
PB16T	16-channel I/O Module Rack	FUSE05B
PB24	24-channel I/O Module Rack	FUSE01B (logic) FUSE05B (I/O)
PB24HQ	Quad 6-module Position Rack with Header Connector	FUSE01B (logic) FUSE05B (I/O)
PB24Q	Quad 6-module Position Rack	FUSE01B (logic) FUSE05B (I/O)
PB32DEC	Quad 8-module Position Rack	FUSE01B (logic) FUSE05B (I/O)
PB32HQ	Quad 8-module Rack with Header Connector for B4 Brain	FUSE02B (logic) FUSE05B (I/O)
PB32P2	Pamux 2	FUSE02B (logic) FUSE05B (I/O)
PB4	4-channel I/O Module Rack	FUSE05B
PB4H	4-channel Rack with header Connector	FUSE01B (logic) FUSE05B (I/O)
PB4R	4-channel Output Module Rack	FUSE05B
PB8	8-channel I/O Module Rack	FUSE05B
PB8H	8-channel Rack with Header Connector	FUSE05B
SNAP-AIMA-HDB	Breakout Board for SNAP-AIMA-32 Analog Input Module	SNAP-FUSE1AC
SNAP-AIMA-HDB-FM	Breakout Board for SNAP-AIMA-32 Analog Input Module, FM-apprv.	SNAP-FUSE1AC
SNAP-B12M	12-module Rack	SNAP-FUSE4AB
SNAP-B12MC	12-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE4AB
SNAP-B12MC-P	12-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE4AB

Opto 22 PN	Description	Fuse
SNAP-B16M	16-module Rack	SNAP-FUSE4AB
SNAP-B16MC	16-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE4AB
SNAP-B16MC-P	16-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE4AB
SNAP-B16MC-SF1	16-module Smart Rack for Sputter Film	SNAP-FUSE4AB
SNAP-B4M	4-module Brain Rack	SNAP-FUSE4AB
SNAP-B8M	8-module Rack	SNAP-FUSE4AB
SNAP-B8MC	8-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE4AB
SNAP-B8MC-P	8-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE4AB
SNAP-D12M	12-module Rack	SNAP-FUSE1AB
SNAP-D12MC	12-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE1AB
SNAP-D12MC-P	12-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE1AB
SNAP-D4M	4-module Rack	SNAP-FUSE1AB
SNAP-D4MC	4-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE1AB
SNAP-D4MC-P	4-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE1AB
SNAP-D6M	6-module Rack	SNAP-FUSE1AB
SNAP-D6MC	6-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE1AB
SNAP-D6MC-P	6-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE1AB
SNAP-D64RS	SNAP 64-point Digital Rack	SNAP-FUSE4AB
SNAP-D8M	8-module Rack	SNAP-FUSE1AB
SNAP-D8MC	8-module Rack with Extra Terminal Block for Field Wiring	SNAP-FUSE1AB
SNAP-D8MC-P	8-module Rack with Extra Terminal Block for Field Wiring, Pluggable	SNAP-FUSE1AB

Opto 22 PN	Description	Fuse
SNAP-IDC-HDB	Breakout Rack for SNAP 32-channel Digital Input Module	SNAP-FUSE1AC
SNAP-IDC-HDB-FM	Breakout Rack for SNAP 32-channel Digital Input Module, FM-apprv.	SNAP-FUSE1AC
SNAP-ODC-HDB	Breakout Rack for SNAP 32-channel Digital Output Modules	SNAP-FUSE1AC
SNAP-ODC-HDB-FM	Breakout Rack for SNAP 32-channel Digital Output Modules, FM-apprv.	SNAP-FUSE1AC
SNAP-M16	4-module Rack	SNAP-FUSE7.5AB
SNAP-M32	8-module Rack	SNAP-FUSE7.5AB
SNAP-M48	12-module Rack	SNAP-FUSE7.5AB
SNAP-M64	16-module Rack	SNAP-FUSE7.5AB
SNAP-PAC-RCK4	4-module Rack	SNAP-FUSE7.5AB
SNAP-PAC-RCK4-FM	4-module Rack, FM-app.	SNAP-FUSE7.5AB
SNAP-PAC-RCK8	8-module Rack	SNAP-FUSE7.5AB
SNAP-PAC-RCK8-FM	8-module Rack, FM-app.	SNAP-FUSE7.5AB
SNAP-PAC-RCK12	12-module Rack	SNAP-FUSE7.5AB
SNAP-PAC-RCK12-FM	12-module Rack, FM-app.	SNAP-FUSE7.5AB
SNAP-PAC-RCK16	16-module Rack	SNAP-FUSE7.5AB
SNAP-PAC-RCK16-FM	16-module Rack, FM-app.	SNAP-FUSE7.5AB
SNAP-TEX-FB16-H	16-channel Breakout Board, Fuses and Bussed Power (120-240 V)	FUSE01G4B
SNAP-TEX-FB16-L	16-channel Breakout Board, Fuses and Bussed Power (12-24 V)	FUSE01G4B