
Rittal SK



Filterlüfter

Fan-and-Filter Units

Ventilateur à filtre

Ventilator

Filterfläkt

Ventilatore-filtro

Ventilador con filtro SK 3152 1S SK 3167 1S

Montageanleitung
Assembly Instructions
Notice de montage
Montage-instruktle
Montageanvisning
Istruzioni di montaggio
Instrucciones de montaje



English

Technical Data: Rated voltage: Rated current: Nominal output: Speed 50/60 Hz:

Nominal output: Speed 50/60 Hz: Air throughput unimpeded airflow at 50/60 Hz: Temperature range:

lemperature range: Protection category DIN VDE 0470 Part 1/11 92: Noise level

at 50/60 Hz: Duty cycle:

Type of connection:

SK 3152 1S 230 V 50/60 Hz 0.28 A/0.24 A 41 W/38 W 2800/3250 rpm **SK 3167 1S** 115 V 50/60 Hz 0.53 A/0.49 A 40 W/39 W

220/250 m³/h - 10 °C to + 55 °C

46/50 dB (A)

IP 43

100 %

Terminal strip 2.5 mm²

2. Assembly

Observe sequence of assembly 1 – 4, and mounting position! Airflow direction can be changed by reversing the fitting of fan. Fully compatible with the cutouts and holes of the "old" units. Quick-assembly system for fan-and-filter units and outlet filter. Simply snap into place, and that's it.

3. Electrical Connection

Supply voltage and frequency must correspond to the rated values stated on the nameplate. The relevant requirements of the local electricity board must be observed. Electrical connection and repair must be carried out by authorised specialist personnel only. Use original spares only. 4. Filter Replacement and Cleaning

The frequency of filter replacements should be determined individually, depending on dust accumulation and operating period. Note: Filter replacement must be carried out in good time. A soiled filter mat will cause the temperature to rise inside the enclosure!

The filter mat can be regenerated by washing or blowing out.

5. Supply Includes

1 fan-and-filter unit, ready for connection

1 drilling template 4 self-tapping screws BZ 5 x 13

4 sell-tapping sciews bz :

6. Guarantee

We will guarantee this unit, if used correctly, for 1 year in respect of materials and manufacturing faults, from the date of its supply.

7. Waste Disposal

The plastic material used in the components can be recycled

8. Accessories

8.1 Spare fitter mats SK 3172 1S

8.2 By using the sealing frame SK 3192 1S the protection category IP 54 is achieved

8.3 For the filtration of extremely fine dust, use the fine filter mat SK 3182 1S in addition to the standard filter mat.

8.4 Enclosure thermostat SK 3112/13

