Installation Guide for the SRAM Cards

NOTE: SRAM Cards do not come with drivers, it has always been the OS vendor's responsibility to include support for these devices. Unlike previous versions of Windows, the SRAM drivers traditionally included on Windows distributions are not included with Windows 2000/XP.

NOTE: This work around is not guaranteed to work with every system configuration.

NOTE: Be certain Windows 2000/XP is up to date with the latest Service Packs and the host hardware correctly supports PC Cards.

Configuring Cards for Windows 2000 (For SRAM cards only)

1. During the Windows 2000 hardware setup process choose Display a list of known drivers... instead of Search for a suitable driver...
2. Select the category Memory technology driver
3. Select the M-Systems DiskOnChip2000 driver from listed manufacturer M-Systems Flash Disk Pioneers
4. Click Yes on the Update Driver Warning message, continue and click Finish to complete the setup process, click No from the restart Windows message
5. Access the Device Manager and highlight M-Systems DiskOnChip2000 from the category Memory technology driver (it has the conflict symbol)
6. Access the M-Systems DiskOnChip2000 and click Update Driver from the Driver tab
7. Choose Display a list of known drivers... instead of Search for a suitable driver... when the options appear
8. You should now have more default driver options, select the Centennial PCMCIA Memory Card driver from listed manufacturer Centennial Technologies, Inc. (other drivers may work, but the Centennial driver was used successfully in testing)
9. If you do not already have a Centennial driver you can find it under the drivers link.
10. Click Yes on the Update Driver Warning message, continue and click Finish to complete the setup process, click Ok from the properties window then Yes from the restart Windows message
11. When Windows restarts, you should see a new drive letter and icon from "My Computer" or Windows Explorer

Configuring Cards for Windows XP (For SRAM Cards Only)

1. Insert the SRAM card into the PC Card slot
2. When the 'Hardware Wizard' appears, select 'Install from a list or specific location (advanced)'
3. Click 'Next'
4. Select 'Don't search I will choose the driver to install'
5. Click 'Next'
6. Scroll through the list of choice and select 'PCMCIA and Flash memory devices'
7. Click 'Next'
8. Double click 'generic' under the Manufacturer listing
9. Select 'Generic PCMCIA Memory Card' from the Model listing
10. Click 'Next'
11. Click the 'Yes' button when the warning dialog appears, to dismiss it
12. Click 'Finish' when the 'Completing the found new hardware wizard' dialog appears