SIEMENS

Preface, Contents

,	
Product Overview	1
Installation	2
Wiring	3
Commissioning	4
Diagnostics	5
General Technical Data	6
Terminal Blocks and Supplementary Terminals – Technical Data	7
ET 200L Electronics Blocks – Technical Data	8
ET 200L-SC Electronics Blocks – Technical Data	9
SC Digital Electronic Modules – Technical Data	10
SC Analog Electronic Modules – Parameters	11
SC Analog Electronic Modules – Technical Data	12
SC 1COUNT40kHz Counter Module	13
Order Numbers	A
	В
Type and Device Master Files Configuration Frame and	С
Parameterization Frame	D
ESD	

Glossary, Index

SIMATIC

ET 200L, ET 200L-SC and ET 200L-SC IM-SC Distributed I/O Device

Manual

EWA 4NEB 780 6009-02c

Safety Guidelines

This manual contains notices which you should observe to ensure your own personal safety, as well as to protect the product and connected equipment. These notices are highlighted in the manual by a warning triangle and are marked as follows according to the level of danger:



Danger

indicates that death, severe personal injury or substantial property damage will result if proper precautions are not taken.



Warning

indicates that death, severe personal injury or substantial property damage can result if proper precautions are not taken.



Caution

indicates that minor personal injury or property damage can result if proper precautions are not taken.

Note

draws your attention to particularly important information on the product, handling the product, or to a particular part of the documentation.

Qualified Personnel

The device/system may only be set up and operated in conjunction with this manual.

Only **qualified personnel** should be allowed to install and work on this equipment. Qualified persons are defined as persons who are authorized to commission, to ground, and to tag circuits, equipment, and systems in accordance with established safety practices and standards.

Correct Usage

Note the following:



Warning

This device and its components may only be used for the applications described in the catalog or the technical description, and only in connection with devices or components from other manufacturers which have been approved or recommended by Siemens.

This product can only function correctly and safely if it is transported, stored, set up, and installed correctly, and operated and maintained as recommended.



가

Trademarks

SIMATIC® and SINEC® are registered trademarks of SIEMENS AG.

Some of the other designations used in these documents are also registered trademarks; the owner's rights may be violated if they are used be third parties for their own purposes.

Copyright © Siemens AG 1996 All rights reserved

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Siemens AG Automation Group Industrial Automation Systems P.O. Box 4848, D-90327 Nuremberg

Disclaimer of Liability

We have checked the contents of this manual for agreement with the hardware and software described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. However, the data in this manual are reviewed regularly and any necessary corrections included in subsequent editions. Suggestions for improvement are welcomed.

Technical data subject to change. © Siemens AG 1996

Preface

Purpose of the Manual

The information in this manual will enable you to run the ET 200L distributed I/O device and Smart Connect SC in the ET 200 distributed I/O system as a DP slave.

Contents of the Manual

Order number 6ES7 130-1AA00-8AA0 comprises the manual

ET 200L, ET 200L-SC and ET 200L-SC IM-SC Distributed I/O Device, Release 4



- User information on the ET 200L, ET 200L-SC and ET 200L-SC IM-SC (SC = Smart Connect)
- Appendices

Applicability of the Manual

This manual is valid for the components of the ET 200L distributed I/O device and Smart Connect SC specified in Appendix A.

It describes the components valid at the time of publication. We reserve the right to attach current product information on new and updated components.

Changes Since the Previous Manual

Changes have been made since the previous version of this manual, order number 6ES7 130-1AA00-8AA0, Release 3, as regards the following:

- ET 200L-SC IM-SC (fine-step modular I/O device)
- ET 200L: AC terminal block and electronics blocks
- ET 200L-SC: High-speed SC analog input modules and counter module

Standards and Certification

The ET 200L and Smart Connect SC meet the requirements and and criteria of IEC 1131, Part 2 and are based on the EN 50170 Volume 2, PROFIBUS standard. They meet the requirements for the CE marking, and have CSA, UL and FM certification.

You will find detailed information on certification and standards in Section 6.1.

Recycling and Disposal

The ET 200L distributed I/O device and Smart Connect SC are environment-friendly products. They are exceptional for the following:

- Development in accordance with the guidelines for environment-friendly products: SN 36350
- Laser inscriptions (i.e. no labels)
- Plastics identification in accordance with DIN 54840
- Fewer materials used due to size reduction; fewer parts due to integration in ASICs

The ET 200L and Smart Connect SC are recyclable due to their low contaminant content.

To recycle and dispose of your old equipment in an environment-friendly manner, contact:

Siemens Aktiengesellschaft Anlagenbau und Technische Dienstleistungen ATD TD3 Kreislaufwirtschaft Postfach 32 40 D-91050 Erlangen

Phone: +49 91 31/7-3 36 98 Fax: +49 91 31/7-2 66 43

The people there will adapt their advice to suit your situation and provide a comprehensive and flexible recycling and disposal system at a fixed price. After disposal you will receive information giving you a breakdown of the relevant material fractions and the associated documents as evidence of the materials involved.

Other Manuals

In addition to this manual, you will require the manual for the relevant DP master.

CD-ROM

The whole of the ET 200 documentation is also available as a collection on CD-ROM.

Aids to Using the Manual

To enable you to access the information you require as quickly as possible, the manual contains the following aids:

- At the beginning of the manual you will find a complete table of contents and lists of all the figures and tables in the manual.
- In the left-hand margin in each chapter you will find headings that provide you with an overview of the contents of the various sections.
- Following the appendices you will find a glossary, which contains definitions of important terms used in the manual.
- At the end of the manual you will find a detailed index, which gives you rapid access to the information you require.

Additional Support

If you have technical questions, please get in touch with your Siemens representative or office. You will find the address in the manuals of the DP masters (e.g. in the appendix entitled "Siemens Worldwide" of the *S7-300 Programmable Controller; Hardware and Installation* manual) in catalogs and in CompuServe (GO AUTFORUM). A hotline is available on +49 (911) 895-7000 (fax: 7001).

If you require the type file or device master file, you can download it by modem. Dial +49 (911) 737972.

If you have questions or comments about the manual itself, please fill in the form at the end of the manual and send it to the specified address. Please give us your personal assessment of the manual on the form.

To make things easier for those new to the ET 200 distributed I/O device, we offer the "KO-ET 200" workshop. If you are interested, please contact your regional training center or the central training center in D-90327 Nuremberg (tel. 0911 895 3154).

Constantly Updated Information

You can get constantly updated information on SIMATIC products:

- On the Internet at http://www.ad.siemens.de/
- On the fax polling no. +49 8765-93 00 50 00

In addition, SIMATIC Customer Support provides you with current information and downloads that can be useful to you when using SIMATIC products:

- On the Internet at http://www.ad.siemens.de/support/html_00/index.shtml
- At the SIMATIC Customer Support mailbox on +49 (911) 895-7100

To access the mailbox, use a modem of up to V.34 (28.8 kbps) with the following parameter settings: 8, N, 1, ANSI. Alternatively, use ISDN (x.75, 64 kbps).

You can contact SIMATIC Customer Support by phone on +49 (911) 895-7000 and by fax on +49 (911) 895-7002. You can also send queries by e-mail on the Internet or to the above mailbox.

Contents

3.5

3.6

3.7

3.8

3.9

3.10

	Pretace	•	
	Conten	its	
1	Produc	t Overview	1-1
	1.1	What Is the ET 200 Distributed I/O System?	1-2
	1.2 1.2.1 1.2.2 1.2.3	What Is the ET 200L Distributed I/O Device and Smart Connect?	1-3 1-8 1-10 1-13
2	Installa	ition	2-1
	2.1	Installing the ET 200L TB 16L/TB 32L Terminal Block and Supplementary minal	Ter- 2-3
	2.2	Installing and Disassembling the ET 200L Electronics Block	2-6
	2.3	Installing the TB 16IM-SC/TB 16SC Terminal Block	2-7
	2.4	Connecting Smart Connect Electronic Modules to the TB 16IM-SC/TB 16S Terminal Block	C 2-13
	2.5	Installing the ET 200L IM-SC Interface Module on the TB 16IM-SC Termina Block	al 2-17
	2.6	Setting the ET 200L PROFIBUS Address	2-18
	2.7	Installing a supplementary terminal and shield terminal on the TB 16IM-SC TB 16SC terminal block	:/ 2-19
3	Wiring		3-1
	3.1	General Rules and Regulations	3-3
	3.2	Configuring the Electrical Installation	3-5
	3.3	Wiring Rules	3-9
	3.4	Wiring the ET 200L TB 16L/TB 32L Terminal Block	3-11

Wiring the ET 200L TB 16IM-SC Terminal Block

Wiring the ET 200L IM-SC Interface Module

nals

Connecting the Smart Connect SC to the ET 200L-SC/TB 16IM-SC

Connecting Shielded Lines to the Shield Terminal of the Supplementary Termi-

3-14

3-16

3-18

3-22

3-23

3-24

4	Comm	issioning	4-1
	4.1	Configuration Software	4-2
	4.2	Commissioning the ET 200L and Smart Connect	4-3
	4.3	Replacing SC Electronic Modules	4-5
5	Diagno	ostics	5-1
	5.1	Diagnostics Using the LEDs	5-2
	5.2 5.2.1 5.2.2 5.2.3	Slave Diagnostics General Remarks on Diagnostics Structure of the Slave Diagnosis Structure of Station Statuses 1 to 3, Master Station Number and Manufact Identification	5-5 5-6 5-7 urer 5-8
	5.2.4	Structure of the Module Diagnosis for the ET 200L-SC and	
	5.2.5	ET 200L-SC IM-SC	5-10 5-13
	5.2.6	Structure of Slave Diagnosis for Default Start-Up of ET 200L-SC and ET 200L-SC IM-SC	5-15
6	Genera	al Technical Data	6-1
	6.1	Standards and Certification	6-2
	6.2	Electromagnetic Compatibility	6-4
	6.3	Shipping and Storage Conditions	6-6
	6.4	Mechanical and Climatic Environmental Conditions	6-7
	6.5	Details of Insulation Testing, Safety Class, and Degree of Protection	6-8
	6.6	Rated Voltage of the ET 200L Distributed I/O Device	6-9
7	Termin	al Blocks and Supplementary Terminals – Technical Data	7-1
	7.1	Terminal Block TB 16L – 6ES7 193-1CH10-0XA0	7-2
	7.2	Terminal Block TB 32L – 6ES7 193-1CL10-0XA0	7-4
	7.3	Terminal Block TB 16L AC 6ES7 193-1CH20-0XA0	7-7
	7.4	Terminal Block TB 16SC	7-10
	7.5	Terminal Block TB 16IM-SC	7-14
	7.6	Supplementary Terminals for the TB 16L and TB 32L	7-18
	7.7	Supplementary Terminals for the TB 16SC and TB 16IM-SC	7-20
8	ET 200	L Electronics Blocks – Technical Data	8-1
	8.1	Electronics Block L 16 DI DC 24 V - 6ES7 131-1BH00-0XB0	8-3
	8.2	Electronics Block L 16 DO DC 24 V/0.5 A – 6ES7 132-1BH00-0XB0	8-6
	8.3	Electronics Block L 32 DI DC 24 V 6ES7 131-1BL00-0XB0	8-9
	8 4	Electronics Block L 32 DO DC 24 V/0 5 A –6ES7 132-1BI 00-0XB0	8-12

	8.5	Electronics Block L 16 DI/16 DO DC 24 V/0.5 A – 6ES7 133-1BL00-0XB0	8-15
	8.6	Electronics Block L 16 DI AC 120 V – 6ES7 131-1EH00-0XB0	8-18
	8.7	Electronics Block L 16 DO AC 120 V/1.0 A – 6ES7 132-1EH00-0XB0	8-21
	8.8	Electronics Block L 16 RO DC 24 V/AC 120 V/2.0 A – 6ES7 132-1JH00-0XB0	8-24
	8.9	Electronics Block L 8 DI/8 DO AC 120 V/1.0 A – 6ES7 133-1EH00-0XB0	8-28
	8.10	Electronics Block L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0 A – 6ES7 133-1JH00-0XB0	8-31
9	ET 200L	-SC Electronics Blocks – Technical Data	9-1
	9.1	Interface Module IM-SC	9-2
	9.2	Electronics Block L-SC 16 DI DC 24 V – 6ES7 131-1BH11-0XB0	9-4
	9.3	Electronics Block L-SC 16 DO DC 24 V/0.5 A $-$ 6ES7 132-1BH11-0XB0 .	9-7
	9.4	Electronics Block L-SC 32 DI DC 24 V – 6ES7 131-1BL11-0XB0	9-10
	9.5	Electronics Block L-SC 16 DI/16 DO DC 24 V/0.5 A – 6ES7 133-1BL10-0XB0	9-13
10	SC Digit	al Electronic Modules – Technical Data	10-1
	10.1	Digital Electronic Module 2DIDC24V	10-2
	10.2	Digital Electronic Module 2DODC24V0.5A	10-5
	10.3	Digital Electronic Module 2DODC24V2A	10-8
	10.4	Digital Electronic Module 1DIAC120/230V	10-11
	10.5	Digital Electronic Module 1DOAC120/230V1A	10-14
	10.6	Digital Electronic Module 1DORel.AC230V, DC 24 V to 120 V	10-17
11	SC Anal	og Electronic Modules – Parameters	11-1
	11.1	Parameters of the Analog Input Modules	11-2
	11.2	Notes on the Parameters of the Analog Input Modules	11-4
	11.3	Default Parameters of the Analog Input Modules	11-6
	11.4	Behavior of the Analog Input Modules	11-7
	11.5	Conversion and Cycle Times of the Analog Input Channels	11-8
	11.6	Connecting Thermocouples	11-9
	11.7	Connecting Non-Isolated Voltage Sensors	11-14
	11.8	Connecting Current Sensors	11-15
	11.9	Connecting resistance thermometers and resistors	11-17
	11.10	Floating Measuring Sensors	11-18
	11.11	Wiring Unused Inputs of Analog Input Modules	11-19
	11.12	Parameters of the Analog Output Modules	11-20
	11.13	Notes on the Parameters of the Analog Output Modules	11-21

	11.14	Default Parameters of the Analog Output Modules	11-22
	11.15	Behavior of the Analog Output Modules	11-23
	11.16	Conversion, Cycle, Settling and Response Times of the Analog Output Modules	11-24
	11.17	Connecting Loads/Actuators to Analog Outputs	11-26
	11.18	Wiring Unused Analog Output Modules	11-28
	11.19	Analog Value Representation in S7 Number Format	11-29
	11.20	Analog Measurement Ranges for Input Channels in S7 Number Format .	11-30
	11.21	Analog Value Representation for Analog Input Modules in S7 Number Format	11-32
	11.22	Analog Output Ranges for Output Channels in S7 Number Format	11-37
	11.23	Analog Value Representation for Output Modules in S7 Number Format .	11-39
	11.24	Analog Value Representation in S5 Number Format	11-41
	11.25	Analog Measurement Ranges for Input Channels in S5 Number Format .	11-43
	11.26	Analog Value Representation for Analog Input Modules in S5 Number Format	11-45
	11.27	Analog Output Ranges for Output Channels in S5 Number Format	11-50
	11.28	Analog Value Representation for Output Modules in S5 Number Format .	11-52
12	SC Anal	og Electronic Modules – Technical Data	12-1
	12.1	Analog Electronic Module 2 Al U	12-2
	12.2	High-Speed Analog Electronic Module 2 AI HS U	12-8
	12.3	Analog Electronic Module 2 Al I (123-1GB00)	12-14
	12.4	Analog Electronic Module 2 Al I (123-1GB10)	12-20
	12.5	High-Speed Analog Electronic Module 2 AI HS I (0/4-20 mA, 4-Wire Measuring Transducer)	12-26
	12.6	High-Speed Analog Electronic Module 2 AI HS I (4–20 mA, 2-Wire Measuring Transducer)	12-32
	12.7	Analog Electronic Module 2 Al TC	12-38
	12.8	Analog Electronic Module 1 AI RTD	12-44
	12.9	Analog Electronic Module 1 AO U	12-50
	12.10	Analog Electronic Module 1 AO I	12-54
13	The 1C	OUNT40kHz Counter Module	13-1
	13.1	Front and Side Elevations	13-2
	13.2	Block Diagram	13-3
	13.3 13.3.1 13.3.2 13.3.3	Functions of the Counter Module	13-4 13-7 13-8 13-9

	13.4 13.4.1 13.4.2	Wiring the Counter and Putting the Counter into Operation Wiring the Counter Putting the Counter into Operation	13-15
	13.5	Parameters of the Counter Module	13-17
	13.6	Subdivision of the Data Areas	13-19
	13.7	Application Examples	13-21
	13.8	Technical data	13-25
Α	Order N	umbers	A-1
	A.1	Order Numbers for ET 200L Components	A-2
	A.2	Order Numbers for Smart Connect SC Components	A-6
	A.3	Order Numbers for PROFIBUS Accessories	A-9
В	Type an	d Device Master Files	B-1
С	Configu	ration Frame and Parameterization Frame for the ET 200L	C-1
	C.1	Identifiers for the ET 200L	C-2
	C.2	Types of ET 200L-SC or ET 200L-SC IM-SC Start-Up	C-3
	C.3 C.3.1 C.3.2 C.3.3	Configuration Frame for the ET 200L-SC	C-4 C-6 C-9 C-11
	C.4 C.4.1 C.4.2 C.4.3 C.4.4 C.4.5 C.4.6	Parameterization Frame for the ET 200L-SC or ET 200L-SC IM-SC Standard Section and Parameters for the Status Parameters for the Smart Connect Section Data Record 0 Data Record 128 Data Record 130 Parameterization Frame Example	C-14 C-16 C-17 C-19 C-20 C-22 C-27
	C.5 C.5.1 C.5.2	Default Start-up Default Start-up with Digital Smart Connect Modules Default Start-Up with Analog Smart Connect Modules	C-31 C-32 C-36
D	Guidelir	nes for Handling Electrostatically Sensitive Devices (ESD)	D-1
	D.1	What is ESD?	D-2
	D.2	Electrostatic Charging of Persons	D-3
	D.3	General Protective Measures Against Electrostatic Discharge Damage	D-4
	Glossar	у	

Index

Figures

1-1	A Typical PROFIBUS-DP Installation	1-2
1-2	View of the ET 200L Distributed I/O Device	1-8
1-3	ET 200L-SC IM-SC	1-13
2-1	Installing the Terminal Block	2-4
2-2	Disassembling the Terminal Block	2-5
2-3	Installing the Electronics Block	2-6
2-4	Snapping the Terminal Block onto the Rail	2-8
2-5	Sliding the Labeling Strip into the Terminal Block	2-9
2-6	Positioning the Coding Slide Switches	2-11
2-7	Using the Screwdriver	2-11
2-8	Designation Plate with Labeling Strips (Reduced in Size)	2-12
2-9	Connecting the Electronic Modules to the Terminal Block	2-15
2-10	Installing the IM-SC Interface Module	2-17
2-11	Securing a Supplementary Terminal to the Terminal Block	2-19
2-12	Connecting a Shield Terminal to the Supplementary Terminal	2-20
3-1	Operating the ET 200L from a Grounded Supply	3-7
3-2	Power Supply of the Terminal Block	3-8
3-3	How the Spring Terminal Works	3-10
3-4	Terminal Connections on Terminal Block TB 16L	3-11
3-5	Alternative Ways of Connecting the Voltage Supply	3-12
3-6	Front View of the Terminal Block	3-14
3-0 3-7	Connections of the TB 16IM-SC Terminal Block	3-16
3- <i>1</i> 3-8	Connection Alternatives for the Power Supply	3-17
3-9	Connections of the IM-SC Interface Module	3-17
3-10	Length of Insulation Stripped	3-10
3-10	Wiring the PROFIBUS-DP Screw-Type Terminal	3-20
3-11	Connecting the Power Supply	3-21
3-12	Functioning of the Bus Terminating Switch	3-21
5-13 5-1	Structure of the Slave Diagnosis	5-7
5-1 5-2	Structure of the Module Diagnosis with the COM/S7 Configuration Software	
J-Z	the ET 200L-SC	5-10
5-3	Structure of the Module Diagnosis with the COM/S7 Configuration Software	
J-J	the ET 200L-SC IM-SC	5-11
5-4	Structure of the Module Diagnosis with any Configuration Software for the	J-11
J- 4	ET 200L-SC, ET 200L-SC IM-SC	5-12
5-5	Structure of Station Diagnosis	5-12
5-6	Slave Diagnosis for Default Start-up of the ET 200L-SC and	J-10
3-0	ET 200L-SC IM-SC	5-15
7-1	The TB 16L Terminal Block with the Electronics Block Clipped On, Dimensi	
7-1	Drawing	7-2
7-2	The TB 32L Terminal Block with the Electronics Block Clipped On, Dimensi	
1-2	Drawing	7-5
7-3	The TB 16L AC Terminal Block with the Electronics Block Mounted, Dimens	
7-3	Drawing (mm)	7-8
7-4	Front Elevation of the Terminal Block	7-12
7-4 7-5	Block Diagram of the TB16 SC Terminal Block.	7-12
7-5 7-6	The TB 16IM-SC Terminal Block with the IM-SC Interface Module Mounted	
7-0		, 7-16
7-7	Dimension Drawing	7-10
7-7 7-8	Block Diagram of the TB 16IM-SC Terminal Block	7-17 7-19
7-6 7-9	TB 16L/TB 32L Supplementary Terminals, Dimension Drawing TB 16SC/TB 16IM-SC Supplementary Terminals, Dimension Drawing	7-18
1-9	10 1000/10 101101-30 Supplementary Terminals, Dimension Drawing	1-20

8-1	View of the L 16 DI DC 24 V Electronics Block	8-3
8-2	Block Diagram of the L 16 DI DC 24 V Electronics Block	8-4
8-3	View of the L 16 DO DC 24 V/0.5 A Electronics Block	8-6
8-4	Block diagram of the L 16 DO DC 24 V/0.5 A Electronics Block	8-7
8-5	View of the L 32 DI DC 24 V Electronics Block	8-9
8-6	Block diagram of the L 32 DI DC 24 V Electronics Block	8-10
8-7	View of the L 32 DO Electronics Block DC 24 V/0.5 A	8-12
8-8	Block Diagram of the L 32 DO DC 24 V/0.5 A Electronics Block	8-13
8-9	View of the L 16 DI/16 DO DC 24 V/0.5 A Electronics Block	8-15
8-10	Block Diagram of the L 16 DI/16 DO DC 24 V/0.5 A Electronics Block	8-16
8-11	View of the L 16 DI AC 120 V Electronics Block	8-18
8-12	Block Diagram of the L 16 DI AC 120 V Electronic Block	8-19
8-13	View of the L 16 DO AC 120 V/1.0 A Electronics Block	8-21
8-14	Block Diagram of the L 16 DO AC 120 V/1.0 A Electronics Block	8-22
8-15	View of the L 16 RO DC 24 V/AC 120V/2.0 A Electronics Block	8-24
8-16	Block Diagram of the L 16 RO DC 24 V/AC 120 V/2.0 A Electronics Block	8-25
8-17	View of the L 8 DI/8 DO AC 120 V/1.0 A Electronics Block	8-28
8-18	Block Diagram of the L 8 DI/8 DO AC 120 V/1.0 A Electronics Block	8-29
8-19	View of the L 8DI AC 120 V/8 RO DC 24 V/AC 2.0A Electronics Block	8-31
8-20	Block Diagram of the L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0A Elect	tron-
	ics Block	8-32
9-1	IM-SC Interface Module	9-2
9-2	Block Diagram of the IM-SC Interface Module	9-3
9-3	View of the L-SC 16 DI DC 24 V Electronics Block	9-4
9-4	Block Diagram of the L-SC 16 DI DC 24 V Electronics Block	9-5
9-5	View of the L-SC 16 DO DC 24 V/0.5 A Electronics Block	9-7
9-6	Block diagram of the L-SC 16 DO DC 24 V/0.5 A Electronics Block	9-8
9-7	View of the L-SC 32 DI DC 24 V Electronics Block	9-10
9-8	Block diagram of the L-SC 32 DI DC 24 V Electronics Block	9-11
9-9	View of the L-SC 16 DI/16 DO DC 24 V/0.5 A Electronics Block	9-13
9-10	Block Diagram of the L-SC 16 DI/16 DO DC 24 V/0.5 A Electronics Block	9-14
10-1	Front and Side Elevations of the 2DIDC24V Digital Electronic Module	10-2
10-2	Block Diagram of the 2DIDC24V Digital Electronic Module	10-3
10-3	Front and Side Elevations of the 2DODC24V0.5A Digital Electronic	
	Module	10-5
10-4	Block Diagram of the 2DODC24V0.5A Digital Electronic Module	10-6
10-5	Front and Side Elevations of the 2DODC24V2A Digital Electronic Module	10-8
10-6	Block Diagram of the 2DODC24V2A Digital Electronic Module	10-9
10-7	Front and Side Elevations of the 1DIAC120/230V Digital Electronic	
	Module	10-11
10-8	Block diagram of the 1DIAC120/230V Digital Electronic Module	10-12
10-9	Front and Side Elevations of the 1DOAC120/230V1A Digital Electronic	
	Module	10-14
10-10	Block Diagram of the 1DOAC120/230V1A Digital Electronic Module	10-15
10-11	Front and Side Elevations of the 1DORel.AC230V Digital Electronic	
	Module	10-17
10-12	Block Diagram of the 1DORel.AC230V Digital Electronic Module	10-18
11-1	Structure of Thermocouples	11-9
11-2	Connecting Insulated Thermocouples Without Compensation, With Interna	al
	Compensation, or Use of the Reference Temperature	
	(Example TB 16SC)	11-11

11-3	Connecting Insulated Thermocouples of the Same Type with External Conpensation, via a Resistance Thermometer Connected to the Resistance M	
44 4	surement Module, to Slot A of the Terminal Block (Example TB 16SC)	_
11-4	Connecting Voltage Sensors (Example TB 16SC)	11-14
11-5	Connecting 4-Wire Measuring Transducers (Example TB 16SC)	11-15
11-6	Connecting 2-wire measuring transducers (Example TB 16SC)	11-16
11-7	4-Conductor Connection for Resistance Thermometers and Resistors (Ex	
	ple TB 16SC)	11-17
11-8	Response Time of the Analog Output Channels	11-25
11-9	Connecting Loads/Actuators to a Current Output (Example TB 16SC)	11-26
11-10	Connecting Loads/Actuators to a Voltage Output via a 4-Wire Circuit (Exar	-
	TB 16SC)	11-27
12-1	Front and Side Elevations of the 2 Al U Analog Electronic Module	12-2
12-2	Block Diagram of the 2 AI U Analog Electronic Module	12-3
12-3	Jump response	12-5
12-4	Front and Side Elevations of the 2 AI HS U High Speed Analog Electronic	
	Module	12-8
12-5	Block Diagram of the 2 AI HS U High-Speed Analog Electronic Module .	12-9
12-6	Jump response	12-11
12-7	Front and Side Elevations of the 2 Al I Analog Electronic Module	12-14
12-8	Block Diagram of the 2 Al I Analog Electronic Module	12-15
12-9	Jump Response	12-17
12-10	Front and Side Elevations of the 2 Al I Analog Electronic Module	12-20
12-11	Block Diagram of the 2 Al I Analog Electronic Module	12-21
12-12	Jump Response	12-23
12-13	Front and Side Elevations of the 2 Al HS I High-Speed Analog Electronic N	√lod-
	ule (0/4–20mA, 4-Wire Measuring Transducer)	12-26
12-14	Block Diagram of the 2 Al HS I High-Speed Analog Electronic Module	
	(0/4–20mA, 4-Wire Measuring Transducer)	12-27
12-15	Jump Response	12-29
12-16	Front and Side Elevations of the 2 Al HS I High-Speed Analog Electronic N	
	ule (4–20mA, 2-Wire Measuring Transducer)	12-32
12-17	Block Diagram of the 2 Al HS I High-Speed Analog Electronic Module (4–2	
	2-Wire Measuring Transducer)	12-33
12-18	Jump response	12-35
12-19	Front and Side Elevations of the 2 Al TC Analog Electronic Module	12-38
12-20	Block Diagram of the 2 Al TC Analog Electronic Module	12-39
12-21	Jump Response	12-41
12-22	Front and Side Elevations of the 1 Al RTD Analog Electronic Module	12-44
12-23	Block Diagram of the 1 Al RTD Analog Electronic Module	12-45
12-24	Jump Response	12-47
12-25	Front and Side Elevations of the 1 AO U Analog Electronic Module	12-50
12-25	Block Diagram of the 1 AO U Analog Electronic Module	12-50
12-20	Front and Side Elevations of the 1 AO I Analog Electronic Module	12-51
12-27	Block Diagram of the 1 AO I Analog Electronic Module	12-55
13-1	Front and Side Elevations of the 1COUNT40kHz Counter Module	13-2
13-1		13-2
13-2	Block Diagram of the 1COUNT40kHz Counter Module	13-3
13-3 13-4	Continuous Upward Counting	13-4
13-4 13-5	<u> </u>	13-4
	Single-Pass Upward Counting	13-5
13-6 13-7	Single-Pass Downward Counting	13-5
1.3-/	OHORER 455 COURTING WITH LOADED VAIDE AND CARE FUNCTION	1.7-7

13-8	Periodic Upward Counting	13-6
13-9	Periodic Downward Counting	13-6
13-10	Signals of a 24V Pulse Initiator with Direction Indicator	13-7
13-11	Opening and Closing of a Gate	13-8
13-12	Example 1: The Output Is Set to Be Active from the Comparison Value to	
	Overflow	13-12
13-13	Example 2: The Output Is Set to Be Active from the Comparison Value to I	Un-
	derflow	13-12
13-14	Example 3: The Output Is Set to Be Active for the "Pulse Duration on Read	ching
	the Comparison Value Counting Upward"	13-13
13-15	Example 4: The Output Is Set to Be Active for the "Pulse Duration on Read	ching
	the Comparison Value Counting Downward"	13-13
13-16	Example 5: The Output Is Set to Be Active for the "Pulse Duration on Read	ching
	the Comparison Value Counting Upward/Downward"	13-13
13-17		13-15
13-18	Example 1	13-21
13-19	Example 1, Continued	13-22
13-20	Example 2	13-23
13-21	Example 2, Continued	13-24
A-1	Labeling Strips 6ES7 193-1BH00-0XA0	A-4
A-2	Labeling Strips 6ES7 193-1BL00-0XA0	A-5
A-3	Labeling Strips for Smart Connect	A-8
C-1	Structure of the Parameterization Frame of the ET 200L-SC and	
	ET 200L-SC IM-SC	C-14
C-2	Standard Section of the Parameterization Frame	C-16
C-3	Parameters for the Status	C-16
C-4	Structure of Data Record 0	C-19
C-5	Structure of the Header of Data Record 128	C-20
C-6	Structure of Data Record 128, Bytes 7 to 62	C-21
C-7	Structure of the Header of Data Record 128	C-22
C-8	Structure of Data Record 130 for Single-Channel Modules	C-23
C-9	Structure of Data Record 130 for Two-Channel Modules	C-23
C-10	Structure of Data Record 130 for the 1COUNT40kHz Counter Module	C-24
C-11	Al Parameters in Byte 12 or 17 of DS130	C-25
C-12	1COUNT40kHz Counter Module - Purpose of Bytes 11 to 17 of Data Reco	ord
	130	C-26
C-13	Structure of the Parameterization Frame	C-34
C-14	Default Setting for Digital SC Modules with the ET 200L-SC	C-34
C-15	Default Setting for Digital SC Modules with the ET 200L-SC IM-SC	C-35
C-16	Structure of the Parameterization Frame	C-37
C-17	Default Setting for Analog Smart Connect Modules	C-38
D-1	Electrostatic Voltages which can Build up on a Person	D-3

Tables

1-1	General Components for the ET 200L, ET 200L-SC, ET 200L-SC IM-SC	1-6
1-2	Components of the ET 200L Distributed I/O Device	1-9
1-3	Components of a ET 200L-SC	1-11
1-4	Components of an ET 200L-SC IM-SC	1-14
3-1	DIN VDE Regulations for Installation of a Controller	3-5
3-2	Pinout of the PROFIBUS-DP Terminal Connection	3-9
3-3	Pinout of the PROFIBUS-DP Terminal Connection	3-13
3-4	Assignment of the PROFIBUS-DP Connection at the IM-SC	
	Interface Module	3-19
3-5	Assignment of the Power Supply	3-21
5-1	Diagnostics Using the LED Display	5-2
5-2	Diagnostics Using the LEDs of the ET 200L-SC or ET 200L-SC IM-SC	5-3
5-3	Function Blocks for Slave Diagnosis	5-7
5-4	Structure of Station Status 1 (Byte 0)	5-8
5-5	Structure of Station Status 2 (Byte 1)	5-9
5-6	Bytes 13 to 16 for the Diagnostic Interrupt	5-14
6-1	Rated Voltage of the ET 200L Distributed I/O Device	6-9
7-1	Pinout of the TB 16L Terminal Block	7-3
7-2	Pinout of the TB 32L Terminal Block	7-6
7-3	Pinout of the TB 16L AC Terminal Block	7-9
7-4	Supplied Versions of the Supplementary Terminals	7-18
7-5	Supplied Versions of the Supplementary Terminals	
	TB16SC/ TB 16IM-SC	7-20
8-1	Assignment of the ET 200L Electronic Blocks to the Terminal Blocks	8-1
8-2	Service Life of the Contacts	8-27
8-3	Service Life of the Contacts	8-34
9-1	Assignment of the Interface Module/ET 200L-SC Electronics Blocks to the	
	minal Blocks	9-1
10-1	Switching capacity and lifetime of the contacts	10-20
11-1	Default Parameters of the Analog Input Modules	11-6
11-2	Effect of the Operating Mode of the CPU and the Supply Voltage L+ on the	
44.0	Analog Input Values	11-7
11-3	Compensation of the Reference Junction Temperature	11-10
11-4	Parameters of the Analog Output Modules	11-20
11-5	Output Types/Output Ranges of the Analog Output Modules	11-21
11-6	Default Parameters of the Analog Output Modules	11-22
11-7	Effect of the Operating Mode of the CPU and the Supply Voltage L+ on the	
11 0	Analog Output Values	11-23
11-8	Bipolar Input Ranges	11-30
11-9	Unipolar Input Ranges	11-30
11-10	Life-Zero Input Ranges	11-31 11-37
11-11	Bipolar Output Ranges	
11-12	Unipolar Output Ranges	11-37
11-13	Life-Zero Output Ranges	11-38
11-14	Representation of the Measurement Ranges for Analog Inputs	11-41
11-15	Representation of the Measurement Rangesfor Analog Outputs	11-42
11-16	Bipolar Input Ranges	11-43 11-43
11-17	Unipolar Input Ranges	11-43
11-18	Life-Zero Input Ranges	
11-19	Bipolar Output Ranges	11-50
11-20	Unipolar Output Ranges	11-50

11-21	Life-Zero Output Ranges	11-51
12-1	Static Parameters of the 2 Al U Electronic Module	12-4
12-2	Static Parameters of the 2 Al HS U HighSpeed Electronic Module	12-10
12-3		12-16
12-4	Static Parameters of the 2 Al I Electronic Module	12-22
12-5	Static Parameters of the 2 AI HS I Electronic Module	12-28
12-6	Static Parameters of the 2 AI HS I Electronic Module (4-20mA, 2-Wire Mea	asur-
	ing Transducer)	12-34
12-7	Static Parameters of the 2 AI TC Electronic Module	12-40
12-8		12-40
12-9	Static Parameters of the 2 AI RTD Electronic Module	12-46
12-10		12-52
12-11		12-56
13-1	Displays, Colour and Functions of the LEDs	13-2
13-2	Parameter List	13-17
A-1	Terminal Block Order Numbers	A-2
A-2	Electronics Block Order Numbers	A-2
A-3	Supplementary Terminal Order Numbers	A-3
A-4	Terminal Block and Terminal Order Numbers	A-6
A-5	Digital SC Electronic Module Order Numbers	A-6
A-6	Analog SC Electronic Module Order Numbers	A-7
A-7	Function Modules	A-7
A-8	Accessories for the ET 200 Distributed I/O Device	A-9
A-9	Manuals for STEP 7 and SIMATIC S7	A-10
A-10	Manuals for ET 200 on SIMATIC S5	A-10
B-1	Version der Projektier-Software	B-2
B-2	Data for PROFIBUS-DP	B-3
B-3	Maximum Number of Inputs and Outputs with the ET 200L	B-4
B-4	Maximum Number of Inputs and Outputs with the ET 200L-SC or	
	ET 200L-SC IM-SC	B-4
C-1	DP Identifiers for the ET 200L	C-2
C-2	Types of ET 200L-SC of ET 200L-SC IM-SC Start-Up	C-3
C-3	Structure of the Configuration Frame	C-4
C-4	Identifiers for the ET 200L-SC	C-6
C-5	Identifiers for the Smart Connect with Digital ET 200L-SC Modules	C-7
C-6	Identifiers for the Smart Connect with Analog ET 200L-SC Modules	C-7
C-7	Identifiers for the Smart Connect with Digital ET 200L-SC IM-SC Modules	C-9
C-8	Identifiers for the Smart Connect with ET 200L-SC IM-SC	0 0
	Analog Modules	C-9
C-9	Data Records for the ET 200L-SC	C-17
C-10	Data Records for the ET 200L-SC IM-SC	C-18
C-11	Al Parameters in Byte 11 and 16 of DS130	C-24
C-12	AO Parameters in Byte 11 or 16 of DS130	C-25
C-13	ET 200L-SC IM-SC Example	C-27
C-14	Type Files for the ET 200L-SC Default Start-up with Digital SC Modules .	C-32
C-15	ET 200L-SC: Configuration Frame Extension for Analog Smart Connect M	
5 .5	ules	C-36
C-16	ET 200L-SC IM-SC: Configuration Frame Extension for Analog Smart Con	
-	Modules	C-36

Product Overview 1

In This Chapter

The product overview provides information about

- The role of the ET 200L distributed I/O device and Smart Connect within the ET 200 distributed I/O system.
- The components which make up the ET 200L distributed I/O device.
- The components which make up the Smart Connect SC.
- How the components of the ET 200L and Smart Connect SC can be used together.

Contents of the Chapter

Section	Subject	Page
1.1	What Is the ET 200 Distributed I/O System?	1-2
1.2	What Is the ET 200L Distributed I/O Device?	1-3

1.1 What Is the ET 200 Distributed I/O System?

What Is the ET 200?

When a system is installed, the input/output modules are normally installed centrally in the programmable logic controller.

If inputs and outputs are made at long distances from the programmable logic controller, there may be long runs of cabling which are not immediately comprehensible, and electromagnetic interference may impair reliability.

In such systems, we recommend you to use the ET 200 distributed I/O system:

- The controller CPU is located centrally.
- The I/O (input/output) system operates locally in a distributed fashion.
- The ET 200 high-performance bus system ensures that the CPU and I/O system communicate with each other without problems owing to its high data transfer rates.

What Does the ET 200 Consist Of?

The ET 200 distributed I/O system consists of active (master) and passive (slave) nodes that are interconnected via the PROFIBUS-DP.




Figure 1-1 A Typical PROFIBUS-DP Installation

PROFIBUS-DP

PROFIBUS-DP (DP means distributed I/O) is an open bus system conforming with EN 50170 Volume 2, PROFIBUS. The PROFIBUS-DP consists of a DP master and DP slaves.

- **DP master**: The link between the controller and the distributed I/O system is the DP master. The DP master exchanges data with the distributed I/O system over the PROFIBUS-DP and monitors the field bus.
- **DP slave**: The I/O devices are connected as DP slaves. DP slaves process data locally from the sensors and signal control elements in such a manner that they can be transferred over the PROFIBUS-DP field bus.

1.2 What Is the ET 200L Distributed I/O Device and Smart Connect?

Definition

The ET 200L distributed I/O device and Smart Connect is a DP slave within the ET 200 distributed I/O system, its degree of protection being IP 20.

Applications

Owing to its compact and flat design, the ET 200L distributed I/O device and Smart Connect is particularly suitable for applications in which space is at a premium. The ET 200L distributed I/O device and Smart Connect has been designed for the low-end to medium performance ranges.

The ET 200L and Smart Connect is available in three versions:


- The ET 200L block I/O device
- The ET 200L-SC modular I/O device
- The ET 200L-SC IM-SC fine-step modular I/O device

ET 200L Block I/O Device

The ET 200L block I/O device is not expandable.

The ET 200L consists of a terminal block for the wiring, to which an electronics block is connected. The electronics block determines the number of input/output channels.

The ET 200L block I/O device is available with 16 or 32 channels.




ET 200L-SC Modular I/O Device

The ET 200L-SC modular I/O device can be upgraded with the SIMATIC Smart Connect.

The ET 200L-SC also consists of a terminal block to which an electronics block is connected. The electronics block has an interface for connecting the SIMATIC Smart Connect.

The Smart Connect (SC) consists of a TB 16SC terminal block and up to 8 SC electronic modules. There are one- and two-channel SC electronic modules for digital and analog inputs/outputs or for count functions.




ET 200L-SC IM-SC Fine-Step Modular I/O Device

The ET 200L-SC IM-SC fine-step modular I/O device can be upgraded with the SIMATIC Smart Connect.

The ET 200L-SC IM-SC consists of a TB 16IM-SC terminal block to which you can connect the IM-SC interface module and up to 8 Smart Connect electronic modules.

The IM-SC interface module connects the ET 200L-SC IM-SC to the PROFIBUS-DP.

You can add the TB 16SC to the ET 200L-SC IM-SC, thus allowing you to run an additional 8 SC electronic modules.



General Components for the ET 200L, ET 200L-SC,

A range of components are available for setting up the ET 200L,

 ${\rm ET~200L\text{-}SC}$ or ${\rm ET~200L\text{-}SC}$ IM-SC. You will find the components that you

require for all versions of the ET 200L in Table 1-1.

ET 200L-SC IM-SC You will find other components in Sections 1.2.1 to 1.2.3.

Table 1-1 General Components for the ET 200L, ET 200L-SC, ET 200L-SC IM-SC

Component	Function	Illustration
Rail (EN 50022, 35 × 15 or 35 × 7.5)	is the mounting rack for the ET 200L.	
Power supply (PS)	converts the mains voltage (120/230 VAC) into a 24 V DC operating voltage for supplying the ET 200L.	
	is the load current power supply for the 24 V DC load circuits.	00000000000000000000000000000000000000
PROFIBUS cables with bus connector	interconnect the nodes of a PROFIBUS-DP installation.	

Terminal Block

The terminal block (TB) is used for mounting the electronics block (EB). It contains the wiring so that if the electronics block is replaced, leads do not have to be loosened.

The terminal block is characterized by the following:

- It can be pre-wired before the electronics block is mounted.
- Depending on the design, wiring can be connected by means of screwtype or spring terminals.
- It has a two-wire termination and can be upgraded to a three- or four-wire termination by using supplementary terminals.
- It does not contain any active electronic components. The terminal block cannot therefore be destroyed electrically.
- You can insert different electronics blocks.
- There are 16-channel (TB 16L) and 32-channel (TB 32L) terminal blocks.
- The TB 16IM-SC terminal block is used in conjunction with the IM-SC interface module, offers pre-wiring and can be expanded directly by means of a TB 16SC terminal block of the Smart Connect.

Electronics Block

The electronics block contains the logic circuitry and is inserted into the terminal block and screwed. It is characterized by the following:

- It defines the number of input/output channels.
- You do not have to loosen the terminal lead to replace the electronics block; you merely have to remove the bus connector.
- The PROFIBUS-DP is connected via a bus connector to the electronics block.
- You can set PROFIBUS addresses 1 to 99.
- There is galvanic isolation between the PROFIBUS-DP and the internal electronics.
- LEDs are used to display: The voltage supply of the electronics block (ON), bus faults (BF), group errors (SF; not for ET 200L), the status of inputs and outputs
- There is a labeling strip in the electronics block for clear identification of inputs and outputs. You can order the labeling strip separately (refer to Appendix A.1).
- A circuit diagram is displayed on the electronics block. The circuit diagram is located beneath the labeling strip.
- The electronics blocks of the ET 200L-SC can each be be upgraded with a TB 16SC terminal block of the SIMATIC Smart Connect.

Processing Time

The internal processing time is < 1ms.

1.2.1 What Is the ET 200L Block I/O Device?

Features of the ET 200L

Figure 1-2 shows you a view of the ET 200L distributed I/O device. It consists of a terminal block and an electronics block.




Figure 1-2 View of the ET 200L Distributed I/O Device

ET 200L Modules

The modules incorporated in the ET 200L include:

- 24 V DC digital input and/or output modules
- AC digital input and/or output modules

ET 200L Components

A whole range of components is available for installing and commissioning the ET 200L. The most important components and their functions are listed in Table 1-2:

Table 1-2 Components of the ET 200L Distributed I/O Device

Component	Function	Illustration
TB 16L, TB 32L, TB 16L AC terminal block	carries the wiring and accepts the electronics block.	00000 00000000000000000000000000000000
Electronics block	is mounted on the terminal block. It defines the function (input or output).	
Supplementary terminals - 1-row - 2-row	are an extension for actuators and sensors with a 3- or 4-wire termination.	
Labeling sheet	allows the labeling strips to be labeled automatically or printed using a laser printer.	

Technical Data

You will find the technical data for the terminal blocks in Sections 7.1 to 7.3 and the technical data for the electronics blocks in Chapter 8.

1.2.2 What Is the ET 200L-SC Modular I/O Device?

ET 200L-SC Modules

The modules of the ET 200L-SC can be upgraded with a Smart Connect. The modules of the ET 200L-SC include:

- 24 V DC digital input modules
- 24 V DC digital output modules
- 24 V DC digital input and output modules

Smart Connect SC

The digital and analog electronic modules of the Smart Connect SC add to the digital inputs and outputs of the ET 200L-SC.

Modules of the Smart Connect SC

The Smart Connect SC has the following modules:

- 24 V 0.5A/2A DC digital input/output modules
- 120/230 V AC digital input/output modules
- 230 V AC relay module
- Analog input modules (U, I, TC, RTD)
- Analog output modules (U, I)

Features of the Smart Connect SC

The Smart Connect SC consists of a terminal block and various electronic modules that you can connect to it.

The Smart Connect SC allows you to fine tune the inputs and outputs to your process.

You can connect both analog and digital electronic modules to the terminal block at the same time.

Smart Connect Connecting Cable

You connect the ET 200L to the Smart Connect SC by means of the prefabricated connecting cable. Chapter 3.10 describes how to do this.

Components of the Smart Connect SC

A number of components are available to you for installing and commissioning a Smart Connect. Table 1-3 lists these components and their functions:

Table 1-3 Components of a ET 200L-SC

Component	Function	Illustration
TB 16L, TB32L terminal block - With spring terminal - With screw-type terminal	carries the wiring and accepts the electronics block.	
Electronics block for the SC	is mounted on the terminal block. It defines the function and has an interface for connect- ing the Smart Connect.	
TB16 SC terminal block - With spring terminal - With screw-type terminal	carries the wiring and the SC electronic modules.	
Digital/analog electronic modules	are connected to the TB 16SC terminal block. Electronic modules define the functions (input/output).	
Smart Connect connecting cable (comes with the TB 16SC terminal block)	connects the TB 16SC to the SC electronic modules.	
Supplementary terminal, single- row - Spring terminal - Screw-type terminal	is an add-on module for actuators and sensors with 3-conductor connections.	
Supplementary terminal, 2-row - Spring terminal - Screw-type terminal	is an add-on module for actuators and sensors with 4-conductor connections.	

Table 1-3 Components of a ET 200L-SC, continued

Component	Function	Illustration
Shield terminal	connects the shielding of analog signal lines with the supplementary terminal.	
Labeling sheet	allows the labeling strips to be labeled automatically or printed using a laser printer.	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 W M M M M M M M M M M M M M M M M M M

Technical Data

You will find the technical data in the following chapters and sections:

• TB 16L and TB 32L terminal blocks: Sections 7.1 and 7.2

• Electronics blocks for the Smart Connect: Chapter 9

• TB 16SC terminal block: Section 7.4

• SC electronic modules: Chapters 10 and 12

1.2.3 What Is the ET 200L-SC IM-SC Fine-Step Modular I/O Device?

Features of the ET 200L-SC IM-SC

The ET 200L-SC IM-SC consists of the TB 16IM-SC terminal block, to which the IM-SC interface module and up to 8 Smart Connect electronic modules are connected.




Figure 1-3 ET 200L-SC IM-SC

IM-SC Interface Module

The IM-SC interface module connects the ET 200L-SC IM-SC to the PROFIBUS-DP.

- It is tilted onto the TB 16IM-SC terminal block.
- It has a connector for the PROFIBUS-DP.
- The PROFIBUS addresses 1 to 99 can be set.

Modules of the SC Electronic Modules

You can connect up to 8 SC electronic modules to the TB 16IM-SC terminal block directly. The Smart Connect SC modules include:

- 24 V 0.5A/2A DC digital input/output modules
- 120/230 V AC digital input/output modules
- 230 V AC relay module
- High-speed analog input modules (U, I)
- Analog input modules (U, I, TC, RTD)
- Analog output modules (U, I)
- 40 kHz counter module

Expanding the ET 200L-SC IM-SC

The ET 200L-SC IM-SC can be expanded by means of a TB 16SC terminal block to connect 8 additional SC electronic modules.

High-Speed Analog Input Modules

These modules offer high-speed measured-value acquisition and data transfer. They are particularly well suited to rapid data acquisition for pressure and flow measurements.

The high-speed analog input modules can only be used in the TB 16IM-SC terminal block or in the expanded TB 16SC terminal block.

Components for the ET 200L-SC IM-SC

There are a range of components available for installing and commissioning a Smart Connect. Table 1-4 lists the components and specifies their functions:

Table 1-4 Components of an ET 200L-SC IM-SC

Component	Function	Illustration
IM-SC interface module	connects the TB 16IM-SC terminal block to the PROFIBUS-DP.	IM-SC
TB 16IM-SC terminal block - With spring terminal - With screw-type terminal	carries the wiring, the IM-SC interface module and the SC electronic modules.	
TB 16SC terminal block (with SC connection cable) - With spring terminal - With screw-type terminal	is added to the TB 16IM-SC and carries the wiring and 8 additional SC electronic modules.	
Digital/analog electronic modules/counter module	are connected to the TB 16IM-SC and TB 16SC terminal blocks. Electronic modules determine the functions (input/output).	
Smart Connect connecting cable (comes with the TB 16IM-SC terminal block)	connects the ET 200L-SC IM-SC to the TB 16SC for connecting 8 additional SC electronic modules.	

Table 1-4 Components of an ET 200L-SC IM-SC

Component	Function	Illustration
Supplementary terminal, singletier - Spring terminal - Screw-type terminal	is an extension for actuators and sensors with a 3-wire connection.	
Supplementary terminal, two-tier - Spring terminal - Screw-type terminal	is an extension for actuators and sensors with a 4-wire connection.	
Shield terminal	connects the shielding of analog signal lines with the supplementary terminal.	
Labeling sheet	enables automatic labeling or printing by laser printer.	1 2 3 4 5 6 7 8 9 10 11 12 [3 14 5 5 16 17] 18 M M M M M M M M M M M M M M M M M M

Technical Data

You will find the technical data for the ET 200L-SC IM-SC in the following sections and chapters:

• IM-SC interface module: Section 9.1

• TB 16IM-SC terminal block: Section 7.5

• TB 16SC terminal block: Section 7.4

• SC electronic modules: Chapters 10 and 12

Counter module: Chapter 13

Installation

Introduction

The ET 200L distributed I/O device and Smart Connect has been designed for simple installation and wiring. To this end, the label of the ET 200L distributed I/O device and Smart Connect has been made self-explanatory.

In this chapter, you will find additional information on installing and wiring the ET 200L distributed I/O device and Smart Connect.

Procedure

A number of steps are involved in the installation of the ET 200L distributed I/O device and Smart Connect. We suggest you adhere to the following sequence:

	Procedure	Section
Installing the ET 200L	1. Install the ET 200L TB 16L/TB 32L terminal block and supplementary terminal	2.1
	2. Install and disassemble the ET 200L electronics block	2.2
	3. Set the ET 200L PROFIBUS address	2.6
Installing the ET 200L-SC and	1. Install the ET 200L TB 16L/TB 32L terminal block and supplementary terminal	2.1
Smart Connect	2. Install and disassemble the ET 200L electronics block	2.2
	3. Install the SC TB 16SC terminal block	2.3
	4. Connect the Smart Connect electronic modules to the TB 16SC terminal block	2.4
	5. Set the ET 200L PROFIBUS address	2.6
	Install a supplementary terminal and shield terminal on the TB 16SC terminal block	2.7
Installing the	1. Install the ET 200L TB 16IM-SC terminal block	2.3
ET 200L-SC IM-SC and Smart Connect	Connect Smart Connect electronic modules to the TB 16IM-SC terminal block	2.4
Smart Connect	3. Install the SC TB 16SC terminal block	2.3
	Connect Smart Connect electronic modules to the TB 16SC terminal block	2.4
	5. Set the ET 200L PROFIBUS address on the IM-SC	2.6
	6. Install a supplementary terminal and shield terminal on the TB 16IM-SC/TB 16SC terminal block	2.7

Contents of the Chapter

Section	Торіс	Page
2.1	Installing the ET 200L TB 16L/TB 32L Terminal Block and Supplementary Terminal	2-3
2.2	Installing and Disassembling the ET 200L Electronics Block	2-6
2.3	Installing the TB 16IM-SC/TB 16SC Terminal Block	2-7
2.4	Connecting the Smart Connect Electronic Modules to the TB 16IM-SC/TB 16SC Terminal Block	2-13
2.5	Installing the ET 200L IM-SC Interface Module on the TB 16IM-SC Terminal Block	2-17
2.6	Setting the ET 200L PROFIBUS Address	2-18
2.7	Installing a Supplementary Terminal and Shield Terminal on the TB 16IM-SC/TB 16SC Terminal Block	2-19

2.1 Installing the ET 200L TB 16L/TB 32L Terminal Block and Supplementary Terminal

Introduction

In this section, we describe how you install the terminal block and the supplementary terminal.

Requirements

Install the terminal block on a rail.

- You install the ET 200L distributed I/O device on a rail conforming with EN 50022 (35 × 7.5 or 35 × 15).
- The preferred mounting position is horizontal installation on a vertical wall. All other mounting positions are conceivable.
- You require a free space on a rail of 145 mm (16 channels) or 191 mm (32 channels).
- The minimum installation depth is 82 mm (with an electronics block installed and an MLFB 6ES7 972-0CA30 0XA0 bus connector connected) when using a 35 × 7,5 mm rail.
- You require a free space of 35 mm above the terminal block. You require a free space of 20 mm below the terminal block(when using the 42 mm single-tier supplementary terminal or the 57 mm two-tier supplementary terminal).

If you add a TB 16SC to the ET 200L, you need a free space of 40 mm instead of 35 mm above the terminal block.

Installing the Terminal Block

Install the terminal block in the following order:

- 1. Mount the terminal block on the rail.
- Tilt the terminal block backwards until you hear both the safety bolts engage.

You can now wire the terminal block (refer to Chapter 3) before you install the electronics block. If you are using supplementary terminals, you must install them before you commence wiring.




Figure 2-1 Installing the Terminal Block

Installing and Disassembling Supplementary Terminals

Push the supplementary terminals into the existing guideways on the lower side of the terminal block until you hear the safety bolt engage.

To disassemble supplementary terminals, proceed as follows:

- 1. Pull the safety bolt downwards as far as the stop.
- 2. Pull out the supplementary terminals forwards from the guideways.

Disassembling the Terminal Block

Remove the terminal block in the following order (refer also to Figure 2-2):

- 1. Turn off the power supply.
- 2. Remove the electronics block.
 - Remove the bus connector.
 - Loosen the fixing screw.
 - Tilt the electronics block forwards.
- 3. Loosen the wiring.
- 4. If you are using supplementary terminals, you must remove them before disassembling the terminal block (see above).
- 5. Press the two safety bolts downwards in succession with a screwdriver.
- 6. Tilt and remove the terminal block from the rail.




Figure 2-2 Disassembling the Terminal Block

2.2 Installing and Disassembling the ET 200L Electronics Block

Installing the Electronics Block

Attach the electronics block to the terminal block in the following order:

- 1. Insert the electronics block from above into the guideways on the terminal block.
- 2. Tilt the electronics block backwards as far as the stop.
- 3. Secure the electronics block on the terminal block by tightening the screw:




Figure 2-3 Installing the Electronics Block

Disassembling the **Electronics Block**

To disassemble the electronics block, proceed in the reverse order.

- 1. Turn off the power supply.
- 2. Remove the bus connector.
- 3. Loosen the fixing screw.
- 4. Tilt the electronics block forwards.

2.3 Installing the TB 16IM-SC/TB 16SC Terminal Block

Installation

The terminal blocks are intended for installation in a cabinet or in an enclosed casing or operating room.

The TB 16SC and TB 16IM-SC terminal blocks can be installed horizontally. Provided temperatures do not exceed 40 °C, other installation locations are also possible.

Installation Dimensions and Clearances

When working out the space requirements of a terminal block, you must maintain adequate clearances to other components.

These minimum clearances are necessary at installation and during operation for the following reasons:

- For installing and removing the terminal block and the electronic modules
- To guarantee the air flow required for cooling during operation
- TB 16IM-SC terminal block: You require a free space of 40 mm above the terminal block and 50 mm under the terminal block (when using the 50 mm single-tier supplementary terminal or the 57 mm two-tier supplementary terminal).
- TB 16SC terminal block: You require a free space of 40 mm above the terminal block and 20 mm under the terminal block (when using the 42 mm single-tier supplementary terminal or the 57 mm two tier supplementary terminal).

Installation Work

If you carry out installation work with AC modules with a 230 V load supply that involves disconnecting the protective conductor from the TB 16SC or TB16 IM-SC, you must first switch off the 230 V load supply.

Installing the Terminal Block

Proceed as follows:

- 1. Mount the terminal block in such a way that sufficient clearance remains for ventilating the terminal block and installing and ventilating the electronic modules.
- 2. Screw the rail (35 mm wide) to the cabinet frame or the mounting block (screw size: M5).
- 3. Position the terminal block on the 35 mm rail from above, and swing it down. The terminal block snaps onto the rail (see Figure 2-4).




Figure 2-4 Snapping the Terminal Block onto the Rail

Sliding the Labeling Strips into the Terminal Block

Proceed as follows:

- 1. Note the assignment between the slot and the module on the labeling strip.
- 2. Slide the labeling strip from the side into the terminal block guide.




Figure 2-5 Sliding the Labeling Strip into the Terminal Block

Positioning the Coding Slide Switches

You must now position the coding slide switches correctly in accordance with the configuration of your system so that you can install the electronic modules. Each slot has a coding slide switch. The terminal blocks are supplied with coding slide switches at position 0.

Electronic Module	Position of the 1st Coding Slide Switch
DC Modules	
Digital electronic module 2DIDC24V (single width)	DC position (up)
Digital electronic module 2DODC24V0.5A (single width)	DC position (up)
Digital electronic module DODC24V2A (single width)	DC position (up)
Counter module 1COUNT40kHz (single width)	DC position (up)
AC Modules	
Digital electronic module 1DIAC120/230V (single width)	AC position (down)
Digital electronic module 1DOAC120/230V1A (single width)	AC position (down)
Digital electronic module 1DORel.AC230V (single width)	AC position (down)
Analog Electronic Modules	
Analog electronic module 2 AI U, 2 AI HS U (single width)	DC position (up)
Analog electronic module 2 AI I, 2 AI HS I (single width)	DC position (up)
Analog electronic module 2 AI TC (single width)	DC position (up)
Analog electronic module 1 AI RTD (single width)	DC position (up)
Analog electronic module 1 AO U (double width)	DC position (up)
Analog electronic module 1 AO I (double width)	DC position (up)



Warning

There is a risk of injury and damage to property.

Do not attempt to force the coding slide switch.

Forcing the coding slide switch is dangerous and can destroy electronic modules.




Figure 2-6 Positioning the Coding Slide Switches

- 1. Select a screwdriver with a blade width of 3.5 mm.
- 2. Insert the screwdriver into the slot on the coding slide switch (see Figure 2-7).
- 3. Apply slight pressure to push the coding slide switch into the required position.




Figure 2-7 Using the Screwdriver

Noting the System Designation

Note your system designations on the enclosed labeling strip for the electronic module.




Figure 2-8 Designation Plate with Labeling Strips (Reduced in Size)

2.4 Connecting Smart Connect Electronic Modules to the TB 16IM-SC/TB 16SC Terminal Block

Connection Rules for the Electronic Modules

The following connection rules apply to the SC electronic modules:

- You can connect up to 10 counter modules in an ET 200L-SC IM-SC (with TB 16SC).
- The slot immediately to the **right** of an AC module/relay module must either have an AC module/relay module or be free (see the following example).
- Under certain circumstances the number of plug-in SC electronic modules is limited (see the next page).

Note

If you use the TB 16IM-SC and TB 16SC together, you have a maximum of 16 slots available. This gives you up to 32 digital/analog channels, which can include a maximum of 12 analog channels.

Examples

8 slots (A...H) are available to you on each terminal block.

You Want to Connect the Following Electronic Modules to a Terminal Block	A	В	С	D	Е	F	G	Н
Only DC modules	DC							
Only analog electronic modules	Analog	Ana	log	Analog	Analog	Analog	Analog	Analog
Only AC modules	AC	AC	AC	AC	AC	AC	Re	lay
DC modules and AC modules	AC		DC	DC	AC	AC	Re	lay
Analog electronic modules and AC modules	Ana	alog	Analog	AC	AC	AC	AC	AC
Analog electronic modules, DC modules and AC modules	Analog	Analog	Analog	DC	DC	Analog	AC	AC
Analog electronic modules and DC modules	Analog	DC	Analog	DC	DC	Analog	DC	Analog

Circuit Schematic

The circuit schematic is shown on the front of every electronic module. Up to two LEDs are located below the circuit schematic. In the operating mode, the circuit schematic is covered by the labeling strip. The LEDs are visible through the transparent part of the labeling strip.

Number of Plug-in Analog SC Electronic Modules

The number of plug-in analog SC electronic modules is limited in the following cases:

- When there is no S7 DP master
- When they are used in an ET 200L-SC IM-SC with a TB 16SC connected

The PROFIBUS-DP standard EN 50 170, Volume 2, restricts the length of the parameterization data to a maximum of 244 bytes. This means that when analog SC electronic modules are used, the number of plug-in SC electronic modules may be limited. You will find a formula below for calculating the maximum number of SC electronic modules permitted in an ET 200L-SC IM-SC:

$$244 \le 10 + [(14 + D \times 7)]_1 + [(21 + A \times 9 + K \times 5 + C \times 18)]_2$$

Key:

D = total number of digital SC electronic modules plugged in

A = total number of analog SC electronic modules plugged in

K = total number of analog channels plugged in

C = total number of SC counter modules plugged in

[...]1 only necessary if digital SC electronic modules are plugged in

[...]₂ only necessary if analog SC electronic modules are plugged in

Example 1

ET 200L-SC IM-SC:
$$15 \times 2AE$$
; $1 \times 2DE$: —> $D = 1$; $A = 15$; $K = 30$

$$10 + (14 + 1 \times 7) + (21 + 15 \times 9 + 30 \times 5) = 10 + 21 + 306 = 337$$

The result is greater than 244 so this configuration is not possible.

Example 2

ET 200L-SC IM-SC:
$$8 \times 2AE$$
; $4 \times 2DE$: —> $D = 4$; $A = 8$; $K = 16$

$$10 + (14 + 4 \times 7) + (21 + 8 \times 9 + 16 \times 5) = 10 + 42 + 173 = 225$$

The result is less than 244 so this configuration is not possible.

Example 3

ET 200L-SC IM-SC:
$$6 \times 2AE$$
; $3 \times 1COUNT40kHz$; $4 \times 2DE$:

$$--> D = 4$$
; $A = 6$; $K = 12$; $C = 3$

$$10 + (14 + 4 \times 7) + (21 + 6 \times 9 + 12 \times 5 + 3 \times 18) = 10 + 42 + 189 = 241$$

The result is less than 244 so this configuration is not possible.

Labeling Strips of the Electronic Modules

Slide the labeling strip down from the top into the electronic module to be plugged in.

Note

You will only achieve full operating safety of the electronic modules if you have inserted the labeling strips on the front of the electronic modules (electrostatic discharge on the front of the module, covering the LEDs).




Figure 2-9 Connecting the Electronic Modules to the Terminal Block



Warning

There is a risk of injury and damage to property.

If you install a combination of AC and DC modules on a terminal block, you must comply with the rules for doing this. If you do not, injury and damage can be caused.

Always position the electronic modules in accordance with the connection rules.



Warning

There is a risk of injury and damage to property.

When using AC modules, you must use a supplementary terminal (screw-type terminal), to which you must connect the protective conductor.

When using AC modules, you must use **screw-type** supplementary terminals.

2.5 Installing the ET 200L IM-SC Interface Module on the TB 16IM-SC Terminal Block

Requirements

Before you install the IM-SC interface module on the TB 16IM-SC terminal block, note the following:

 The screw for fixing the IM-SC interface module is shipped screwed into the terminal block.

Use a screwdriver to remove the screw.

• When the IM-SC interface module is installed, a cable lug providing a connection to chassis ground is fixed at the same time.

Secure the ground cable in the cable lug, and establish a connection to chassis ground. See Section 3.7.

Installing the IM-SC Interface Module

Secure the IM-SC interface module by proceeding in the following sequence:

- 1. Hook the interface module from above into the guides on the terminal block.
- 2. Tilt the interface backward until the stop.
- 3. Put the cable lug for chassis ground (with the ground cable) on the screw, and secure the IM-SC interface module on the TB 16IM-SC terminal block by tightening the screw.




Figure 2-10 Installing the IM-SC Interface Module

2.6 Setting the ET 200L PROFIBUS Address


Introduction

The PROFIBUS address defines the address of the ET 200L distributed I/O device on the PROFIBUS-DP.

Location of Rotary Switches

The two rotary switches for the PROFIBUS address are located on the electronics block beneath the bus connector.


Tip: You must set the PROFIBUS address before clipping on the bus connector. When clipped on, the bus connector conceals the two rotary switches.



Rotary Switches of the ET 200L-SC IM-SC

The two rotary switches are on the right-hand side of the IM-SC interface module

Tip: Set the PROFIBUS address before you wire the TB 16IM-SC terminal block or before you mount the IM-SC interface module. The rotary switches are more accessible then.



Modifying the PROFIBUS Address

You modify the PROFIBUS address at the two rotary switches by using a small screwdriver. PROFIBUS addresses 1 to 99 are authorized for the ET 200L distributed I/O device.

PROFIBUS address 0, which is set when the ET 200 distributed I/O system leaves the works, is reserved for a PU or PC. Any change made to the PROFIBUS address takes effect when the supply voltage is turned on.

2.7 Installing a supplementary terminal and shield terminal on the TB 16IM-SC/TB 16SC terminal block

Securing the Supplementary Terminal to the Terminal Block If you want to connect a single-tier or two-tier supplementary terminal, proceed as follows:

- 1. Hold the supplementary terminal parallel to the terminal block. Use the right edge as a guide.
- 2. Insert the mountings (dovetails) into the grooves on the underside of the terminal block.
- 3. Press the upper side of the supplementary terminal against the underside of the terminal block, and slide the supplementary terminal to the back. The supplementary terminal engages.




Figure 2-11 Securing a Supplementary Terminal to the Terminal Block

Shielding for Analog Processing

In analog processing, you insert the cables of the signal lines in the shield terminal. To do this, proceed as follows:

- 1. Clip the TB 16IM-SC/TB 16SC terminal block onto the rail.
- 2. Connect a 1- or 2-tier supplementary terminal to the TB 16IM-SC/TB 16SC terminal block.
- 3. Connect the metallic shield terminal to the 1- or 2-tier supplementary terminal.




Figure 2-12 Connecting a Shield Terminal to the Supplementary Terminal

- 4. Secure the shield terminal in the supplementary terminal by tightening the screw of the slot with a screwdriver.
- 5. If you are using a TB 16IM-SC/TB 16 SC (screw-type terminal):

Secure the shield terminal in the supplementary terminal by tightening the screw of the slot with a screwdriver.

If you are using a TB 16IM-SC/TB 16 SC (spring terminal):

Secure the shield terminal in the supplementary terminal by inserting a screwdriver in the lower opening and the shield terminal in the upper opening until the stop.

- 6. Strip the insulation to bare the conductors.
- 7. Secure the bared wire ends in the terminal block, and pull them through the shield terminal.

Wiring 3

Introduction

The ET 200L distributed I/O device and Smart Connect has been designed for simple wiring. To this end, the label of the ET 200L distributed I/O device and Smart Connect has been made self-explanatory.

In this chapter, you will find additional information on wiring the ET 200L distributed I/O device and Smart Connect.

Procedure

The wiring of the ET 200L distributed I/O device and Smart Connect involves several steps. We suggest you adhere to the following sequence:

	Procedure	Section
Important infor-	General rules and regulations	3.1
mation on wiring	2. Configuring the electrical installation	3.2
	3. Wiring rules	3.3
Wiring the ET 200L	1. Wire the ET 200L TB 16L/TB 32L terminal block	3.4
Installing the	1. Wire the ET 200L TB 16L/TB 32L terminal block	3.4
ET 200L-SC and Smart Connect	2. Wire the Smart Connect TB 16SC terminal block	3.5
Smart Connect	3. Install a supplementary terminal for the TB 16SC	3.8
	4. Connect shielded cables to the shield terminal of the supplementary terminals	3.9
	5. Connect the Smart Connect SC to the ET 200L-SC	3.10
Wiring the	1. Wire the ET 200L TB 16IM-SC terminal block	3.4
ET 200L-SC IM-SC and	2. Wire the ET 200L IM-SC interface module	3.7
Smart Connect	3. Wire the Smart Connect TB 16SC terminal block	3.5
	4. Install the supplementary terminal for the TB 16SC/TB 16IM-SC	3.8
	5. Connected shielded cables to the shield terminal of the supplementary terminals	3.9
	6. Connect the Smart Connect SC to the TB 16IM-SC	3.10

Contents of the Chapter

Section	Торіс	Page
3.1	General Rules and Regulations	3-3
3.2	Configuring the Electrical Installation	3-5
3.3	Wiring Rules	3-9
3.4	Wiring the ET 200L TB 16L/TB 32L Terminal Block	3-11
3.5	Wiring the Smart Connect TB 16SC Terminal Block	3-14
3.6	Wiring the ET 200L TB 16IM-SC Terminal Block	3-16
3.7	Wiring the ET 200L IM-SC Interface Module	3-18
3.8	Installing a Supplementary Terminal for the TB 16SC/TB 16IM-SC	3-22
3.9	Connecting Shielded Cables to the Shield Terminal of the Supplementary Terminals	3-23
3.10	Connecting the Smart Connect SC to the ET 200L-SC/TB 16IM-SC	3-24

3.1 General Rules and Regulations

Introduction

As a component part of a plant or system, the ET 200L distributed I/O device necessitates observance of special rules and regulations, depending on where it is to be used.

This section provides an overview of the most important rules which you have to observe for integrating the ET 200L distributed I/O device in a plant or system.

Specific Application

Observe the safety and accident prevention regulations – for example, the machine protection guidelines – for specific applications.

EMERGENCY STOP Devices

EMERGENCY STOP devices conforming with IEC 204 (corresponds to DIN VDE 113) must remain effective in all the operating modes of the plant or system.

Plant Start-up After Certain Events

The following table shows the points you have to take into account upon start-up of a plant following certain events.

If	Then
Start-up follows a voltage drop or failure Start-up of the ET 200L follows an interruption of bus communications	No hazardous operating states may occur. Force an EMER- GENCY STOP, if necessary.
Start-up follows unlocking of the EMER- GENCY STOP device	There must not be an uncontrolled or undefined start-up.
ET 200L start-up occurs without the DP master addressing the ET 200L	

Supply Voltage

The following table shows you the items you have to take into account in respect of the supply voltage.

With	It Is Essential That
A permanently installed plant or system not having an all- pole supply isolating switch	A supply isolating switch or a fuse be present in the building installation
Load current power supplies, power supply modules	The set rated voltage range corresponds to the local supply voltage
All circuits of the ET 200L distributed I/O device	The fluctuation or deviation of the supply voltage from the rated value be within the permitted tolerance (refer to Section 6.6)

24 VDC Supply

The following table shows the points that you have to take into account in respect of the 24 VDC supply.

With	Pay Attention to		
Buildings	Outdoor lightning protection	Take lightning protection precautions – for	
24 VDC supply lines, signal lines	Indoor lightning protection	example, lightning conductors	
24 VDC supply	Safe (electrical) isolation of extra-low voltage		

Protection Against External Electrical Phenomena

The following table shows you the items you have to take into account in respect of protection against electrical phenomena or faults.

With	Pay Attention to:
Any plant or system in which the ET 200L is installed	Is the plant or system connected to a protective conductor for diverting electromagnetic interference?
Connecting leads, signal and bus lines	Are the wiring arrangement and installation correct?
Signal and bus lines	Any break of a line or conductor must not result in undefined states of the plant or system.

3.2 Configuring the Electrical Installation

Introduction

In this section, you will find information on the overall installation of an ET 200L distributed I/O device and Smart Connect on a grounded supply (TN-S system). The specific topics discussed are:

- Circuit-breaking devices, short-circuit and overload protection in accordance with DIN VDE 0100 and DIN VDE 0113
- · Load current power supplies and load circuits.

Definition: Grounded Supply

With grounded supplies, the neutral conductor of the system is grounded. A mere ground fault between a live conductor and ground or a grounded section of the plant causes the protective devices to trip.

Components and Protective Measures

Different components and protective measures are specified for erecting a complete plant. The types of component and the degree to which the protective measures are binding depend on the DIN VDE regulation that applies to the installation of your plant. The following table refers to Figure 3-1.

Table 3-1 DIN VDE Regulations for Installation of a Controller

Compare	Ref. to Fig. 3-1	DIN VDE 0100	DIN VDE 0113
Circuit-breaking device for PLC, sensors and signal control elements	1	Part 460: Main switch	Part 1: Disconnector
Short-circuit and overload- protection: Grouped for sensors and sig- nal control elements	2	Part 725: Single-pole protection of circuits	Part 1: • With grounded secondary circuit: singlepole protection • In all other cases: all-pole protection
Load current power supply for AC load circuits with more than five electromag- netic apparatus	3	Galvanic isolation by means of a transformer is rec- ommended	Galvanic isolation by means of a transformer is es- sential

Note

The ET 200L and Smart Connect cannot be operated with an ungrounded supply.

Characteristics of Load Current Power Supplies

The load current power supply feeds input and output circuits (load circuits) as well as sensors and actuators. The following table lists the characteristics of load current power supplies that are required in specific applications.

Characteristic of Load Current Power Supply	Required for	Remarks
Safe (electrical) isolation	Modules that have to be supplied with voltages ≤ 60 VDC or ≤ 25 VAC	Power supply PS 307 and Siemens Series 6EP1 load current power supplies have this characteristic
	24 VDC load circuits	
Output voltage tolerances: 20.4 V to 28.8 V	24 VDC load circuits	If the output tolerances are exceeded, we recommend that you install a back-up capacitor. Rating: 200 µF per 1 A load current (with full-wave rectification).

Rule: Ground Load Circuits

Load circuits should be grounded.

Fault-free operating reliability is ensured by the common reference potential (ground). Install a detachable connection to the protective conductor on the external power supply (terminal L or M) or on the isolation transformer (Figure 3-1, $\boxed{4}$). This measure makes it simpler for you to locate ground faults in the power distribution system.

EMC

You will find notes on EMC⁻compatible installation and wiring in the manual for the DP master you are using or for the host system.

Take into account the following notes on EMC-compatible installation of the ET 200L distributed I/O device:

- We recommend that you place the cable shield of the PROFIBUS-DP on both sides of a shield bus.
- The chassis ground and the ground terminal are interconnected in the ET 200L distributed I/O device. Connect the ground terminal of the ET 200L distributed I/O device using a copper cable of at least 2.5 mm² to the central grounding point in the installation cabinet.
- In the case of the ET 200L-SC, connect the ground terminals of the ET 200L-SC and Smart Connect SC using a short copper cable of at least 2.5 mm².

ET 200L in Overall Installation

Figure 3-1 shows the location of the ET 200L in the overall system (load current voltage supply and grounding philosophy) for supply from a TN-S system.

Remark: The arrangement of the power supply connections shown in the figure does not correspond to the actual arrangement but was chosen for the sake of clarity.




Figure 3-1 Operating the ET 200L from a Grounded Supply

Smart Connect in Overall Installation

Only safely isolated low voltage (DC $\,24\,V$) can be used as the power supply. Safe isolation from the mains supply can be achieved in accordance with the requirements in VDE 0100 Part 410 / HD 384-4-41 / IEC 364-4-41 (as functional low voltage with safe isolation) or VDE 0805 / EN 60950 / IEC 950 (as safety extralow voltage with safe isolation SELV) or VDE 0106 Part 101.




Figure 3-2 Power Supply of the Terminal Block

Special Feature

The 1DIAC120/230V and 1DOAC120/230V1A electronic modules do not require any auxiliary voltage (L+, M).

A supplementary terminal for connecting the protective conductor is required when these electronic modules are used.

3.3 Wiring Rules

Rules for Wiring

The table below shows you what you must observe when wiring the terminal block and the supplementary terminal.

Table 3-2 Pinout of the PROFIBUS-DP Terminal Connection

Rules for	Terminal block		
	Spring Terminal	Screw-Type Terminal	
Suitable cable cross-sections:			
Solid cables	0.14 to 1.5 mm ² (for PI connection: 2.5 mm ²)		
Flexible cables			
Without wire end ferrule	0.14 to 1.5 mm ² (for P)	connection: 2.5 mm ²)	
With wire end ferrule	0.14 to 1	1.5 mm ²	
Number of cables per connection	1 or combination of 2 cables to a total of 1.5 mm ² in one wire end ferrule		
Max. diameter of cable insulation	Ø 3.1 mm Ø 3.8 mm for 2.5 mm ²		
Insulation stripping length of the cables			
Without insulation collars	7 to 11 mm		
With insulation collars	7 to 1	1 mm	
Wire end ferrule in accordance with DIN 46228			
Without insulation collars	Shape A; up to 12 mm long	Shape A; up to 12 mm long	
With insulation collars			
- 0.25 to 1.0 mm ²	Shape E; up to 12 mm long Shape E; up to 12 mm long		
- 1.5 mm ²	Shape E; 12 mm long	Shape E; 18 mm long*	
Blade width of the screwdriver	3.5 mm (cylindrical design)		
Tightening torque for connecting cables (not applicable to spring terminals)	-	0.4 to 0.7 Nm	
Ground connection	up to 6 mm ² in cable lug for M4 screw		

Terminal Block with Screw-Type Terminal

To wire the terminal block (screw-type terminal), proceed as follows:

- 1. Strip the insulation of the wires down to 11 mm.
- 2. Connect the conductors. Begin on the left under the terminal block.
- 3. Screw the ends of the cables onto the terminal block with a tightening torque of 0.5 Nm. Tighten the screws on the unwired terminals as well.

Terminal Block with Spring Terminal

To wire the terminal block (spring terminal), proceed as follows:

1. Strip the insulation of the wires down to 11 mm.

Remember to:

- Insert the screwdriver in the lower opening.
- Insert the cable in the upper opening until the stop.




Figure 3-3 How the Spring Terminal Works

- 4. Release the spring terminal of the first connection using a screwdriver $(0.5 \times 3.5 \text{ mm DIN } 5264)$. Begin at the bottom left of the terminal block.
- 5. Push the first wire into the released spring terminal and withdraw the screwdriver.
- 6. Repeat steps 1 to 3 for all other wires.



Warning

There is a risk of injury and damage to property.

Connecting different phases of a three-phase system to a terminal block can cause injury and damage to property.

Connect only one phase to each terminal block.

3.4 Wiring the ET 200L TB 16L/TB 32L Terminal Block

Introduction

When wiring the ET 200L distributed I/O device, we distinguish between the terminal block with its supplementary terminal and the electronics block.

- The terminal block and, if required, the supplementary terminal carry the wiring.
- The electronics block incorporates the PROFIBUS-DP connection.

Wiring the Terminal Block

All terminal connections on the terminal block and supplementary terminals are located on the front and are clearly marked and readily visible from the front. Assignment of terminal connections to input/output channels is simple to perform, without danger of confusion.

Connect the terminal block and the supplementary terminal in accordance with the configuration. Figure 3-4 shows the terminal connections for terminal block TB 16L. Its pinout is described in Chapter 7.




Figure 3-4 Terminal Connections on Terminal Block TB 16L

Connecting the Voltage Supply

There are three different ways to connect the voltage supply to the terminal block.




Figure 3-5 Alternative Ways of Connecting the Voltage Supply

Block Diagram

The block diagrams relating to the ET 200L distributed I/O device will be found in Chapter 7.

Label

A labeling strip is located on the front of the electronics block for noting the assignment of inputs and outputs.

Terminal Connection Model

A terminal connection model showing the terminal connection assignment and electrical connections is located beneath the labeling strip on the electronics block (refer to Chapter 8).

Clipping on the Bus Connector

Clip the bus connector on the electronics block.

- 1. Clip the bus connector on the PROFIBUS-DP terminal connection after setting the PROFIBUS address of the ET 200L distributed I/O device (refer to Section 2.6).
- 2. Tighten the fastening screws of the bus connector.

PROFIBUS-DP Terminal Connection

The table below describes the pinout of the 9-pin PROFIBUS-DP terminal connection.

Table 3-3 Pinout of the PROFIBUS-DP Terminal Connection

View	Pin No.	Signal Name	Description
	1	_	_
10	2	_	_
6 0	3	RxD/TxD-P	Data line B
7. 2	4	RTS	Request To Send
8 3	5	M5V2 ¹	Data reference potential (from station)
9 4	6	P5V2 ¹	Supply Plus (from station)
5●	7	_	-
	8	RxD/TxD-N	Data line A
	9	_	_

¹ For connecting an ET 200 handheld or an optical-fiber module

3.5 Wiring the Smart Connect TB 16SC Terminal Block

Introduction

The TB 16SC terminal block and – if required – the supplementary terminal carry the wiring.

Wiring the TB 16SC

The figure below shows the connections of the TB 16SC terminal block:




Figure 3-6 Front View of the Terminal Block



Warning

When installing the following electronic modules

- 2DODC24V0.5A (6ES7 122-1BB00-0AA0)
- 2DODC24V2A (6ES7 122-1BB10-0AA0)

check that the polarity of 1L+ and 1M and 2L+ and 2M on the TB 16SC terminal block is correct before you switch on the load voltage. If the polarity is incorrect, any actuators connected may be activated.

Connecting to Local Ground

The terminal block has one local ground point.

- You must provide a low resistance connection between the local ground point and the rail. For this purpose, use at least a 4mm² conductor with a maximum length of 0.5 m (cable lug rated size 4-6 in accordance with DIN 46237).
- 2. Provide a low-resistance connection between the rail and foundation ground. Ungrounded installation is not possible.

TB 16SC Terminal Designation

The following table contains an example of the assignment of terminals to slots.

Slot	Terminals
	1L+; 2L+
	1M; 2M
Slot A (on the extreme left)	A1;A2;A3;A4
Slot B	B1;B2;B3;B4
Slot C	C1;C2;C3:C4
Slot D	D1;D2;D3;D4
Slot E	E1;E2;E3;E4
Slot F	F1;F2;F3;F4
Slot G	G1;G2;G3;G4
Slot H	H1;H2;H3;H4

Terminal Assignments

Not all electronic modules use all the terminals assigned to the slot.

Unused terminals must not be wired in order to maintain the clearance and creepage distances.



Warning

There is a risk of injury and damage to property.

Connecting cables to unassigned terminals can cause injury and damage to property.

Do not connect cables to unassigned terminals.

3.6 Wiring the ET 200L TB 16IM-SC Terminal Block

Introduction

The TB 16IM-SC terminal block and – if required – the supplementary terminal carry the wiring. The TB 16IM-SC terminal block also has an interface to the Smart Connect.

Wiring the TB16 IM-SC

The figure below shows the connection of the TB 16IM-SC terminal block:




Figure 3-7 Connections of the TB 16IM-SC Terminal Block



Warning

There is a risk of injury and damage to property.

Connecting cables to unassigned terminals can cause injury and damage to property.

Do not connect cables to unassigned terminals.

Connecting the Power Supply

There are two different ways to connect the voltage supply to the terminal block.




Table 3-5).

Figure 3-8 Connection Alternatives for the Power Supply

TB 16IM-SC Terminal Designation

Unused terminals must not be wired in order to maintain the clearances and creepage distances.

Terminals	Description	Load Group
1L+, 1M	Power supply slot A to D	_
2L+, 2M; 3L+, 3M	Power supply slot E to H	_
A1;A2;A3;A4	Slot A (extreme left)	A
B1;B2;B3;B4	Slot B	A
C1;C2;C3:C4	Slot C	A
D1;D2;D3;D4	Slot D	A
E1;E2;E3;E4	Slot E	В
F1;F2;F3;F4	Slot F	В
G1;G2;G3;G4	Slot G	В
H1;H2;H3;H4	Slot H	В

3.7 Wiring the ET 200L IM-SC Interface Module

Introduction

The IM-SC connects the TB 16IM-SC terminal block to the PROFIBUS-DP.

Wiring the IM-SC

The figure below shows all the connections of the IM-SC interface module:




Figure 3-9 Connections of the IM-SC Interface Module

IM-SC Connection to Chassis Ground

The chassis ground connection of the ET 200L-SC IM-SC is on the IM-SC interface module.

- 1. You must connect the connection point to the rail with low resistance. To do this, use at least a 4mm² cable with a maximum length of 0.5 m and a cable lug with a nominal size of 4-6 (in accordance with DIN 46237). Place the cable lug on the screw by means of which you attach the interface module to the terminal block.
- 2. Connect the rail with low resitance to the foundation ground.

Ungrounded installation is not possible.

Strain Relief Grip

Attach a strain relief grip approximately 20 - 30 cm from the IM-SC for the connecting cables for the power supply and PROFIBUS-DP.

IM-SC PROFIBUS-DP Connection

A plug-in, 6-pin screw-type terminal with a shield support connects the ET 200L-SC IM-SC to the PROFIBUS-DP. You can connect the bus lines and the shield to the screw-type terminal.

The 6-pin screw-type terminal is shipped with the IM-SC interface module.

Table 3-4 Assignment of the PROFIBUS-DP Connection at the IM-SC Interface Module

View	Signal Name	Designation
	Ground	Bus line shield
	A1	Data line A (IN)
	B1	Data line B (IN)
	A2	Data line A (OUT)
Cover	B2	Data line B (OUT)
Holder	Ground	Bus line shield

Wiring the PROFIBUS-DP Connection

The bus lines (see Appendix A) are connected to the plug-in, multipole screw-type terminal.

Note

When you remove the PROFIBUS-DP screw-type terminal, the subsequent DP slaves are disconnected from the PROFIBUS-DP.

1. Strip the insulation from the bus line as shown in the figure below.




Figure 3-10 Length of Insulation Stripped

2. Connect the bus line to the screw-type terminal, and screw the cover on the holder.




Figure 3-11 Wiring the PROFIBUS-DP Screw-Type Terminal

3. Insert the screw-type terminal in the appropriate socket on the IM-SC interface module.

Power Supply

You connect the power supply for the electronics to the plug-in, 4-pole screw-type terminal. The 4L+, 5L+ and 4M, 5M terminals are linked internally. This enables the power supply to be looped through via the 5L+ and 5M terminals. Insert the screw-type terminal in the appropriate socket on the IM-SC interface module.

Table 3-5 Assignment of the Power Supply

View	Signal Name	Designation
	4L+	DC 24V
	5L+	DC 24V (for looping through)
	4M	Ground
	5M	Ground (for looping through)

Connecting the Power Supply

You connect the 24V DC power supply to the plug- in, 4-pole screw-type terminal.

1. Connect the bus line to the screw-type terminal, and press the cover on the screw-type terminal.




Figure 3-12 Connecting the Power Supply

2. Insert the screw-type terminal in the appropriate socket on the IM-SC interface module.

IM-SC Bus Terminating Resistors

The bus terminating switch allows you to switch bus terminating resistors on or off. The bus terminating switch is located in a recess on the front of the IM-SC interface module.




Figure 3-13 Functioning of the Bus Terminating Switch

3.8 Using the Supplementary Terminal for the TB 16SC/TB 16IM-SC

Possible Uses of the Single-Tier Supplementary Terminal

The terminals are electrically connected to each other internally. You can use the single-tier supplementary terminal for different purposes. You must adapt the labeling of the supplementary terminal according to the application.

- 1. You must use the **screw-type** single-tier supplementary terminal:
 - Connection of protective conductors when using AC modules or the relay module for switching circuits that are not safely isolated. The printed label must remain visible.
- 2. You can use the single-tier supplementary terminal for the following purposes:
- Connecting protective ground for BEROs: For this purpose, you must leave the original labeling visible.
- Multiplying M potentials: For this purpose, select either
 - the labeling strip marked M
 - or leave the original labeling visible.
- Multiplying any potentials: For this purpose, you must label the strip yourself.

Possible Uses of the Two-Tier Supplementary Terminal

All the terminals of a tier are electrically connected to each other internally. You can use the two-tier supplementary terminal for different purposes. You must adapt the labeling of the supplementary terminal according to the application.

1. You must use the **screw-type** 2-tier supplementary terminal:

Lower tier

Connection of protective conductors when using AC modules or the relay module for switching circuits that are not safely isolated. The printed label must remain visible.

2. You can use the two-tier supplementary terminal for the following purposes:

Upper tier

Multiplying M potentials:

For this purpose, select either:

- the labeling strip marked M
- or leave the original labeling visible
- Multiplying the potential of any one potential
 For this purpose, you must label the blank strip yourself.

Lower tier

• Connecting protective ground for BEROs or shield terminals

3.9 Connecting Shielded Lines to the Shield Terminal of the Supplementary Terminals

Application

The shield terminal makes it easy to connect to ground all shielded cables that lead to or from electronic modules of the Smart Connect.

You obtain a connection to ground by installing the shield terminal in the supplementary terminal and connecting it to local ground at low resistance.

Structure of the Shield Terminal

The shield terminal is subdivided by function into a connecting lug and a spring terminal. The connecting lug establishes the electrical contact in the supplementary terminal. The spring terminal contacts the shield of the signal line.

Mounting the Shield Terminal

To secure the shield terminal, proceed as follows:

- Make as short a connection as possible between 2M on the TB 16SC/TB 16IM-SC terminal block and the tier of the supplementary terminal in which you want to insert the shield terminals.
- 2. Insert the shield terminal into the desired position in the supplementary terminal.
- Use a screwdriver with a blade width of 3.5 mm to secure the shield terminal.

Connecting Cables

You can only connect one or two shielded cables to each shield terminal. You connect the cables to the bared cable shield. The bared length of the cable shield must be at least 20 mm. Cables with cross-sections of 4...7 mm are connected securely.

3.10 Connecting the Smart Connect SC to the ET 200L-SC/TB 16IM-SC

Introduction

The electronics blocks of the ET 200L-SC and the ET 200L-SC IM-SC can all be supplemented by means of the Smart Connect:

- ET 200L-SC 16 DI DC 24 V 6ES7 131-1BH11-0XB0
- ET 200L-SC 32 DI DC 24 V 6ES7 131-1BL11-0XB0
- ET 200L-SC 16 DO DC 24 V/0.5 A 6ES7 132-1BH11-0XB0
- ET 200L-SC 16 DI/16 DO DC 24 V/0.5 A 6ES7 133-1BL10-0XB0
- ET 200L-SC TB 16IM-SC 6ES7 120-0AH50-0AA0 (screw-type terminal), 6ES7 120-0BH50-0AA0 (spring terminal)

Connecting the Smart Connect

Enclosed with every TB 16SC terminal block is a 5 cm long Smart Connect cable set with which you can connect the Smart Connect.

- 1. Insert the sheathed end of the cable set into the Smart Connect interface of the ET 200L-SC or ET 200L-SC IM-SC.
- One of the connecting cable's connectors has a lug. Insert this connector into the terminal block of the Smart Connect.

Note

All open Smart Connect interfaces must be closed using the accompanying SC cover before operating the ET 200L-SC or ET 200L-SC IM-SC. Only then are the requirements for handling electrostatically sensitive components met.

Removing the Smart Connect

When you remove Smart Connect, do it in the following order:

- Turn off the power supply on the ET 200L-SC or ET 200L-SC IM-SC and Smart Connect.
- 2. Detach the cable set from the terminal block of the Smart Connect.
- 3. Place the SC cover on the Smart Connect interface of the ET 200L-SC or ET 200L-SC IM-SC. Only then are the requirements for handling electrostatically sensitive components met.

Commissioning

Contents of the Chapter

Section	Topic	Page
4.1	Configuration Software	4-2
4.2	Commissioning the ET 200L and Smart Connect	4-3
4.3	Replacing SC Electronic Modules	4-5

4.1 Configuration Software

ET 200L

You configure the ET 200L distributed I/O device and SC using the following configuration software.

- COM ET 200 Windows as of Version 1.0
- COM PROFIBUS as of Version 3.0
- STEP 7 as of Version 2.1

You will find the name of the type file for the various electronics blocks and the contents of the device master file described in Appendix C.

ET 200L-SC

The following applies to the ET 200L-SC:

DP Master	Configuration Software	Type Files	see Section
SIMATIC S7	STEP 7 as of Version 3.0	See Table C-14	• 5.2.1 to 5.2.5
IM 308C	COM ET 200 Windows as of Version 1.0	See Table C-14	• 5.2.6 • C.5
IM 308C	COM ET 200 Windows as of Version 2.1	See Table C-14 Device master files: See Table C-2	• 5.2.1 to 5.2.5
	COM PROFIBUS as of Version 3.0	See Table C-14	• 5.2.1 to 5.2.5
S5-95U with DP master interface	COM ET 200 Windows as of Version 1.0	See Table C-14	• 5.2.6 • C.5
Other master	COM PROFIBUS Version 3.1	Recommendation: See Table C-14 and Device master files: See Table C-2	• 5.2.6 • C.5

ET 200L-SC IM-SC The following applies to the ET 200L-SC IM-SC:

DP Master	Configuration Software	Type Files	see Section
SIMATIC S7	STEP 7 as of Version V 4.1	See Table C-14	• 5.2.1 to 5.2.5
IM 308-C	COM PROFIBUSas of Version V 3.2	See Table C-14	• 5.2.1 to 5.2.5
S5-95U with DP master interface	COM PROFIBUS as of Version V 3.2	See Table C-14	• 5.2.6 • C.5
Other master	COM PROFIBUS as of Version V 3.2	Recommendation: S. Table C-14 and Device master files: See Table C-2	• 5.2.6 • C.5

4.2 Commissioning the ET 200L and Smart Connect

Commissioning the ET 200L

Commission the ET 200L distributed I/O device as follows:

Step	Activity	Explanation
1	Install and wire up the ET 200L.	You will find detailed instructions on installing and wiring in Chapters 2 and 3.
2	Set the PROFIBUS address of the ET 200L.	The two rotary switches used to set the
3	Clip the bus connector on the electronics block.	PROFIBUS address are concealed by the bus connector (refer to Section 2.6).
4	If you are using an ET 200L-SC or ET 200L-SC IM-SC, you can now connect the Smart Connect.	Use the enclosed Smart Connect cable set for this purpose.
5	Turn on the power supply for the ET 200L.	-
	Result: The ET 200L starts up automatically.	
6	If you are using an ET 200L-SC or ET 200L-SC IM-SC, turn on the power supply of the Smart Connect SC and ET 200L-SC.	The power supply of the Smart Connect SC must not be turned on after that of the ET 200L-SC or ET 200L-SC IM-SC.
	Result: The ET 200L-SC or ET 200L-SC IM-SC and Smart Connect SC starts up automatically.	

Note

Full operational safety of the electronics blocks is not ensured until you have applied the labeling strips to the front of the electronics blocks (electrostatic discharge at the front of the module, LED coverage).

Start-up

The ET 200L distributed I/O device and Smart Connect starts up automatically when the power supply is turned on. A separate switch is not available.

During start-up, both LEDs (ON and BF = Bus Fault) are on.

The ET 200L distributed I/O device ...

- Sets the outputs to "0".
- Applies the PROFIBUS address from the two rotary switches.
- Receives the configuration data from the DP master and evaluates the
 details contained in the configuration data. If the configuration agrees
 with the installation, the ET 200L distributed I/O device and Smart Connect initiates data exchange, and the BF LED goes off.

ET 200L-SC or ET 200L-SC IM-SC with SC-Modules

The ET 200L-SC or ET 200L-SC IM-SC behaves as follows when analog SC modules are connected:

- SC modules can only be detected at ET 200L-SC or ET 200L-SC IM-SC start-up after power on. If the 24V supply on the SC terminal block is not yet connected at start-up, SC modules are not detected.
- The ET 200L-SC or ET 200L-SC IM-SC starts up when the power supply is switched on.

This behavior can result in the following errors:

- A configured SC module is not detected at start-up. As a result, a diagnostic interrupt occurs with a parameterization error for the SC add-on, and the SF LED on the ET 200L-SC or ET 200L-SC IM-SC comes on.
- ET 200L-SC (as of version 3), ET 200L-SC IM-SC. An SC module or counter module fails during operation. As a result, a diagnostic interrupt occurs with a module error for the SC add-on, and the SF LED on the ET 200L-SC or ET 200L-SC IM-SC comes on.

Data Exchange

After start-up, data exchange is initiated between the DP master and the ET 200L distributed I/O device and Smart Connect.

The data exchange is displayed by the ET 200L distributed I/O device as follows:

- The green operating LED (ON) is on.
- The bus fault LED (BF) is off.
- The inputs and outputs are enabled.
- Conductive inputs and outputs are indicated on the status LEDs by the corresponding LED flashing.

4.3 Replacing SC Electronic Modules

Starting point

The system is running. You want to change the system configuration of the Smart Connect.

You Want to Connect Additional Electronic Modules

The system is in RUN mode. You want to plug in one or more additional electronic modules.

- 1. Set the CPU to STOP mode.
- 2. Switch off the load voltage supply to the ET 200L and Smart Connect.
- 3. Extend the process wiring.
- 4. Insert the new electronic modules into the terminal block in accordance with the positioning of the coding slide switches.
- 5. Create a new configuration.
- 6. Switch on the load voltage supply to the ET 200L and Smart Connect again.
- 7. Expand your user program.
- 8. Set the CPU to RUN mode.
- 9. Check the actual status of the system

Note

Never connect and disconnect the SC electronic modules during operation.

Diagnostics

Introduction

The ET 200L distributed I/O device and Smart Connect was designed to make working with and commissioning it as simple as possible. If a failure nevertheless occurs, you can find out what it is by means of LEDs and slave diagnostics.

Contents of the Chapter

Section	Topic	
5.1	Diagnostics Using the LEDs	5-2
5.2	Slave Diagnostics	5-5

5.1 Diagnostics Using the LEDs

Introduction

The ET 200L distributed I/O device features the following diagnostic options:

- LEDs
- Slave diagnostics (refer to Section 5.2)

Status Display

Each input and output of the ET 200L distributed I/O device has a status display. The status display LED lights up when the input or output is active.

ET 200L LED Display

The ET 200L distributed I/O device has two LEDs for displaying statuses.

Table 5-1 Diagnostics Using the LED Display

BF LED (Bus Fault)	ON LED	Meaning	Error Handling
Off	Off	 No voltage is being applied to the ET 200L. An ET 200L hardware fault has occurred. 	 Check the power supply. Switch on the on-off switch for 24 VDC on the power supply module. Check whether the electronics block is properly secured on the terminal block.
On	On	ET 200L is in the process of starting up.	_
		 The connection to the DP master has failed. ET 200L has still not received any configuration data. 	 Check the PROFIBUS connection. Check the DP master. Check the configuration in the DP master (station type, input/output, PROFIBUS address). Check which PROFIBUS address has been set.
Off	On	Data exchange	_

LEDs on the ET 200L-SC or ET 200L-SC IM-SC The ET 200L-SC or ET 200L-SC IM-SC distributed I/O device has three LEDs for indicating its status.

Table 5-2 Diagnostics Using the LEDs of the ET 200L-SC or ET 200L-SC IM-SC

SF LED (Group Error)	BF LED (Bus Fault)	ON LED	Meaning	Error Handling
Off	Off	Off	 No voltage is being applied to the ET 200L-SC/ET 200L-SC IM-SC An ET 200L-SC IM-SC hardware fault has occurred. 	 Check the power supply. Switch on the on-off switch for 24 V DC on the power supply module. Check whether the electronics block is properly secured on the terminal block.
Off	Off	On	Power supply of the ET200L-SC/ET 200L-SC IM-SC is on (comes on briefly when the power is switched on) Data exchange	
On			Incorrect assignment of parameters	 Check whether parameter assignment for the Smart Connect configuration matches the actual Smart Connect configuration. Check that the cable to the Smart Connect is properly connected. Check the power supply of the TB16 SC.
			• SC communication error (see byte 15.1, Table 5-6)	Connection to SC module with serial data transfer aborted (analog module, counter)
				 24 V power supply of the SC modules is switched off (analog module, counter) Module defective
No mean- ing	On	On	• Transmission rate is being adjusted (max. 4s).	Check the PROFIBUS connection.Check the DP master.

Table 5-2 Diagnostics Using the LEDs of the ET 200L-SC or ET 200L-SC IM-SC

SF LED (Group Error)	BF LED (Bus Fault)	ON LED	Meaning	Error Handling
Off	Flashing	On	ET 200L-SC/ET 200L-SC IM-SC has still not received any configuration data or has received incorrect data. Bus protocol incorrect	 Check the configuration in the DP master (station type, input/output, PROFIBUS address). Check the format of the parameterization frame.
On			Error in configuration frame.	 Check the configuration in the DP master (station type, input/output, PROFIBUS address). Check the configuration of the configuration frame.

5.2 Slave Diagnostics

In Section 5.2 You will find the following topics in this section:

Section	Торіс	Page
5.2.1	General Remarks on Diagnostics	5-6
5.2.2	Structure of the Slave Diagnosis	5-7
5.2.3	Structure of Station Statuses 1 to 3, Master Station Number and Manufacturer Identification	5-8
5.2.4	Structure of the Module Diagnosis for the ET 200L-SC	5-10
5.2.5	Structure of the Station Diagnosis for the ET 200L-SC	5-13
5.2.6	Structure of the Slave Diagnosis for Default Start-Up of the ET 200L-SC	5-15

Definition

Diagnostics is the detection and localization of errors. The diagnostics structure is laid down in EN 50170 Volume 2, PROFIBUS. ET 200L diagnostics complies with this standard. Slave diagnostics is explained in the section that follows for the ET 200L.

5.2.1 General Remarks on Diagnostics

Diagnostics with an S7/M7 DP Master

If you are operating the ET 200L-SC or ET 200L-SC IM-SC as a DP slave with a **SIMATIC S7/M7** DP master, the modules behave like S7 300 CPU modules.

You read out the diagnosis (data record 0) with SFC 13, "DPNRM_DG".

Diagnostics with Another DP Master

If you are operating the ET 200L-SC or ET 200L-SC IM-SC as a DP slave with another DP master for example, with an IM 308-C on a SIMATIC S5 – you will find the slave diagnosis structure in Sections 5.2.2 to 5.2.6.

Diagnostic Interrupt and Process Interrupt

The ET 200L-SC or ET 200L-SC IM-SC supports diagnostic interrupts.

You can evaluate these types of interrupt with an S7/M7 DP master. In the event of an interrupt, interrupt OBs run automatically in the CPU – refer to the programmer's manual, *System Software for S7-300/S7-400, Program Design*).

If you are operating the ET 200L-SC or ET 200L-SC IM-SC with another DP master, these interrupts are simulated within station diagnostics.

Note

In order to be able to evaluate diagnostic interrupts by means of a station diagnosis with another DP master, you must take the following into account:

- The DP master should be able to store diagnostic messages; this means
 that diagnostic messages should be stored within the DP master in a ring
 buffer store. If the DP master cannot store diagnostic messages, only the
 latest diagnostic message to be received would always be stored, for
 instance.
- You have to poll regularly in your application the corresponding bits in the station diagnosis. In doing so, you have to take into account the bus run time of the PROFIBUS-DP so that you poll the bits at least once in synchronization with the bus run time, for instance.

Diagnosis upon Erroneous Assignment of Parameters

If the DP master sends an erroneous parameter assignment for the SC extension in the parameterization frame, the ET 200L-SC or ET 200L-SC IM-SC responds with a diagnostic message – in the event of diagnostics being enabled. Owing to an internal processing time, the reply does not immediately follow the parameterization frame, but there is a delay. In the start-up OB, therefore, the diagnosis of the module should be read after a period of approximately 100 ms to determine whether the ET 200L-SC or ET 200L-SC IM-SC is operating properly.

If the ET 200L-SC or ET 200L-SC IM-SC is already exchanging data, all the available SC inputs are supplied as zeros, and all the available SC outputs remain at zero.

5.2.2 Structure of the Slave Diagnosis

Introduction

The diagnostics of the ET 200L/ET 200L-SC/ET 200L-SC IM-SC distributed I/O device comply with EN 50710 Volume 2, PROFIBUS. The slave diagnosis is explained below.

Structure of the Slave Diagnosis

The slave diagnosis comprises 6 bytes for the ET 200L and not more than 17 bytes for the ET 200L-SC/ET 200L-SC IM-SC:




Figure 5-1 Structure of the Slave Diagnosis

Requesting a Slave Diagnosis

You can request a slave diagnosis with the following function blocks:

Table 5-3 Function Blocks for Slave Diagnosis

PLC Family	Number	Name
SIMATIC S5 with IM 308-C	FB 192 192	FB IM308C
SIMATIC S7/M7	SFC 13 13	SFC "DPNRM_DG"
S5-95U with DP master interface	FB 230 230	FB S_DIAG
SIMATIC S5 with CP 5431 DP/FMS	Communication function blocks (see standard FBs) SEND and RECEIVE with job number 209	

5.2.3 Structure of Station Statuses 1 to 3, Master Station Number and Manufacturer Identification

Definition of Station statuses 1 to 3 provide an overview of the status of a DP slave (refer

Station Status to Figure 5-1, bytes 0 to 2).

Structure of Station status 1 provides information about the DP slave and is structured as follows:

Table 5-4 Structure of Station Status 1 (Byte 0)

Bit	Meaning	Action
0	1: The DP slave cannot be addressed by the DP master.	 Correct PROFIBUS address set on ET 200L? Bus connector connected? Voltage at DP slave? RS 485 repeater set correctly? Supply voltage ON/ OFF performed on ET 200L?
1	1: The DP slave is not yet ready to exchange data.	Wait, because the ET 200L is just being powered up.
2	1: The configuration data sent by the DP master to the DP slave do not agree with the installation of the DP slave.	Correct station type or correct installation of the ET 200L entered in the system configura- tion software?
3	1: An external diagnosis exists.	Check the contents of the external diagnosis.
4	1: The requested function is not supported by the DP slave.	Check the configuration.
5	1: The DP master cannot interpret the reply from the DP slave.	Check the bus installation.
6	1: The DP slave type does not agree with the software configuration.	Correct station type entered in the system configuration software?
7	1: Parameters have been assigned to the DP slave by a different DP master from that which currently has access to the DP slave.	The bit is always 1 if you are in the process of accessing, for example, the ET 200L with the PU or another DP master. The PROFIBUS address of the parameterization master is located in the "master PROFIBUS address" diagnostic byte.

Structure of Station Status 2

Station status 2 provides additional information about the DP slave and is structured as follows:

Table 5-5 Structure of Station Status 2 (Byte 1)

Bit	Meaning
0	1: Parameters have to be assigned again to the DP slave.
1	A diagnostic message has been issued. The DP slave cannot resume operation until the fault has been corrected (static diagnostic message).
2	1: The bit is always set to "1" if the DP slave having this PROFIBUS address is present.
3	1: Response monitoring has been enabled for this DP slave.
4	1: The DP slave has received the "FREEZE" control command ¹ .
5	1: The DP slave has received the "SYNC" control command ¹ .
6	1: The bit is always set to "0".
7	1: The DP slave is disabled – that is, it has been removed from the processing in progress.

¹ The bit is updated only if another diagnostic message changes too.

Structure of Station Status 3

Station status 3 is reserved and is not relevant in as far as the diagnostics of the ET 200L distributed I/O device are concerned.

Definition of the Master PROFIBUS Address

The Master PROFIBUS Address diagnostic byte stores the PROFIBUS address of the DP master which has assigned parameters to the DP slave (refer to Figure 5-1, byte 3).

Structure of the Master PROFIBUS Address

The master PROFIBUS address comprises one byte with the PROFIBUS address of the DP master that assigned parameters to the DP slave and has read and write access to the DP slave.

Definition of the Manufacturer ID

A code is stored in the manufacturer identification that describes the type of the DP slave (refer to Figure 5-1, bytes 4 and 5).

Structure of the Manufacturer ID

The manufacturer identification of the DP slave comprises two bytes. You will find the manufacturer identifications of the different electronics blocks in Appendix C, Table C-1 and C-4.

5.2.4 Structure of the Module Diagnosis for the ET 200L-SC and ET 200L-SC IM-SC

Module Diagnosis

The module diagnosis for the ET 200L-SC and ET 200L-SC IM-SC (bytes 6 to 8) tells you the slot for which a diagnosis is available.

Structure with the COM/S7 Configuration Software

The structure of the module diagnosis is indicated below. You will find an explanation of the slots in Appendix C.3.




Figure 5-2 Structure of the Module Diagnosis with the COM/S7 Configuration Software for the ET 200L-SC




Figure 5-3 Structure of the Module Diagnosis with the COM/S7 Configuration Software for the ET 200L-SC IM-SC

Structure with any Configuration Software

A module diagnosis is structured as follows. You will find an explanation of the slots in Appendix C.3.




Figure 5-4 Structure of the Module Diagnosis with any Configuration Software for the ET 200L-SC, ET 200L-SC IM-SC

5.2.5 Structure of the Station Diagnosis for the ET 200L-SC and ET 200L-SC IM-SC

Definition

The station diagnosis provides detailed information about a DP slave.

Data record 0, which is typical of the SIMATIC S7, is stored in the station diagnosis (bytes 9 to 16).

The contents of the station diagnosis always refer to the Smart Connect section.

Structure

The station diagnosis contains a maximum of eight bytes. You will find an explanation of the slots in Appendix C.3.




Figure 5-5 Structure of Station Diagnosis

Saving the Diagnosis

Transfer the contents of the station diagnosis to a data block, since the station diagnosis will be updated periodically.

Bytes 13 to 16 for the Diagnostic Interrupt

Table 5-6 shows the structure and contents of bytes 13 to 16 for a diagnostic interrupt.

Table 5-6 Bytes 13 to 16 for the Diagnostic Interrupt

Byte	Bit	Meaning	Error Handling
13	0	Module malfunction	A module malfunction has occurred.
	1	Internal error	An internal error has occurred (see byte 13.6, byte 13.7 and byte 15.0).
	2	External error	An external error has occurred (see byte 15.1).
	2 to 6	Not applicable	
	7	Wrong parameters in module	Check the ET 200L-SC parameter assignment.
14	0 to 3	Module class: 0010 (special module)	
	4 to 7	Not applicable	
15	0	User module wrong or missing	Smart Connect incorrect or missing.
	1	SC communication error (ET 200L-SC, as of version 3)	 Connection to the SC module with serial data transfer aborted (analog module, counter). Module defective 24V power supply of the SC modules is switched off (analog module, counter).¹
15	2 to 7	Not applicable	
16	0 to 7	Not applicable	

After the 24V power supply is connected, the SC module is included in cyclic data transfer again with the parameters received at start-up. It is reported that the diagnosis has been processed and the problem thus corrected.

5.2.6 Structure of Slave Diagnosis for Default Start-Up of ET 200L-SC and ET 200L-SC IM-SC

Default Start-up

When you execute a default start-up (see Appendix C.5), the following slave diagnosis applies. You will find an explanation of the slots in Appendix C.3.




Figure 5-6 Slave Diagnosis for Default Start-up of the ET 200L-SC and ET 200L-SC IM-SC

General Technical Data

6

What Is General Technical Data?

The general technical data consists of the standards and test values with which the ET 200L conforms and which it fulfills, and the test criteria by which the ET 200L distributed I/O device was tested.

Contents of the Chapter

Section	Торіс	Page
6.1	Standards and Certification	6-2
6.2	Electromagnetic Compatibility	6-4
6.3	Shipping and Storage Conditions	6-6
6.4	Mechanical and Climatic Environmental Conditions	6-7
6.5	Details of Insulation Testing, Safety Class, and Degree of Protection	6-8
6.6	Rated Voltage of the ET 200L Distributed I/O Device	6-9

6.1 Standards and Certification

Introduction

This chapter contains information the following for the modules and components of the ET 200L and Smart Connect SC:

- The most important standards complied with by the ET 200L and Smart Connect SC
- The certification of the ET 200L and Smart Connect SC

IEC 1131

The ET 200L distributed I/O device and Smart Connect SC meet the requirements and criteria of IEC 1131, Part 2.

PROFIBUS DP

The ET 200L distributed I/O device and Smart Connect SC meet the requirements and criteria of EN 50 170 Volume 2, PROFIBUS.

CE Marking

CE

Our products fulfill the requirements and safety objectives of the following EC Directives and comply with the harmonized European standards (EN) published for stored-program controllers in the official journals of the European Communities:

- 89/336/EEC Electromagnetic Compatibility Directive
- 73/23/EEC Low Voltage Directive (for electrical equipment)

The EC Declarations of Conformity are available to the relevant authorities at the following address:

Siemens Aktiengesellschaft Bereich Automatisierungstechnik A&D AS E 14 Postfach 1963 D-92209 Amberg

PNO

The ET 200L has the following PNO certificates:

Product Name	Order Number	Release	PNO Certificate
ET 200L 16 DI DC 24 V	6ES7 131-1BH00-0XB0	1	Z00179
ET 200L-SC 16 DI DC 24 V	6ES7 131-1BH11-0XB0	1	Z00210
ET 200L 32 DI DC 24 V	6ES7 131-1BL00-0XB0	1	Z00180
ET 200L-SC 32 DI DC 24 V	6ES7 131-1BL11-0XB0	1	Z00212
ET 200L 16 DO DC 24 V/0.5 A	6ES7 132-1BH00-0XB0	1	Z00181
ET 200L-SC 16 DO DC 24 V/0.5A	6ES7 132-1BH11-0XB0	1	Z00211
ET 200L 32 DO DC 24 V/0.5 A	6ES7 132-1BL00-0XB0	1	Z00182
ET 200L 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL00-0XB0	1	Z00183

UL Recognition UL Recognition Mark

Underwriters Laboratories (UL) to Standard UL 508, File No. 116536

CSA Certification CSA Certification Mark

Canadian Standard Association (CSA) to Standard C22.2 No. 142, File No. LR 48323

FM Approval

Factory Mutual Approval Standard Class Number 3611, Class I, Division 2, Group A, B, C, D.



Warning

There is a risk of injury and damage to property.

In potentially explosive atmospheres, there is a risk of injury to people and damage to property if you disconnect connectors when a ET 200 is in operation.

Always de-energize the ET 200 in potentially explosive atmospheres before disconnecting any connectors.

6.2 Electromagnetic Compatibility

Definition

Electromagnetic compatibility is the ability of an electric device to function satisfactorily in its electromagnetic environment without interfering with this environment.

The ET 200L distributed I/O device also meets the requirements, among others, of the EMC act of the European inner market. A requirement for this is that the ET 200L distributed I/O device meets the specifications and directives concerning electrical installation.

Pulse-Shaped Interference

The following table shows the electromagnetic compatibility of the ET 200L distributed I/O device with regard to pulse-shaped interference.

Pulse-Shaped Interference	Tested with	Corresponds to Severity
Electrostatic discharge to IEC 801-2 (DIN VDE 0843, Part 2)	8 kV 4 kV	3 (air discharge) 2 (contact discharge)
Burst impulses in accordance with IEC 801-4 (DIN VDE 0843, Part 4)	2 kV (supply line) 2 kV (signal line)	3
Surge in accordance with IEC 801-5 (DII Only with lightning protection elements (manual).		
Assymmetrical connection	2 kV (supply line) 2 kV (signal line/data line)	3
Symmetrical connection	1 kV (supply line) 1 kV (signal line/data line)	

Sine-Shaped Interference

The following table shows the electromagnetic compatibility of the ET 200L distributed I/O device with regard to sine-shaped interference.

HF Radiation to ENV 50140 (Corresponds to IEC 801-3) Electromagnetic RF Field		RF Coupling to ENV 50141 (Corresponds to IEC 801-6)
Amplitude-Modulated	Pulse-Modulated	
80 to 1000 MHz	$900 \text{ MHz} \pm 5 \text{ MHz}$	0.15 to 80 MHz
10 V/m		10 V _{rms} unmodulated
80 % AM (1 kHz)	50 % ED	80 % AM (1 kHz)
	200 Hz repetition frequency	150 Ω source impedance

Emission of Radio Interference

Emitted interference of electromagnetic fields in accordance with EN 55011: Limit Value Class A, Group 1 (measured at a distance of 30 m).

Frequency	Emitted Interference
From 20 to 230 MHz	$< 30 \text{ dB } (\mu\text{V/m})\text{Q}$
From 230 to 1000 MHz	$< 37 \text{ dB } (\mu\text{V/m})\text{Q}$

6.3 Shipping and Storage Conditions

Conditions

The ET 200L distributed I/O device surpasses the requirements of IEC 1131, Part 2, with regard to shipping and storage conditions. The following details apply to modules that are shipped and stored in their original packaging.

Type of Condition	Admissible Range
Free fall	≤ 1m
Temperature	From -40 °C to $+70$ °C
Temperature variation	20 K/h
Air pressure	From 1080 to 660 hPa (corresponds to a height of -1000 to 3500 m)
Relative humidity	From 5 to 95 %, without condensation

6.4 Mechanical and Climatic Environmental Conditions

Climatic Environmental Conditions

The following climatic environmental conditions apply:

Environmental Conditions	Operating Ranges	Remarks
Temperature	From 0 to 60 °C From 0 to 40 °C	Horizontal wall mounting All other installation positions
Temperature variation	10 K/h	
Relative humidity	From 15 to 95 %	Without condensation, corresponds to relative humidity (RH) stress rate 2 to IEC 1131-2
Air pressure	From 1080 to 795 hPa	Corresponds to a height of -1000 to 2000 m
Contaminant concentration	SO ₂ : < 0.5 ppm; rel. humidity < 60 %, no moisture condensation H ₂ S: < 0.1 ppm; rel. humidity < 60 %, no moisture condensation	Test: 10 ppm; 4 days 1 ppm; 4 days

Mechanical Environmental Conditions

The mechanical environmental conditions are shown in the following table in the form of sinusoidal oscillations.

Frequency Range	Permanent	Occasional
10 ≤ f ≤58 Hz	0.0375 mm amplitude	0.075 mm amplitude
58 ≤ f ≤150 Hz	0.5 g constant acceleration	1 g constant acceleration

Testing Mechanical Environmental Conditions

The following table provides information on the type and extent of tests of mechanical environmental conditions.

Test for	Test Standard	Remarks
Oscilla- tions	Oscillation test to IEC 68, Part 2-6 (sine)	Oscillation type: frequency sweeps with a rate of change of 1 octave per minute. $10 \text{ Hz} \leq f \leq 58 \text{ Hz}, \text{ const. amplitude } 0.075 \text{ mm}.$ $58 \text{ Hz} \leq f \leq 150 \text{ Hz}, \text{ const. acceleration } 1 \text{ g}.$ Oscillation time: 10 frequency sweeps per axis in all of the three perpendicular axes.
Shock	Shock test to IEC 68, Part 2-27	Type of shock: half sine Force of shock: 15 g peak value, 11 ms duration Direction of shock: 3 shocks per +/- direction in all of the three perpendicular axes.

6.5 Details of Insulation Testing, Safety Class, and Degree of Protection

Test Voltage

Insulation strength is demonstrated in the routine test with the following test voltage in accordance with IEC 1131, Part 2:

Circuits with a Rated Voltage U _e to Other Circuits or to Ground	Test Voltage
$0 \text{ V} < \text{U}_{\text{e}} \le 50 \text{ V}$	500 VDC

Safety Class

Safety class II in accordance with IEC 536 (VDE 0106, Part 1) – that is, connection to a protective conductor is not necessary.

Protection Against Foreign Matter and Water

IP 20 degree of protection in accordance with IEC 529 – that is, protection against contact with standard test fingers.

Furthermore, it is protected against foreign matter having a diameter greater than 12.5 mm.

No special protection against water.

6.6 Rated Voltage of the ET 200L Distributed I/O Device

Rated Voltage for Operation

The ET 200L distributed I/O device operates with the rated voltage and corresponding tolerances shown in the following table.

Table 6-1 Rated Voltage of the ET 200L Distributed I/O Device

Rated Voltage	Tolerance Range
24 VDC	20.4 to 28.8 VDC

Bridging Voltage Drops

The ET 200L distributed I/O device bridges voltage drops of the power supply of up to 20 ms long (does not apply to SC electronic modules).

Terminal Blocks and Supplementary Terminals – Technical Data

7

Introduction

The product spectrum of ET 200L and Smart Connect includes various terminal blocks to which you can connect different electronics blocks. This chapter contains the technical data for the terminal blocks and their supplementary terminals.

Contents of the Chapter

Section	Subject	Page
7.1	Terminal Block TB 16L – 6ES7 193-1CH00-0XA0, 6ES7 193-1CH10-0XA0	7-2
7.2	Terminal Block TB 32L – 6ES7 193-1CL00-0XA0, 6ES7 193-1CL10-0XA0	7-4
7.3	Terminal Block TB 16L AC- 6ES7 193-1CH20-0XA0	7-7
7.4	Terminal Block TB 16SC 6ES7 120-0AH01-0AA0, 6ES7 120-0BH01-0AA0	7-10
7.5	Terminal Block TB 16IM-SC – 6ES7 120-0AH50-0AA0, 6ES7 120-0BH50-0AA0	7-14
7.6	Supplementary Terminals for TB 16L and TB 32L	7-18
7.7	Supplementary Terminals for TB 16SC and TB 16IM-SC	7-20

7.1 Terminal Block TB 16L – 6ES7 193-1CH00-0XA0, 6ES7 193-1CH10-0XA0

Order Numbers

The TB 16L terminal block is available with two types of connection.

- Connection by means of a screw-type terminal (Order Number 6ES7 193-1CH00-0XA0)
- Connection by means of a spring terminal (Order Number 6ES7 193-1CH10-0XA0)

Plug-In Electronics Blocks

You can connect the following electronics blocks to the TB 16L terminal block:

Chapter	Plug-In Electronics Blocks	Order Number
Chapter 9:	ET 200L 16 DI DC 24 V	6ES7 131-1BH00-0XB0
ET 200L Electronics Blocks	ET 200L-SC 16 DI DC 24 V	6ES7 131-1BH11-0XB0
Technical Data	ET 200L 16 DO DC 24 V/0.5A	6ES7 132-1BH00-0XB0
	ET 200L-SC 16 DO DC 24 V/0.5 A	6ES7 132-1BH11-0XB0

Characteristics The terminal block bears the stationary wiring.

Dimension Drawing

In Figure 7-1 you can see the dimension drawing of the TB 16L terminal block with the 16 DI 24 V DC electronics block clipped on.




Figure 7-1 The TB 16L Terminal Block with the Electronics Block Clipped On, Dimension Drawing

Pinout

Table 7-1 shows the pinout of the TB 16L terminal block.

Table 7-1 Pinout of the TB 16L Terminal Block

Terminal	Assignment	
	Inputs	Outputs
1 to 8	I0: Signals .0 to .7	Q0: Signals .0 to .7
9 to 16	I1: Signals .0 to .7	Q1: Signals .0 to .7
17 to 24	I0: Sensor supply	Q0: Chassis ground (internally jumpered)
25 to 32	I1: Sensor supply Q1: Chassis ground (internally jumpered)	
1L+	Power supply for channel gro	up A (I0 and Q0)
2L+	Power supply for channel group B (I1 and Q1) internally	
3L+	jumpered	
4L+	Dower supply for electronics, internally jumpered	
5L+	Power supply for electronics, internally jumpered	
1M		
2M	Chassis ground connection for channel group A, channel group B, and electronics (all internally jumpered)	
3M		
4M		
5M		
÷	PE	

Technical Data

Dimensions and Weight		
Dimensions $W \times H \times D$ (mm)	$145 \times 100 \times 40.5$	
Height with electronics block from top edge rail (with bus termina- tor 6ES7 972-0CA30-0XA0)	82 mm	
Weight	230 g	
Module-Specific Data		
Number of channels	16	

7.2 Terminal Block TB 32L – 6ES7 193-1CL00-0XA0, 6ES7 193-1CL10-0XA0

Order Numbers

The TB 32L terminal block is available with two types of connection.

- Connection via screw-type terminal (Order Number 6ES7 193-1CL00-0XA0)
- Connection via spring terminal (Order Number 6ES7 193-1CL10-0XA0)

Plug-In Electronics Blocks

You can connect the following electronics blocks to the TB 32L terminal block:

Chapter	Plug-In Electronics Blocks	Order Number
Chapter 9:	ET 200L 32 DI DC 24 V	6ES7 131-1BL00-0XB0
ET 200L Electronics Blocks	ET 200L-SC 32 DI DC 24 V	6ES7 131-1BL11-0XB0
Technical Data	ET 200L 32 DO DC 24 V/0.5 A	6ES7 132-1BL00-0XB0
	ET 200L 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL00-0XB0
	ET 200L-SC 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL10-0XB0

Characteristics

The terminal block bears the stationary wiring.

Dimension Drawing

In Figure 7-2 you can see the dimension drawing of the TB 32L terminal block with the LSC 32 DI 24 V electronics block clipped on.




Figure 7-2 The TB 32L Terminal Block with the Electronics Block Clipped On, Dimension Drawing

Pinout

Table 7-2 shows the pinout of the TB 32L terminal block.

Table 7-2 Pinout of the TB 32L Terminal Block

Terminal	Assignment	
	Inputs	Outputs
1 to 8	I0: Signals .0 to .7	Q0: Signals .0 to .7
9 to 16	I1: Signals .0 to .7	Q1: Signals .0 to .7
17 to 24	I2: Signals .0 to .7	Q2: Signals .0 to .7
25 to 32	I3: Signals .0 to .7	Q3: Signals .0 to .7
33 to 40	I0: Sensor supply	Q0: Chassis ground (internally jumpered)
41 to 48	I1: Sensor supply	Q1: Chassis ground (internally jumpered)
49 to 56	I2: Sensor supply	Q2: Chassis ground (internally jumpered)
57 to 64	I3: Sensor supply	Q3: Chassis ground (internally jumpered)
1L+	Power supply for channel group A (I0 and I1 or Q0 and Q1)	
2L+	Power supply for channel group B	
3L+	(I2 and I3 or Q2 and Q3) internally jumpered	
4L+		
5L+	Power supply for electronics, internally jumpered	
1M	Chassis ground connection for channel group A, channel group B, and electronics (all internally jumpered)	
2M		
3M		
4M		
5M		
÷	PE	

Technical Data

Dimensions and Weight		
Dimensions $W \times H \times D$ (mm)	$191 \times 100 \times 40.5$	
Height with electronics block from top edge rail (with bus terminator 6ES7 972-0CA30-0XA0)	82 mm	
Weight	350 g	
Module-Specific Data		
Number of channels	32	

7.3 Terminal Block TB 16L AC 6ES7 193-1CH20-0XA0

Characteristics

The TB 16L AC terminal block has the following characteristics:

- Screw-type terminal connection
- The terminal block bears the stationary wiring

Plug-In Electronics Blocks

You can connect the following electronics blocks to the TB 16L AC terminal block:

Chapter	Plug-In Electronics Blocks	Order Number
Chapter 9:	ET 200L 16 DI AC 120 V	6ES7 131-1EH00-0XA0
ET 200L Electronics Blocks	ET 200L 16 DO AC 120V/1.0A	6ES7 132-1EH00-0XB0
Technical Data	ET 200L 16 DO DC 24 V/AC 120V/2.0 A	6ES7 132-1JH00-0XB0
Technical Data	ET 200L 8 DI/8 DO AC 120V/1.0A	6ES7 133-1EH00-0XB0
	ET 200L 8DI AC 120V/8 DO DC 24V/AC 120V/2.0 A	6ES7 133-1JH00-0XB0

Dimension Drawing

In Figure 7-3 you can see the dimension drawing of the TB 16L AC terminal block with the L 16 DI AC 120 V electronics block clipped on.




Figure 7-3 The TB 16L AC Terminal Block with the Electronics Block Mounted, Dimension Drawing (mm)

Pinout

Table 7-2 shows the pinout of the TB 16L AC terminal block.

Table 7-3 Pinout of the TB 16L AC Terminal Block

Terminal	Assignment	
	Inputs	Outputs
1 to 8	I0: Signals .0 to .7	Q0: Signals .0 to .7
9 to 16	I1: Signals .0 to .7	Q1: Signals .0 to .7
17	I0.0: Sensor neutral	Q0.0: Load voltage
18	I0.1: Sensor neutral	Q0.1: Load voltage
19	I0.2: Sensor neutral	Q0.2: Load voltage
20	I0.3: Sensor neutral	Q0.3: Load voltage
21	I0.4: Sensor neutral	Q0.4: Load voltage
22	I0.5: Sensor neutral	Q0.5: Load voltage
23	I0.6: Sensor neutral	Q0.6: Load voltage
24	I0.7: Sensor neutral	Q0.7: Load voltage
25	I1.0: Sensor neutral	Q1.0: Load voltage
26	I1.1: Sensor neutral	Q1.1: Load voltage
27	I1.2: Sensor neutral	Q1.2: Load voltage
28	I1.3: Sensor neutral	Q1.3: Load voltage
29	I1.4: Sensor neutral	Q1.4: Load voltage
30	I1.5: Sensor neutral	Q1.5: Load voltage
31	I1.6: Sensor neutral	Q0.6: Load voltage
32	I1.7: Sensor neutral Q1.7: Load voltage	
L1	Power supply line for electronics	
N	Power supply neutral for electronics	
Ť	PE	

Technical Data

The following table shows the technical data of the TB 16L AC terminal block.

Dimensions and Weight		
Dimensions $W \times H \times D$ (mm)	$191 \times 100 \times 40.5$	
Height with electronics block from top edge rail (with bus terminator)	98.5 mm	
Weight	283 g	
Module-Specific Data		
Number of channels	16	

7.4 Terminal Block TB 16SC

Order Numbers

The TB 16SC terminal block is available with two types of connection:

- Connection by means of a screw-type terminal (Order Number 6ES7 120-0AH01-0AA0)
- Connection by means of a spring terminal (Order Number 6ES7 120-0BH01-0AA0)

Plug-In Electronic Modules

You can connect the following electronic modules to the TB 16 SC terminal block:

Chapter	Plug-In Electronic Modules	Order Number
Chapter 10:	2DIDC24V	6ES7 121-1BB00-0AA0
Digital SC Electronic	2DODC24V0.5A	6ES7 122-1BB00-0AA0
Modules Technical Data	2DODC24V2A	6ES7 122-1BB10-0AA0
Technical Data	1DIAC120/230V	6ES7 121-1FA00-0AA0
	1DOAC120/230V	6ES7 122-1FA00-0AA0
	1DORel.AC230V	6ES7 122-1HA01-0AA0
	Counter module 1COUNT40kHz *	6ES7 127-1BE00-0AB0
Chapter 12:	2 AI U	6ES7 123-1FB00-0AB0
Analog SC Electronic Modules	2 AI HS U *	6ES7 123-1FB50-0AB0
Technical Data	2 AI I	6ES7 123-1GB00-0AB0 , 6ES7 123-1GB10-0AB0
	2 AI HS I *	6ES7 123-1GB50-0AB0, 6ES7 123-1GB60-0AB0
	2 AI TC	6ES7 123-1JB00-0AB0
	1 AI RTD	6ES7 123-1JA00-0AB0
	1 AO U	6ES7 124-1FA00-0AB0
	1 AO I	6ES7 124-1GA00-0AB0

^{*} Only in conjunction with TB 16IM-SC

Characteristics

The TB 16SC terminal block has the following characteristics:

- It can be wired before you plug in the electronic modules.
- Depending on the design, the wiring can be connected either via screwtype terminals or via spring terminals.
- You must establish a connection to local ground.
- The TB16 SC enables a 2-wire connection and can be expanded to 3-wire and 4-wire connection using supplementary terminals.
- You can slide a labeling strip into the TB16 SC terminal block for noting the assignments between slot and module.
- The counter module and the high-speed analog SC-electronic modules can only be used in the TB 16SC, when the TB 16SC is connected to a TB 16IM-SC.

Dimension Drawing

Figure 7-4 shows the front elevation of the TB 16SC terminal block.




Figure 7-4 Front Elevation of the Terminal Block



Caution

The spring terminal will be destroyed if you insert the screwdriver into the opening for the wires.

Only press the screwdriver into the rectangular openings of the terminal block.

Block Diagram

The figure below shows you the block diagram of the TB16 SC terminal block.

The connections 2L+ and 2M are used for looping through the load voltage supply 1L+ and 1M.




Figure 7-5 Block Diagram of the TB16 SC Terminal Block.



Warning

There is a risk of injury and damage to property.

Connecting different phases of a three-phase system to a terminal block can lead to injury and damage to property.

Connect only one phase to each terminal block.

Technical Data

Dimensions and Weight		
Dimensions $W \times H \times D$ (mm)	145×100×40.5	
Weight	230 g	
Module-S _I	pecific Data	
Number of slots	8	
Current-carrying capacity via 1L+ and 2L+	max. 8A	
Current-carrying capacity per slot with parallel supply	max. 1,5 A	
Number of times an electronic module can be plugged into a slot of the TB 16 SC	max. 20	
Insulation tested (from slot to slot)	DC 4000 V	

7.5 Terminal Block TB 16IM-SC

Order Numbers

The TB 16IM-SC terminal block is available with two types of connection.

- Connection by means of a screw-type terminal (Order Number 6ES7 120-0AH50-0AA0)
- Connection by means of a spring terminal (Order Number 6ES7 120-0BH50-0AA0)

Characteristics

The TB 16IM-SC terminal block has the following characteristics:

- It can be wired before you plug in the electronic modules.
- Depending on the design, the wiring can be connected either via screwtype terminals or via spring terminals.
- The TB 16IM-SC enables a 2-wire connection and can be expanded to a 3- and 4-wire connection with the supplementary terminals of the TB 16SC.
- You can slide a labeling strip into the TB 16IM-SC terminal block for noting the assignments between slot and module.
- the TB 16IM-SC can be expanded with the TB 16SC to connect another 8 SC electronics modules.
- two load voltage supplies (load voltage group 1L+: A to D, load voltage group 2L+, 3L+: E to F)

Plug-In Electronic Modules

You can connect the following electronic modules to the TB 16IM-SC terminal block:

Chapter	Plug-In Electronic Modules	Order Number
Chapter 10:	2DIDC24V	6ES7 121-1BB00-0AA0
Digital SC Electronic	2DODC24V0.5A	6ES7 122-1BB00-0AA0
Modules Technical Data	2DODC24V2A	6ES7 122-1BB10-0AA0
Technical Data	Counter module 1COUNT40kHz	6ES7 127-1BE00-0AB0
	1DIAC120/230V	6ES7 121-1FA00-0AA0
	1DOAC120/230V	6ES7 122-1FA00-0AA0
	1DORel.AC230V	6ES7 122-1HA01-0AA0
Chapter 12:	2 AI U	6ES7 123-1FB00-0AB0
Analog SC Electronic	2 AI HS U	6ES7 123-1FB50-0AB0
Modules Technical Data	2 AI I	6ES7 123-1GB00-0AB0 6ES7 123-1GB10-0AB0
	2 AI HS I	6ES7 123-1GB50-0AB0, 6ES7 123-1GB60-0AB0
	2 AI TC	6ES7 123-1JB00-0AB0
	1 AI RTD	6ES7 123-1JA00-0AB0
	1 AO U	6ES7 124-1FA00-0AB0
	1 AO I	6ES7 124-1GA00-0AB0

Dimension Drawing

Figure 7-6 shows the front elevation of the TB 16IM-SC terminal block.




Figure 7-6 The TB 16IM-SC Terminal Block with the IM-SC Interface Module Mounted, Dimension Drawing



Caution

The spring terminal will be destroyed if you insert the screwdriver into the opening for the wires.

Only press the screwdriver into the rectangular openings of the terminal block.

Block Diagram

The figure below shows you the block diagram of the TB 16IM-SC terminal block.

The connections 3L+ and 3M are used for looping through the load voltage supply 2L+ and 2M.




Figure 7-7 Block Diagram of the TB 16IM-SC Terminal Block



Warning

There is a risk of injury and damage to property.

Connecting different phases of a three-phase system to a terminal block can lead to injury and damage to property.

Connect only one phase to each terminal block.

Technical Data

Dimensions and Weight		
Dimensions W×H×D (mm)	$160 \times 100 \times 73.6$	
Weight	260 g	
Module-Sp	pecific Data	
Number of slots	8	
Current-carrying capacity via 1L+ and 2L+	max. $2 \times 8A$	
Number of times an electronic module can be plugged into a slot of the TB 16IM-SC	max. 8	
Isolation tested (from slot to slot)	DC 4000 V	

7.6 Supplementary Terminals for the TB 16L and TB 32L

Definition The supplementary terminals allow you to upgrade the two-wire termination

of the ET 200L distributed I/O device to a three- or four-wire termination.

Versions Supplied

Table 7-4 Supplied Versions of the Supplementary Terminals

Channels	Tiers	Fixing	Order Number
	1	Screw-type terminal	6ES7 193-1FH20-0XA0
16	1	Spring terminal	6ES7 193-1FH50-0XA0
16	2	Screw-type terminal	6ES7 193-1FH30-0XA0
	2	Spring terminal	6ES7 193-1FH60-0XA0
	1	Screw-type terminal	6ES7 193-1FL20-0XA0
22	1	Spring terminal	6ES7 193-1FL50-0XA0
32		Screw-type terminal	6ES7 193-1FL30-0XA0
	2	Spring terminal	6ES7 193-1FL60-0XA0

Characteristics

With the supplementary terminals, every tier is jumpered internally.

Dimension Drawing

Figure 7-8 shows the dimension drawings for the supplementary terminals.




Figure 7-8 TB 16L/TB 32L Supplementary Terminals, Dimension Drawing

7.7 Supplementary Terminals for the TB 16SC and TB 16IM-SC

Definition

The supplementary terminals allow you to upgrade the two-wire termination of the ET 200L-SC IM-SC distributed I/O device and Smart Connect to a three- or four-wire termination.

Versions Supplied

Table 7-5 Supplied Versions of the Supplementary Terminals TB16SC/ TB 16IM-SC

Tiers	Fixing	Order Number
1	Screw-type terminal	6ES7 120-1AH00-0AA0
1	Spring terminal	6ES7 120-1BH00-0AA0
2	Screw-type terminal	6ES7 120-2AH00-0AA0
2	Spring terminal	6ES7 120-2BH00-0AA0
Shield terminal		6ES7 192-0AA0-0AA0

Characteristics

With the supplementary terminals, every tier is jumpered internally.

Dimension Drawing

Figure 7-8 shows the dimension drawings for the supplementary terminals.




Figure 7-9 TB 16SC/TB 16IM-SC Supplementary Terminals, Dimension Drawing

ET 200L Electronics Blocks – Technical Data

8

Introduction The components of the ET 200L cannot be upgraded with a Smart Connect.

This chapter contains the technical data of the ET 200L electronics blocks.

TB⇔EB Assignment The following table contains the assignment of the ET 200L electronic

blocks to the terminal blocks.

Table 8-1 Assignment of the ET 200L Electronic Blocks to the Terminal Blocks

Terminal Block	Electronics Block	Order Number
TB 16L – (6ES7 193-1CH00-0XA0,	ET 200L 16 DI DC 24 V	6ES7 131-1BH00-0XB0
6ES7 193-1CH00-0XA0,	ET 200L 16 DO DC 24 V/0.5A	6ES7 132-1BH00-0XB0
TB 32L -	ET 200L 32 DI DC 24 V	6ES7 131-1BL00-0XB0
(6ES7 193-1CL00-0XA0, 6ES7 193-1CL10-0XA0)	ET 200L 32 DO DC 24 V/0.5 A	6ES7 132-1BL00-0XB0
,	ET 200L 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL00-0XB0
TB 16L AC	ET 200L 16 DI AC 120 V	6ES7 131-1EH00-0XB0
(6ES7 193-1CH20-0XA0)	ET 200L 16 DO AC 120 V/1.0 A	6ES7 132-1EH00-0XB0
	ET 200L 16 DO DC 24 V/AC 120V/2.0 A	6ES7 132-1JH00-0XB0
	ET 200L 8 DI/8DO AC 120 V/1.0 A	6ES7 133-1EH00-0XB0
	ET 200L 8DI AC 120V/8 DO DC 24V/AC 120V/2.0 A	6ES7 133-1JH00-0XB0

Contents of the Chapter

Section	Subject	Page
8.1	Electronics Block L 16 DI DC 24 V – 6ES7 131-1BH00-0XB0	8-3
8.3	Electronics Block L 16 DO DC 24 V/0.5 A – 6ES7 132-1BH00-0XB0	8-9
9.2	Electronics Block L 32 DI DC 24 V – 6ES7 131-1BL00-0XB0	0-4
8.4	Electronics Block L 32 DO DC 24 V/0.5 A – 6ES7 132-1BL00-0XB0	8-12
8.5	Electronics Block L 16 DI/16 DO DC 24 V/0.5 A – 6ES7 133-1BL00-0XB0	8-15
8.6	Electronics Block L 16 DI AC – 6ES7 131-1EH00-0XB0	8-18
8.7	Electronics Block L 16 DO AC 120 V/ 1.0 A – 6ES7 132-1EH00-0XB0	8-21
8.8	Electronics Block L 16 DO DC 24 V/AC 120V/2.0 A – 6ES7 132-1JH00-0XB0	8-24
8.9	Electronics Block L 8 DI/8 DO AC 120 V/1.0 A – 6ES7 133-1EH00-0XB0	8-28
8.10	Electronics Block L 8DI AC 120V/8 DO DC 24V/AC 120V/2.0 A – 6ES7 133-1JH00-0XB0	8-31

8.1 Electronics Block L 16 DI DC 24 V – 6ES7 131-1BH00-0XB0

Characteristics

The L 16 DI DC 24 V electronics block has the following characteristics:

- 16 inputs in two groups, each of eight inputs
- Rated input voltage of 24 V DC
- Suitable for switches and proximity switches (BEROs)

View

The following figure shows a view of the electronics block.




Figure 8-1 View of the L 16 DI DC 24 V Electronics Block

Block Diagram

Figure 8-2 shows the block diagram.




Figure 8-2 Block Diagram of the L 16 DI DC 24 V Electronics Block

Technical Data The following table shows the technical data of the L 16 DI DC 24 V electronics block.

Dimensions and Weight		
Dimensions	$145 \times 60 \times 60.5$	
$W \times H \times D $ (mm)		
Weight	Approx. 130 g	
Module-Sp	ecific Data	
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	
Bus protocol	PROFIBUS-DP	
FREEZE compatibility	Yes	
Number of inputs	16	
Cable length		
• Unshielded	Max. 600 m	
• Shielded	Max. 1000 m	
Manufacturer ID	$0014_{\rm H}$	
Voltages, Curr	ents, Potentials	
Rated supply voltage for electronics (4L+, 5L+)	24 V DC	
• Reverse polarity protection	Yes	
• Power failure with- stand time	At least 20 ms	
Rated load voltage (1L+, 2L+ and 3L+)	24 V DC	
Maximum number of inputs driven simultaneously	16	
Galvanic isolation		
Between channels	No	
Between channels and PROFIBUS-DP	Yes	
Insulation tested with	500 V DC	
Power input		
• From supply voltage L4+/L5+	Max. 70 mA	
• From load voltage L1+ and L2+/L3+ (without load)	Max. 50 mA per load group	
Power loss of module	Typically 2.2 W	

Status, Interru	pts, Diagnostics	
Status display	Green LED per channel	
Interrupts	None	
Diagnostic function	Yes	
• Bus monitoring PROFIBUS-DP	Red "BF" LED	
• Monitoring of electronics power supply	Green "ON" LED	
Sensor Selection Data		
Input voltage		
• Rated value	24 V DC	
• At signal "1"	13 to 30 V	
• At signal "0"	-30 to 5 V	
Input current		
• At signal "1"	Typically 5 mA at 24 V	
Input delay		
• With "0" after "1"	2.0 to 4.5 ms	
• With "1" after "0"	2.0 to 4.5 ms	
Input characteristic	To IEC 1131-2 Type 1	
Connection of 2-wire BEROs	Possible	
• Permissible closed-cir- cuit current	Max. 1.5 mA	

8.2 Electronics Block L 16 DO DC 24 V/0.5 A – 6ES7 132-1BH00-0XB0

Characteristics

The L 16 DO DC 24 V/0.5 A electronics block has the following characteristics:

- 16 outputs in two groups, each of eight outputs
- Output current of 0.5 A per output
- Rated load voltage of 24 V DC
- Suitable for solenoids, DC contactors, and indicator lights

View

The following figure shows a view of the electronics block.




Figure 8-3 View of the L 16 DO DC 24 V/0.5 A Electronics Block

PROFIBUS-DP ON connection Internal Electronics В power supply Galvanic isolation $\times 10$ (Z) ×1 PROFIBUS address 4 4 EΒ 1L+ 2L+ 3L+ 4L+ 5L 10 ΤВ 1M 2M 3M 4M 5M 17 18 20 21 22 23 24 25 26 27 28 29 19 30 31 32 24 V_A 24 V_B 24 V_{internal} _ _B_ _

Block Diagram Figure 8-4 shows the block diagram.

Figure 8-4 Block diagram of the L 16 DO DC 24 V/0.5 A Electronics Block

Technical Data The following table shows the technical data of the L 16 DO DC 24 V/0.5 A electronics block.

Dimensi	ons and Weight	Cable length	
Dimensions	$145 \times 60 \times 60.5$	Unshielded	Max. 600 m
$W \times H \times D (mm)$		Shielded	Max. 1000 m
Weight	Approx. 130 g	Manufacturer ID	$0016_{\rm H}$
Module	e-Specific Data		
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	_	
Bus protocol	PROFIBUS-DP		
SYNC compatibility	Yes		
Number of outputs	16		

Voltages, Currents, Potentials		Actuator Selection Data		
Rated supply voltage for	24 V DC	Output voltage		
electronics (4L+, 5L+)Reverse polarity	Yes	• At signal "1"	At least L1+ (- 3 V) or L2+/L3+ (3 V)	
protection	103	Output current	L2+/L3+ (5 V)	
• Power failure with- stand time	At least 20 ms	• At signal "1"		
Rated load voltage (1L+, 2L+ and 3L+)	24 V DC	Rated value Permissible range	0.5 A 1 mA to 0.5 A	
Aggregate current of output	ts (per byte)	At signal "0" (residual current)	Max. 1 mA	
• Horizontal installation		[]	a load)	
Up to 30 °C	Max. 4 A	Output delay (with resistive		
Up to 40 °C	Max. 3 A	• With "0" after "1"	Max. 50 μs	
Up to 60 °C	Max. 2 A	• With "1" after "0"	Max. 200 μs	
All other installation		Load resistance range	41 Ω to 28 k Ω	
positions		Lamp load	Max. 5 W	
Up to 40 °C	Max. 2 A	Parallel connection of two outputs		
Galvanic isolation		For redundant control of load	Possible (outputs in same group only)	
 Between channels 	No	For performance im-	Not possible	
 Between channels and PROFIBUS-DP 	Yes	provement	•	
Insulation tested with	500 V DC	Driving a digital input	Possible	
Power input		Switching frequency		
• from supply voltage	Max. 70 mA	Resistive load	Max. 100 Hz	
L4+/L5+ • from load voltage L1+	• Inductive load to IEC 947-5-1, DC1	• Inductive load to IEC 947-5-1, DC13	Max. 0.5 Hz	
• from load voltage L1+ and L2+/L3+ (without load)		Lamp load	Max. 8 Hz	
		Limitation of voltage in-	Typically L1+ (-55 V) or	
Power loss of module	Typically 5 W	duced on circuit interrup-	L2+/L3+ (- 55 V)	
Status, Interru	pts, Diagnostics		Yes	
Status display	Green LED per channel	Short-circuit protection • Response threshold	Typically 0.7 A	
Interrupts	None	Response unesnote	Typically 0.7 A	
Diagnostic function	Yes			
Bus monitoring PROFIBUS-DP	Red "BF" LED			
• Monitoring of electronics power supply	Green "ON" LED			

8.3 Electronics Block L 32 DI DC 24 V 6ES7 131-1BL00-0XB0

Characteristics

The L 32 DI DC 24 V electronics block has the following characteristics:

- 32 inputs in two groups, each of 16 outputs
- Rated input voltage of 24 V DC
- Suitable for switches and proximity switches (BEROs)

View

The following figure shows a view of the electronics block.




Figure 8-5 View of the L 32 DI DC 24 V Electronics Block

Block Diagram Figure 8-6 shows the block diagram.




Figure 8-6 Block diagram of the L 32 DI DC 24 V Electronics Block

Technical Data The following table shows the technical data of the L 32 DI DC 24 V electronics block.

Dimensions and Weight				
Dimensions	$145 \times 60 \times 60.5$			
$W \times H \times D (mm)$				
Weight	Approx. 150 g			
Module-Specific Data				
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud			
Bus protocol	PROFIBUS-DP			
FREEZE compatibility	Yes			
Number of inputs	32			
Cable length				
• Unshielded	Max. 600 m			
• Shielded	Max. 1000 m			
Manufacturer ID	0015_{H}			
Voltages, Curr	ents, Potentials			
Rated supply voltage for electronics (4L+, 5L+)	24 V DC			
• Reverse polarity protection	Yes			
• Power failure with- stand time	At least 20 ms			
Rated load voltage (1L+, 2L+ and 3L+)	24 V DC			
Maximum number of inputs driven simultaneously	32			
Galvanic isolation				
• Between channels	No			
Between channels and PROFIBUS-DP	Yes			
Insulation tested with	500 V DC			
Power input				
• from supply voltage L4+/L5+	Max. 70 mA			
• from load voltage L1+ and L2+/L3+ (without load)	Max. 100 mA per load group			
Power loss of module	Typically 3.2 W			

Status, Interrupts, Diagnostics				
Status display	Green LED per channel			
Interrupts	None			
Diagnostic function	Yes			
• Bus monitoring PROFIBUS-DP	Red "BF" LED			
• Monitoring of electronics power supply	Green "ON" LED			
Sensor Selection Data				
Input voltage				
Rated value	24 V DC			
• At signal "1"	13 to 30 V			
• At signal "0"	-30 to 5 V			
Input current				
• At signal "1"	Typically 5 mA at 24 V			
Input delay				
• With "0" after "1"	2.0 to 4.5 ms			
• With "1" after "0"	2.0 to 4.5 ms			
Input characteristic	To IEC 1131-2 Type 1			
Connection of 2-wire BEROs	Possible			
• Permissible closed-circuit current	Max. 1.5 mA			

8.4 Electronics Block L 32 DO DC 24 V/0.5 A – 6ES7 132-1BL00-0XB0

Characteristics

The L 32 DO DC 24 V/0.5 A electronics block has the following characteristics:

- 32 outputs in two groups, each of 16 outputs
- Output current of 0.5 A per output
- Rated load voltage of 24 V DC
- Suitable for solenoids, DC contactors, and indicator lights

View

The following figure shows a view of the electronics block.




Figure 8-7 View of the L 32 DO Electronics Block DC 24 V/0.5 A

₩ H BF PROFIBUS-DP -7 ON connection _A _B Internal Electronics power supply \triangleright 24 V_A 24 V_B 24 V_{internal} Galvanic isolation $\times 1$ **PROFIBUS** \forall address 1M 2M 3M 4M 5M EΒ 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 17 18 19 20 21 49 50 51 52 53 26 27 28 29 30 31 32 58 59 60 61 62 63 64 22 54 24 56 25 57 ΤB

Block Diagram Figure 8-8 shows the block diagram.

Figure 8-8 Block Diagram of the L 32 DO DC 24 V/0.5 A Electronics Block

Technical data The following table shows the technical data of the L 32 DO DC 24 V/0.5 A electronics block.

Dimensions and Weight		
Dimensions W×H×D (mm)	$145 \times 60 \times 60.5$	
Weight	Approx. 150 g	
Module-	-Specific Data	
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	
Bus protocol	PROFIBUS-DP	
SYNC compatibility	Yes	
Number of outputs	32	
Cable length		
Unshielded	Max. 600 m	
Shielded	Max. 1000 m	
Manufacturer ID	$0011_{\rm H}$	

	Voltages, Currents, Potentials		
	ated supply voltage for ectronics (4L+, 5L+)	24 V DC	
•	Reverse polarity protection	Yes	
•	Power failure with- stand time	At least 20 ms	
	ated load voltage L+, 2L+ and 3L+)	24 V DC	
A	ggregate current of outpu	ts (per byte)	
•	Horizontal installation		
	Up to 30 °C	Max. 4 A	
	Up to 40 °C	Max. 3 A	
	Up to 60 °C	Max. 2 A	
•	All other installation positions		
	Up to 40 $^{\circ}$ C	Max. 2 A	

Galvanic isolation		Actuator Se	election Data	
Between channels	No	Output voltage		
Between channels and PROFIBUS-DP	Yes	• At signal "1"	At least L1+ (- 3 V) or L2+/L3+ (3 V)	
Insulation tested with	500 V DC	Output current		
Power input		• At signal "1"		
• from supply voltage L4+/L5+	Max. 70 mA	Rated value Permissible range	0.5 A 1 mA to 0.5 A	
• from load voltage L1+ and L2+/L3+ (without load)	Max. 100 mA per load group	• At signal "0" (residual current)	Max. 1 mA	
Power loss of module	Typically 7 W	Output delay (with resistive	e load)	
		• With "0" after "1"	Max. 50 μs	
Status, Interrupts, Diagnostics		• With "1" after "0"	Max. 200 μs	
Status display	Green LED per channel	Load resistance range	41 Ω to 28 $k\Omega$	
Interrupts	None	Lamp load	Max. 5 W	
Diagnostic function	Yes	Parallel connection of two outputs		
Bus monitoring PROFIBUS-DP	Red "BF" LED	For redundant control of load	Possible (outputs in same group only)	
Monitoring of electro-	Green "ON" LED			
nics power supply		 For performance improvement 	Not possible	
		Driving a digital input	Possible	
		Switching frequency		
		Resistive load	Max. 100 Hz	
		• Inductive load to IEC 947-5-1, DC13	Max. 0.5 Hz	
		Lamp load	Max. 8 Hz	

Limitation of voltage in-

duced on circuit interrup-

Short-circuit protection

Response threshold

Typically L1+ (-55 V) or

L2+/L3+ (55 V)

Typically 0.7 A

Yes

8.5 Electronics Block L 16 DI/16 DO DC 24 V/0.5 A – 6ES7 133-1BL00-0XB0

Characteristics

The L 16 DI/16 DO DC 24 V/0.5 A electronics block has the following characteristics:

- 16 inputs in a single group of 16 inputs
 - Rated input voltage of 24 V DC
 - Suitable for switches and proximity switches (BEROs)
- 16 outputs in a single group of 16 outputs
 - Output current of 0.5 A
 - Rated load voltage of 24 V DC
 - Suitable for solenoids, DC contactors, and indicator lights

View

The following figure shows a view of the electronics block.




Figure 8-9 View of the L 16 DI/16 DO DC 24 V/0.5 A Electronics Block

Block Diagram Figure 8-10 shows the block diagram.




Figure 8-10 Block Diagram of the L 16 DI/16 DO DC 24 V/0.5 A Electronics Block

Technical Data The following table shows the technical data of the L 16 DI/16 DO DC 24 V/0.5 A electronics block.

Dimensions and Weight		Cable length	
Dimensions	$145 \times 60 \times 60.5$	Unshielded	Max. 600 m
$W \times H \times D (mm)$		Shielded	Max. 1000 m
Weight	Approx. 130 g	Manufacturer ID	0017_{H}
Module-	Specific Data	Voltages, Cur	rents, Potentials
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	Rated supply voltage for electronics (4L+, 5L+)	24 V DC
Bus protocol	PROFIBUS-DP	Reverse polarity	Yes
FREEZE compatibility	Yes	protection	
SYNC compatibility	Yes	Power failure with-	At least 20 ms
Number of inputs	16	stand time	
Number of outputs	16	Rated load voltage (1L+, 2L+ and 3L+)	24 V DC
		Maximum number of inputs driven simultaneously	16

s (per byte)	Input delay	
- (F 0) (C)		2.0 to 4.5 ms
Max 4 A		2.0 to 4.5 ms
		To IEC 1131-2 Type 1
	_	Possible
Max. 2 A	BEROs	FOSSIDIE
	Permissible closed-cir- cuit current	Max. 1.5 mA
Max. 2 A		lection Data
		At least L1+ (- 3 V) or
Yes	-	L2+/L3+ (3 V)
500 V DC	_	
	_	
Max. 70 mA		0.5 A
		1 mA to 0.5 A
Max. 50 mA per load group	• At signal "0" (residual current)	Max. 1 mA
	Output delay (with resistive	load)
	• With "0" after "1"	Max. 50 μs
ots, Diagnostics	• With "1" after "0"	Max. 200 μs
Green LED per channel	Load resistance range	41 Ω to 28 $k\Omega$
None	Lamp load	Max. 5 W
Yes	Parallel connection of two of	outputs
Red "BF" LED	For redundant control of load	Possible (outputs in same group only)
Green "ON" LED	For performance improvement	Not possible
ection Data	Driving a digital input	Possible
	Switching frequency	
24 V DC	Resistive load	Max. 100 Hz
13 to 30 V	Inductive load to	Max. 0.5 Hz
-30 to 5 V	IEC 947-5-1, DC13	
	Lamp load	Max. 8 Hz
Typically 5 mA at 24 V	Limitation of voltage in- duced on circuit interrup- tion	Typically L1+ (- 55 V) or L2+/L3+ (- 55 V)
		Yes
	Response threshold	Typically 0.7 A
	500 V DC Max. 70 mA Max. 50 mA per load group Typically 5 W ots, Diagnostics Green LED per channel None Yes Red "BF" LED Green "ON" LED ction Data 24 V DC 13 to 30 V -30 to 5 V	Max. 3 A Max. 2 A Max. 2 A Max. 2 A Max. 2 A No Yes No Yes Output voltage At signal "1" Rated value Permissible range At signal "0" (residual current) Output delay (with resistive With "0" after "1" With "0" after "1" With "1" after "0" Load resistance range Lamp load Parallel connection of two of load For redundant control of load For performance improvement Driving a digital input Switching frequency Red "BF" LED Ction Data Input characteristic Connection of 2-wire BEROs Permissible closed-circuit current Output voltage At signal "1" Rated value Permissible range At signal "0" (residual current) Output delay (with resistive With "0" after "1" For performance improvement Driving a digital input Switching frequency Resistive load Inductive load to IEC 947-5-1, DC13 Lamp load Limitation of voltage in-

8.6 Electronics Block L 16 DI AC 120 V – 6ES7 131-1EH00-0XB0

Characteristics

The L 16 DI AC 120 V electronics block has the following characteristics:

- 16 inputs, fully isolated
- Rated input voltage of 120 VAC
- Suitable for switches and proximity switches compatible with IEC Type 2 currents

View

Figure 8-11 shows a view of the L 16 DI AC 120V electronics block.




Figure 8-11 View of the L 16 DI AC 120 V Electronics Block

Block Diagram Figure 8-12 shows the block diagram of the L 16 DI AC 120 V electronics block.




Figure 8-12 Block Diagram of the L 16 DI AC 120 V Electronic Block

Technical Data The following table shows the technical data of the L 16 DI AC 120 V electronics block.

Dimensions and Weight		
Dimensions	191 × 61 × 85.5	
$W \times H \times D (mm)$		
Weight	Approx. 341 g	
Module-Sp	ecific Data	
Baud rate	9.6; 19.2; 93.75; 187.5; 500, 1500, 3000, and 6000 kBaud	
Bus protocol	PROFIBUS-DP	
FREEZE compatibility	Yes	
Number of inputs	16	
I/O Cable length		
Unshielded	Max. 600 m	
Shielded	Max. 1000 m	
Manufacturer ID	$002A_{\mathrm{H}}$	
Voltages, Curr	ents, Potentials	
Supply voltage L1		
Rated value	120 VAC	
Permissible range	74 to 132 VAC	
Frequency	47 to 63 Hz	
Power failure withstand time	At least 20 ms	
Maximum number of inputs driven simultaneously	16	
Optical isolation		
Between channels	Yes	
Between L1 and PROFIBUS-DP	Yes	
Between channels and PROFIBUS-DP	Yes	
Insulation tested with	1500 VAC	
Power input		
• from supply voltage L1	Max. 90 mA	
Power loss of module	Typically 5.4 W	

Status, Ala	rms, Diagnostics
Status display	Green LED per channel
Alarms	None
Diagnostic function	Yes
• Bus monitoring PROFIBUS-DP	Red "BF" LED
 Monitoring of electronics power supply 	Green "ON" LED
Sensor S	Selection Data
Input voltage	
• Rated value	120 VAC
• With signal 1	74 to 132 VAC
• With signal 0	0 to 20 VAC
Input current	
• With signal 1	9 to 27 mA
• With signal 0	0 to 4 mA
Input delay	
• From 0 to 1	2 to 14 ms
• From 1 to 0	6 to 25 ms
Input characteristic	To IEC 1131-2 Type 2
Connection of 2-wire BEROs	Possible

8.7 Electronics Block L 16 DO AC 120 V/1.0 A – 6ES7 132-1EH00-0XB0

Characteristics

The L 16 DO AC 120 V/1.0 A electronics block has the following characteristics:

- 16 outputs, fully isolated
- Output current of 1.0 A
- Rated load voltage of 120 VAC
- Suitable for solenoids, AC contactors, and indicator lights

View

Figure 8-13 shows a view of the L 16 DO AC 120 V/1.0 A electronics block.




Figure 8-13 View of the L 16 DO AC 120 V/1.0 A Electronics Block

Block Diagram Figure 8-14 shows the bl

Figure 8-14 shows the block diagram of the $\,L$ 16 DO AC 120 V/1.0 A electronics block.




Figure 8-14 Block Diagram of the L 16 DO AC 120 V/1.0 A Electronics Block

Technical data The following table shows the technical data of the L 16 DO AC 120 V/1.0 A electronics block.

Dimensions and Weight		Status, Alarms, Diagnostics	
imensions	191 × 61 × 85.5	Status display	Green LED p
\forall H \times D (mm)		Alarms	None
eight	Approx. 294 g	Diagnostic function	Yes
Module-S ₁	pecific Data	Bus monitoring	Red "BF" LE
aud rate	9.6; 19.2; 93.75; 187.5	PROFIBUS-DP	Red DI EE
	500, 1500, 3000, and 6000 kBaud	Monitoring of electronics	Green "ON" I
us protocol	PROFIBUS-DP	power supply	
YNC compatibility	Yes	Actuator Se	election Data
umber of outputs	16	Load voltage L	
Cable length		Rated voltage	120 VAC
Unshielded	Max. 600 m	Permissible range	74 to 132 VA
Shielded	Max. 1000 m	Frequency	47 to 63 Hz
anufacturer ID	$0028_{\rm H}$	Output voltage	
Voltages, Curi	rents, Potentials	• With signal 1	At least L (- 1
ipply voltage L1		Output current	
Rated voltage	120 VAC	With signal 1	
Permissible range	74 to 132 VAC	Rated value	1.0 A Pilot Du
Frequency	47 to 63 Hz	Permissible range	0.1 to 1.0 A
Power failure withstand time	At least 20 ms	• With signal 0 (residual current)	Max. 2.6 mA
Aggregate current of outputs (per point)		Zero cross inhibit voltage	Max. 60 V
Horizontal installation	Y - F/	Output delay	Max. 20 ms
up to 40°C	Max. 1 A	(with resistive load)	
up to 60°C	Max. 0.4 A	Size of motor starter	
All other installation	1111/1 U.T 11	• Up to 40°C	Max. size 4 ac
positions		• Up to 60°C	Max. size 3 ac
up to 40°C	Max. 0.4 A	Lamp load	Max. 50 W
ptical isolation		Parallel connection of two	outputs
Between channels	Yes	For redundant control	Possible
Between L1 and PROFIBUS-DP	Yes	• For performance	Not possible
Between channels and PROFIBUS-DP	Yes	improvement Driving a digital input	Possible
nsulation tested with	1500 VAC	Switching frequency	
ower input		Resistive load	Max. 10 Hz
from supply voltage L	Max. 170 mA	Inductive load	Max. 0.5 Hz
Power loss of module	Typically 18.9 W	Lamp load	Max. 1 Hz
		Short-circuit protection	No

8.8 Electronics Block L 16 RO DC 24 V/AC 120 V/2.0 A – 6ES7 132-1JH00-0XB0

Characteristics

The L 16 RO DC 24 V/AC 120 V/2.0 A electronics block has the following characteristics:

- 16 relay outputs, fully isolated
- Output current of 2.0 A
- Rated load voltage of 24 V DC or 120 VAC
- Suitable for solenoids, contactors, and indicator lights
- Adjacent outputs of 24 V DC and 120 VAC are permitted

View

Figure 8-15 shows a view of the L 16 RO DC 24 V/AC 120 V/2.0 A electronics block.




Figure 8-15 View of the L 16 RO DC 24 V/AC 120V/2.0 A Electronics Block

Block Diagram Figure 8-16 shows the block diagram of the L 16 RO DC 24 V/AC 120 V/2.0 A electronics block.




Figure 8-16 Block Diagram of the L 16 RO DC 24 V/AC 120 V/2.0 A Electronics Block

Technical data The following table shows the technical data of the L 16 RO DC 24 V/AC 120 V/2.0 A electronics block.

Dimensions and Weight		Module	Module-Specific Data	
Dimensions W×H×D (mm) Weight	191 × 61 × 85.5 Approx. 302 g	Baud rate	9.6; 19.2; 93.75; 187.5; 500, 1500, 3000, and 6000 kBaud	
Weight	търгом. 302 д	Bus protocol	PROFIBUS-DP	
		SYNC compatibility	Yes	
		Number of outputs	16	
		I/O Cable length		
		Unshielded	Max. 600 m	
		Shielded	Max. 1000 m	
		Manufacturer ID	$0026_{\rm H}$	

Voltages, Currents, Potentials		Actuator Selection Data	
Supply voltage L1		Load voltage L	
Rated voltage	120 VAC	Rated voltage	24 V DC or 120 VAC
Permissible range	85 to 132 VAC	Permissible DC range	4.5 to 30 V DC
• Frequency	47 to 63 Hz	Permissible AC range	6 to 132 VAC
• Power failure withstand time	At least 20 ms	AC Frequency Output voltage	47 to 63 Hz
Aggregate current of output	ts (per byte)	With signal 1	At least L (– 1.0V)
Horizontal installation		Output current	At least L (- 1.0 v)
up to 40° C	Max. 2 A		
up to 60°C	Max. 1 A	• With signal 1 Rated value	2.0 A Pilot Duty
All other installation		Permissible range	10 mA to 2.0 A
positions up to 40°C	Max. 1 A	With signal 0 (residual current)	none
Optical isolation		Output delay	Max. 10 ms
Between channels	Yes	(with resistive load)	
Between L1 and	Yes	Size of motor starter	
PROFIBUS-DP		• Up to 40°C	NEMA Size 5
 Between channels and PROFIBUS-DP 	Yes	• Up to 60°C	NEMA Size 4
Insulation tested with	1500 VAC	Lamp load	Max. 50 W
Power input	1300 VIIC	Parallel connection of two	outputs
• from supply voltage L	Max. 220 mA	For redundant control of load	Possible
Power loss of module	Typically 25.6 W	For performance improvement	Not possible
Status, Alarn	ns, Diagnostics	Driving a digital input	Possible
Status display	Green LED per channel	Switching frequency	
Alarms	None	Resistive load	Max. 10 Hz
Diagnostic function	Yes	Inductive load	Max. 0.5 Hz
Bus monitoring PROFIBUS-DP	Red "BF" LED	Lamp load Short singuit protection	Max. 1 Hz
 Monitoring of electronics power supply 	Green "ON" LED	Short-circuit protection	No

Table 8-2 Service Life of the Contacts

	Resistive Load	Voltage	Switching Cycles (Typical)
•	Resistive load		
	0.5 A	30 V DC or 250 V AC	800.000
	1.0 A	30 V DC or 250 V AC	550.000
	2.0 A	30 V DC or 250 V AC	300.000
•	Inductive load (L/R = 7 ms; power factor = 0.4)		
	0.5 A	30 V DC or 250 V AC	500.000
	1.0 A	30 V DC or 250 V AC	300.000
	2.0 A	30 V DC or 250 V AC	100.000
•	Mechanical		20.000.000

8.9 Electronics Block L 8 Dl/8 DO AC 120 V/1.0 A – 6ES7 133-1EH00-0XB0

Characteristics

The L 8 DI/8 DO AC 120 V/1.0 A electronics block has the following characteristics:

- 8 inputs, fully isolated
 - Rated input voltage of 120 VAC
 - Suitable for switches and proximity switches, compatible with IEC Type 2 currents
- 8 outputs, fully isolated
 - Output current of 1.0 A
 - Rated load voltage of 120 VAC
 - Suitable for solenoids, AC contactors, and indicator lights

View

Figure 8-17 shows a view of the L 8 DI/8 DO AC 120 V/1.0 A electronics block.




Figure 8-17 View of the L 8 DI/8 DO AC 120 V/1.0 A Electronics Block

Block Diagram Figure 8-18 shows the block diagram of the L 8 DI/8 DO AC 120 V/1.0 A electronics block.




Figure 8-18 Block Diagram of the L 8 DI/8 DO AC 120 V/1.0 A Electronics Block

Technical dataThe following table shows the technical data of the L 8 DI/8 DO AC 120 V/1.0 A electronics block.

Dimensions and Weight		
Dimensions WxHxD (mm)	145 × 61 × 85 .5	
Weight	Approx. 318 g	
Module-Specific Data		
Baud rate	9.6; 19.2; 93.75; 187.5; 500, 1500, 3000, and 6000kBaud	
Bus protocol	PROFIBUS-DP	
FREEZE compatibility	Yes	
SYNC compatibility	Yes	
Number of inputs	8	

Number of outputs	8
I/O Cable length	
Unshielded	Max. 600 m
Shielded	Max. 1000 m
Manufacturer ID	$0029_{\rm H}$

Voltages, Curr	rents, Potentials	• From 1 to 7	6 to 25 ms
Supply voltage L1		Input characteristic	To IEC 1131-2 Type 2
Rated voltage	120 VAC	Connection of 2-wire	Possible
Permissible range	74 to 132 VAC	BEROs	
Frequency	47 to 63 Hz	Actuator Se	election Data
Power failure	At least 20 ms	Load voltage L	
withstand time		Rated voltage	120 VAC
Aggregate current of output	ts (per byte)	Permissible range	74 to 132 VAC
Horizontal installation		Frequency	47 to 63 Hz
up to 40° C	Max. 1 A	Output voltage	
up to 60° C	Max. 0.4 A	• With signal 1	At least L (- 1.5V)
All other installation		Output current	
positions		With signal 1	
up to 40° C	Max. 0.4 A	Rated value	1.0 A Pilot Duty
Optical isolation		Permissible range	0.1 to 1.0 A
Between channels	Yes	• With signal 0	Max. 2.6 mA
Between L1 and PROFIBUS-DP	Yes	(residual current) Zero cross inhibit voltage	Max. 60 V
Between channels and PROFIBUS-DP	Yes	Output delay (with resistive load)	Max. 20 ms
Insulation tested with	1500 VAC		
Power input		Size of motor starter	
• from supply voltage L	Max. 130 mA	• Up to 40°C	Max. size 4 acc. to NEMA
Power loss of module	Typically 12.2 W	• Up to 60°C	Max. size 3 acc. to NEMA
Status, Alarn	ns, Diagnostics	Lamp load	Max. 50 W
Status display	Green LED per channel	Parallel connection of two	
Alarms	None	For redundant control	Possible
Diagnostic function	Yes	of load	Tossioie
Bus monitoring PROFIBUS-DP	Red "BF" LED	For performance improvement	Not possible
Monitoring of	Green "ON" LED	Driving a digital input	Possible
electronics		Switching frequency	
power supply	ection Data	Resistive load	Max. 10 Hz
Input voltage	CCHOII Data	Inductive load	Max. 0.5 Hz
Rated value	120 VAC	Lamp load	Max. 1 Hz
With signal 1	74 to 132 VAC	Short-circuit protection	No
• With signal 0	0 to 20 VAC		
Input current	0 10 20 VIIC		
With signal 1	9 to 27 mA		
With signal 0	0 to 4 mA		
_	U IU 4 IIIA		
Input delay	2 to 14 mg		
• From 0 to 1	2 to 14 ms		

8.10 Electronics Block L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0 A – 6ES7 133-1JH00-0XB0

Characteristics

The L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0 A electronics block has the following characteristics:

- 8 inputs, fully isolated
 - Rated input voltage of 120 VAC
 - Suitable for switches and proximity switches, compatible with IEC Type 2 currents
- 8 relay outputs, fully isolated
 - Output current of 2.0 A
 - Rated load voltage of 24 V DC or 120 VAC
 - Suitable for solenoids, contactors, and indicator lights
 - Adjacent outputs of 24 V DC and 120 VAC are permitted

View

Figure 8-19 shows a view of the L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0 A electronics block.




Figure 8-19 View of the L 8DI AC 120 V/8 RO DC 24 V/AC 2.0A Electronics Block

Block Diagram Figure 8-20 shows the block diagram of the L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0 A electronics block.




Figure 8-20 Block Diagram of the L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0A Electronics Block

Technical dataThe following table shows the technical data of the L 8 DI AC 120 V/8 RO DC 24 V/AC 120 V/2.0A electronics block.

Dimensions and Weight		
Dimensions WxHxD (mm)	145 × 61 × 85.5	
Weight	Approx. 322 g	
Module-Specific Data		
Baud rate	9.6; 19.2; 93.75; 187.5; 500, 1500, 3000, and 6000kBaud	
Bus protocol	PROFIBUS-DP	
FREEZE compatibility	Yes	
SYNC compatibility	Yes	
Number of inputs	8	

Number of outputs	8
I/O Cable length	
 Unshielded 	Max. 600 m
• Shielded	Max. 1000 m
Manufacturer ID	0027н

Voltages, Curr	rents, Potentials	Input delay	
Supply voltage L1		• From 0 to 1	2 to 14 ms
Rated voltage	120 VAC	• From 1 to 7	6 to 25 ms
Permissible range	74 to 132 VAC	Input characteristic	To IEC 1131-2 Type 2
Frequency	47 to 63 Hz	Connection of 2-wire	Possible
Power failure	At least 20 ms	BEROs	
withstand time		Actuator Se	election Data
Aggregate current of output	ts (per point)	Load voltage L	
Horizontal installation		Rated voltage	24 V DC or 120 VAC
up to 40° C	Max. 2 A	Permissible DC range	4.5 to 30 V DC
up to 60° C	Max. 1 A	Permissible AC range	6 to 132 VAC
All other installation		AC Frequency	47 to 63 Hz
positions		Output voltage	
up to 40° C	Max. 1A	• With signal 1	At least L (- 1.0V)
Optical isolation		Output current	
Between channels	Yes	• With signal 1	
Between L1 and PROFIBUSDB	Yes	Rated value	2.0 A Pilot Duty
Between channels and	Yes	Permissible range	10 mA to 2.0 A
PROFIBUS-DP		• With signal 0 (residual current)	none
Insulation tested with	1500 VAC	Output delay (with	Max. 10 ms
Power input	15 460 4	resistive load)	
• from supply voltage L	Max. 160 mA		
Power loss of module	Typically 15.1 W	Size of motor starter	
·	ns, Diagnostics	• Up to 40°C	NEMA Size 5
Status display	Green LED per channel	• Up to 60°C	NEMA Size 4
Alarms	None	Lamp load	Max. 50 W
Diagnostic function	Yes	Parallel connection of two	outputs
Bus monitoring PROFIBUS-DP	Red "BF" LED	For redundant control of load	Possible
Monitoring of electronics power supply	Green "ON" LED	For performance improvement	Not possible
1 11 1	ection Data	Driving a digital input	Possible
Input voltage	TOWN DAVID	Switching frequency	
Rated value	120 VAC	Resistive load	Max. 10 Hz
With signal 1	74 to 132 VAC	Inductive load	Max. 0.5 Hz
• With signal 0	0 to 20 VAC	Lamp load	Max. 1 Hz
Input current	0.10.20 1110	Short-circuit protection	No
With signal 1	9 to 27 mA		
• With signal 0			
- with signal o	0 to 4 mA		

Table 8-3 Service Life of the Contacts

	Resistive Load	Voltage	Switching Cycles (Typical)
•	Resistive load		
	0.5 A	30 V DC or 250 V AC	800.000
	1.0 A	30 V DC or 250 V AC	550.000
	2.0 A	30 V DC or 250 V AC	300.000
•	Inductive load (L/R = 7 ms; power factor = 0.4)		
	0.5 A	30 V DC or 250 V AC	500.000
	1.0 A	30 V DC or 250 V AC	300.000
	2.0 A	30 V DC or 250 V AC	100.000
•	Mechanical		20.000.000

ET 200L-SC Electronics Blocks – Technical Data

Introduction The components of the ET 200L-SC can be upgraded with a Smart Connect.

This chapter contains the technical data of the ET 200L-SC electronics

blocks and the IM-SC interface module.

TB⇔EB Assignment The following table assigns the interface module/electronics blocks to the

terminal blocks.

Table 9-1 Assignment of the Interface Module/ET 200L-SC Electronics Blocks to the Terminal Blocks

Terminal Block	Interface Module/Electronics Block	Order Number
TB 16IM-SC (6ES7 120-0AH50-0AA0, 6ES7 120-0BH50-0AA0)	IM-SC interface module	6ES7 138-1XL00-0XB0
TB 16L – (6ES7 193-1CH00-0XA0,	ET 200L-SC 16 DI DC 24 V	6ES7 131-1BH11-0XB0
6ES7 193-1CH10-0XA0)	ET 200L-SC 16 DO DC 24 V/0.5 A	6ES7 132-1BH11-0XB0
TB 32L - (6ES7 193-1CL00-0XA0,	ET 200L-SC 32 DI DC 24 V	6ES7 131-1BL11-0XB0
6ES7 193-1CL10-0XA0)	ET 200L-SC 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL10-0XB0

Contents of the Chapter

Section	Topic	Page
9.1	Interface Module IM-SC 6ES7 138-1XL00-0XB0	9-2
9.2	Electronics Block L-SC 16 DI DC 24 V – 6ES7 131-1BH11-0XB0	9-4
9.3	Electronics Block L-SC 16 DO DC 24 V/0.5 A – 6ES7 132-1BH11-0XB0	9-7
9.4	Electronics Block L-SC 32 DI DC 24 V – 6ES7 131-1BL11-0XB0	9-10
9.5	Electronics Block L-SC 16 DI/16 DO DC 24 V/0.5 A 6ES7 133-1BL10-0XB0	9-13

9.1 Interface Module IM-SC

Order Number

6ES7 138-1XL00-0XB0

Characteristics

The IM-SC interface module has the following characteristics:

- It connects the TB 16IM-SC terminal block with the PROFIBUS-DP.
- It is swiveled onto the TB 16IM-SC terminal block.
- The PROFIBUS-DP can be connected and disconnected at the IM-SC interface module by means of the bus terminating switsch. In this way, a data line connected at A2 and B2 can be disconnected or looped through.
- When the PROFIBUS-DP screw-type terminal is removed, subsequent DP slaves are disconnected from the PROFIBUS-DP.
- When the connector for the power supply is removed, the IM-SC is switsched off. Subsequently connected slaves are not affected.

View

The following figure shows a view of the IM-SC interface module:




Figure 9-1 IM-SC Interface Module

Block Diagram Figure 9-2 shows the block diagram.




Figure 9-2 Block Diagram of the IM-SC Interface Module

Technical Data The following table shows the technical data of the IM-SC interface module:

Dimensions and Weight		
Dimensions		
$B \times H \times T (mm)$	$54 \times 100 \times 55$	
Weight	Approx. 130 g	
Module-Specific Data		
Baud rate	9.6; 19.2; 93.75; 187.5;	
	500 and 1500 kBaud	
Bus protocol	PROFIBUS-DP	
FREEZE compatibility	Yes	
SYNC compatibility	Yes	
Number of inputs	Max. 32	
Number of outputs	Max. 32	
Manufacturer ID	$802B_{\mathrm{H}}$	

Voltages, Currents, Potentials		
Rated supply voltage for electronics (4L+, 5L+)	24 V DC	
• Reverse polarity protection	Yes	
• Power failure with- stand time	At least 20 ms	
Maximum number of inputs/outputs driven simultaneously	32	
Galvanic isolation		
• Between channels and PROFIBUS-DP	Yes	
Insulation tested with	500 V DC	
Power loss of module	Typically 1.4 W	
Status, Interru	pts, Diagnostics	
Interrupts	None	
Diagnostic function	Yes	
Group error	Red "SF" LED	
Bus monitoring PROFIBUS-DP	Red "BF" LED	
• Monitoring of electronics power supply	Green "ON" LED	

9.2 Electronics Block L-SC 16 DI DC 24 V – 6ES7 131-1BH11-0XB0

Characteristics

The upgraded L-SC 16 DI DC 24 V electronics block has the following characteristics:

- 16 inputs in two groups, each of 8 inputs
- Rated input voltage of 24 VDC
- Suitable for switches and proximity switches (BEROs)
- Connection of a TB 16SC

View

The following figure shows a view of the electronics block.




Figure 9-3 View of the L-SC 16 DI DC 24 V Electronics Block

Block Diagram Figure 9-4 shows the block diagram.




Figure 9-4 Block Diagram of the L-SC 16 DI DC 24 V Electronics Block

Technical Data The following table shows the technical data of the L-SC 16 DI DC 24 V electronics block.

Dimensions and Weight		
Dimensions $145 \times 60 \times 60.5$		
$W \times H \times D \text{ (mm)}$	143 / 00 / 00.5	
Weight	Approx. 130 g	
Module-S ₁	pecific Data	
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	
Bus protocol	PROFIBUS-DP	
FREEZE compatibility	Yes	
SYNC compatibility for SC outputs	Yes	
Number of inputs	16	
Cable length		
Unshielded	Max. 600 m	
Shielded	Max. 1000 m	
Manufacturer ID	8027 _H	
Voltages, Curr	ents, Potentials	
Rated supply voltage for electronics (4L+, 5L+)	24 VDC	
Reverse polarity protection	Yes	
Power failure with- stand time	At least 20 ms	
Rated load voltage (1L+, 2L+ and 3L+)	24 VDC	
Maximum number of inputs driven simultaneously	16	
Galvanic isolation		
Between channels	No	
Between channels and PROFIBUS-DP	Yes	
Insulation tested with	500 VDC	
Power input		
• from supply voltage L4+/L5+	Max. 180 mA	
• from load voltage L1+ and L2+/L3+ (without load)	Max. 50 mA per load group	
Power loss of module	Typically 4.0 W	

Status, Interru	pts, Diagnostics
Status display	Green LED per channel
Interrupts	None
Diagnostic function	Yes
• Bus monitoring PROFIBUS-DP	Red "BF" LED
• Monitoring of electronics power supply	Green "ON" LED
• Group error	Red "GE" LED
Sensor Sele	ection Data
Input voltage	
• Rated value	24 VDC
• At signal "1"	13 to 30 V
• At signal "0"	-30 to 5 V
Input current	
• At signal "1"	Typically 5 mA at 24 V
Input delay	
• With "0" after "1"	2.0 to 4.5 ms
• With "1" after "0"	2.0 to 4.5 ms
Input characteristic	To IEC 1131-2 Type 1
Connection of 2-wire BEROs	Possible
• Permissible closed-cir- cuit current	Max. 1.5 mA

9.3 Electronics Block L-SC 16 DO DC 24 V/0.5 A – 6ES7 132-1BH11-0XB0

Characteristics

The upgraded L 16 DO DC 24 V/0.5 A electronics block has the following characteristics:

- 16 outputs in two groups, each of eight outputs
- Output current of 0.5 A
- Rated load voltage of 24 VDC
- Suitable for solenoids, DC contactors, and indicator lights
- TB 16SC connection

View

The following figure shows a view of the electronics block.




Figure 9-5 View of the L-SC 16 DO DC 24 V/0.5 A Electronics Block

Block Diagram Figure 9-6 shows the block diagram.




Figure 9-6 Block diagram of the L-SC 16 DO DC 24 V/0.5 A Electronics Block

Technical Data The following table shows the technical data of the L-SC 16 DO DC 24 V/0.5 A electronics block.

Dimensions and Weight		
Dimensions W×H×D (mm)	$145 \times 60 \times 60.5$	
Weight	Approx. 130 g	
Module-Specific Data		
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	
Bus protocol	PROFIBUS-DP	
SYNC compatibility	Yes	
FREEZE compatibility for SC inputs	Yes	
Number of outputs	16	

Cable length				
• Unshielded	Max. 600 m			
• Shielded	Max. 1000 m			
Manufacturer ID	8028 _H			

Voltages, Curr	ents, Potentials
ated supply voltage for ectronics (4L+, 5L+)	24 VDC
Reverse polarity protection	Yes
Power failure with- stand time	At least 20 ms
ated load voltage L+, 2L+ and 3L+)	24 VDC
aggregate current of output	ts (per byte)
Horizontal installation	
Up to 30 °C	Max. 4 A
Up to 40 °C	Max. 3 A
Up to 60 °C	Max. 2 A
All other installation positions	
Up to 40 °C	Max. 2 A
lvanic isolation	
Between channels	No
Between channels and PROFIBUS-DP	Yes
sulation tested with	500 VDC
wer input	
from supply voltage L4+/L5+	Max. 180 mA
from load voltage L1+ and L2+/L3+ (without load)	
Power loss of module	Typically 4.0 W
Status, Interru	pts, Diagnostics
atus display	Green LED per channel
terrupts	None
agnostic function	Yes
Bus monitoring PROFIBUS-DP	Red "BF" LED
Monitoring of electronics power supply	Green "ON" LED
Group error	Red "SF" LED

	election Data	
Output voltage		
• At signal "1"	At least L1+ (- 3 V) or L2+/L3+ (3 V)	
Output current		
• At signal "1"		
Rated value	0.5 A	
Permissible range	1 mA to 0.5 A	
• At signal "0" (residual current)	Max. 1 mA	
Output delay (with resistive load)		
• With "0" after "1"	Max. 50 μs	
• With "1" after "0"	Max. 200 μs	
Load resistance range	41 Ω to 28 $k\Omega$	
Lamp load Max. 5 W		
Parallel connection of two outputs		
• For redundant control of load	Possible (outputs in same group only)	
• For performance improvement	Not possible	
Driving a digital input	Possible	
Switching frequency		
• Resistive load	Max. 100 Hz	
• Inductive load to IEC 947-5-1, DC13	Max. 0.5 Hz	
Lamp load	Max. 8 Hz	
Limitation of voltage induced on circuit interruption	Typically L1+ (- 55 V) or L2+/L3+ (- 55 V)	
Short-circuit protection	Yes	
Response threshold	Typically 0.7 A	

9.4 Electronics Block L-SC 32 DI DC 24 V – 6ES7 131-1BL11-0XB0

Characteristics

The upgraded L-SC 32 DI DC 24 V electronics block has the following characteristics:

- 32 inputs in two groups, each of 16 outputs
- Rated input voltage of 24 VDC
- Suitable for switches, and proximity switches (BEROs)
- TB 16SC connection

View

The following figure shows a view of the electronics block.




Figure 9-7 View of the L-SC 32 DI DC 24 V Electronics Block

Block Diagram Figure 9-8 shows the block diagram.




Figure 9-8 Block diagram of the L-SC 32 DI DC 24 V Electronics Block

Technical Data The following table shows the technical data of the L-SC 32 DI DC 24 V electronics block.

Dimensions and Weight			
Dimensions W×H×D (mm)	$145 \times 60 \times 60.5$		
Weight	Approx. 150 g		
Module-S ₁	oecific Data		
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud		
Bus protocol	PROFIBUS-DP		
FREEZE compatibility	Yes		
SYNC compatibility for SC outputs	Yes		
Number of inputs	32		
Cable length			
Unshielded	Max. 600 m		
Shielded	Max. 1000 m		
Manufacturer ID	8029 _H		
Voltages, Curr	ents, Potentials		
Rated supply voltage for electronics (4L+, 5L+)	24 VDC		
Reverse polarity protection	Yes		
Power failure with- stand time	At least 20 ms		
Rated load voltage (1L+, 2L+ and 3L+)	24 VDC		
Maximum number of inputs driven simultaneously	32		
Galvanic isolation			
Between channels	No		
Between channels and PROFIBUS-DP	Yes		
Insulation tested with	500 VDC		
Power input			
• from supply voltage L4+/L5+	Max. 180 mA		
• from load voltage L1+ and L2+/L3+ (without load)	Max. 100 mA per load group		
Power loss of module	Typically 4.8 W		

Status, Interru	pts, Diagnostics			
Status display	Green LED per channel			
Interrupts	None			
Diagnostic function	Yes			
Bus monitoring PROFIBUS-DP	Red "BF" LED			
 Monitoring of electronics power supply 	Green "ON" LED			
Group error	Red "GE" LED			
Sensor Sele	ection Data			
Input voltage				
Rated value	24 VDC			
• At signal "1"	13 to 30 V			
• At signal "0"	-30 to 5 V			
Input current				
• At signal "1"	Typically 5 mA at 24 V			
Input delay				
• With "0" after "1"	2.0 to 4.5 ms			
• With "1" after "0"	2.0 to 4.5 ms			
Input characteristic	To IEC 1131-2 Type 1			
Connection of 2-wire BEROs	Possible			
Permissible closed-cir- cuit current	Max. 1.5 mA			

9.5 Electronics Block L-SC 16 DI/16 DO DC 24 V/0.5 A – 6ES7 133-1BL10-0XB0

Characteristics

The L-SC 16 DI/16 DO DC 24 V/0.5 A electronics block has the following characteristics:

- 16 inputs in a single group of 16 inputs
 - Rated input voltage of DC 24 V
 - Suitable for switches and proximity switches (BEROs)
- 16 outputs in a single group of 16 outputs
 - Output current of 0.5 A
 - Rated load voltage of DC 24 V
 - Suitable for solenoids, DC contactors, and indicator lights
- TB 16SC connection

View

The following figure shows a view of the electronics block.




Figure 9-9 View of the L-SC 16 DI/16 DO DC 24 V/0.5 A Electronics Block

Block Diagram Figure 8-10 shows the block diagram.




Figure 9-10 Block Diagram of the L-SC 16 DI/16 DO DC 24 V/0.5 A Electronics Block

Technical Data The following data shows the technical data of the L-SC 16 DI/16 DO DC 24 V/0.5 A electronics block.

Dimensions	and Weight	Number of outputs	16
Dimensions	$145 \times 60 \times 60.5$	Cable length	
$W \times H \times D (mm)$		Unshielded	Max. 600 m
Weight	Approx. 130 g	Shielded	Max. 1000 m
Module-Specific Data		Manufacturer ID	802C _H
Baud rate	9.6; 19.2; 93.75; 187.5; 500 and 1500 kBaud	Voltages,	Currents, Potentials
Bus protocol	PROFIBUS-DP	Rated supply voltage f electronics (4L+, 5L+)	
FREEZE compatibility for SC outputs	Yes	Reverse polarity protection	Yes
SYNC compatibility for SC outputs	Yes	Power failure with stand time	- At least 20 ms
Number of inputs	16		

Rated load voltage	DC 24 V	Input delay	
(1L+, 2L+ and 3L+)	DC 24 V	• At "0" after "1"	2,0 to 4.5 ms
Number of inputs driven	16		,
simultaneously		710 1 ditei 0	2.0 to 4.5 ms
Aggregate current of output	rs (per byte)	Input Characteristic	to IEC 1131-2 Type 1
Horizontal installation		Connection of 2-wire BEROs	Possible
Up to 30 °C	Max. 4 A	Permissible closed-cir-	Max. 1.5 mA
Up to 40 °C	Max. 3 A	cuit current	
Up to 60 °C	Max. 2 A	Actuator Se	lection Data
All other installation		Output voltage	
positions		• At signal "1"	At least $L1+(-3 \text{ V})$ or
Up to 40 °C	Max. 2 A		L2+/L3+ (- 3 V)
Galvanic isolation		Output current	
Between channels	No	• At signal "1"	
Between channels and BROFINIS DR	Yes	Rated value	0.5 A
PROFIBUS-DP	DC 500 V	Permissible range	1 mA to 0.5 A
Isolation tested with	DC 500 V	• At signal "0" (residual current)	Max. 1 mA
Power inputFrom supply voltage	Max. 180 mA	Output delay (with resistive	load)
L4+/L5+	Max. 100 IIIA	• At "0" after "1"	Max. 50 μs
From load voltage L1+	Max. 50 mA per load	• At "1" after "0"	Max. 200 μs
and L2+/L3+ (without	group	Load resistance range	41 Ω to 28 k Ω
load)	m : 11 5 W	Lamp load	Max. 5 W
Power loss of module	Typically 5 W	Parallel connection of two	
	pts, Diagnostics	For redundant control	Possible (outputs in same
Status display	Green LED per channel	of load	group only)
Interrupts	None	For performance im-	Not possible
Diagnostic function	Yes	provement	
Bus monitoring PROFIBUS-DP	Red LED "BF"	Driving a digital input	Possible
Monitoring of elec-	Green LED "ON"	Switching frequency	
tronics power supply	Older ELD OIT	Resistive load	Max. 100 Hz
Group error	Red LED "SF"	• Inductive load to IEC 947-5-1, DC13	Max. 0.5 Hz
Actuator Se	lection Data	Lamp load	Max. 8 Hz
Input voltage		Limitation of voltage in-	Typically L1+ (- 55 V) or
Rated value	DC 24 V	duced on circuit interrup-	L2+/L3+ (- 55 V)
• At signal "1"	13 to 30 V	Short-circuit protection	
• At signal "0"	-30 to 5 V	Response threshold	Typically 0.7 A
Input current			71 7
• At signal "1"	Typically 5 mA at 24 V		

SC Digital Electronic Modules – Technical Data

10

Contents of Chapter

Section	Торіс	Page
10.1	Digital Electronic Module 2DIDC24V	10-2
10.2	Digital Electronic Module 2DODC24V0.5A	10-5
10.3	Digital Electronic Module 2DODC24V2A	10-8
10.4	Digital Electronic Module 1DIAC120/230V	10-11
10.5	Digital Electronic Module 1DOAC120/230V1A	10-14
10.6	Digital Electronic Module 1DORel.AC230V	10-17

Order Numbers

Product Name	Order Number
Digital Electronic Module 2DIDC24V	6ES7 121-1BB00-0AA0
Digital Electronic Module 2DODC24V0.5A	6ES7 122-1BB00-0AA0
Digital Electronic Module 2DODC24V2A	6ES7 122-1BB10-0AA0
Digital Electronic Module 1DIAC120/230V	6ES7 121-1FA00-0AA0
Digital Electronic Module 1DOAC120/230V1A	6ES7 122-1FA00-0AA0
Digital Electronic Module 1DORel.AC230V	6ES7 122-1HA01-0AA0

10.1 Digital Electronic Module 2DIDC24V

Order Number 6ES7 121-1BB00-0AA0

Front Elevation/ Side Elevation

The figure below shows you the front elevation and the side elevation of the input module.

The circuit schematic is shown on the front of the input module. The two LEDs are located below the circuit schematic. In the operating state, the circuit schematic is covered by the labeling strip. The LEDs are visible through the transparent part of the labeling strip.




Figure 10-1 Front and Side Elevations of the 2DIDC24V Digital Electronic Module

Note

The status LEDs of the input module indicate the system status.

Block Diagram Figure 10-2 shows the block diagram of the 2DIDC24V digital electronic module.




Figure 10-2 Block Diagram of the 2DIDC24V Digital Electronic Module

Technical Data The technical data of the 2DIDC24V digital electronic module is listed below.

Dimensions and	Weight	Power input	
Dimensions W×H×D (mm)	10×64×51	From load voltage L+	_
Weight	approx. 15 g	Power loss of the module	typ. 0.4 W
Module-Specifc Data		Status, Interrupts, Diagnostics	
Number of inputs	2	Status indication	green LED per channel
Cable lengthUnshiededShielded	max. 600 m	Interrupts Diagnostic functions	none
Number of times the electronic module can be plugged into a	max. 20	Sensor Selection Input voltage	on Data
TB 16 SC Voltages, Current,	Potentials	Rated valueAt signal "1"	DC 24 V 13 30 V
Rated load voltage L+ Number of simultaneously con- trollable imputs	DC 24 V	At signal "0"Input currentAt signal "1"	-3 5 V typ. 7 mA
 Galvanic isolation Between channels and SC bus Between different channels 	no no	Input delay • At "0" to "1" • At "1" to "0"	1.24.8 ms 1.24.8 ms
Permissible potential difference • Between different circuits	DC 75 V/AC 60 V	Input characteristic to Connection of 2-wire BEROs Permissible closed-circuit current	IEC 1131, Type 1 possible max 1.5 mA

10.2 Digital Electronic Module 2DODC24V0.5A

Order Number 6ES7 122-1BB00-0AA0

Front Elevation/ Side Elevation

The figure below shows you the front elevation and the side elevation of the output module.

The circuit schematic is shown on the front of the output module. The two LEDs are located below the circuit schematic. In the operating state, the circuit schematic is covered by the labeling strip. The LEDs are visible through the transparent part of the labeling strip.




Figure 10-3 Front and Side Elevations of the 2DODC24V0.5A Digital Electronic Module

Note

The status LEDs of the output module indicate the system status.

Special Features

When L+ is connected by means of a mechanical contact, a disturbing pulse appears at the output with an exponentially increasing width from 8 μ s at rated current to 20 μ s at 10 mA load current. (The time specifications are based on a threshold of 10 V.)

Block Diagram

Figure 10-4 shows the block diagram of the 2DODC24V0.5A digital electronic module.




Figure 10-4 Block Diagram of the 2DODC24V0.5A Digital Electronic Module

Technical Data The technical data of the 2DODC24V0.5A digital electronic module is listed below.

Dimensions and	l Weight	
Dimensions W×H×D (mm)	10×64×51	
Weight	approx. 15 g	
Module-Specia	ic Data	
Number of outputs	2	
Cable length		
Unshielded	max. 600 m	
Shielded	max. 1000 m	
Number of times the electronic module can be plugged into a max. 20 TB 16 SC		
Voltages, Currents	s, Potentials	
Rated load voltage L+	DC 24 V	
Total current of the outputs (per module)		
• to 40°C	1 A	
• to 60°C	0.8 A	
Galvanic isolation		
Between channels and SC		
bus	no	
Between the different channels	no	
Permissible potential difference		
Between different circuits	DC 75 V/AC 60 V	
Power input		
- From load voltage L+	2	
(without load)	3 mA	
Power loss of the module	typ. 0.4 W	
Status, Interrupts,		
Status indication	green LED per channel	
Interrupts	none	
Diagnostic functions	none	

Actuator Selection Data			
Output voltage			
• At signal "1"	min. L+ (-0.5 V)		
Output current			
 At signal "1" Rated value Permissible range At signal "0" (residual cur- 	0.5 A 5 mA 0.6 A		
rent)	max. 0.5 mA		
Output delay (with resistive load)			
• At "0" to "1"	max. 200 μs		
• At "1" to "0"	max. 1.3 ms		
Load resistance range	48 Ω to 4.8 $k\Omega$		
Lamp load	max. 2.5 W		
Parallel switching of 2 outputs			
For redundant control of a load	not possible		
For performance enhancement	possible		
Controlling a digital input	possible		
Switching frequency			
With resistive load	max. 100 Hz		
• With inductive load in accordance with IEC 947-5-1, DC 13	max.2 Hz at 0.3 A max.0.5 Hz at 0.5 A		
With lamp load	max. 1 Hz		
Inductive switch-off voltage limited (internally) to typ. L+ (48 V)			
Short-circuit protection of the output	yes, electronically ¹		
Response threshold	typ. 0.71.8 A		
After a short-circuit, switch-on under full load cannot			

- After a short-circuit, switch-on under full load cannot be guaranteed. Countermeasures are:
- Change the signal at the output, or
- Interrupt the load voltage of the module, or
- Temporarily disconnect the load from the output.

10.3 Digital Electronic Module 2DODC24V2A

Order Number 6ES7 122-1BB10-0AA0

Front Elevation/ Side Elevation

The following figure shows you the front elevation and the side elevation of the output module.

The circuit schematic is shown on the front of the input module. The two LEDs are located below the circuit schematic. In the operating state, the circuit schematic is covered by the labeling strip. The LEDs are visible through the transparent part of the labeling strip.




Figure 10-5 Front and Side Elevations of the 2DODC24V2A Digital Electronic Module

Note

The status LEDs of the output module indicate the system status.

Special Features

When L+ is connected by means of a mechanical contact, a disturbing pulse appears at the output with an exponentially increasing width from 5 μ s at rated current to 100 μ s at 10 mA load current. (The time specifications are based on a threshold of 10 V.)

Block Diagram

Figure 10-6 shows the block diagram of the 2DODC24V2A digital electronic module.




Figure 10-6 Block Diagram of the 2DODC24V2A Digital Electronic Module

Technical Data The technical data of the 2DODC24V2A digital electronic module is listed below.

Dimensions and	l Weight
Dimensions W×H×D (mm)	10×64×51
Weight	approx. 15 g
Module-Specif	ic Data
Number of outputs	2
Cable length	
Unshielded	max. 600 m
Shielded	max. 1000 m
Number of times the electronic module can be plugged into a TB 16 SC	max. 20
Voltages, Current	
Rated load voltage L+	DC 24 V
Total current of the outputs (per module)	DC 24 V
• to 40°C	max. 3 A
• to 60°C	max. 2 A
Galvanic isolation	
Between channels and SC	
bus	no
Between the different channels	no
Permissible potential difference	
Between different circuits	DC 75 V/AC 60 V
Power input	
From load voltage L+ (without load)	6 mA
Power loss of the module	typ. 0.9 W
Status, Interrupts,	Diagnostics
Status indication	green LED per channel
Interrupts	none
Diagnostics function	none

	Actuator Selection Data			
	Output voltage			
	• At signal "1"	min. L+ (-0.5 V)		
	Output current			
	• At signal "1"			
	Rated value Permissible range	2 A		
	 For 0 to 40°C 	5 mA to 2.4 A		
	 For 40 to 60°C 	5 mA to 1.8 A		
	At signal "0" (residual current)	max. 0.6 mA		
=	Output delay (with resistive load)			
	• At "0" to "1"	max. 200 μs		
	• At "1" to "0"	max. 1.3 ms		
	Lamp load	max. 10 W		
	Load resistance range	12 Ω to 4.8 $k\Omega$		
	Parallel switching of 2 outputs			
	For performance enhancement	possible		
	For redundant control of a load	not possible		
	Controlling a digital input	possible		
	Switching frequency			
	With resistive load	max. 100 Hz		
	• With inductive load in accordance with IEC 947-5-1, DC 13	max. 0.2 Hz at 1 A max. 0.1 Hz at 2 A		
	• With lamp load	max. 1 Hz		
	Inductive switch-off voltage limited (internally) to	typ. L+ (48 V)		
	Short-circuit protection of the output	Yes, electronically		
	Response threshold	typ. 2.87.2 A		

- After a short-circuit, switch-on under full load cannot be guaranteed. Countermeasures are:
- Change the signal at the output, or
- Interrupt the load voltage of the module, or
- Temporarily disconnect the load from the output.

10.4 Digital Electronic Module 1DIAC120/230V

Order Number 6ES7 121-1FA00-0AA0

Front Elevation/ Side Elevation

The figure below shows you the front elevation and the side elevation of the digital electronic module.

The circuit schematic is shown on the front of the digital electronic module. The LED is located below the circuit schematic. In the operating state, the circuit schematic is covered by the labeling strip. The LED is visible through the transparent part of the labeling strip.




Figure 10-7 Front and Side Elevations of the 1DIAC120/230V Digital Electronic Module

Note

The status LED of the input module indicates the system status.

Block Diagram

Figure 10-8 shows the block diagram of the 1DIAC120/230V digital electronic module.




Figure 10-8 Block diagram of the 1DIAC120/230V Digital Electronic Module

Special Feature

The 1DIAC120/230V electronic module does not require a supply voltage (L+, M).

Technical Data The technical data of the 1DIAC120/230V electronic module is listed below.

Dimensions and Weight			
Dimensions W×H×D (mm)	10×64×51		
Weight	approx. 15 g		
Module Specific	Data		
Number of Inputs	1		
Cable Length			
Unshielded	max. 600 m		
Shielded	max. 1000 m		
Number of times the electronic module can be plugged into a			
TB 16 SC	max. 20		
Voltages, Currents, Potentials			
Galvanic isolation			
Between channels and SC bus	yes		
Permissible potential difference	Permissible potential difference		
Between ground and input	AC 240 V		
Isolation tested with	DC 2500 V		
Power loss of the module	typ. 0.6 W		
Status, Interrupts, Diagnostics			
Status indication	green LED		
Interrupts	none		
Diagnostic functions	none		

Sensor Selection Data		
Input voltage		
• Rated value	AC 120/230 V	
• At signal "1"	AC 74 264 V DC 75 264 V	
• At signal "0"	AC 0 40 V DC 0 40 V	
 Frequency range 	4763 Hz	
Input current		
• At signal "1"	typ. 3.,7 mA*	
• At signal "0"	typ. 2.2 mA*	
Input delay		
• At "0" to "1"	max. 30 ms	
• At "1" to "0"	max. 30 ms	
Input characteristic	in accordance with IEC 1131, Type 1*	
Connection of 2-wire BEROS	possible	
• Permissible closed-circuit current	max. 1.5 mA	

^{*} With parallel switching of 2 electronic modules, IEC 1131-2/Type 2 is complied with at AC 120 V.

10.5 Digital Electronic Module 1DOAC120/230V1A

Order Number 6ES7 122-1FA00-0AA0

Front Elevation/ Side Elevation The figure below shows you the front elevation and the side elevation of the 1DOAC120/230V1A





Figure 10-9 Front and Side Elevations of the 1DOAC120/230V1A Digital Electronic Module

Special Feature The 1DOAG

The 1DOAC120/230V1A electronic module does not require a supply voltage (L+, M).

Block Diagram Figure 10-10 shows the block diagram of the 1DOAC120/230V1A digital electronic module.



 $Figure\ 10\text{-}10\quad Block\ Diagram\ of\ the\ 1DOAC120/230V1A\ Digital\ Electronic\ Module$

Technical Data The technical data of the 1DOAC120/230V1A electronic module is listed below.

Dimensions and Weight			
Dimensions W×H×D (mm)	10×64×51		
Weight	approx. 15 g		
Module-Specific	Data		
Number of outputs	1		
Cable length			
Unshielded	max. 600 m		
Shielded	max. 1000 m		
Voltages, Currents, I	Potentials		
Rated load voltage L1	AC 120/230 V		
Permissible frequency range	4763 Hz		
Galvanic isolation			
Between channels and SC bus	yes		
Permissible potential difference			
Between ground and the out-	A C 240 M		
put	AC 240 V		
Isolation tested with	DC 2500 V		
Power loss of the module	typ. 0.7 W		
Status, Interrupts, D	iagnostics		
Status indication	green LED		
Interrupts	none		
Diagnostic functions	none		
Actuator Selection	n Data		
Output voltage			
• At signal "1"	min. L (1 V)		
Output current			
• At signal "1"	1 A		
- Rated value	1 A		
- Permissible range for 00 C to 400 C	40 mA 1.1 A		
 Permissible range for 40⁰ C to 60⁰ C 	40 mA 0.6 A		
 Permissible surge current 	max. 10 A (for 2 half-waves)		
At signal "0"(residual current)	max. 3 mA		
Output delay (with resistive load)			
• At "0" to "1"	max. 20 ms		
• At "1" to "0"	max. 20 ms		
Zero crossing	with zero crossing switch		

Size of the motor starter	max. size 8		
Lamp load			
• At AC 230 V	max. 100 W		
• At AC 120 V	max. 50 W		
Parallel switching of 2 outputs			
For redundant control of a load	possible		
For performance enhancement	not possible		
Controlling a digital input	only possible with additional load		
Switching frequency			
With resistive load	max. 50 Hz		
• With inductive load in accordance with			
IEC 947-5-1, AC 15	max. 10 Hz		
With lamp load	max. 1 Hz		
Short-circuit protection of the			
output	no		

10.6 Digital Electronic Module 1DORel.AC230V, DC 24 V to 120 V

Order Number 6ES7 122-1HA00-0AA0

Front Elevation/ Side Elevation The figure below shows you the front elevation and the side elevation of the 1DORel.AC230V digital electronic module.





Figure 10-11 Front and Side Elevations of the 1DORel.AC230V Digital Electronic Module

Block Diagram Figure 10-12 shows you the block diagram of the 1DORel.AC230V digital electronic module.



 $Figure\ 10\text{-}12\quad Block\ Diagram\ of\ the\ 1DORel. AC230V\ Digital\ Electronic\ Module$

Technical Data The technical data of the 1DORel.AC230V digital electronic module is listed below.

Dimensions and Weight				
Dimensions W×H×D (mm) $10\times64\times51$				
Weight	approx. 30 g			
Module-Specific	Module-Specific Data			
Number of outputs	1			
Contact type	1 x A			
Cable length				
Unshielded	max. 600 m			
Shielded	max. 1000 m			
Voltages, Currents, 1	Potentials			
Rated supply voltage of relay				
L+	DC 24 V			
Reverse polarity protection	yes			
Galvanic isolation				
Between channels and SC bus	yes			
Between channel and supply voltage of the relay	yes			
Permissible potential difference				
Between ground and supply voltage of the relay	DC 75 V, AC 60 V			
Between ground or supply voltage of the relay and the output	AC 240 V			
Isolation tested with				
Between ground and supply voltage of the relay	AC 1500 V			
Between ground or supply voltage of the relay and the output	DC 2500 V			
Power input				
From supply voltage L+	max. 15 mA			
Power loss of the module	typ. 0.7 W			
Status, Interrupts, Diagnostics				
Status indication	green LED			
Interrupts	none			
Diagnostic functions	none			

Actuator Selection Data			
Continuous thermal current	max. 5 A		
Minimum load current	1 mA		
Switching capacity and lifetime of the contacts	see Table 10-1		
• For resistive load	see Table 10-1		
For inductive load in accordance with			
IEC 947-5-1 DC13/AC15	see Table 10-1		
Lamp load	see Table 10-1		
Internal contact connection	Varistor rated voltage 275 V		
Parallel switching of 2 outputs			
For redundant control of a load	possible		
For performance enhancement	not possible		
Controlling a digital input	possible		
Switching frequency			
Mechanical	max. 10 Hz		
With resistive load	max. 1 Hz		
• With inductive load in accordance with IEC 947-5-1	max. 1 Hz		
DC13/AC15	max. 0.1 Hz		
With lamp load	max. 0.1 Hz		

Table 10-1 Switching capacity and lifetime of the contacts

With Resistive Load			
Voltage	Current	Number of Operations (Typ.)	
DC 24 V	5.0 A	0.1 million	
DC 24 V	1.0 A	0.5 million	
DC 24 V	0.5 A	1.5 million	
DC 60 V	0.5 A	1.0 million	
DC 120 V	0.2 A	1.0 million	
AC 48 V	5.0 A	0.3 million	
AC 60 V	5.0 A	0.2 million	
AC 120 V	5.0 A	0.1 million	
AC 120 V	1.0 A	1.0 million	
AC 120 V	0.5 A	2.5 million	
AC 230 V	5.0 A	0.2 million	
AC 230 V	1.0 A	0.5 million	
AC 230 V	0.5 A	1.5 million	
	·	·	
For Inductive Load in Accordance with IEC 947-5-1 DC13/AC15 and Lamp Load			
1	Luau		
Voltage	Current	Number of Operations (Typ.)	
Voltage DC 24 V	1		
	Current	(Typ.)	
DC 24 V	Current 1.0 A	(Typ.) 0.1 million	
DC 24 V DC 24 V	1.0 A 0.5 A	(Typ.) 0.1 million 0.5 million	
DC 24 V DC 24 V DC 60 V	1.0 A 0.5 A 0.5 A	(Typ.) 0.1 million 0.5 million 0.5 million	
DC 24 V DC 24 V DC 60 V DC 120 V	Current 1.0 A 0.5 A 0.5 A 0.2 A	(Typ.) 0.1 million 0.5 million 0.5 million 0.1 million	
DC 24 V DC 24 V DC 60 V DC 120 V AC 48 V	Current 1.0 A 0.5 A 0.5 A 0.2 A 2.0 A	(Typ.) 0.1 million 0.5 million 0.5 million 0.1 million 1.0 million	
DC 24 V DC 24 V DC 60 V DC 120 V AC 48 V AC 60 V	Current 1.0 A 0.5 A 0.5 A 0.2 A 2.0 A	(Typ.) 0.1 million 0.5 million 0.5 million 0.1 million 1.0 million	
DC 24 V DC 24 V DC 60 V DC 120 V AC 48 V AC 60 V AC 120 V	Current 1.0 A 0.5 A 0.5 A 0.2 A 2.0 A 2.0 A	(Typ.) 0.1 million 0.5 million 0.5 million 0.1 million 1.0 million 1.0 million 0.5 million	
DC 24 V DC 24 V DC 60 V DC 120 V AC 48 V AC 60 V AC 120 V	Current 1.0 A 0.5 A 0.5 A 0.2 A 2.0 A 2.0 A 1.0 A	(Typ.) 0.1 million 0.5 million 0.5 million 0.1 million 1.0 million 1.0 million 0.5 million 0.7 million	
DC 24 V DC 24 V DC 60 V DC 120 V AC 48 V AC 60 V AC 120 V AC 120 V	Current 1.0 A 0.5 A 0.5 A 0.2 A 2.0 A 2.0 A 1.0 A 0.7 A	(Typ.) 0.1 million 0.5 million 0.1 million 1.0 million 1.0 million 0.5 million 1.0 million 1.0 million 1.0 million	
DC 24 V DC 24 V DC 60 V DC 120 V AC 48 V AC 60 V AC 120 V AC 120 V AC 120 V	Current 1.0 A 0.5 A 0.5 A 0.2 A 2.0 A 2.0 A 1.0 A 0.7 A	(Typ.) 0.1 million 0.5 million 0.1 million 1.0 million 1.0 million 0.7 million 1.0 million 2.0 million	

The lifetime is longer with an external suppression circuit.

SC Analog Electronic Modules – Parameters

11

Contents of the Chapter

Section	Торіс	
11.1	Parameters of the Analog Input Modules	
11.2	Notes on the Parameters of the Analog Input Modules	
11.3	Default Parameters of the Analog Input Modules	
11.4	Behavior of the Analog Input Modules	11-7
11.5	Conversion and Cycle Times of the Analog Input Channels	11-8
11.6	Connection of Thermocouples	11-9
11.7	Connecting Non-Isolated Voltage Sensors	11-14
11.8	Connecting Current Sensors	11-15
11.9	Connecting Resistance Thermometers and Resistors	11-17
11.10	Floating Measuring Sensors	11-18
11.11	Wiring Unused Inputs of Analog Input Modules	11-19
11.12	Parameters of the Analog Output Modules	11-20
11.13	Notes on the Parameters of the Analog Output Modules	11-21
11.14	Default Parameters of the Analog Output Modules	11-22
11.15	Behavior of the Analog Output Modules	11-23
11.16	Conversion, Cycle, Settling and Response Times of the Analog Output Modules	11-24
11.17	Connecting Loads/Actuators to Analog Outputs	11-26
11.18	Wiring Unused Analog Output Modules	11-28
11.19	Analog Value Representation in S7 Number Format	11-29
11.20	Analog Measurement Ranges for Input Channels in S7 Number Format	11-30
11.21	Analog Value Representation for Analog Input Modules in S7 Number Format	11-32
11.22	Analog Output Ranges for Output Channels in S7 Number Format	11-37
11.23	Analog Value Representation for Output Modules in S7 Number Format	
11.24	Analog Value Representation in S5 Number Format	11-41
11.25	Analog Measurement Ranges for Input Channels in S5 Number Format	11-43
11.26	Analog Value Representation for Analog Input Modules in S5 Number Format	11-45
11.27	Analog Output Ranges for Output Channels in S5 Number Format	11-50
11.28	Analog Value Representation for Output Modules in S5 Number Format	11-52

11.1 Parameters of the Analog Input Modules

This section contains an overview of the parameters of the analog input modules.

The modules use a subset of the parameters and value ranges listed below, depending on their functionality.

Tool for Parameterization

You will find the tools for parameterization described in Section 4.1.

Parameters

In the following table, you will find all the parameters used by analog modules.

Parameter			
The following settings are possible for each channel:			
Measurement range deactivated (yes/no)			
Voltage measurement range			
\pm 80 mV			
1 5 V			
\pm 10 V			
Current measurement range for 4-wire measuring transducer			
0 20 mA			
4 20 mA			
$\pm 20 \text{ mA}$			
Current measurement range for 2-wire measuring transducer			
4 20 mA			
Resistance measurement range, 4-conductor connection			
600 Ω			
Thermal resistance with linearization, 4-conductor connection			
Pt 100 climatic range			
Pt 100 standard range			
Ni 100 standard range			
Thermocouples with linearization			
Type R			
Type J			
Type K			

Interference frequency suppression 50 Hz interference suppression 60 Hz interference suppression Smoothing None Weak smoothing Medium smoothing Strong smoothing Reference junction None Dynamic reference temperature at Pt100 module on A Dynamic reference temperature

Format (analog value representation)

S5 format

S7 format

11.2 Notes on the Parameters of the Analog Input Modules

Measurement Type/Measurement Range Each module is intended for a specific measurement type. You can select a measurement range for each channel.

Measurement Type	Measurement Ranges	Notes
Deactivated		Use this parameter if you have not connected a sensor to this channel and you want to shorten the module cycle time.
Voltage measurement range	± 80 mV ± 10 V	
Current, 4-wire measuring transducer	± 20 mA; 420 mA	
Current, 2-wire measuring transducer	420 mA	The 2-wire measuring transducers must be operated via an external voltage source at +24 V.
Resistance measurement range, 4-conductor connection	0 600 Ω	The 4-conductor connection gives the maximum possible accuracy. The conductor resistances are in principle fully compensated.
Resistance thermometer with linearization 4-conductor connection	Platinum and nickel resistance thermometer	Temperature characteristics of various resistance thermometers (dynamic reference temperature) are stored in the module's ROM. The converted analog value is shown in units of 0.1 (0.5)* °C in the standard temperature range and 0.01 (0.05)* °C in the climatic temperature range.
Thermocouples with linearization	Type R (PtRh-Pt) Type J (Fe-CuNi) Type K (NiCr-Ni)	Temperature characteristics of various thermocouples are stored in the module's ROM. The converted analog value is shown in units of 0.1 (1)*oCt. * The values in brackets refer to \$5 format.

Reference Junction

If you have connected a thermocouple, the following options are available to you for specifying the reference junction:

Reference Junction	Notes
None	The module records only the temperature difference between the measurement point and the free ends of the thermocouple.
Dynamic reference temperature module on A	Connect a platinum resistance thermometer to the resistance measurement module on slot A in order to record the reference junction in the climatic temperature range. Any thermocouple types on the remaining slots can then use this reference temperature.
	ET 200L-SC and Smart Connect: The reference temperature refers to slot A on the TB16SC and applies to all other SC modules.
	ET 200L-SC IM-SC and Smart Connect: The reference temperature refers to slot A on the TB 16IM-SC and applies to all other SC modules. Slot A of the TB16 SC cannot generate a reference temperature.
Dynamic reference temperature ¹	Select this option if the temperature at your reference junction is constant or the temperature at the reference junction is recorded by another module. You can specify the temperature in the reference temperature parameter and adjust it dynamically in RUN mode.

In the case of the ET 200L-SC, the dynamic reference temperature is only possible with S7 masters.

Reference Temperature

Here you can enter the reference junction temperature in the climatic temperature range for recording temperatures using thermocouples (in S7 number format: 0.01°C and in S5 number format: 0.05°C).

You can update this parameter using your application program. You can, for instance, record the reference junction temperature via another module.

In the case of the ET 200L-SC or ET 200L-SC IM-SC, entering the reference temperature is only possible with S7 masters.

Interference Frequency Suppression

The frequency of your AC power supply can interfere with the measured value particularly in the case of low voltage ranges and thermocouples. Enter the mains frequency of your system.

Smoothing

The various measured values are smoothed by digital filtering. You can choose between no, weak, medium and strong smoothing for each module. The stronger the smoothing, the greater the time constant of the filter.

Format

The analog input module supplies its information in S5 or S7 number format, depending the parameterization.

11.3 Default Parameters of the Analog Input Modules

Default Parameters

If you have not set the parameters of the relevant module using the specified software (Chapter 4), the default settings apply to all input channels after a restart. Specifically, this means:

Table 11-1 Default Parameters of the Analog Input Modules

Parameters		Default Value	
Measurement type		Each module is intended for a specific measurement type.	
		Measurement Range	
Module type	for voltage input	± 10 V	
Module type	for current input	4 20 mA	
Module type	for resistance input	Pt 100 standard	
Module type	for thermocouple input	Thermocouple type K	
Interference frequency suppression		50 Hz	
Smoothing		None	
Reference junction		None	
Reference temperature value		0000H	
Format		S7 format	

11.4 Behavior of the Analog Input Modules

Introduction

This section describes:

- The dependency of analog input values on the load power supply of the analog modules and the operating states of the CPU
- The behavior of the analog modules depending on the position of the analog values in each value range
- The effect of faults on the analog modules

Extreme Range of the Analog Signals

The behavior of the analog input modules depends on which part of the value range the input values are in.

Table 11-2 Effect of the Operating Mode of the CPU and the Supply Voltage L+ on the Analog Input Values

Operating Mode of the CPU		Supply Voltage L+	Input Value of the Analog Module	
	at the Analog Module		S7 Number Format	S5 Number Format
POWER ON	RUN	L+ applied	Process value	Process value
			7FFF _H until the conclusion of the 1st conversion after the parameterization of the module.	7FFF _H until the conclusion of the 1st conversion after the parameterization of the module.
		L+ not applied	7FFF _H	7FFF _H
POWER ON	STOP	L+ applied	Process value	Process value
			7FFF _H until the conclusion of the 1st conversion after the parameterization of the module.	7FFF _H until the conclusion of the 1st conversion after the parameterization of the module.
		L+ not applied	7FFF _H	7FFF _H
POWER OFF	_	L+ applied	_	_
		L+ not applied	_	-

11.5 Conversion and Cycle Times of the Analog Input Channels

In this section, you will find the definitions and interrelationships of the conversion time and cycle time for analog input modules.

Conversion time

The conversion time consists of the basic conversion time and additional processing times of the module. The basic conversion time depends directly on the conversion process (integrated process, successive approximation) of the analog input channel. In integrating conversion processes, the integration time is included directly with the conversion time. The integration time is dependent on the interface frequency suppression.

Cycle Time in a Module

Analog/digital conversion and transfer of the digitized measured values to the SC bus are sequential. In other words, the analog input channels are converted one after the other. The cycle time (i.e. the time until another analog input value is converted) is the sum of the conversion times of the activated analog input channels of an analog input module (see Chapter 12). You should activate unused analog input channels to reduce the cycle time.

Cycle Time to the System

The transfer of the digitized measured values to the system depends on the interface used and the degree of expansion of the Smart Connect.

If you are using an ET 200L-SC with analog SC modules, you must allow the following times for the transmission of the digitized measured values:

- 12 ms for each analog module
- An additional 10 ms for each 2 AI TC SC module for which you have set the reference temperature transfer parameter (dynamically or from the dynamic reference temperature module on slot A)

The total cycle time thus depends on the cycle time in the SC modules (see Chapter 12) plus the cycle times to the system, as described above.

11.6 Connecting Thermocouples

Thermocouples are used to measure temperature. There are various types of thermocouple, which differ with regard to their temperature range and output voltage, depending on the material of their wires.

Structure of Thermocouples

A thermocouple assembly consists of:

- The thermocouple itself (sensor)
- The required built-in and connected components.

The thermocouple itself consists of two wires made of different metals or metal alloys, the ends of which are soldered or welded together. Thermocouples are categorized into different types (e.g. R, J, K) according to the combination of materials used. The measurement principle is the same for all thermocouple types.




Figure 11-1 Structure of Thermocouples

How Thermocouples Work

If the measurement point is subjected to a different temperature to the free end of the thermocouple, a potential difference develops between the free ends, which is referred to as the thermal e.m.f.

The thermal e.m.f. depends on the difference between the temperature of the measurement point and the temperature at the free ends of the reference junction, as well as the combination of materials used in the thermocouple. A thermocouple always measures a temperature difference, so to determine the temperature of a measurement point the free ends at a reference junction must be kept at a known temperature.

Compensation of the Reference Junction Temperature

You have various options for measuring the reference junction temperature in order to obtain an absolute temperature value from the temperature difference between the reference junction and the measurement point.

Table 11-3 Compensation of the Reference Junction Temperature

Option	Notes	Reference Junction Parameters
No compensation	When you only want to measure the temperature difference between the measurement point and the reference junction.	None
Use of a compensating box in the supply conductors of a single thermocouple	You have already measured and compensated the reference junction temperature using a compensating box looped into the supply conductors of a single thermocouple. No further processing on the part of the module is required.	None
Use of a resistance thermometer to measure the reference junction temperature (recommended method)	You can measure the reference temperature using a resistance thermometer (platinum), and have the module calculate it for any thermocouple of this terminal block.	Dynamic reference temperature module on A
Constant reference junction temperature (thermostat, ice bath)	If the reference junction temperature is constant and known, you can specify this value in the dynamic parameters.	Dynamic reference temperature
Distribution of thermocouples with the same reference junction across several modules	Use a resistance measurement module with a connected dynamic reference temperature module, which measures the reference junction temperature, and set the parameters of the reference junctions of the thermocouples as described above (dynamic reference temperature module on A). Read the climatic temperature into the CPU, and pass the value via SFC55 to the other module.	Dynamic reference temperature

Connecting Thermocouples

Connect the thermocouple to the inputs of the modules either directly or via equalizing conductors. Each channel, independently of the other channel, can use any thermocouple type supported by the analog input module.




Figure 11-2 Connecting Insulated Thermocouples Without Compensation, With Internal Compensation, or Use of the Reference Temperature (Example TB 16SC)

Non-Insulated Thermocouples

If you use non-insulated thermocouples, you must be careful to comply with the permitted common-mode voltage.

Extension to a Reference Junction

The thermocouples can be extended from their connecting point via equalizing conductors to a point with as constant a temperature as possible (reference junction).

The equalizing conductors are made of the same material as the wires of the thermocouple. The supply conductors are of copper. In this case, internal compensation must not be set. Ensure that the polarity of the connection is correct, since otherwise serious measurement errors occur.

Equalizing Circuit

The effect of temperature fluctuations on the reference junction can be compensated for by an equalizing circuit (e.g. by means of a compensating box for a reference junction outside the terminal block or by means of internal compensation for a reference junction in the terminal block). In this case, the equalizing conductors must lead to the terminal block.

Use of a Compensating Box

The effect of temperature on the reference junction of a thermocouple (e.g. terminal box) can be equalized by means of a compensating box.

The compensating box contains a bridge circuit, which is compensated for a specified reference junction temperature (compensating temperature). The connections for the ends of the equalizing conductor of the thermocouple form the reference junction.

If the actual reference temperature differs from the compensating temperature, the temperature-dependent bridge resistance changes. The result is a positive or negative compensation voltage, which is added to the thermal e.m.f.

To compensate the analog input modules, compensating boxes with the **reference junction temperature of 0** °C must be used.

Note:

- The compensating box must be supplied potential-free.
- The power supply unit must have sufficient interference filtering (e.g. by means of a grounded shielding winding).

Compensation by Measurement of the Reference Junction Temperature If all thermocouples connected to the inputs of the analog modules of a terminal block have the same reference junction, compensate them as follows:




Figure 11-3 Connecting Insulated Thermocouples of the Same Type with External Compensation, via a Resistance Thermometer Connected to the Resistance Measurement Module, to Slot A of the Terminal Block (Example TB 16SC)

Connect the resistance thermometer to the module on slot A. Note the parameterization of the reference junction for each thermocouple channel.

Abbreviations

In Figures 11-2 and 11-3, the abbreviations have the following meanings:

IC +: Constant current line (positive)
 IC-: Constant current line (negative)
 M +: Measurement line (positive)
 M-: Measurement line (negative)

11.7 Connecting Non-Isolated Voltage Sensors

Voltage Sensors Figure 11-4 shows how to connect voltage sensors to an analog input module.




Figure 11-4 Connecting Voltage Sensors (Example TB 16SC)

4-wire measuring transducers with voltage output are connected like voltage sensors.

11.8 Connecting Current Sensors

Supply Voltage of the Sensors

You can only connect 4-wire measuring transducers or 2-wire measuring transducers with external supply voltage to the modules.

Connecting 4-Wire Measuring Transducers Figure 11-5 shows you how to connect current sensors as 4-wire measuring transducers to analog input modules.




Figure 11-5 Connecting 4-Wire Measuring Transducers (Example TB 16SC)

Connecting 2-Wire Measuring Transducers

Figure 11-6 shows you how to connect 2-wire measuring transducers with an external power supply to current input modules.




Figure 11-6 Connecting 2-wire measuring transducers (Example TB 16SC)

11.9 Connecting resistance thermometers and resistors

The resistance thermometers and resistors are measured by means of a 4-conductor system. A constant current is fed via terminals IC + and IC - to the resistance thermometers and resistors. The resulting voltage at the resistance thermometer and resistor is measured via terminals M + and M -. Very precise measurement results are thus obtained at the 4-conductor connection.

4-Conductor Connection

Figure 11-7 shows how to implement the 4-conductor connection for resistance thermometers/resistors.




Figure 11-7 4-Conductor Connection for Resistance Thermometers and Resistors (Example TB 16SC)

11.10 Floating Measuring Sensors

Floating Measuring Sensors In the case of floating measuring sensors, potential differences can occur between the individual measuring sensors and in comparison to M. These potential differences can also be caused by malfunctions or the spatial distribution of the measuring sensors. Ensure that U_{CM} does not exceed the permitted value (e.g. by using an equalizing conductor).

11.11 Wiring Unused Inputs of Analog Input Modules

To avoid malfunctions, you should deactivate unused channels of analog input modules using the configuration tool and wire as follows:

- In the case of analog input modules for voltage, current and thermocouples:
 - Insert a bridge between M+ and M-, and connect it to the ground (M) of the terminal block.
- In the case of analog input modules for resistance thermometers:
 - Insert a bridge between M+ and M-, and connect it to the ground (M) of the terminal block. IC+ and IC- remain unwired.
- In the case of the 2 AI HS I analog input module (6ES7 123-1GB50-0AB0):

Leave the inputs of the unused channel unwired.

11.12 Parameters of the Analog Output Modules

This section contains an overview of the parameters of the analog output modules.

The modules use a subset of the parameters and value ranges listed below, depending on their functionality.

Tool for Parameterization

The parameterization tools are described in Chapter 4.

Parameters of the Analog Output Modules

The table 11-4 shows which parameters are used by the analog output modules.

Table 11-4 Parameters of the Analog Output Modules

Parameters									
The following settings are possible:									
Measurement range deactivated (yes/no)									
Voltage range									
1 5 V									
± 10 V									
Current range									
0 20 mA									
4 20 mA									

11.13 Notes on the Parameters of the Analog Output Modules

Output Type/Output Range You specify the output type by selecting the corresponding module type. For each module type, you have the option of entering an output range of the parameters or value ranges listed below.

Table 11-5 Output Types/Output Ranges of the Analog Output Modules

Output Type	Output Range	Notes
Voltage	1 5 V ± 10 V	Wire the S+ and S- sense inputs of the modules directly to the load to be driven in order to compensate for line effects.
Current	0 20 mA 4 20 mA	

11.14 Default Parameters of the Analog Output Modules

Default Parameters

If you have not set the parameters of the corresponding module using the specified software (Chapter 4), the default settings apply to all output channels after a restart. Specifically, this means:

Table 11-6 Default Parameters of the Analog Output Modules

	Parameter	Default Value
Output type		Each module is intended for a specific output type.
		Output Range
Module type	for voltage	± 10 V
Module type	for current	4 20 mA

11.15 Behavior of the Analog Output Modules

Introduction

This section describes the following:

- The effect of the load power supply of the analog modules and the operating modes of the CPU on the analog output values
- The behavior of the analog modules depending on the position of the analog values in the relevant value range
- The effect of errors on the analog modules

Table 11-7 Effect of the Operating Mode of the CPU and the Supply Voltage L+ on the Analog Output Values

Operating Mo	de of the	Supply Voltage L+ at the Analog Mo-	Output Value of the A	analog Output Module
Cru		dule	S7 Number Format	S5 Number Format
POWER ON	RUN	L+applied	CPU values	CPU values
			By the conclusion of the 1st conversion	By the conclusion of the 1st conversion
			• after power on, a signal of 0 mA or 0 V is output.	• after power on, a signal of 0 mA or 0 V is output.
			• after parameterization, a signal of 0 mA or 0 V is output.	• after parameterization, a signal of 0 mA or 0 V is output.
		L+ not applied	0 mA / 0 V	0 mA / 0 V
POWER ON	STOP	L+ applied	0 mA / 0 V	0 mA / 0 V
			0 mA / 0 V	0 mA / 0 V
		L+ not applied	0 mA / 0 V	0 mA / 0 V
POWER OFF	_	L+applied	0 mA / 0 V	0 mA / 0 V
		L+ not applied	0 mA / 0 V	0 mA / 0 V

11.16 Conversion, Cycle, Settling and Response Times of the Analog Output Modules

In this section, you will find the definition and interrelationships of the relevant times for the analog output modules.

Conversion Time

The conversion time of the analog output modules includes transferring the digitized output values from internal memory after a message ends, and digital/analog conversion.

Cycle Time in a Module

The analog output modules are single-channel, so the internal cycle time corresponds to the conversion time described above.

Cycle Time of the System

The data in the analog modules is transmitted sequentially by means of the appropriate interface. The cycle time (i.e. the time that elapses before an analog module is addressed again) depends on the interface used and the number of parameterized analog modules.

Analog Output Module Settling Time

The settling time (t_2 to t_3), which is the time from when the converted value is applied to when the specified value is obtained at the analog output, depends on the load. Distinctions must be drawn between ohmic, capacitive and inductive load.

Response Time

The response time (t_1 to t_3), which is the time from when the digital output values apply in the internal memory of the appropriate interface to when the specified value is reached at the analog output, is, in the worst case, the sum of the cycle time and the settling time. The worst case is when the analog channel is converted just before transfer of a new output value to the interface, and is only transferred again after transfer and conversion of the other channels (cycle time).

Figure 11-8 shows the response time of the analog output channels.




Figure 11-8 Response Time of the Analog Output Channels

11.17 Connecting Loads/Actuators to Analog Outputs

In the figures below, the abbreviations have the following meanings:

QI+: Output current

QV+: Output voltage

S +: Sensor line (positive)
S -: Sensor line (negative)

QV-/QI-: Return line for load (ground connection)

R_L: Load resistance

The figures below show you how to connect loads and actuators to the current or voltage outputs of the analog output modules.

Connecting Loads to a Current Output

Figure 11-9 shows an example of the wiring on an electronic module.




Figure 11-9 Connecting Loads/Actuators to a Current Output (Example TB 16SC)

Connecting Loads to a Voltage Output

If you connect the load to the voltage output via a 4-wire circuit, high accuracy is obtained.




Figure 11-10 Connecting Loads/Actuators to a Voltage Output via a 4-Wire Circuit (Example TB 16SC)

The sensor lines (S +, S -) must be connected directly to the load. The voltage is thus measured and adjusted directly on the load.

You can also use only QV+ and QV- by bridging QV+ with S+ and QV- with S- on the terminal block. This entails a loss of accuracy. In this case, the line resistances are not compensated.

S +and S -must not remain unwired.

11.18 Wiring Unused Analog Output Modules

To avoid faults, you must wire unused channels of analog output modules as follows:

- In the case of analog output modules for voltage:
 Insert a bridge between QV+ and S+ and between QV- and S-.
- In the case of analog output modules for current:
 No wiring is required.

11.19 Analog Value Representation in S7 Number Format

In this section, the analog values are shown in S7 number format for all measurement ranges or output ranges that you can use with the SC analog modules.

All modules use the same analog value representation, but their resolution varies.

Analog Value Representation with 16-Bit Resolution

The digitized analog value is the same for input and output values with the same rated range.

Analog values are represented as fixed-point numbers in two's complement form. The assignment is as follows:

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value of bits	215	214	213	212	211	210	29	28	27	26	25	24	23	22	21	20

Resolution Less Than 16 Bits

If the resolution of an analog module is less than 16 bits, the analog value is stored on the module with left justification. "0" is written to the unused low-value positions.

Example

In the following example, you see how "0" is written to the unused positions when the resolution is low.

Bit pattern of a 14-bit and a 12-bit analog value

Resolution		Analog value														
Bit number	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
14-bit analog value	0	1	0	0	0	1	1	0	0	1	1	1	1	1	0	0
12-bit analog value	0	1	0	0	0	1	1	0	0	1	1	1	0	0	0	0

11.20 Analog Measurement Ranges for Input Channels in S7 Number Format

Input Ranges The input ranges contained in Tables 11-8 to 11-10 are defined in two's complement representation:

Table 11-8 Bipolar Input Ranges

Units	Measured		Data Word										Range					
	Value in %	215	214	2^{13}	2^{12}	2^{11}	2^{10}	29	28	27	26	25	2^4	2^3	2^2	21	2^0	
32767	> 117.589	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Overflow
32511	117.589	0	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1	Overrange
27649	100.004	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	1	
27648	100.000	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	0	
1	0.003617	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	
0	0.000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Rated range
- 1	- 0.003617	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
- 27648	- 100.000	1	0	0	1	0	1	0	0	0	0	0	0	0	0	0	0	
- 27649	100.004	1	0	0	1	0	0	1	1	1	1	1	1	1	1	1	1	Underrange
- 32512	- 117.593	1	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	
- 32768	<-117.593	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Underflow

Table 11-9 Unipolar Input Ranges

Units	Measured							Data	ı Wo	ord								Range
	Value in %	215	2^{14}	2^{13}	2^{12}	2^{11}	2^{10}	2 ⁹	28	27	2^{6}	2^5	2^4	2^3	2^2	2^1	2^0	
32767	> 117.589	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Overflow
32511	117.589	0	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1	Overrange
27649	100.004	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	1	
27648	100.000	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	0	
1	0.003617	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Rated range
0	0.000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
- 1	- 0.003617	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Underrange
- 4864	- 17.593	1	1	1	0	1	1	0	1	0	0	0	0	0	0	0	0	
- 32768	<-17.593	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Underflow

Table 11-10 Life-Zero Input Ranges

Units	Measured							Data	ı Wo	ord								Range
	Value in %	2^{15}	2^{14}	2^{13}	2^{12}	2^{11}	2^{10}	2 ⁹	28	27	2^{6}	2^5	2^4	2^3	2^2	2^1	2^0	
32767	> 117.589	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Overflow
32511	117.589	0	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1	Overrange
27649	100.004	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	1	
27648	100.000	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	0	
1	0.003617	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Rated range
0	0.000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
- 1	- 0.003617	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Underrange
- 4864	- 17.593	1	1	1	0	1	1	0	1	0	0	0	0	0	0	0	0	
32767	<-17.593	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Open circuit

11.21 Analog Value Representation for Analog Input Modules in S7 Number Format

The tables in this section contain the measurement representations for the individual measurement ranges of the analog input modules. The table values apply to all modules with the corresponding measurement ranges.

How to Read the Measurement Tables

The following tables contain the digitized analog values for the various measurement ranges.

Since the binary representation of the analog values is always the same, the following tables contain only the measurement ranges against the units.

For the corresponding binary representation of the measured values, see the tables in Section 11.20.

Voltage Measurement Range +10 V and +80 mV

Measured Value in %	Syste	em	Volta	ge Measuren	nent Range
	Dec.	Hex.	\pm 10 V	\pm 80 mV	
>117.589 %	32767	7FFF	>11.759V		Overflow
117.589 %	32511	7EFF	11.759 V	94.1 mV	Overrange
	27649	6C01			
100.000 %	27648	6C00	10 V	80 mV	Rated range
0.003617 %	1	1	361.7 μV	$2.89~\mu V$	
0 %	0	0	0 V	0 V	
- 0.003617 %	- 1	FFFF	–361.7 μV	– 2.89 μV	
- 100.000 %	- 27648	9400	– 10 V	– 80 mV	
	- 27649	93FF			Underrange
- 117.593 %	- 32512	8100	-11.759 V	-94.1 mV	
< 117.593 %	-32768	8000	<-11.759V	<-94.1mV	Underflow

Voltage Measurement Range 1...5 V

Measured Value in %	Syste	em	Voltage M	easurement Range
	Dec.	Hex.	1 5 V	
>117.589 %	32767	7FFF	>5.704 V	Overflow
117.589 %	32511	7EFF	5.704 V	Overrange
	27649	6C01		
100.000 %	27648	6C00	5 V	Rated range
0.003617 %	1	1	$1~V+144.7~\mu V$	
0 %	0	0	1 V	
	- 1	FFFF		Underrange
-17.593 %	- 4864	ED00	0.296 V	
<-17.593 %	32767	7FFF	< 0.296 V	Open circuit

Current Measurement Range ± 20 mA

Measured Value in %	Syste	em	Current M	easurement Range
	Dec.	Hex.	± 20 mA	
>117.589 %	32767	7FFF	>23.52 mA	Overflow
117.589 %	32511	7EFF	23.52 mA	Overrange
	27649	6C01		
100.000 %	27648	6C00	20 mA	Rated range
0.003617 %	1	1	723.4 nA	
0 %	0	0	0 mA	
- 0.003617 %	- 1	FFFF	– 723.4 nA	
- 100.000 %	- 27648	9400	- 20 mA	
	- 27649	93FF		Underrange
- 117.593 %	- 32512	8100	– 23.52 mA	
<-117.593 %	- 32768	8000	<- 23.52 mA	Underflow

Current Measurement Range 4... 20 mA

Measured Value in %	Syste	em	Current Measurement Range						
	Dec.	Hex.	4 20 mA						
>117.589 %	32767	7FFF	>22.81 mA	Overflow					
117.589 %	32511	7EFF	22.81 mA	Overrange					
	27649	6C01							
100.000 %	27648	6C00	20 mA	Rated range					
0.003617 %	1	1	4 mA + 578.7 nA						
0 %	0	0	4 mA						
	- 1	FFFF		Underrange					
- 17.593 %	- 4864	ED00	1.185 mA						
<- 17.593 %	32767	7FFF	<1.185 mA	Open circuit					

Resistance-Type Sensor 0...600 Ω

Measured Value in %	Syst	em	Resistar	nce-Type Sensor
	Dec.	Hex.	600 Ω	
>117.589 %	32767	7FFF	>705.53 Ω	Overflow
117.589 %	32511	7EFF	705.53 Ω	Overrange
	27649	6C01		
100.000 %	27648	6C00	600 Ω	Rated range
0.003617 %	1	1	$21.70~\mathrm{m}\Omega$	
0 %	0	0	0 Ω	
	- 1	FFFF	*	Underrange
- 17.593 %	- 4864	ED00	*	
<- 17.593 %	- 32768	8000	*	Underflow

^{*}Polarity reversal of IC+, IC

Analog Value Representation for Temperature Sensors

The following two tables show the analog value representation for temperature sensors of various types in various temperature ranges.

S	ystem		Temperature Ra	nge for Thermore	esistors
		Climatic (1 Digit = 0.01 °C)	Standard (1 I		
Dec.	Hex.	Pt100	Pt100	Ni100	
32767	7FFF				Overflow
		*155 °C	*1000 °C	*295 °C	Overrange
		130 °C	850 °C	250 °C	Rated range
1000		10 °C	100 °C	100 °C	
1	1	0.01 °C	0.1 °C	0.1 °C	
0	0	0.00 °C	0.0 °C	0.0 °C	
-1	FFFF	– 0.01 °C	– 0.1 °C	– 0.1 °C	
		– 120 °C	– 200 °C	– 60 °C	
					Underrange
		*– 145 °C	*–243 °C	*– 105 °C	
-32768	8000				Underflow

^{*} Overrange and underrange: In the overrange and underrange, the gradient of the characteristic curve as it leaves the linearized rated range is retained.

S	ystem	Temperature Range for Thermocouples											
			Standard	1 (1 Digit = 0.1 °C)									
Dec.	Hex.	Type R	Type J	Type K									
32767	7FFF				Overflow								
		*2019 °C	*1450 °C	*1622 °C	Overrange								
		1769 °C	1200 °C	1372 °C	Rated range								
	10000	1000 °C	1000 °C	1000 °C									
1	1	0.1 °C	0.1 °C	0.1 °C									
0	0	0.0 °C	0.0 °C	0.0 °C									
- 1	FFFF	− 0.1 °C	−0.1 °C	− 0.1 °C									
		– 50 °C	– 210 °C	– 270 °C									
					Underrange								
		*– 170 °C	*- 330 °C	*- 390 °C									
- 32768	8000				Underflow								

^{*} Overrange and underrange: In the overrange and underrange, the gradient of the characteristic curve as it leaves the linearized rated range is retained.

11.22 Analog Output Ranges for Output Channels in S7 Number Format

O u t R p a u n t The output sanges shown in the following tables are defined for the analog output modules.

Table 11-11 Bipolar Output Ranges

Units		Data Word												Output Value	Range			
	2^{15}	2^{14}	2^{13}	2^{12}	2^{11}	2^{10}	2 ⁹	2^8	27	2^6	2^5	2^4	2^3	2^2	2^1	2^0	in %	
≥ 32512	0	1	1	1	1	1	1	1	X	X	x	X	X	x	X	X	0 %	Overflow
32511	0	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1	117.589	Overrange
27649	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	1	100.004	
27648	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	0	100.000	
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0.003617	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.000	Rated range
- 1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	- 0.003617	
- 27648	1	0	0	1	0	1	0	0	0	0	0	0	0	0	0	0	- 100.000	
- 27649	1	0	0	1	0	0	1	1	1	1	1	1	1	1	1	1	100.004	Underrange
- 32512	1	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	- 117.593	
≤ 32513	1	0	0	0	0	0	0	0	X	X	x	x	x	x	X	x	0 %	Underflow

Table 11-12 Unipolar Output Ranges

Units							Data	w W	ord								Output Value	Range
	215	2^{14}	2^{13}	2^{12}	211	2^{10}	29	28	27	26	25	2^4	2^3	2^2	21	2^0	in %	
≥ 32512	0	1	1	1	1	1	1	1	X	X	X	X	X	X	X	x	0 %	Overflow
32511	0	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1	117.589	Overrange
27649	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	1	100.004	
27648	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	0	100.000	
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0.003617	Rated range
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.000	
- 1 - 32512	1	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0.000	Restricted to rated range lower limit,
- 32312				U		U		1	U	U	U	U	U	U	U	0		· •
≤ 3	2	50 1	0 3	0	0	0	0	0	X	X	X	X	X	X	X	X	0 %	U n d

o r 0 e r f 1 o w

Table 11-13 Life-Zero Output Ranges

Units							Data	Wo	rd								Output Value	Range
	2^{15}	2^{14}	2^{13}	2^{12}	2^{11}	2^{10}	2 ⁹	28	27	2^{6}	2 ⁵	2^4	2^3	2^2	2^1	2^0	in %	
≥ 32512	0	1	1	1	1	1	1	1	X	X	X	X	X	X	X	X	0 %	Overflow
32511	0	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1	117.589	Overrange
27649	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	1	100.004	
27648	0	1	1	0	1	1	0	0	0	0	0	0	0	0	0	0	100.000	
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0.003617	Rated range
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.000	
- 1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	- 0.003617	Underrange
- 6912	1	1	1	0	0	1	0	1	0	0	0	0	0	0	0	0	-25.000	
- 6913 - 32512	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	- 25.000	Restricted to overrange lower limit, 0 V or 0 mA
≤ -32513	1	0	0	0	0	0	0	0	X	X	X	X	X	X	X	X	- 25 %	Underflow

11.23 Analog Value Representation for Output Modules in S7 Number Format

The tables in this section contain the measurement representations for the individual measurement ranges of the analog output modules. The table values apply to all modules with the corresponding measurement ranges.

How to Read the Measurement Tables

The following tables contain the digitized analog values for the various measurement ranges.

Since the binary representation of the analog values is always the same, the following tables contain only the measurement ranges against the units.

Voltage Range ±10 V

Measured Value in %	Syst	em	Voltage Range						
	Dec.	Hex.	± 10 V						
118.5149 %	32767	7FFF	0.00 V	Overflow, no voltage and no					
117.593 %	32512	7F00	0.00 V	current					
117.589 %	32511	7EFF	11.76 V	Overrange					
	27649	6C01							
100 %	27648	6C00	10 V	Rated range					
0.003617 %	1	1	361.7 μV						
0 %	0	0	0 V						
- 0.003617 %	- 1	FFFF	– 361.7 μV						
- 100 %	- 27648	9400	– 10 V						
	- 27649	93FF		Underrange					
117.593 %	- 32512	8100	– 11.76 V						
-117.596%	- 32513	80FF	0.00 V	Underflow, no voltage and no					
- 118.519 %	- 32768	8000	0.00 V	current					

Voltage Range 1...5 V

Measured Value in %	Syst	em		Voltage Range
	Dec.	Hex.	1 5 V	
118.5149 %	32767	7FFF	0.00 V	Overflow, no voltage and no
117.593 %	32512	7F00	0.00 V	current
117.589 %	32511	7EFF	5.70 V	Overrange
	27649	6C01		
100 %	27648	6C00	5 V	Rated range
0.003617 %	1	1	1V+144.7μV	
0 %	0	0	1 V	
	- 1	FFFF	1V-144.7μV	Underrange
- 25 %	- 6912	E500	0 V	
	- 6913	E4FF	0.00 V	Impossible; output value
117.593 %	- 32512	8100	0.00 V	restricted to 0 V
- 117.596 %	- 32513	80FF	0.00 V	Underflow, no voltage and no
- 118.519 %	- 32768	8000	0.00 V	current

Current range 0...20 mA and 4...20 mA

Sy	stem			Current rang	ge
	Dec.	Hex.	0 20 mA	4 20 mA	
118.5149 %	32767	7FFF	0.00 mA	0.00 mA	Overflow, no
117.593 %	32512	7F00			voltage and no current
117.589 %	32511	7EFF	23.52 mA	22.81 mA	Overrange
	27649	6C01			
100 %	27648	6C00	20 mA	20 mA	Rated range
0.003617 %	1	1	723.4 nA	4mA+578.7 nA	
0 %	0	0	0 mA	4 mA	
	- 1	FFFF	0 mA	4mA-578.7 nA	Underrange
- 25 %	- 6912	E500	0 mA	0 mA	
	- 6913	E4FF	0 mA	0 mA	Impossible; output value
- 117.593 %	- 32512	8100	0 mA	0 mA	restricted to 0 mA
- 117.596 %	- 32513	80FF	0 mA	0 mA	Underflow, no voltage and no
- 118.519 %	- 32768	8000	0 mA	0 mA	current

11.24 Analog Value Representation in S5 Number Format

In this section, the differences between the analog value representation in S5 number format and S7 number format are explained.

The measurement and output ranges are always represented with left justification, with the exception of temperature ranges. Temperature ranges (PT100, Ni100, thermocouples) refer to bit 3, with right justification.

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	212	211	2^{10}	2 ⁹	28	27	26	25	2^{4}	2^3	2^2	21	2^{0}	X	F	Ü

Bits \ddot{U} , F and x are reserved for diagnostic functions:

Bit	Meaning
Bit $2^0 = \ddot{U}$	Overflow bit
Bit $2^1 = F$	Fault (open circuit)
Bit $2^2 = x$	Not used

The individual measurement ranges are represented as follows:

Table 11-14 Representation of the Measurement Ranges for Analog Inputs

Measurement Ranges for Analog Electronic Modules

Measurement range	Representation in S5 Number Format	Representation in S7 Number Format
± 80 mV	- 2048+2048	-27648+27648
± 10 V		
± 20 mA		
15 V; 420 mA	512+2560	0+27648
PT100 Standard	0.5 °C/digit	0.1 °C/digit
−100+850 °C	-200+1700	
– 200+850 °C		- 2000+8500
PT100 climatic	0.05 °C/digit	0.01 °C/digit
– 120+130 °C	- 2400+2600	-12000+13000
Ni100 standard	0.5 °C/digit	0.1 °C/digit
– 60+250 °C	- 120+500	-600+2500
Resistor		
0600 Ω	0+2048	0+27648
Thermocouple type J	1 °C/digit	0.1 °C/digit
− 210+1200 °C		- 2100+12000
-200+1200 °C	−200+1200 °C	
Thermocouple type K	1 °C/digit	0.1 °C/digit
– 270+1372 °C		- 2700+13720
-100+1369 °C	−100+1369 °C	

Table 11-14 Representation of the Measurement Ranges for Analog Inputs

Measurement range	Representation in S5 Number Format	Representation in S7 Number Format				
Thermocouple type R	1 °C/digit	0.1 °C/digit				
– 50+1769 °C	- 50+1769	-500+17690				

Table 11-15 Representation of the Measurement Rangesfor Analog Outputs

Output Range	Representation in S5 Number Format	Representation in S7 Number Format
± 10 V	-1024+1024	- 27648+27648
15 V		
020 mA	01024	0+27648
420 mA		

• Overrange 117.59% (as S7)

Overflow value Greatest overrange value +1
 Underflow value Greatest underrange value -1
 In both cases, the 0 (overflow) bit is set for inputs.

11.25 Analog Measurement Ranges for Input Channels in S5 Number Format

Input Ranges The input ranges contained in Tables 11-16 to 11-18 are defined in two's complement representation:

Table 11-16 Bipolar Input Ranges

Units	Measured							Data	ı Wo	ord								Range
	Value in %	212	211	2^{10}	2^{9}	28	27	2^{6}	25	2^4	2^3	2^2	21	2^0	x	F	Ü	
2409	> 117.578	0	1	0	0	1	0	1	1	0	1	0	0	1	0	0	1	Overflow
2408	117.578	0	1	0	0	1	0	1	1	0	1	0	0	0	0	0	0	Overrange
2049	100.05	0	1	0	0	0	0	0	0	0	0	0	0	1	0	0	0	
2048	100.000	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
1	0.0488	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	
0	0.000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Rated range
- 1	- 0.0488	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	
- 2048	- 100.000	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
- 2049	- 100.05	1	0	1	1	1	1	1	1	1	1	1	1	1	0	0	0	Underrange
- 2408	- 117.578	1	0	1	1	0	1	0	0	1	1	0	0	0	0	0	0	
- 2409	<-117.578	1	0	1	1	0	1	0	0	1	0	1	1	1	0	0	1	Underflow

Table 11-17 Unipolar Input Ranges

Units	Measured							Data	ı Wo	ord								Range
	Value in %	212	211	2^{10}	29	28	27	2^{6}	25	2^4	2^3	2^2	2^1	2^0	*	F	Ü	
2409	> 117.578	0	1	0	0	1	0	1	1	0	1	0	0	1	0	0	1	Overflow
2408	117.578	0	1	0	0	1	0	1	1	0	1	0	0	0	0	0	0	Overrange
2049	100.05	0	1	0	0	0	0	0	0	0	0	0	0	1	0	0	0	
2048	100.000	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
1	0.0488	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	Rated range
0	0.000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
- 1	- 0.0488	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	Overrange
- 360	- 17.593	1	1	1	1	0	1	0	0	1	1	0	0	0	0	0	0	
- 361	<-17.593	1	0	0	1	0	1	0	0	1	0	1	1	1	0	0	1	Underflow

Table 11-18 Life-Zero Input Ranges

Units	Measured							Data	ı We	ord								Range
	Value in %	212	2^{11}	2^{10}	2^9	2^8	2^7	2^{6}	25	2^4	2^3	2^2	21	2^0	x	F	Ü	
2921	117.578	0	1	0	1	1	0	1	1	0	1	0	0	1	0	0	1	Overflow
2920	117.578	0	1	0	1	1	0	1	1	0	1	0	0	0	0	0	0	Overrange
2561	100.05	0	1	0	1	0	0	0	0	0	0	0	0	1	0	0	0	
2560	100.000	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	
513	0.0488	0	0	0	1	0	0	0	0	0	0	0	0	1	0	0	0	Rated range
512	0.000	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	
511	0.0488	0	0	0	0	1	1	1	1	1	1	1	1	1	0	0	0	Underrange
151	- 17.593	0	0	0	0	0	1	0	0	1	0	1	1	1	0	0	0	
4095	≤-17.593	0	1	1	1	1	1	1	1	1	1	1	1	1	0	1	1	Open circuit

11.26 Analog Value Representation for Analog Input Modules in S5 Number Format

The tables in this section contain the measurement representations for the individual measurement ranges of the analog input modules. The table values apply to all modules with the corresponding measurement ranges.

How to Read the Measurement Tables

The following tables contain the digitized analog values for the various measurement ranges.

Since the binary representation of the analog values is always the same, the following tables contain only the measurement ranges against the units.

Voltage Measurement Range \pm 10 V and \pm 80 mV

Measured Value in %	System	Voltage Measurement Range						
	Dec.	± 10 V	± 80 mV					
>117.589 %	2409	>11.769 V	≥94.1 mV	Overflow				
117.589 %	2408	11.758 V	94.06 mV	Overrange				
	2049							
100.000 %	2048	10 V	80 mV	Rated range				
0.0488 %	1	4.9 mV	39 μV					
0 %	0	0 V	0 V					
-0.0488 %	- 1	–4.9 mV	–39 μV					
- 100.000 %	- 2048	– 10 V	- 80 mV					
	- 2049			Underrange				
- 117.593 %	- 2408	– 11.759 V	– 94.06 mV					
<- 117.593 %	- 2409	<11.759 V	≤-94.1 mV	Underflow				

Voltage Measurement Range 1...5 V

Measured Value in %	System	Voltage Measurement Range							
	Dec.	1 5 V							
>117.589 %	2921	≥5.704 V	Overflow						
117.589 %	2920	5.704 V	Overrange						
100.05 %	2561								
100.000 %	2560	5 V	Rated range						
0.0488 %	513	1 V + 1.95 mV							
0	512	1 V							
- 0.0488 %	511		Underrange						
- 17.593 %	151	0.296 V							
<- 17.593 %	4095	<0.296 V	Open circuit						

$\begin{array}{c} \text{Current} \\ \text{Measurement} \\ \text{Range} \pm \text{20 mA} \end{array}$

Measured Value in %	System	Current Measurement Range					
	Dec.	± 20 mA					
>117.589 %	2409	>23.52 mA	Overflow				
117.589 %	2408	23.52 mA	Overrange				
	2049						
100.000 %	2048	20 mA	Rated range				
0.0488 %	1	9.766 μΑ					
0 %	0	0 mA					
-0.0488 %	- 1	–9.766 μΑ					
- 100.000 %	- 2048	– 20 mA					
	- 2049		Underrange				
- 117.593 %	- 2408	– 23.52 mA					
<- 117.593 %	- 2409	<- 23.52 mA	Underflow				

Current Measurement Range 4...20 mA

Measured Value in %	System	Current Measurement Range					
	Dec.	4 20 mA					
>117.589 %	2921	>22.81 mA	Overflow				
117.589 %	2920	22.81 mA	Overrange				
	2561						
100.000 %	2560	20 mA	Rated range				
0.0488 %	513	$4~mA + 7.813~\mu A$					
0 %	512	4 mA					
- 0.0488 %	511		Underrange				
- 17.593 %	151	1,185 mA					
<- 17.593 %	4095	<1,185 mA	Open circuit				

Resistance-Type Sensor 600 Ω

Measured Value in %	System	Resistance-Type Sensor				
	Dec.	600 Ω				
>117.589 %	2409	>705.53 Ω	Overflow			
117.578 %	2408	705.53 Ω	Overrange			
	2049					
100.000 %	2048	600 Ω	Rated range			
0.0488 %	1	0.293 Ω				
0 %	0	0 Ω				
	-1	*	Underrange			
- 17.593 %	-360	*				
<- 17.593 %	-361	*	Underflow			

^{*} Polarity reversal of constant current IC+, IC-

Analog Value Representation for Temperature Sensors The following two tables show the analog value representation for temperature sensors of various types in various temperature ranges.

... for Resistance Thermometers

System		Temperati	ure Range	
	Climatic (1 Digit = 0.05 °C)	Standard (1 D	Pigit = 0.5 °C)	
Dec.	Pt100	Pt100	Ni100	
3101	> 155 °C			Overflow
2001		> 1000 °C		
591			> 295 °C	Overflow
	*155 °C	*1000 °C	*295 °C	Overrange
	130 °C	850 °C	250 °C	Rated range
200	10 °C	100 °C	100 °C	
1	0.05 °C	0.5 °C	0.5 °C	
0	0.00 °C	0.0 °C	0.0 °C	
	– 120 °C	100 °C	60 °C	
				Underrange
	*– 145 °C	*- 243 °C	*- 105°C	
211			<- 105 °C	Underflow
487		<- 243 °C		
2901	<- 145 °C			

^{*} Overrange and underrange: In the overrange and underrange, the gradient of the characteristic curve as it leaves the linearized rated range is retained.

System	Temperature Range														
	Standard (1 Digit = 1 °C)														
Dec.	Type R	Type J	Type K												
2020	> 2019 °C			Overflow											
1623			> 1622 °C												
1451		> 1450 °C													
	*2019 °C	1450 °C	1622 °C	Overrange											
	1769 °C	1200 °C	1372 °C	Rated range											
	1000 °C	1000 °C	1000 °C												
1	1 °C	1 °C	1 °C												
0	0.0 °C	0.0 °C	0.0 °C												
- 1	– 1 °C	– 1 °C	– 1 °C												
	– 50 °C	– 210 °C	– 270 °C												
				Underrange											
	*– 170 °C	– 330 °C	− 390 °C												
- 171	<- 170 °C			Underflow											
- 331		<- 330 °C													
- 390			<- 390 °C												

^{*} Overrange and underrange: In the overrange and underrange, the gradient of the characteristic curve as it leaves the linearized rated range is retained.

11.27 Analog Output Ranges for Output Channels in S5 Number Format

O u t Rp au nt The outpst ranges shown in the following tables are defined for the analog output modules.

Table 11-19 Bipolar Output Ranges

Units	Data Word													Output Value	Range			
	211	2^{10}	2^9	2^8	2 ⁷	2^{6}	2^5	2^4	2^3	2^2	2^1	2^0	x	X	X	X	in %	
≥ 1205	0	1	0	0	1	0	1	1	0	1	0	1	x	X	X	X	0 %	Overflow
1204	0	1	0	0	1	0	1	1	0	1	0	0	х	X	X	X	117.578	Overrange
1025	0	1	0	0	0	0	0	0	0	0	0	1	x	X	X	X	100.097	
1024	0	1	0	0	0	0	0	0	0	0	0	0	x	X	X	X	100.000	
1	0	0	0	0	0	0	0	0	0	0	0	1	x	X	X	X	0.097	
0	0	0	0	0	0	0	0	0	0	0	0	0	x	X	X	X	0.000	Rated range
- 1	1	1	1	1	1	1	1	1	1	1	1	1	x	X	X	X	0.097	
- 1024	1	1	0	0	0	0	0	0	0	0	0	0	x	X	X	X	100.000	
- 1025	1	0	1	1	1	1	1	1	1	1	1	1	х	X	X	X	100.097	Underrange
- 1204	1	0	1	1	0	1	0	0	1	1	0	0	x	X	X	X	- 117.578	
≤ 1205	1	0	1	1	0	1	0	0	1	0	1	1	х	X	X	X	0 %	Underflow

x=irrelevant

Table 11-20 Unipolar Output Ranges

Units	Data Word														Output Value	Range		
	211	2^{10}	2^9	2^8	2^7	2^{6}	2^5	2^4	2^3	2^2	2^1	2^0	x	X	X	X	in %	
≥ 1205	0	1	0	0	1	0	1	1	0	1	0	1	X	X	X	X	0 %	Overflow
1204	0	1	0	0	1	0	1	1	0	1	0	0	х	X	X	X	117.578	Overrange
1025	0	1	0	0	0	0	0	0	0	0	0	1	x	X	X	x	≥ 100.097	
1024	0	1	0	0	0	0	0	0	0	0	0	0	х	X	X	X	100.000	
1	0	0	0	0	0	0	0	0	0	0	0	1	x	X	X	X	0.0971	Rated range
0	0	0	0	0	0	0	0	0	0	0	0	0	x	X	X	x	0.000	
- 1	1	1	1	1	1	1	1	1	1	1	1	1	х	X	X	Х	0.000	Restricted to rated range lower limit,
- 1204	1	0	1	1	0	1	0	0	1	1	0	0	X	X	X	X		0 V
≤- 1	2	00 5	1	1	0	1	0	0	1	0	1	1	х	X	X	X	0 %	U n d

or 0 m A

x = i r r e l e v

Table 11-21 Life-Zero Output Ranges

Units							Data	a Wo	ord								Output Value	Range
	211	2^{10}	2^{9}	2^8	2^7	2^{6}	2 ⁵	2^4	2^3	2^2	2^1	2^0	x	X	X	x	in %	
≥ 1205	0	1	0	0	1	0	1	1	0	1	0	1	Х	X	X	X	0 %	Overflow
1204	0	1	0	0	1	0	1	1	0	1	0	0	х	X	X	X	117.578	Overrange
1025	0	1	0	0	0	0	0	0	0	0	0	1	X	X	X	X	100.097	
1024	0	1	0	0	0	0	0	0	0	0	0	0	х	X	X	X	100.000	
1	0	0	0	0	0	0	0	0	0	0	0	0	x	x	X	X	0.097	Rated range
0	0	0	0	0	0	0	0	0	0	0	0	0	X	X	X	X	0.000	
- 1	1	1	1	1	1	1	1	1	1	1	1	1	х	X	X	X	0.097	Underrange
- 256	1	1	1	1	0	0	0	0	0	0	0	0	X	X	X	X	- 25.000	
- 257 - 1204	1	0	1	0	0	1	0	0	1	1	0	0	X	X	X	X	-25.000	Restricted to overrange lower limit, 0 V or 0 mA
- 1204 ≤ -1205	1	0	1	1	0	1	0	0	1	0	1	1	X	X	X	X	- 25 %	Underflow
≤ -1205	1	U	1	1	U	1	U	U	1	U	1	1	X	X	X	X	- 25 %	Underflow

x=irrelevant

11.28 Analog Value Representation for Output Modules in S5 Number Format

The tables in this section contain the measurement representations for the individual measurement ranges of the analog output modules. The table values apply to all modules with the corresponding measurement ranges.

How to Read the Measurement Tables

The following tables contain the digitized analog values for the various measurement ranges.

Since the binary representation of the analog values is always the same, the following tables contain only the measurement ranges against the units.

Analog Value Representation

The following tables show the analog value representation for output channels in various voltage ranges.

Voltage Range ± 10 V

System		Voltage Range			
	Dec.	± 10 V			
> 117.578 %	>1204	0.00 V	Overflow, no voltage and no current		
117.578 %	1204	11.76 V	Overrange		
	1025				
100 %	1024	10 V			
0.097 %	1	9.76 mV			
0 %	0	0 V	Rated range		
-0.097 %	- 1	– 9.76 mV			
- 100 %	- 1024	- 10 V			
	- 1025		Underrange		
- 117.578 %	- 1204	– 11.76 V			
>-117.578 %	>-1204	0.00 V	Underflow, no voltage and no current		

Voltage Range 1...5 V

Systen	1	Voltage Range		
	Dec.	1 5 V		
> 117.578 %	1205	0 V	Overflow, no voltage and no current	
117.578 %	1204	5.70 V	Overrange	
	1025			
100 %	1024	5 V		
0.0976 %	1	1V + 3.9 mV	Rated range	
0 %	0	1 V		
	- 1	1 V – 3.9 mV	Underrange	
- 25 %	- 256	*0 V		
	- 257	0 V	Impossible; output value restricted	
<-117.578 %	<-1205	0 V	to 0 V	

Current range 0...20 mA and 4...20 mA

System	m	Current Measurement Range				
	Dec.	0 20 mA	4 20 mA			
>117.578 %	>1204	0.00 mA	0.00 mA	Overflow, no voltage and no current		
117.578 %	1204	23.52 mA	22.81 mA	Overrange		
	1025					
100 %	1024	20 mA	20 mA			
0.0976 %	1	19.5 μΑ	4mA+15.6 μA	Rated range		
0 %	0	0 mA	4 mA			
-0.0976 %	- 1	0 mA		Underrange		
- 25 %	- 256	0 mA	0 mA			
	- 257	0 mA	0 mA	Impossible;		
- 117.578 %	-1204	0 mA	0 mA	output value restricted to 0 mA		
<- 117.578%	<-1205	0.00 mA	0.00 mA	Underflow, no voltage and no current		

SC Analog Electronic Modules – Technical Data

Contents of the Chapter

Section	Торіс	Page
12.1	Analog Electronic Module 2 AI U	12-2
12.2	High Speed Analog Electronic Module 2 AI HS U	12-8
12.3	Analog Electronic Module 2 AI I (123-1GB00)	12-14
12.4	Analog Electronic Module 2 AI I (123-1GB10)	12-20
12.5	High-Speed Analog Electronic Module 2 AI HS I (0/4–20 mA, 4-Wire Measuring Transducer)	12-26
12.6	High-Speed Analog Electronic Module 2 AI HS I (4–20 mA, 2-Wire Measuring Transducer)	12-32
12.7	Analog Electronic Module 2 AI TC	12-38
12.8	Analog Electronic Module 1 AI RTD	12-44
12.9	Analog Electronic Module 1 AO U	12-50
12.10	Analog Electronic Module 1 AO I	12-54

Order Numbers

Product Name	Order Number
Analog Electronic Module 2 AI U	6ES7 123-1FB00-0AB0
High-Speed Analog Electronic Module 2 AI HS U	6ES7 123-1FB50-0AB0
Analog Electronic Module 2 AI I	6ES7 123-1GB00-0AB0 6ES7 123-1GB10-0AB0
HighSpeed Analog Electronic Module 2 AI HS I (0/4–20 mA, 4-Wire Measuring Transducer)	6ES7 123-1GB60-0AB0
, , ,	CEGZ 122 1CD 50 0 1 D0
HighSpeed Analog Electronic Module 2 AI HS I (4–20 mA, 2-Wire Measuring Transducer)	6ES7 123-1GB50-0AB0
Analog Electronic Module 2 AI TC	6ES7 123-1JB00-0AB0
Analog Electronic Module 1 AI RTD	6ES7 123-1JA00-0AB0
Analog Electronic Module 1 AO U	6ES7 124-1FA00-0AB0
Analog Electronic Module 1 AO I	6ES7 124-1GA00-0AB0

12.1 Analog Electronic Module 2 Al U

Order Number

6ES7 123-1FB00-0AB0

Characteristics

The 2 AI U analog electronic module is an analog input module with the following characteristics:

- 2 inputs for voltage measurement
- Input ranges \pm 10 V and 1...5 V
- 13/12-bit resolution
- Input range selection
- Isolated from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the input module.

The block diagram is shown on the front of the input module. In the operating state, the block diagram is covered by the labeling strip.




Figure 12-1 Front and Side Elevations of the 2 AI U Analog Electronic Module

Block Diagram Figure 12-2 shows the block diagram of the 2 AI U analog electronic module.




Figure 12-2 Block Diagram of the 2 AI U Analog Electronic Module

Parameters

The 2 AI U electronic module uses the following parameters:

Table 12-1 Static Parameters of the 2 AI U Electronic Module

Parameters	Value Range	Default Parameters	Scope
Measurement type	deactivated		Channel
	Voltage	Voltage	
Measurement range (volt-	± 10 V	± 10 V	Channel
age)	1 5 V		
Interference frequency sup-	50 Hz (integration time 60	50 Hz	Module
pression	ms)		
	60 Hz (integration time 50		
	ms)		
Smoothing	None	None	Channel
	Weak		
	Medium		
	Strong		
Format	SIMATIC S7	SIMATIC S7	Channel
	SIMATIC S5		

Default Parameters

If you have not set the parameters of the 2 AI U electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-1).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to the system in the current cycle n

Jump Response

Figure 12-3 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-3 Jump response

Technical Data The technical data of the 2 AI U electronic module is listed below.

Dimensions and V	Veight	Interference Suppression,	Limits of Erro
Dimensions $W \times H \times D$ (mm) Weight	10×64×51 approx. 20 g	Interference voltage suppression for f=n x (f1 \pm 1%) (f1=interference frequency;	
Module-Specific	Data	n=1,2)	
Number of inputs	2	Common-mode interference	>90 dB
Line length • Shielded Protection of the electronic module against surge stress	max. 200 m external protective device in the power	• Series-mode interference (peak value of interference < rated value of input range) Crosstalk between inputs	>70 dB
to IEC801-5	supply and signal	• at 50 Hz/60 Hz	>50 dB
Number of times the electronic module can be plugged into a	lines required	Operational limit (in entire tem- perature range, relative to rated input range)	± 1.0%
TB 16 SC	max. 20	Basic error limit (operational	
Voltages, Currents, I	Potentials	limit at 25°C, relative to rated in-	± 0.7%
Rated supply voltage of the electronics L+ Reversed polarity protection Galvanic isolation Between channels and SC bus	DC 24 V yes	put range) Temperature error (relative to rated input range) Linearity error (relative to rated input range) Repeatability in settled state at 25°C, (relative to rated input	± 0.01%/K ± 0.05%
	по	range)	$\pm 0.1\%$
• Between channels and power supply of electronics	no	Statuses, Interrupts, I	Diagnostics
Between channels	no	Interrupts	none
Permissible potential difference		Diagnostic functions	
Between inputs and ground (V _{CM})	DC 2 V/ AC 2 V _{SS}	Fault display on moduleReadable diagnostic function	no no
Power input			
• From supply voltage L+	max. 30 mA		
Power loss of the module	typ. 0.6 W		

Analog value formation					
Measurement principle	integra	itive			
Integration and conversion time/ resolution per channel					
Parameterized	у	es			
Integration time in ms	60	50			
Conversion time in ms	65	55			
Resolution (incl. overrange/ representation in two's com- plement)					
– S7 format/S5 format					
± 10 V/13 bits					
15 V/12 bits					
• Interference voltage suppression for interference frequency f1 in Hz	50	60			
quelley 11 III 112	50	00			

Senso	Sensor Selection Data					
Input ranges (rated valuesistance	Input ranges (rated values)/input resistance					
Permitted input voltag For voltage input (destruction limit)	max.20 V permanent; 75 V for max. 1 s (pulse duty factor 1:20)					
Connection of sensors						
For voltage measu	rement	possible				
Characteristic curve lin	nearization	no				
Temperature compensa	ation	no				
Smoothing of measure	Smoothing of measured values					
	Step None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time				

12.2 High-Speed Analog Electronic Module 2 AI HS U

Order Number

6ES7 123-1FB50-0AB0

Characteristics

The 2 AI HS U high-speed analog electronic module is an analog input module with the following characteristics:

- 2 inputs for voltage measurement
- Input ranges ± 10 V
- 12-bit resolution
- Isolated from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the twochannel input module.

The circuit shematic is shown on the front elevation of the input module. In its operative state the circuit schematic is covered by the labeling strip.




Figure 12-4 Front and Side Elevations of the 2 AI HS U High Speed Analog Electronic Module

Block Diagram Figure 12-5 shows the block diagram of the 2 AI HS U high speed analog electronic module.




Figure 12-5 Block Diagram of the 2 AI HS U High-Speed Analog Electronic Module

Parameters

The 2 AI HS U electronic module uses the following parameters:

Table 12-2 Static Parameters of the 2 AI HS U HighSpeed Electronic Module

Parameters	Value Range	Default Parameters	Scope
Measurement type	Deactivated		Channel
	Voltage	Voltage	
Measurement range (voltage)	± 10 V	± 10 V	Channel
Smoothing	None	None	Channel
	Weak		
	Medium		
	Strong		
Format	SIMATIC S7	SIMATIC S7	Channel
	SIMATIC S5		

Default Parameters

If you have not set the parameters of the 2 AI HS U electronic module using the specified software (Chapter 4), the default settings of all parameters apply to both input channels after a restart (see Table 12-2).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to the system in the current cycle n

Jump Response

Figure 12-3 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-6 Jump response

Technical Data The technical data of the 2 AI HS U high speed electronic module is listed below.

Dimensions and Weight		
Dimensions $W \times H \times D$ (mm)	10×64×51	
Weight	approx. 20 g	
Module-Specific	Data	
Number of inputs	2	
Line length		
• Shielded	max. 200 m	
Protection of the electronic mod- ule against surge stress to IEC801-5	external protective device in the power supply and signal lines required	
Number of times the electronic module can be plugged into a TB 16IM-SC	max. 20	
Voltages, Currents, I	Potentials	
Rated supply voltage of the elec-		
tronics L+	DC 24 V	
 Reversed polarity protection 	yes	
Galvanic isolation		
Between channels and SC		
bus	no	
• Between channels and power supply of electronics	no	
Between channels	no	
Permissible potential difference		
Between inputs and ground (V _{CM})	DC 2 V/ AC 2 V _{SS}	
Power input		
• From supply voltage L+	max. 30 mA	
Power loss of the module	typ. 0.6 W	

Interference voltage suppression for f=n x (f1 ± 1%) (f1=interference frequency; n=1,2) • Common-mode interference >50 dB • Series-mode interference (peak value of interference rated value of input range) >70 dB (with smoothing factor k = 128) Crosstalk between inputs • at 50 Hz/60 Hz >50 dB		
• Series-mode interference (peak value of interference < rated value of input range) >70 dB (with smoothing factor k = 128) Crosstalk between inputs		
(peak value of interference < rated value of input range) >70 dB (with smoothing factor k = 128) Crosstalk between inputs		
. 50 ID		
• at 50 Hz/60 Hz >50 dB		
W 20 112/00 112		
Operational limit (in entire temperature range, relative to rated input range) ± 1.0%		
Basic error limit (operational limit at 25°C, relative to rated input range) ± 0.7%		
Repeatability in settled state at 25°C, (relative to rated input range) ± 0.1%		
Temperature error (relative to rated input range) ± 0.01%/K		
Linearity error (relative to rated input range) ± 0.05%		
Statuses, Interrupts, Diagnostics		
Interrupts none		
Diagnostic functions		
• Fault display on module no		
Readable diagnostic function no		

Analog value formation			
Measurement principle	instantaneous value encoding		
Conversion time/resolution per channel			
Parameterized	no		
• Time constant of the input filter in μs	300 ± 20 %		
Conversion time in ms	2		
Resolution (incl. overrange/ representation in two's com- plement)			
- S7 format/S5 format			
$\pm 10 \text{ V}/12 \text{ bits incl. sign}$			

Sensor Selection Data			
Input ranges (rated values)/input resistance Permitted input voltage For voltage input (destruction limit)	\pm 10 V/approx. 100k Ω max.20 V permanent; 75 V for max. 1 s (pulse duty factor 1:20)		
Connection of sensors • For voltage measurement Characteristic curve linearization Temperature compensation Smoothing of measured values	possible no no yes; set by parameters in 4 steps by digital filtering		
Step None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time		

12.3 Analog Electronic Module 2 Al I (...123-1GB00...)

Order Number

6ES7 123-1GB00-0AB0

Characteristics

The 2 AI I analog electronic module is an analog input module with the following characteristics:

- 2 inputs for current measurement
- Input ranges \pm 20 mA and 4...20 mA
- 13/12-bit resolution
- Input range selection
- Isolation from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the twochannel input module.

The circuit shematic is shown on the front elevation of the input module. In its operative state the circuit schematic is covered by the labeling strip.




Figure 12-7 Front and Side Elevations of the 2 AI I Analog Electronic Module

Block Diagram Figure 12-8 shows the block diagram of the 2 AI I analog electronic module.




Figure 12-8 Block Diagram of the 2 AI I Analog Electronic Module

Parameters

The 2 AI I electronic module uses the following parameters:

Table 12-3 Static Parameters of the 2 AI I Electronic Module

Parameter	Value Range	Default Parameters	Scope
Measurement type	Deactivated		Channel
	Current (4-wire measuring transducer)	Current (4-wire measuring transducer)	
Measurement range (4-wire	420 mA	420 mA	Channel
measuring transducer)	± 20 mA		
Interference frequency suppression	50 Hz (integration time 60 ms)	50 Hz	Module
	60 Hz (integration time 50 ms)		
Smoothing	None	None	Channel
	Weak		
	Medium		
	Strong		
Format	SIMATIC S7	SIMATIC S7	Channel
	SIMATIC S5		

Default Parameters

If you have not set the parameters of the 2 AI I electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-3).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to system in cycle n

Jump Response

Figure 12-9 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-9 Jump Response

Technical Data The technical data of the 2 AI I electronic module is listed below.

		1	
Dimensions and Weight		Interference Suppression, 1	Limits of Error
Dimensions $W \times H \times D$ (mm)	$10\times64\times51$	Interference voltage suppression	
Weight	approx. 20 g	for f=n x (f1 \pm 1%) (f1=interference frequency;	
Module-Specific	Data	n=1,2)	
Number of inputs	2	Common-mode interference	>90 dB
Line length		Series-mode interference	
• Shielded	max. 200 m	(peak value of interference < rated value of input range)	>70 dB
Protection of the electronic mod- ule against surge stress	external protective device in the power	Crosstalk between inputs	
to IEC801-5	supply and signal	• at 50 Hz/60 Hz	>50 dB
Number of times the electronic	lines required	Operational limit (in entire temperature range, relative to rated	
module can be plugged into a		input range)	± 1.0%
TB 16 SC	max. 20	Basic error limit (operational	
Voltages, Currents, I	Potentials	limit at 25°C, relative to rated input range)	± 0.8%
Rated supply voltage of the elec-			1 0.670
tronics L+	DC 24 V	Temperature error (relative to rated input range)	± 0.01%/K
 Reversed polarity protection 	yes	Linearity error (relative to rated	_ ***-/**
Galvanic isolation		input range)	± 0.05%
Between channels and SC bus	no	Repeatability in settled state at 25°C, (relative to rated input	
 Between channels and power 	по	range)	\pm 0.1%
supply of electronics	no	Statuses, Interrupts, I	Diagnostics
Between channels	no	Interrupts	none
Permissible potential difference		Diagnostic functions	
Between inputs and		Fault display on module	no
ground (V _{CM})	DC 2 V/ AC 2 V_{SS}	Readable diagnostic function	no
Power input			
• From supply voltage L+	max. 30 mA		

typ. 0.6 W

Power loss of the module

Analog value formation			
Measurement principle	integrativ	e	
Integration and conversion time/ resolution per channel			
Parameterized	yes		
Integration time in ms	50	60	
Conversion time in ms	55	65	
 Resolution (incl. overrange/ representation in two's com- plement) 			
$-\pm 20 \text{ mA}$	13 bits		
- 420 mA	12 bits		

Sensor Selection Data				
Input ranges (rated values)/input resistance	±20 mA/50 Ω 420 mA/50 Ω			
Permissible input current For current input (destruction limit)	40 mA, permanent			
Connection of sensors				
For voltage measurement				
As 2-wire measuring transducer	possible; with exter- nal measuring trans- ducer feed			
As 4-wire measuring transducer	possible			
Characteristic curve linearization	no			
Temperature compensation	no			
Smoothing of measured values	yes; set by parameters in 4 steps by digital filtering			
<u>Step</u> None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time			

12.4 Analog Electronic Module 2 Al I (...123-1GB10-...)

Order Number

6ES7 123-1GB10-0AB0

Characteristics

The 2 AI I analog electronic module is an analog input module with the following characteristics:

- 2 inputs for current measurement
- Input ranges \pm 20 mA and 4...20 mA
- 13/12-bit resolution
- Basic error ± 0.1 %; operating error ± 0.3 %
- Input range selection
- Isolation from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the twochannel input module.

The circuit shematic is shown on the front elevation of the input module. In its operative state the circuit schematic is covered by the labeling strip.




Figure 12-10 Front and Side Elevations of the 2 AI I Analog Electronic Module

Block Diagram Figure 12-8 shows the block diagram of the 2 AI I analog electronic module.




Figure 12-11 Block Diagram of the 2 AI I Analog Electronic Module

Parameters

The 2 AI I electronic module uses the following parameters:

Table 12-4 Static Parameters of the 2 AI I Electronic Module

Parameter	Value Range	Default Parameters	Scope
Measurement type	Deactivated		Channel
	Current (4-wire measuring transducer)	Current (4-wire measuring transducer)	
Measurement range (4-wire	420 mA	420 mA	Channel
measuring transducer)	± 20 mA		
Interference frequency suppression	50 Hz (integration time 60 ms)	50 Hz	Module
	60 Hz (integration time 50 ms)		
Smoothing	None	None	Channel
	Weak		
	Medium		
	Strong		
Format	SIMATIC S7	SIMATIC S7	Channel
	SIMATIC S5		

Default Parameters

If you have not set the parameters of the 2 AI I electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-3).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to system in cycle n

Jump Response

Figure 12-9 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-12 Jump Response

Technical Data The technical data of the 2 AI I electronic module is listed below.

Dimensions and V	Veight	Interference Suppression, Limits of Error
Dimensions W×H×D (mm)	10×64×51	Interference voltage suppression
Weight	approx. 20 g	for f=n x (f1 \pm 1%) (f1=interference frequency;
Module-Specific Data		n=1,2)
Number of inputs	2	Common-mode interference >90 dB
Line length		Series-mode interference
Shielded	max. 200 m	(peak value of interference < rated value of input range) >70 dB
Protection of the electronic module against surge stress	external protective device in the power	Crosstalk between inputs
to IEC801-5	supply and signal	• at 50 Hz/60 Hz >50 dB
	lines required	Operational limit (in entire tem-
Number of times the electronic		perature range, relative to rated input range) ± 0.3%
module can be plugged into a TB 16 SC	max. 20	
Voltages, Currents, I		Basic error limit (operational limit at 25°C, relative to rated in-
	- Otentials	$-$ put range) $\pm 0.1\%$
Rated supply voltage of the electronics L+	DC 24 V	Temperature error (relative to
Reversed polarity protection	yes	rated input range) $\pm 0.01\%/K$
	•	Linearity error (relative to rated
Galvanic isolation		input range) $\pm 0.05\%$
Between channels and SC		Repeatability in settled state at
bus	no	25°C, (relative to rated input range) $\pm 0.06\%$
Between channels and power		Statuses, Interrupts, Diagnostics
supply of electronics	no	
Between channels	no	Interrupts none
Permissible potential difference		Diagnostic functions
Between inputs and ground (V _{CM})	DC 2 V/ AC 2 V _{SS}	• Fault display on module no
	DC 2 V/ AC 2 VSS	Readable diagnostic function no
Power inputFrom supply voltage L+	max. 30 mA	
Power loss of the module	typ. 0.6 W	
1 Ower 1088 of the module	typ. 0.0 W	

Interference voltage suppression for f=n x (f1 ± 1%) (f1=interference frequency; n=1,2) • Common-mode interference >9 • Series-mode interference (peak value of interference <	00 dB		
n=1,2) • Common-mode interference >9 • Series-mode interference	90 dB		
Common-mode interference >9Series-mode interference	00 dB		
Series-mode interference	00 dB		
•	′0 dB		
Crosstalk between inputs			
• at 50 Hz/60 Hz >5	60 dB		
Operational limit (in entire temperature range, relative to rated input range) ±	0.3%		
Basic error limit (operational limit at 25°C, relative to rated input range) ±	0.1%		
Temperature error (relative to rated input range) ±	0.01%/K		
Linearity error (relative to rated input range) \pm	0.05%		
Repeatability in settled state at 25°C, (relative to rated input			
range) ±	0.06%		
Statuses, Interrupts, Diagnostics			
Interrupts no	ne		
Diagnostic functions			
• Fault display on module no	•		
Readable diagnostic function no	,		

Analog value formation		
Measurement principle	integrativ	ve
Integration and conversion time/ resolution per channel		
Parameterized	ye	S
Integration time in ms	50	60
Conversion time in ms	55	65
Resolution (incl. overrange/ representation in two's com- plement)		
$-\pm 20 \text{ mA}$	13 bit	S
– 420 mA	12 bit	S

Sensor Selection Data			
Input ranges (rated values)/input resistance		$\pm 20 \text{ mA/50 }\Omega$ $420 \text{ mA/50 }\Omega$	
Permissible input current For current input (destruction limit)		40 mA, permanent	
Connection of sensors			
For voltage measur	rement		
As 2-wire meas transducer	suring	possible; with exter- nal measuring trans- ducer feed	
As 4-wire measuring transducer		possible	
Characteristic curve lin	earization	no	
Temperature compensation		no	
Smoothing of measured values		yes; set by parameters in 4 steps by digital filtering	
	Step None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time	

12.5 High-Speed Analog Electronic Module 2 Al HS I (0/4-20 mA, 4-Wire Measuring Transducer)

Order Number 6ES7 123-1GB60-0AB0

Characteristics

The 2 AI HS I high-speed analog electronic module is an analog input module with the following characteristics:

- 2 inputs for current measurement
- Input ranges 0/4...20 mA
- 12 bit resolution
- Input range selection
- Isolation from the SC bus
- Permissible common-mode voltage AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the twochannel input module.

The circuit shematic is shown on the front elevation of the input module. In its operative state the circuit schematic is covered by the labeling strip.




Figure 12-13 Front and Side Elevations of the 2 AI HS I High-Speed Analog Electronic Module (0/4–20mA, 4-Wire Measuring Transducer)

Block Diagram

Figure 12-14 shows the block diagram of the 2 AI HS I high-speed analog electronic module (0/4–20mA, 4-wire measuring transducer).




Figure 12-14 Block Diagram of the 2 AI HS I High-Speed Analog Electronic Module (0/4–20mA, 4-Wire Measuring Transducer)

Note

The current limitation applies to both measuring transducers of the 2 AI HS I analog electronic module.

If a short circuit occurs at one measuring transducer and thus activates current limitation, the second measuring transducer does not indicate a valid value.

Parameters

The 2 AI HS I electronic module uses the following parameters:

Table 12-5 Static Parameters of the 2 AI HS I Electronic Module

Parameter	Value Range	Default Parameters	Scope
Measurement type	Deactivated		Channel
	Current (4-wire measuring transducer)	Current (4-wire measuring transducer)	
Measurement range (4-wire measuring transducer)	420 mA ± 20 mA	420 mA	Channel
Smoothing	None	None	Channel
	Weak		
	Medium		
	Strong		
Format	SIMATIC S7	SIMATIC S7	Channel
	SIMATIC S5		

Default Parameters

If you have not set the parameters of the 2 AI HS I electronic module using the specified software (see Chapter 4), the default settings of all parameters apply to both input channels after a restart (see Table 12-3).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to system in current cycle n

Jump Response

Figure 12-9 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-15 Jump Response

Technical Data The technical data of the 2 AI HS I electronic module is listed below.

Dimensions and V	Veight	Interference Suppression,	Limits of Error
Dimensions W×H×D (mm)	10×64×51	Interference voltage suppression for $f=n x (f1 \pm 1\%)$	
Weight	approx. 20 g	(f1=interference frequency;	
Module-Specific	Data	n=1,2)	
Number of inputs	2	Common-mode interference	>50 dB
Line length • Shielded	max. 200 m	• Series-mode interference (peak value of interference < rated value of input range)	>70 dB (with
Protection of the electronic module against surge stress to IEC801-5	external protective device in the power supply and signal lines required	Crosstalk between inputs	smoothing factor k = 128)
Number of times the electronic module can be plugged into a TB 16IM-SC	max. 20	• at 50 Hz/60 Hz Operational limit (in entire temperature range, relative to rated	
Voltages, Currents, Potentials		input range)	± 1.0%
Rated supply voltage of the electronics L+	DC 24 V	Basic error limit (operational limit at 25°C, relative to rated input range)	± 0.7%
Reversed polarity protection	yes	Temperature error (relative to rated input)	± 0.01%/K
Galvanic isolation		Linearity error (relative to rated	
Between channels and SC		input range)	$\pm~0.05\%$
 Between channels and power supply of electronics 	no no	Repeatability in settled state at 25°C, (relative to rated input	
Between channels	no	range)	± 0.1%
	по	Statuses, Interrupts, I	Diagnostics
Permissible potential difference		Interrupts	none
 Between inputs and ground (V_{CM}) 	DC 2 V/ AC 2 V _{SS}	Diagnostic functions	no
Power input		• Fault display on module	no
From supply voltage L+	max. 30 mA	Readable diagnostic function	110
Power loss of the module	typ. 0.6 W		

Analog value formation			
Measurement principle	Instantaneous value encoding		
Conversion time/resolution per channel			
Parameterized	no		
• Time constant of the input filter	typ. 1 ms		
Conversion time in ms	1		
Resolution (incl. overrange/ representation in two's com- plement)			
− ±20 mA	12 bits incl. sign		
- 420 mA	11 bits		

Sensor Selection Data		
Input ranges (rated val resistance	ues)/input	±20 mA/approx. 50 Ω 420 mA/approx. 50 Ω
Permitted input current For current input (destruction limit)		35 mA, permanent; 150mA for max. 1s; (pulse duty factor 1:20)
Connection of sensors		
• For current measur	rement	
As 4-wire mea transducer	suring	possible
Characteristic curve lin	nearization	no
Temperature compensa	ation	no
Smoothing of measured values		yes; set by parameters in 4 steps by digital filtering
	Step None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time

12.6 High-Speed Analog Electronic Module 2 Al HS I (4–20 mA, 2-Wire Measuring Transducer)

Order Number 6ES7 123-1GB50-0AB0

Characteristics

The 2 AI HS I high-speed analog electronic module is an analog input module with the following characteristics:

- 2 inputs for current measurement
- Input ranges 4...20 mA
- 12 bit resolution
- Short circuit-proof supply of the measuring transducers
- Isolation from the SC bus
- Common-mode voltage irrelevant

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the twochannel input module.

The circuit shematic is shown on the front elevation of the input module. In its operative state the circuit schematic is covered by the labeling strip.




Figure 12-16 Front and Side Elevations of the 2 AI HS I High-Speed Analog Electronic Module (4–20mA, 2-Wire Measuring Transducer)

Block Diagram

Figure 12-17 shows the block diagram of the 2 AI HS I high-speed analog electronic module (4–20mA, 2-wire measuring transducer).




Figure 12-17 Block Diagram of the 2 AI HS I High-Speed Analog Electronic Module (4–20mA, 2-Wire Measuring Transducer)

Parameters

The 2 AI HS I high-speed electronic module (4–20mA, 2-wire measuring transducer) uses the following parameters:

Table 12-6 Static Parameters of the 2 AI HS I Electronic Module (4–20mA, 2-Wire Measuring Transducer)

Parameter	Value Range	Value Range Default Parameters		Value Range Default Parameters		
Measurement type	Deactivated		Channel			
	Current (2-wire measuring transducer)	Current (2-wire measuring transducer)				
Measurement range (4-wire measuring transducer)	420 mA	420 mA	Channel			
Smoothing	None	None	Channel			
	Weak					
	Medium					
	Strong					
Format	SIMATIC S7	SIMATIC S7	Channel			
	SIMATIC S5					

Defaultparameter

If you have not set the parameters of the 2 AI HS I high-speed electronic module (4–20mA, 2-wire measuring transducer) using the specified software (see Chapter 4), the default settings for all parameters apply to both input channels after a restart (see Table 12-6).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to the system in the current cycle n

Jump Response

Figure 12-18 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-18 Jump response

Technical Data The technical data of the 2 AI HS I high-speed electronic module (4-20mA, 2-wire measuring transducer) is listed below.

Dimensions and V	Veight	Interference Suppression, l	Limits of Error
Dimensions W×H×D (mm) Weight	10×64×51 approx. 20 g	Interference voltage suppression for f=n x (f1 ± 1%) (f1=interference frequency;	
Module-Specific		n=1,2)	
Number of inputs	2	Common-mode interference	>50 dB
Line length • Shielded	max. 200 m	Series-mode interference (peak value of interference < rated value of input range)	>70 dB (with smoothing facto = 128)
Protection of the electronic mod- ule against surge stress to IEC801-5	external protective device in the power supply and signal	Crosstalk between inputs • at 50 Hz/60 Hz	>50 dB
Number of times the electronic module can be plugged into a TB 16IM-SC	lines required max. 20	Operational limit (in entire temperature range, relative to rated input range) Basic error limit (operational	± 1,0%
Voltages, Currents, 1	Potentials	limit at 25°C, relative to rated in-	
Rated supply voltage of the elec-		put range)	± 0.7%
tronics L+	DC 24 V	Temperature error (relative to rated input range)	± 0.01%/K
Reversed polarity protection	yes	Linearity error (relative to rated input range)	± 0.05%
Galvanic isolation		Repeatability in settled state at	_ 0.00 /0
 Between channels and SC bus 	no	25°C, (relative to rated input	
 Between channels and power 	по	range)	± 0.1%
supply of electronics	no	Statuses, Interrupts, D	Diagnostics
• Between channels	no	Interrupts	none
Permissible potential difference		Diagnostic functions	
Between inputs and		Fault display on module	no
ground (V _{CM})	DC 2 V/ AC 2 V_{SS}	Readable diagnostic function	no
Power input			
• From supply voltage L+	max. 30 mA		
Power loss of the module	typ. 0.6 W		
Sustained short-circuit current from M0+/ M1+ against M	to 100mA		

 Common-mode interference Series-mode interference (peak value of interference < rated value of input range) 	>50 dB >70 dB (with smoothing factor k	
(peak value of interference <	,	
rated value of hiput range)	>70 dB (with smoothing factor k = 128)	
Crosstalk between inputs		
• at 50 Hz/60 Hz	>50 dB	
Operational limit (in entire temperature range, relative to rated input range)	± 1,0%	
Basic error limit (operational limit at 25°C, relative to rated input range)	± 0.7%	
Temperature error (relative to rated input range)	± 0.01%/K	
Linearity error (relative to rated input range)	± 0.05%	
Repeatability in settled state at 25°C, (relative to rated input range)	± 0.1%	
E /		
Statuses, Interrupts, D	iagnostics	
Interrupts	none	
Diagnostic functions		
Fault display on module	no	
Readable diagnostic function	no	

Analog value formation						
Measurement principle	instantaneous value encoding					
Conversion time/resolution per channel						
Parameterized	no					
Time constant of the input filter	typ. 1 ms					
Conversion time in ms	1					
Resolution (incl. overrange/ representation in two's com- plement)						
- 420 mA	12 bits					

Sensor Selection	Data
Input ranges (rated values)/input resistance	420 mA/approx. 50 Ω
Permitted input current For current input (destruction limit)	35 mA, permanent; 150mA for max. 1s; (pulse duty factor 1:20)
Connection of sensors	
• For current measurement	
 As 2-wire measuring transducer 	possible
 Load of the 2-wire measuring transducer 	up to $750~\Omega$
Characteristic curve linearization	no
Temperature compensation	no
Smoothing of measured values	yes; set by parameters in 4 steps by digital filtering
<u>Step</u> None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time

12.7 Analog Electronic Module 2 AI TC

Order Number

6ES7 123-1JB00-0AB0

Characteristics

The 2 AI TC analog electronic module is an analog input module with the following characteristics:

- 2 inputs for thermocouples or voltage measurement
- Input ranges for thermocouples of type R, J or K or voltage measurement $\pm\,80~\text{mV}$
- 0.1°C/digit or 14-bit resolution
- Input range selection
- Linearization of sensor characteristic curves
- Isolation from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the input module.

The block diagram is shown on the front of the input module. In the operating state, the block diagram is covered by the labeling strip.




Figure 12-19 Front and Side Elevations of the 2 AI TC Analog Electronic Module

Block Diagram Figure 12-20 shows the block diagram of the 2 AI TC analog electronic module




Figure 12-20 Block Diagram of the 2 AI TC Analog Electronic Module

Parameters

The 2 AI TC electronic module uses the following parameters:

Table 12-7 Static Parameters of the 2 AI TC Electronic Module

Parameter	Value Range	Default Parameters	Wirkungsbereich
Measurement type	Deactivated		Channel
	Voltage	Voltage	
Measurement range (voltage)	± 80 mV	± 80 mV	Channel
Thermocouple with linea-	Type R	Туре К	Channel
rization	Type J		
	Type K		
Interference frequency suppression	50 Hz (integration time 60 ms)	50 Hz	Module
	60 Hz (integration time 50 ms)		
Smoothing	None	None	Channel
	Weak		
	Medium		
	Strong		
Reference junction	None		Module
	Dynamic reference temperature on the AI RTD electronic module at slot A		
	Dynamic reference temperature		
Format	SIMATIC S7	SIMATIC S7	Module
	SIMATIC S5		

Table 12-8 Dynamic Parameters of the 2 AI TC Electronic Module

Parameter	SIMATIC S7 Value Range	SIMATIC S5 Value Range
Reference temperature in 0.01 °C	In 0.01°C - 14500 + 15500	In 0.05°C − 2900 + 3100*

*The following applies to the SIMATIC S5 value range:

Bit	15	14					8	7	6	5	4	3	2	1	0
	Reference temperature						0	0	0						

Default Parameters

If you have not set the parameters of the 2 AI TC electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-7).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to system in cycle n

Jump Response

Figure 12-21 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-21 Jump Response

Technical Data The technical data of the 2 AI TC electronic module is listed below.

Dimensions and V	Weight	Interference Suppression,	Limits of Error
Dimensions W×H×D (mm)	10×64×51	Interference voltage suppression	
Weight	approx. 20 g	for f=n x (f1 \pm 1%) (f1=interference frequency;	
Module-Specific	Data	n=1,2)	
Number of inputs	2	Common-mode interference	>90 dB
Line length		Series-mode interference	
• Shielded	max. 50 m	(peak value of interference < rated value of input range)	>70 dB
Protection of the electronic mod-		Crosstalk between inputs	>10 db
ule against surge stress to IEC801-5	device in the power supply and signal lines required	• at 50 Hz/60 Hz	>50 dB
Number of times the electronic	<u>4</u>	Operational limit (in entire tem-	
module can be plugged into a		perature range, relative to rated input range)	± 1.0%
TB 16 SC	max. 20	Basic error limit (operational	1.070
Voltages, Currents, Potentials		limit at 25°C, relative to rated in-	$\pm~0.8\%$
Rated supply voltage of the elec-	DCALL	put range)	
tronics L+	DC 24 V	Temperature error (relative to	
 Reversed polarity protection 	yes	rated input range)	$\pm 0.01\%/K$
Galvanic isolation		Linearity error (relative to rated input range)	± 0.05%
Between channels and SC			± 0.05%
bus	no	Repeatability in settled state at 25°C, (relative to rated input	
Between channels and power		range)	± 0.1%
supply of electronics	no	Statuses, Interrupts, I	Diagnostics
 Between channels 	no	Interrupts	none
Permissible potential difference		Diagnostic functions	
Between inputs and		Fault display on module	no
ground (V _{CM})	DC 2 V/ AC 2 V_{SS}	Readable diagnostic function	no
Power input	20 4	Treaducte diagnostic function	
• From supply voltage L+	max. 30 mA		
Power loss of the module	typ. 0.6 W		

Analog value for	Analog value formation					
Measurement principle	integr	rative				
Integration and conversion time/resolution per channel						
 Parameterized 		yes				
 Integration time in ms 	50	60				
 Conversion time in ms 	55	65				
Resolution (incl. overrange/representation in two's complement)						
	S7 format					
$\pm80\mathrm{mV}$ Type J Type K Type R		14 bit 0.1°C/digit 0.1°C/digit 0.1°C/digit				
	S5 format					
±80mV Type J Type K Type R		13 bit 1°C/digit 1°C/digit 1°C/digit				
• Interference voltage sup- pression for interference frequency f1 in Hz	50	60				

Ser	Sensor Selection Data		
Input ranges (rated put resistance	values)/in-	\pm 80 mV/>1M Ω Type J/1200°C/>1M Ω Type K/1372°C/> 1 M Ω Type R/1769°C/> 1 M Ω	
Permitted input volution for voltage input (destruction limit)	tage	max.10 V permanent; 25 V for max. 1 s (pulse duty factor 1:20)	
Connection of sense	ors		
For voltage mea	asurement	possible	
Characteristic curve	e lineariza-	yes; parameterized Type J, K, R to IEC 584	
Temperature compe Internal temperature pensation	ature com-	yes; parameterized not possible	
 External temperature com- pensation by means of a compensating box looped into the measuring circuit 		possible; one compensating box per channel	
Smoothing of meas	ured values	yes; set by parameters in 4 steps by digital fil- tering	
	Step None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time	

12.8 Analog Electronic Module 1 AI RTD

Order Number

6ES7 123-1JA00-0AB0

Characteristics

The 1 AI RTD analog electronic module is an analog input module with the following characteristics:

- 1 input for a resistance thermometer or resistance measurement
- 0.01°C/digit or 14-bit resolution
- Input ranges for the Pt100 climatic range, Pt100 standard range, Ni100 standard range or 0... 600 Ω
- Input range selection
- Linearization of sensor characteristic curves
- Isolation from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the input module.

The block diagram is shown on the front of the input module. In the operating state, the block diagram is covered by the labeling strip.




Figure 12-22 Front and Side Elevations of the 1 AI RTD Analog Electronic Module

Block Diagram Figure 12-23 shows the block diagram of the 1 AI RTD analog electronic module




Figure 12-23 Block Diagram of the 1 AI RTD Analog Electronic Module

Parameters

The 1 AI RTD electronic module uses the following parameters:

Table 12-9 Static Parameters of the 2 AI RTD Electronic Module

Parameter	Value Range	Default Parameters	Scope
Measurement type	Deactivated Resistance 0600Ω Temperature measurement with thermal resistance	Resistance 0600 Ω	Channel
Measurement range Resistance measurement with 4-conductor connection Temperature measurement with thermal resistance Interference frequency suppression	Resistance 0600 Ω Pt100 climatic range Pt100 standard range Ni100 standard range 50 Hz (integration time 60 ms)	Pt100 standard range 50 Hz	Channel
Smoothing	60 Hz (integration time 50 ms) None Weak Medium Strong	None	Channel
Format	SIMATIC S7 SIMATIC S5	SIMATIC S7	Channel

Default Parameters

If you have not set the parameters of the 1 AI RTD electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-9).

Time Response of the Digital First-Order Low-Pass Filter

The smoothing is adjustable in 4 steps. Smoothing factor k multiplied by the cycle time of the electronic module corresponds to the time constant of the smoothing filter.

Smoothing factor: k:

None	1
Weak	8
Medium	64
Strong	128

Calculation of the Time Response

You can calculate the time response for any jump of the input value x and the smoothing factor k by using the following formula:

$$y_n := \frac{x_n + (k-1)y_{n-1}}{k}$$

 y_n = value passed to system in cycle n

Jump Response

Figure 12-24 shows the jump response for various smoothing factors, depending on the number of module cycles.




Figure 12-24 Jump Response

Technical Data The technical data of the 1 AI RTD electronic module is listed below.

Dimensions and V	Veight	Interference Suppression,	Limits of Error
Dimensions W×H×D (mm)	10×64×51	Interference voltage suppression	
Weight	approx. 20 g	for f=n x (f1 \pm 1%) (f1=interference frequency;	
Module-Specific	Data	n=1,2)	
Baud rate of the SC bus	9.6 KBaud	Common-mode interference	>90 dB
Number of inputs	1	Series-mode interference	
Line length		(peak value of interference < rated value of input range)	>70 dB
Shielded	max. 50 m	Crosstalk between inputs	>70 db
Protection of the electronic mod-	external protective	• at 50 Hz/60 Hz	>50 dB
ule against surge stress to IEC801-5	device in the power supply and signal lines required	Operational limit (in entire temperature range, relative to rated input range)	230 u B
Number of times the electronic		0600Ω	± 1.0%
module can be plugged into a TB 16 SC	max. 20	Pt100 (climatic)	4 °C
		Pt100 (standard) Ni100 (standard)	8 °C 4 °C
Voltages, Currents, l	Potentials	Tittoo (standard)	4 6
Rated supply voltage of the electronics L+	DC 24 V	Basic error limit (operational	
		limit at 25°C, relative to rated in-	
 Reversed polarity protection 	yes	put range)	0.7.0/
		0600Ω Pt100 (climatic)	0.7 % 1 °C
Galvanic isolation		Pt100 (standard)	4 °C
 Between channels and SC bus 	no	Ni100 (standard)	2 °C
 Between channels and power 	по		
supply of electronics	no		
Between measurement and		Temperature error (relative to	± 0.03%/K
current channels	no	rated input range)	± 0.03%/K
Permissible potential difference		Linearity error (relative to rated input range)	± 0.05%
 Between input and ground (V_{CM}) 	DC 2 V/AC 2 V _{SS}	after a restart (see Table in settled state at 25°C, (relative to rated	
Constant current for resistance		input range)	± 0.1%
sensor approx. 1.5 mA		Statuses, Interrupts, Diagnostics	
Power input		Interrupts	none
From supply voltage L+	max. 30 mA	Diagnostic functions	
Power loss of the module	typ. 0.6 W	Fault display on module	no
		Readable diagnostic function	no

yes 60 0 130 0 130
60 0 130
60 0 130
0 130
0 100
0 130
format
14 bits
0.1°C/digit
0.1°C/digit
0.1°C/digit
format
13 bits
0.05°C/digit
0.5°C/digit
0.5°C/digit

Senso	or Selection	Data
Input ranges (rated va	lues)/input	0600 Ω / >1 MΩ
	atio: 120 I	-130 °C) />1 MΩ
`	,	,
,	,	+850 °C) / >1 MΩ
Ni100 (stan	dard; -60+	250 °C) / >1 MΩ
Permitted input voltag for resistance measure and constant current i puts (destruction limit	ement input nputs/out-	max.10 V permanent; 25 V for max. 1 s (pulse duty factor 1:20)
Connection of sensors	S	
• For resistance mea	asurement	
– 4-conductor c	onnection	yes; with compensa- tion of the line re- sistances
Characteristic curve linearization		yes; parameterized
- For Pt100 to DIN IEC 751		
 For Ni100 to 1 	DIN 43760	
Temperature compens		no
Smoothing of measure		yes; set by parameters in 4 steps by digital filtering
	Step None Weak Medium Strong	Time constant 1x cycle time 8x cycle time 64x cycle time 128x cycle time

12.9 Analog Electronic Module 1 AO U

Order Number 6ES7 124-1FA00-0AB0

Characteristics

The 1 AO U analog electronic module is an analog output module with the following characteristics:

- 1 voltage output
- Output ranges $\pm 10 \text{ V}$ and 1...5 V
- 12/11-bit resolution
- Isolation from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the output module.

The block diagram is shown on the front of the output module. In the operating state, the block diagram is covered by the labeling strip.




Figure 12-25 Front and Side Elevations of the 1 AO U Analog Electronic Module

Block Diagram Figure 12-26 shows the block diagram of the 1 AO U analog electronic module




Figure 12-26 Block Diagram of the 1 AO U Analog Electronic Module

Parameters

The 1 AO U electronic module uses the following parameters:

Table 12-10 Static Parameters of the 1 AO U Electronic Module

Parameter	Value Range	Default Parameters
Measurement type	Deactivated	
	Voltage	Voltage
Output range (voltage)	± 10 V	± 10 V
	1 5 V	
Interference frequency suppression	50 Hz (integration time 60 ms)	50 Hz
	60 Hz (integration time 50 ms)	
Smoothing	None	None
	Weak	
	Medium	
	Strong	
Format	SIMATIC S7	SIMATIC S7
	SIMATIC S5	

Default Parameters

If you have not set the parameters of the 1 AO U electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-10).

Technical Data The technical data of the 1 AO U analog electronic module is listed below.

Weight ap	$0\times64\times51$	Interference Suppression, l	
Weight ap		 Common-mode interference 	
	pprox. 25 g	V_{CM} < 2 V_{SS} AC (50Hz)	>30 dB
Module-Specific Da		Operational limit (in entire tem-	
Number of outputs 1		perature range, relative to rated output range)	± 0.9%
Line length		Basic error limit (operational	± 0.770
_	nax. 200 m	limit at 25°C, relative to rated	
	xternal protective	output range)	± 0.6%
	evice in the power	Temperature error (relative to	. 0.010//77
	apply and signal nes required	rated output range)	± 0.01%/K
Number of times the electronic		Linearity error (relative to rated output range)	1 0 0 0 0 0
module can be plugged into a			± 0.06%
	nax. 20	Repeatability in settled state at 25°C (relative to rated output	
Voltages, Currents, Pote	entials	range)	± 0.1%
Rated supply voltage of the electronics L+ D	OC 24 V	Statuses, Interrupts, D	Diagnostics
Reversed polarity protection years.		Interrupts	none
Galvanic isolation		Diagnostic interrupt	none
Between output channel and		Actuator Selection	n Data
SC bus	0	Output range (rated values)	±10 V
Between output channel and			15 V
current supply of electronics no	0	Load resistance (in rated range of the output)	min. 1kΩ
Permissible potential difference		Short circuit protection	yes
CIVID	nax. DC 2 V/ .C 2 V _{SS}	Short circuit current	approx. 30 mA
	C 2 VSS	Capacitive load	max. 1 μF
Power input • From supply voltage L+ m	nax. 50 mA	Destruction limit against exter-	
	nax. 1 W	nally applied voltages/currents	
Analog value format		Voltage at outputs against	max. 15 V perma-
Resolution (incl. overrange)		ground; QV-	nent; 75 V for max. 1 s (pulse duty
- ·	5.C		factor 1:20)
S7 format / S5		• Current	max. DC 50 mA
$\pm 10 \text{ V}$ 12	2 bits	Connection of the actuators	
15 V 11	1 bits	 2-conductor connection 	possible
Conversion time m	nax. 5 ms	- 4-conductor connection	possible
Settling time		(measuring lead)	
• For resistive load 0.	.1 ms		
• For capacitive load 3.	.3 ms		
Tor capacity croad			

12.10 Analog Electronic Module 1 AO I

Order Number

6ES7 124-1GA00-0AB0

Characteristics

The 1 AO I analog electronic module is an analog output module with the following characteristics:

- 1 current output
- Output ranges 0..20 mA and 4...20 mA
- 12-bit resolution
- Output range selection
- Isolation from the SC bus
- Permissible common-mode voltage of AC 2 V_{SS}

Front Elevation/ Side Elevation

The figure below shows the front elevation and the side elevation of the output module.

The block diagram is shown on the front of the output module. In the operating state, the block diagram is covered by the labeling strip.




Figure 12-27 Front and Side Elevations of the 1 AO I Analog Electronic Module

Block Diagram

Figure 12-28 shows the block diagram of the 1 AO I analog electronic module.




Figure 12-28 Block Diagram of the 1 AO I Analog Electronic Module

Parameters

The 1 AO I electronic module uses the following static parameters, which are stored in data record 0:

Table 12-11 Static Parameters of the 1 AO I Electronic Module

Parameter	Value Range	Default Parameters
Measurement type	Deactivated	
	Current	Current
Output range (current)	0 20 mA	4 20 mA
	4 20 mA	
Format	SIMATIC S7	SIMATIC S7
	SIMATIC S5	

Default Parameters

If you have not set the parameters of the 1 AO I electronic module using the specified software (see Chapter 4), the default settings apply to both input channels after a restart (see Table 12-11).

Technical Data The technical data of the 1 AO I analog electronic module is listed below.

Dimensions and V	Veight	Interference Suppression,	Limits of Error
Dimensions W×H×D (mm)	20×64×51	Common-mode interference	
Weight	approx. 25 g	$V_{CM} < V_{SS} AC (50Hz)$	>30 dB
Module-Specific		Operational limit (in entire tem-	
Number of outputs	1	perature range, relative to rated output range)	± 1.0%
Line length			± 1.0%
Shielded	max. 200 m	Basic error limit (operational limit at 25°C, relative to rated	
Protection of the electronic mod-	external protective	output range)	± 0.7%
ule against surge stress	device in the power	Temperature error (relative to	
to IEC801-5	supply and signal lines required	rated output range)	$\pm 0.01\%/K$
NT 1 Car at 1 a c	inies required	Linearity error (relative to rated	1 0 0 0 0 0
Number of times the electronic module can be plugged into a		output range)	± 0.06%
TB 16 SC	max. 20	Repeatability in settled state at 25°C (relative to rated output	
Voltages, Currents, I	Potentials	range)	± 0.1%
Rated supply voltage of the elec-		Statuses, Interrupts, Diagnostics	
tronics L+	DC 24 V	Interrupts	none
Reversed polarity protection	yes	Diagnostic interrupt	none
Galvanic isolation		Actuator Selection Data	
Between channel and SC bus	no	Output ranges (rated values)	020 mA;
Between output channel and voltage supply of electronics	no		420 mA
Permissible potential difference	110	Load resistance (in rated range of the output)	
Between reference point of	max. DC 2 V/	at common-mode voltage of	
load and QV- (V _{CM})	AC 2 V _{SS}	2 V	max. 500Ω
Power input		• at common-mode voltage of	
From supply voltage L+	max. 50 mA	0 V	max. 600Ω
Power loss of the module	max. 1 W	Idling-proof	yes
Analog value forr	nation	Open-circuit voltage	approx. 16 V
Resolution (incl. overrange)		Inductive load	max. 1mH
S7 format /	S5 format	Destruction limit against externally applied voltages/currents	
020 mA	12 bits	Voltage at outputs against ground	max. 15 V permanent; 75 V for
420 mA	12 bits	Bround	max. 1 s (pulse duty
Conversion time	max. 5 ms	• Comment	factor 1:20)
Settling time		• Current	max. DC 50 mA
For resistive load	0.1 ms	Connection of the actuators	
For inductive load	0.5 ms	 2-conductor connection 	possible
Substitute values applicable	no		

The 1COUNT40kHz Counter Module

13

Contents of the Chapter

Section	Торіс	Page
13.1	Front and Side Elevations	13-2
13.2	Block Diagram	13-3
13.3	Functions of the Counter Module	13-4
13.4	Wiring the Counter and Putting it into Operation	13-14
13.5	Parameters of the Counter Module	13-17
13.6	Subdivision of the Data Areas	13-19
13.7	Application Examples	13-21
13.8	Technical Data	13-25

Order Numbers

Product Name	Order Number
Counter module 1COUNT40kHz	6ES7 127-1BE00-0AB0

Characteristics

The 1COUNT40kHz counter module is a counter for use in the ET 200L-SC IM-SC. The module incorporates a counter that can work in the following range:

Counting Range	Lower count limit	Upper count limit
16 bits (unipolar)	0	+65535

The maximum input frequency of the count signals is 40 kHz.

You can use the 1COUNT40kHz counter module for the following types of counting:

- Continuous counting
- Single-pass counting
- Periodic counting

What Signals Can the 1COUNT40kHz Count?

The 1COUNT40kHz counter module can count signals generated by the following pulse initiators: 24-V pulse initiator

- with direction indicator (e.g. light barrier or proximity switch)
- without a direction indicator (e.g. light barrier or proximity switch)

13.1 Front and Side Elevations

Front/Side Elevation

The figure below shows you the front and side elevations of the 1COUNT40kHz counter module.




Figure 13-1 Front and Side Elevations of the 1COUNT40kHz Counter Module

Status LEDs

The 1COUNT40kHz counter module has two LEDs, which indicate the status of the 1COUNT40kHz counter module.

Table 13-1 lists the LED displays, giving their display, colour and function.

Table 13-1 Displays, Colour and Functions of the LEDs

Display	Color	Function
†	Green	This LED comes on when the counter is counting upward (door open and status of the direction input $B=0$ signal)
<u> </u>	Green	This LED comes on when the counter is counting downward (gate open and status of the direction input $B=1$ signal)

13.2 Block Diagram




Figure 13-2 Block Diagram of the 1COUNT40kHz Counter Module

Abbreviations Used

1A = count input

3B = direction input

4M = load voltage brought out (neg. potential) 2L+ = load voltage brought out (pos. potential)

13.3 Functions of the Counter Module

Contents of the Section

Section	Topic	Page
13.3.1	24V Pulse Initiator With/Without Direction Indicator	13-7
13.3.2	Gate Function	13-8
13.3.3	Digital Output	13-9

Continuous Counting

The counter begins at the lower count limit.

If the counter reaches the upper limit when counting upward and there is then another count pulse, the counter jumps to the lower limit and starts to count the count pulses again, thus counting continuously.

If the counter reaches the lower count limit when counting downward and there is then another count pulse, the counter jumps to the upper count limit and starts to count downward from there.




Figure 13-3 Continuous Upward Counting




Figure 13-4 Continuous Downward Counting

Single-Pass Counting

The counter begins at the loaded value.

In single-pass counting, the counter starts at the loaded value. If the counter reaches the upper count limit when counting upward and there is then another count pulse, the counter jumps to the lower count limit and stays there even when there are additional count pulses.

If the counter reaches the lower count limit when counting downward and there is then another count pulse, it jumps to the upper count limit and stays there even when there are additional count pulses.




Figure 13-5 Single-Pass Upward Counting




Figure 13-6 Single-Pass Downward Counting

Repeated Single-Pass Counting with Door Function




Figure 13-7 Single-Pass Counting with Loaded Value and Gate Function

Periodic Counting

The counter begins at the loaded value.

In periodic counting, the counter starts at the loaded value. If the counter reaches the upper value when counting upward and there is then another count pulse, the counter jumps to the loaded value and starts to count the count pulses again.

If the counter reaches the lower count limit when counting downward and there is then another count pulse, the counter jumps to the loaded value and continues to count downward from there.




Figure 13-8 Periodic Upward Counting




Figure 13-9 Periodic Downward Counting

13.3.1 24V Pulse Initiator With/Without Direction Indicator

The pulse initiator – a proximity switch (BERO) or light barrier, for example – supplies only one count signal, which must be connected to terminal A on the terminal block.

You can also connect a signal for direction identification to terminal B of the terminal block. If you do not connect a direction signal, the counter counts upward.

Note the parameterization of the count direction.




Figure 13-10 Signals of a 24V Pulse Initiator with Direction Indicator

13.3.2 Gate Functions

Counting with Gate Functions

Many applications require counting to start or stop as of a defined time, dependent on other events. In the case of the counter module, this starting and stopping of counting is effected by means of a gate function. If the gate is opened, count pulses can get through to the counter. If the gate is closed, count pulses can no longer get through to the counter and counting stops.

Gate Function

The counter module has a gate function. This is controlled by the user program in the CPU. The transmission times must be taken into account here.

Example

When the gate signal is set, the gate is opened and the count pulses are counted. When the gate signal is taken away, the gate is closed and the count pulses are no longer registered by the counter. The count remains constant.

Figure 13-11 shows the opening and closing of a gate and the counting of the pulses.




Figure 13-11 Opening and Closing of a Gate

Terminating
Counting with the
Gate Stop
Function

You can terminate counting by setting the "gate" bit to "0".

13.3.3 Digital Output

Introduction

You can store a comparison value on the 1COUNT40kHz counter module. This is assigned to the digital output. The output is activated depending on the count and the comparison value. This section describes the various ways of setting the responses of the output.

The digital output of the counter module is only available as a status bit. To operate a digital output, you must read in this status bit, which is in the input range, and output it to a digital output.

Comparison Value

You transfer the comparison value to the 1COUNT40kHz counter module. Counting is not affected by this.

The comparison value must lie within the count range of the counter module. The comparison value is interpreted in accordance with the selected count mode. If you specify a comparison value of $FFFF_H$, for example, in 16-bit mode the number is interpreted as 65535.

Enabling the Output

The output cannot be activated unless you first enable it by setting the appropriate bit (see also Section 13.6, Subdivision of the Data Areas).

Default Setting

By default, the output is switched off.

Pulse Duration

The pulse duration can be set for the purpose of adaptation to the actuators being used. The pulse duration specifies how long the output is to be set. The pulse duration can be set between 0 and 3 s in steps of 100 ms.

Digital Output: Logic

If you set the digital output: logic parameter to inverted, in its active state the digital output has a 0 in its status bit.

This does not take effect until the parameter values are received.

Behavior of the Output

You can set one of 6 possible responses for the output when the comparison value is reached. The alternatives are shown in the table below.

Behavior of the Output				
Output disabled	Underflow Comparison value Overflow			
	The output remains deactivated and is not affected by the events comparison value, zero-crossing, overflow or underflow.			
Active from comparison value to overflow	Underflow Comparison value Overflow			
	The output is activated when the counter is in the range between the comparison value n and overflow. When the counter is set to a value between comparison value and overflow, the output is activated.			
Active from comparison value to underflow	Underflow Comparison value Overflow			
	The output is activated when the counter is in the range between the comparison value n and underflow. When the counter is set to a value between comparison value and underflow, the output is activated.			
Active at comparison value counting upward	Underflow Comparison value Overflow			
	The output is activated for the length of the pulse duration when the comparison value is reached counting upward.			
Active at comparison value counting downward *	Underflow Comparison value Overflow			
	The output is activated for the length of the pulse duration when the comparison value is reached counting downward.			
Active at comparison value counting upward/downward	Upward t t Downward Underflow Comparison value Overflow Underflow Comparison value Overflow			
	The output is activated for the length of the pulse duration when the comparison value is reached regardless of the direction of counting.			

* Note the conditions overleaf

= output active

t = pulse duration

Conditions

When you parameterize the behavior of the digital outputs, you must comply with the following:

If	Then
you want to parameterize the output as active from the comparison value to overflow or underflow	you must ensure that the time between these events is greater than the transmission time. Otherwise, the control pulses are lost at the output. If the count reaches the comparison value again while the output is still active, no new pulse is released. Another pulse cannot be released until the output is no longer active.

Hysteresis

Hysteresis is only significant in upward/downward count mode.

Hysteresis, which can be set from 0 to 255 allows you to prevent the switching output from changing with the direction signal around the comparison value or the pulse duration from being restarted.

If the counter counter reaches the comparison value for the first time after entry, the output is activated.

Here are five examples:




Figure 13-12 Example 1: The Output Is Set to Be Active from the Comparison Value to Overflow




Figure 13-13 Example 2: The Output Is Set to Be Active from the Comparison Value to Underflow




Figure 13-14 Example 3: The Output Is Set to Be Active for the "Pulse Duration on Reaching the Comparison Value Counting Upward"




Figure 13-15 Example 4: The Output Is Set to Be Active for the "Pulse Duration on Reaching the Comparison Value Counting Downward"




Figure 13-16 Example 5: The Output Is Set to Be Active for the "Pulse Duration on Reaching the Comparison Value Counting Upward/Downward"

13.4 Wiring the Counter and Putting the Counter into Operation

Contents of the Chapter

Section	Торіс	Page
13.4.1	Wiring the Counter	13-15
13.4.2	Putting the Counter into Operation	13-16

13.4.1 Wiring the Counter

You wire the 1COUNT40kHz counter module as shown in the following figure:




Figure 13-17 Connecting a Pulse Initiator with a Direction Signal (Example TB 16SC)

Note

You can run up to 10 counter modules in the ET 200L-SC IM-SC.

13.4.2 Putting the Counter into Operation

Characteristics

After the power is switched on and before any data is transmitted, the state of the module is as follows:

- The count is at zero.
- The continuous counting mode is set.
- Status messages are updated.
- The gate is closed.
- The module is waiting for parameters.

13.5 Parameters of the Counter Module

Parameter

In the table below you will find a list of the parameters, their value ranges and default values:

Table 13-2 Parameter List

Parameter	Value Range	Default Values
Count limit: lower	0 65535	0
Count limit: upper	0 65535	65535
Mode	Continuous	Continuous
	Single-pass	
	Periodic	
Count mode	Upward	Upward
	Upward/downward	
Enable comparison value	Disable	Disable
	Enable	
Digital output:	Disable	Disable
activated on	Comparison value to overflow	
	Comparison value to underflow	
	Reaching the comparison value for the pulse duration counting upward	
	Reaching the comparison value for the pulse duration counting downward	
	Reaching the comparison value for the pulse duration counting upward or downward	
Digital output:	Not inverted	Not inverted
logic	Inverted	
Digital output: pulse duration	0 3000 ms in steps of 100 ms	0
Hysteresis	0 255 count pulses	0

Count Mode

You can choose between the following count directions:

- Upward
- Upward/downward

In the upward count mode the direction input is ignored.

Comparison Values

You can store a comparison value in the counter module. An output of the counter module is assigned to this value. If the count reaches the comparison value, the output can be set in order to trigger direct control operations in the process.

Comparison Value Enabling

If the comparison value is disabled, the count is not compared with the comparison value and the output is thus not activated.

Default Parameters

If no other values are supplied from data records, the counter module works with the default parameters.

Peculiarities

If the DP line fails or the CPU goes into STOP mode (see Section 13.6, Subdivision of the Data Areas: Note), the counter module continues to count provided the gate was open.

When a connection to the DP station is re-established or the CPU goes into RUN mode, and provided the lower and upper count limit parameters have not been changed, you can read the current count.

13.6 Subdivision of the Data Areas


Control Data

Control data is transferred from the CPU to the counter module cyclically. Control data amounting to more than 1 byte is stored as follows:



You can use the control data to change the functioning of the counter module. The following table indicates which function can be affected by which address/addresses.


Output Range



Note

You generally have to set bit 7 (valid control commands) to 1 in the user program. As a result, when there are changes to the operating status of the CPU or in the event of the DP strang failing or being switched off, you can recognize this and continue to count, provided the gate was open.

Input range



13.7 Application Examples

Example 1

The following example shows how to count upward in a single pass, with gate function, without output.

Conditions: The input and output address of the counter module have been parameterized as 0.




Figure 13-18 Example 1




Figure 13-19 Example 1, Continued

Example 2

The following example shows how to count upward periodically, with gate function, output at comparison value.

Conditions: The input and output address of the counter module have been parameterized as 0.




Figure 13-20 Example 2




Figure 13-21 Example 2, Continued

13.8 Technical data

Dimensions and	Weight	Statuses, Interrupts,	Diagnostics
Dimensions $W \times H \times D$ (mm) Weight	10×64×51 Approx. 15 g	Status display	1 green LED each for – Counting upward
Module-Specific	: Data		Counting down-Counting down-
Number of counters Cable length	1	Interrupts Diagnostic functions	ward None None
Shielded	Max. 100 m	Data on the Count	Signals
Voltages, Currents,	Potentials	24 V input signals	
Rated load voltage L+	DC 24 V	Rated value	DC 24 V
Reverse polarity protection	Yes	• For signal "1"(high level)	11 30 V
Galvanic isolation		• For signal "0" (low level)	−3 5 V
Between channels and SC busBetween the inputs	No No	Input current • At signal "I"(high level)	Typ. 6 mA
Permissible potential difference		Minimum pulse width (max. input frequency)	≥ 12.5 µs (40 kHz)
Between different circuits	DC 75 V/ AC 60 V	• Input characteristic curve to	IEC 1131, Type 1
Power input		Connection to 2-wire BEROs	Possible
• From load voltage L+	Approx. 20 mA	Permissible closed–circuit	Max. 1.5 mA
Power loss of the module	Max. 0.5 W	current	1111A. 1.5 IIII

Order Numbers



Introduction

Should you require additional components for the ET 200L distributed I/O device or should you wish to upgrade the PROFIBUS, you will find the order numbers here for the corresponding components.

We have divided the components into:

- ET 200L components
- Smart Connect SC components
- Accessories for the PROFIBUS with a note on the manuals for the different PROFIBUS-DP masters and system configuration software

Contents of the Appendix

Section	Subject	Page
A.1	Order Numbers for ET 200L Components	A-2
A.2	Order Numbers for Smart Connect SC Components	A-6
A.3	Order Numbers for PROFIBUS Accessories	A-9

A.1 Order Numbers for ET 200L Components

Introduction

You will find here the order numbers for ET 200L components.

Terminal Blocks

Table A-1 Terminal Block Order Numbers

Description	Order Number
Terminal block TB 16L, screw-type terminal	6ES7 193-1CH00-0XA0
Terminal block TB 16L, spring terminal	6ES7 193-1CH10-0XA0
Terminal block TB 32L, screw-type terminal	6ES7 193-1CL00-0XA0
Terminal block TB 32L, spring terminal	6ES7 193-1CL10-0XA0
Terminal block TB 16L AC, screw-type terminal	6ES7 193-1CH20-0XA0
Terminal block TB 16SC, spring terminal	6ES7 193-1CH10-0XA0
Terminal block TB 16SC, spring terminal	6ES7 193-1CL10-0XA0
Terminal block TB 16IM-SC, screw-type terminal	6ES7 120-0AH50-0AA0
Terminal block TB 16IM-SC, spring terminal	6ES7 120-0BH50-0AA0

Electronics Blocks

Table A-2 Electronics Block Order Numbers

Description	Order Number
Interface module IM-SC	6ES7 138-1XL00-0XB0
L 16 DI DC 24 V	6ES7 131-1BH00-0XB0
L-SC 16 DI DC 24 V	6ES7 131-1BH11-0XB0
L 16 DI AC 120 V	6ES7 131-1EH00-0XB0
L 32 DI DC 24 V	6ES7 131-1BL00-0XB0
L-SC 32 DI DC 24 V	6ES7 131-1BL11-0XB0
L 16 DO DC 24 V/0.5 A	6ES7 132-1BH00-0XB0
L-SC 16 DO DC 24 V/0.5 A	6ES7 132-1BH11-0XB0
L DO AC 120 V/1.0 A	6ES7 132-1EH00-0XB0
L 16 DO DC 24 V/AC 120V/2.0 A	6ES7 132-1JH00-0XB0
L 32 DO DC 24 V/0.5 A	6ES7 132-1BL00-0XB0
L 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL00-0XB0
L-SC 16 DI/16 DO DC 24 V/0.5 A	6ES7 133-1BL10-0XB0
L-8 DI/8 DO AC 120 V/1.0 A	6ES7 133-1EH00-0XB0
L 8DI AC 120V/8 DO DC 24V/AC 120V/2.0 A	6ES7 133-1JH00-0XB0

Supplementary Terminal

Table A-3 Supplementary Terminal Order Numbers

Description	Order Number
Single-tier, 16 channels, screw-type terminal	6ES7 193-1FH20-0XA0
Two-tier, 16 channels, screw-type terminal	6ES7 193-1FH30-0XA0
Single-tier, 16 channels, spring terminal	6ES7 193-1FH50-0XA0
Two-tier, 16 channels, spring terminal	6ES7 193-1FH60-0XA0
Single-tier, 32 channels, screw-type terminal	6ES7 193-1FL20-0XA0
Two-tier, 32 channels, screw-type terminal	6ES7 193-1FL30-0XA0
Single-tier, 32 channels, spring terminal	6ES7 193-1FL50-0XA0
Two-tier, 32 channels, spring terminal	6ES7 193-1FL60-0XA0

Labeling Strips

You obtain additional labeling strips by quoting the following order number:

- DIN A4 with 10 strips, 16 channels: 6ES7 193-1BH00-0XA0
- DIN A4 with 10 strips, 32 channels: 6ES7 193-1BL00-0XA0

ET 200L	2NET - 7810022
Labeling strips 16 channels	6ES7 - 193 - IBH00 - 0XA0
A B	A B
1 9	1 9
02 10 0	2 10
3 11	3 11
	4 12
6 14	
7 15	7 15
8 16 🗆	8 16
A B	A B
1 9	
2 10□	2 10
	4 12
5 13	5 13
6 14 🗆	6 14
	7 15
8 16	8 16
A B	A B
1 9	1 9
│	3 11
4 12	4 12
5 13	5 13
06 14 0	6 14
A B	A B
	2 10
3 11 🗓	3 11
04 12	4 12
5 13	5 13
	8 16
A B	A B
1 9	1 9
	3 11
	5 13
6 14	6 14
7 15	7 15
8 16	8 16

Figure A-1 Labeling Strips 6ES7 193-1BH00-0XA0




Figure A-2 Labeling Strips 6ES7 193-1BL00-0XA0

A.2 Order Numbers for Smart Connect SC Components

Introduction

You will find here the order numbers for Smart Connect SC components.

Terminal Block and **Terminals**

Table A-4 Terminal Block and Terminal Order Numbers

Description	Order Number
Terminal block TB16 SC (screw-type terminal)	6ES7 120-0AH01-0AA0
Terminal block TB16 SC (spring terminal)	6ES7 120-0BH01-0AA0
Supplementary terminal, single-tier (screw-type terminal)	6ES7 120-1AH00-0AA0
Supplementary terminal, single-tier (spring terminal)	6ES7 120-1BH00-0AA0
Supplementary terminal, double-tier (screw-type terminal)	6ES7 120-2AH00-0AA0
Supplementary terminal, double-tier (spring terminal)	6ES7 120-2BH00-0AA0
Shield terminal	6ES7 192-0AA00-0AA0

Digital SC Electronic Modules

Table A-5 Digital SC Electronic Module Order Numbers

Description	Order Number
Digital electronic module 2DIDC24V	6ES7 121-1BB00-0AA0
Digital electronic module 2DODC24V0.5A	6ES7 122-1BB00-0AA0
Digital electronic module 2DODC24V2A	6ES7 122-1BB10-0AA0
Digital electronic module 1DIAC120/230V	6ES7 121-1FA00-0AA0
Digital electronic module 1DOAC120/230V1A	6ES7 122-1FA00-0AA0
Digital electronic module 1DORel.AC230V	6ES7 122-1HA01-0AA0

Analog SC Electronic Modules

Table A-6 Analog SC Electronic Module Order Numbers

Description	Order Number
Analog electronic module 2 AI U	6ES7 123-1FB00-0AB0
High-speed analog electronic module 2 AI HS U	6ES7 123-1FB50-0AB0
Analog electronic module 2 AI I	6ES7 123-1GB00-0AB0
Analog electronic module 2 AI I	6ES7 123-1GB10-0AB0
High-speed analog electronic module 2 AI HS I	6ES7 123-1GB60-0AB0
(0/4–20 mA, 4-wire measuring transducer)	
High-speed analog electronic module 2 AI HS I	6ES7 123-1GB50-0AB0
(4–20 mA, 2-wire measuring transducer)	
Analog electronic module 2 AI TC	6ES7 123-1JB00-0AB0
Analog electronic module 1 AI RTD	6ES7 123-1JA00-0AB0
Analog electronic module 1 AO U	6ES7 124-1FA00-0AB0
Analog electronic module 1 AO I	6ES7 124-1GA00-0AB0

Function Modules

Table A-7 Function Modules

Description	Order Number
Counter module 1COUNT40kHz	6ES7 127-1BE00-0AB0




Figure A-3 Labeling Strips for Smart Connect

A.3 Order Numbers for PROFIBUS Accessories

Introduction

In this section, we have listed the order numbers for PROFIBUS accessories which you require for the ET 200L.

Further, you will find notes on the different manuals you will require, depending on the PROFIBUS-DP master being used.

Network Components for the ET 200

Table A-8 lists all the network components for the ET 200L distributed I/O device which you may require in conjunction with the ET 200L.

Table A-8 Accessories for the ET 200 Distributed I/O Device

Accessories	Order Number
RS 485 repeater, PROFIBUS -DP, IP 20	6ES7 972-0AA00-0XA0
PROFIBUS bus terminator (12 MBaud) (not for interface module IM-SC)	
Anthracite (without programming port)	6ES7 972-0BA10-0XA0
Anthracite (with programming port)	6ES7 972-0BB10-0XA0
PROFIBUS bus terminator (1.5 MBaud)	6ES7 972-0CA30-0XA0
Bus cable (not for interface module IM-SC)	
Normal	6XV1 830-0AH10
Drum cable	6XV1 830-3BH10
Direct-buried cable	6XV1 830-3AH10
Repeater adapter	6GK1 510-1AA00
Optical link modules for glass fiber-optic	6GK1 502-3AB00
cables	6GK1 502-4AB00
PROFIBUS drop cable	6ES7 901-4BD00-0XA0

Manuals for STEP 7 and SIMATIC S7

You require one of the manuals listed in Table A-9 to program and commission the ET 200L with STEP 7.

Table A-9 Manuals for STEP 7 and SIMATIC S7

Manual	Contents
S7-300 Programmable Controller	Includes
Hardware and Installation	 Description of the PROFIBUS-DP interface of CPU 315-2 DP
	Installing a PROFIBUS-DP network
	Bus connector and RS 485 repeater
M7-300 Programmable Controller	Includes
Hardware and Installation	 Description of the PROFIBUS-DP interface in M7-300
	Installing a PROFIBUS-DP network
	Bus connector and RS 485 repeater
S7-400, M7-400 Programmable	Includes
Controllers Hardware and Installation	• Description of the PROFIBUS-DP interface in S7-400 and M7-400
	Installing a PROFIBUS-DP network
	Bus connector and RS 485 repeater
System software for S7-300 and S7-400 Program Design Programming manual	Includes Description of addressing and diagnostics on SIMATIC S7
System software for S7-300 and S7-400 System and Standard Functions Reference manual	Description of the SFCs in STEP 7

Manual for ET 200 on SIMATIC S5

You require one of the manuals listed in Table A-9 to program and commission the ET 200L with COM ET 200.

Table A-10 Manuals for ET 200 on SIMATIC S5

Manual	Order Number	Contents
ET 200 distributed I/O device	6ES5 998-3ES.1	Description of master interface IM 308-B for S5-115U/H, S5-135U, and S5-155U/H
		Handling COM ET 200 V 4.x
ET 200 distributed I/O device	6ES5 998-3ES.2	Description of master interface IM 308-C for S5-115U/H, S5-135U and S5-155U/H
		Description of the S5-95U with PROFIBUS-DP master interface
		Handling COM ET 200 Windows
		Handling FB IM308C

Type and Device Master Files

B

Type File

All the properties of a DP slave are stored in a type file.

You can integrate the type file of the ET 200L (Table C-1) in COM ET 200 as of Version 4.0, COM ET 200 Windows and STEP 7.

The type files for the ET 200L-SC (Table C-4) can be integrated in COM ET 200 Windows as of Version 2.1.

The type files for a default start-up of the ET 200L-SC with a standard, non-Siemens DP master are described in Table C-14. You can integrate the type files of the default start-up in COM ET 200 Windows as of Version 1.0.

If you need the type file, you can get it using a modem by calling +49 (911) 737972 or from the SINEC library in AUTFORUM in CompuServe (GO AUTFORUM).

Device Master File

All slave-specific characteristics are stored in a device master file (GSD file). The structure of the device master file is laid down in EN 50 170 Volume 2, PROFIBUS.

If you need the device master file, you can get it using a modem by calling +49 (911) 737972 or from the SINEC library in AUTFORUM in CompuServe (GO AUTFORUM).

Configuration Software

The following table shows the version of the configuration software as of which the ET 200L, ET 200L-SC and ET 200L-SC IM-SC are integrated.

Table B-1 Version der Projektier-Software

Order Number of the Module (6ES7 0XB0)	COM ET 200 Windows as of Version	COM PROFIBUS as of Version	STEP 7 as of Version
131-1BH00	2.1	3.0	3.0
131-1BL00	2.1	3.0	3.0
132-1BH00	2.1	3.0	3.0
132-1BL00	2.1	3.0	3.0
133-1BL00	2.1	3.0	3.0
131-1EH00	_	3.0	3.1
132-1EH00	_	3.0	3.1
133-1EH00	_	3.0	3.1
131-1BH10	2.1	3.0	3.0
131-1BH11	_	3.0	3.0
131-1BL10	2.1	3.0	3.0
131-1BL11	_	3.0	3.0
132-1BH10	2.1	3.0	3.0
132-1BH11	_	3.0	3.0
133-1BL10	_	3.0	3.0
138-1XL00	_	3.2	4.1

Most Important Characteristics

If you do not have the device master file in front of you, the most important characteristics of the ET 200L distributed I/O device are listed here in tabular form.

Table B-2 Data for PROFIBUS-DP

Characteristic	DP Keyword in Accordance with EN 50 170 Volume 2, PROFIBUS	ET 200L	ET 200L-SC or ET 200L-SC IM-SC
Manufacturer ID	Ident_Number	See Table C-1	See Table C-4
Supports FMS	FMS_supp	No	No
Supports 9.6 kbps	9.6_supp	Yes	Yes
Supports 19.2 kbps	19.2_supp	Yes	Yes
Supports 93.75 kbps	93.75_supp	Yes	Yes
Supports 187.5 kbps	187.5_supp	Yes	Yes
Supports 500 kbps	500_supp	Yes	Yes
Supports 1.5 Mbps	1.5M_supp	Yes	Yes
Supports 3 Mbps	3M_supp	No*	No
Supports 6 Mbps	6M_supp	No*	No
Supports the FREEZE control command	Freeze_Mode_supp	Yes	Yes
Supports SYNC control command	Sync_Mode_supp	Yes	Yes
Supports automatic baud rate recognition	Auto_Baud_supp	Yes	Yes
PROFIBUS address modifiable using software	Set_Slave_Add_supp	No	No
User-specific parameterization data (default)	User_Prm_Data	Yes	Yes
Length of the user-specific data	User_Prm_Data_Len	5 bytes 5×00 _H	Variable
Modular device	Modular_Station	0	1
Maximum number of modules	Max_Module	0	8 (ET 200L-SC) 16 (ET 200L-SC IM-SC)
Maximum number of inputs	Max_Input_Len	See Table 1	B-3 and B-4
Maximum number of outputs	Max_Output_Len		
Maximum number of inputs and outputs together	Max_Data_Len		
Central display of manufacturer-specific status and error messages	Unit_Diag_Bit	Not used	Not used
Assignment of values to texts in device-specific diagnostic field	Unit_Diag_Area	Not used	Used
Identification of all modules of a modular DP slave	Module, End_Module	No	No
Assignment of manufacturer-specific error types to texts in channel-specific diagnostic field	Channel_Diag	No	No

^{*} Exception: AC terminal blocks of the ET 200L

Inputs and Outputs with the ET 200L

Table B-3 indicates the maximum number of inputs and outputs of the different ET 200L electronics blocks:

Table B-3 Maximum Number of Inputs and Outputs with the ET 200L

Electronics Block	Maximum Number of					
	Inputs (Bytes)	Outputs (Bytes)	Inputs and Outputs Together (Bytes)			
L 16 DI DC 24 V	2	0	2			
L 32 DI DC 24 V	4	0	4			
L 16 DO DC 24 V/0.5 A	0	2	2			
L 32 DO DC 24 V/0.5 A	0	4	4			
L 16 DI/16 DO DC 24 V/0.5 A	2	2	4			

Inputs and Outputs with the ET 200L-SC or ET 200L-SC IM-SC Table B-4 indicates the maximum number of inputs and outputs of the different ET 200L-SC electronics blocks.

Table B-4 Maximum Number of Inputs and Outputs with the ET 200L-SC or ET 200L-SC IM-SC

Electronics Block	Maximu	m Number o	of Digital ¹	Maximum Number of Analog ²		
	Inputs (Bytes)	Outputs (Bytes)	Inputs and Outputs Together (Bytes)	Inputs (Bytes)	Outputs (Bytes)	Inputs and Outputs Together (Bytes)
	Type File	with SI8022	XA?.200 ^{3,4}	Type File	with SI8022	XB?.200 ^{3,4}
L-SC 16 DI DC 24 V	10	8	18	34	32	66
L-SC 32 DI DC 24 V	12	8	20	36	32	68
L-SC 16 DO DC 24 V/0,5 A	8	10	18	32	34	66
L-SC 16 DI/16 DO DC 24 V/0,5 A	_	_	_	34	34	68
L-SC IM-SC	64	64	128	_	_	_

Only digital input and output modules are connected to the ET 200L-SC.

Analog and digital input and output modules are connected to the ET 200L-SC; you can use digital or analog or digital and analog modules on the Smart Connect.

 $^{^3}$ "X" = 7, 8, 9 or C

⁴ "?" stands for a language abbreviation; D = German

Configuration Frame and Parameterization Frame for the ET 200L



Using STEP 7 as of V 3.2 or COM PROFIBUS as of V 3.0

If you configure and parameterize the ET 200L using STEP 7 or using COM PROFIBUS as of V 3.0 (or COM ET 200 Windows as of Version 2.1), you can call on an on-line help system for assistance with your entries.

You need **only** the information in Section C.5. If you want to run your ET 200L-SC or ET 200L-SC IM-SC without parameterization, you will find the default configuration for a default start-up in Section C.5.

Using Any Configuration Software

If you enter the configuration of the ET 200L-SC or ET 200L-SC IM-SC using a configuration frame and a parameterization frame, you will find the information you require in Section C.3/C.4.

Default Start-Up

If you run your ET 200L-SC or ET 200L-SC IM-SC without parameterization (e.g. with S5-95U), you will find the default configuration for a default start-up in Section C.5.

Note

When creating the configuration and parameterization frames, you must use the predefined identifiers. If you use the wrong identifiers, the ET 200L-SC or ET 200L-SC IM-SC cannot work properly.

The ET 200L-SC or ET 200L-SC IM-SC does not check all the contents of the configuration and parameterization frames for plausibility.

Contents of the Chapter

Section	Торіс	Page
C.1	Identifiers for the ET 200L	C-2
C.2	Types of ET 200L-SC or ET 200L-SC IM-SC Start-Up	C-3
C.3	Configuration Frame for the ET 200L-SC or ET 200L-SC IM-SC	C-4
C.4	Parameterization Frame for the ET 200L-SC or ET 200L-SC IM-SC	C-14
C.5	Default Start-Up	C-31

C.1 Identifiers for the ET 200L

DP Identifier

The various electronic blocks are distinguished by means of the DP identifier within PROFIBUS-DP. Table C-1 lists the DP identifiers for the ET 200L distributed I/O device.

Table C-1 DP Identifiers for the ET 200L

Electronics Block ET 200L	Order Number	Name of Manufac- Type File turer ID		entifier	Con- sis-	Address Length	Ad- dress	
E1 200L	6ES70XB0	.200	* *	Slot 0	Slot 1	tency	(Bytes)	Area
L 16 DI DC 24 V	131-1BH00	SI0014AX ¹	0014 _H	000	017	Byte	2	Digital
L 32 DI DC 24 V	131-1BL00	SI0015AX ¹	0015 _H	000	019	Byte	4	Digital
L 16 DO DC 24 V/0.5 A	132-1BH00	SI0016AX ¹	0016 _H	033	000	Byte	2	Digital
L 32 DO DC 24 V/0.5 A	132-1BL00	SI0011AX ¹	0011 _H	035	000	Byte	4	Digital
L 16 DI/16 DO DC 24 V/0.5 A	133-1BL00	SI0017AX ¹	0017 _H	033	017	Byte	2×2^2	Digital
L 16 DI AC 120 V	131-1EH00	SI002AAX ¹	002A _H	000	017	Byte	2	Digital
L 16 DO AC 120 V/ 1.0A	132-1EH00	SI0028AX ¹	0028 _H	033	000	Byte	2	Digital
L 8 DI/DO AC 120 V/1.0 A	133-1EH00	SI0029AX ¹	0029 _H	032	016	Byte	2	Digital

^{1 &}quot;X" stands for a language-independent version

Two bytes each for the input and output ranges

C.2 Types of ET 200L-SC or ET 200L-SC IM-SC Start-Up

ET 200L-SC or ET 200L-SC IM-SC In the case of the ET 200L-SC or ET 200L-SC IM-SC you can carry out a normal start-up (with configuration) or a default start-up (with a default configuration). The table below indicates how the different electronics blocks are displayed in the configuration software and which type/device master files are valid.

Table C-2 Types of ET 200L-SC of ET 200L-SC IM-SC Start-Up

Display in the Configura- tion Software	Type File Name	Order Number in the Configuration Software 6ES70XB0	Device Master File Name ³	Start-Up Type
L-SC 16DI DP	SI8027A?.200 ¹	131-1BH10	-	Normal (SC digital only)
L-SC 16DI /a DP	SI8027B?.200 ¹	131-1BH11	SIEM8027.GSG	Normal (SC analog and digital)
L-SC 16DI/def. DP	SI8027ZX.200 ²	131-1BH10	-	Default (SC digital only)
L-SC 32DI DP	SI8029A?.200 ¹	131-1BL10	-	Normal (SC digital only)
L-SC 32DI /a DP	SI8029B?.200 ¹	131-1BL11	SIEM8029.GSG	Normal (SC analog and digital)
L-SC 32DI/def. DP	SI8029ZX.200 ²	131-1BL10	-	Default (SC digital only)
L-SC 16DO DP	SI8028A?.200 ¹	132-1BH10	-	Normal (SC digital only)
L-SC 16DO /a DP	SI8028B?.200 ¹	132-1BH11	SIEM8028.GSG	Normal (SC analog and digital)
L-SC 16DO/def. DP	SI8028ZX.200 ²	132-1BH10	-	Default (SC digital only)
L-SC 16DI/DO /a DP	SI802CB?.200 ¹	133-1BL10	SIEM802C.GSG	Normal (SC analog and digital)
L-SC 16DI/DO/d. DP	SI802CZX.200 ²	133-1BL10	-	Default (SC digital only)
L-SC IM-SC DP	SI802BA?.200 ¹	138-1XL00	SIEM802B.GSG	Normal (SC analog and digital)
L-SC IM-SC/def. DP	SI802BZX.200 ²	138-1XL00	-	Default (SC digital only)

^{1 &}quot;?" stands for a language-dependent abbreviation; D = German

Note

You can also use the SI80_B?.200 type files to configure the existing (only digitally upgradable) ET 200L-SC (131-1BH10, 131-1BL10 and 132-1BH10). You can of course then only use digital SC modules.

² "X" stands for a language-independent version

³ The extension ".GSG" stands for German, ".GSE" for English, ".GSF" for French, and so on.

C.3 Configuration Frame for the ET 200L-SC

Introduction

If a configuration frame is sent to the ET 200L-SC (or ET 200L-SC IM-SC) that deviates from the default configuration, a parameterization frame must be sent to the ET 200L-SC (or ET 200L-SC IM-SC) as well.

In this case, the ET 200L-SC (or ET 200L-SC IM-SC) always expects a complete parameterization frame for all the slots in use.

If you have not connected any SC electronic modules in the ET 200L-SC or ET 200L-SC IM-SC, the module only starts up when there is no configuration available for the Smart Connect part (see Section C.3.3 for an example).

Structure of the Configuration Frame

The structure of the configuration frame depends on the address distribution of the Smart Connect electronic modules used.

The ET 200L-SC or ET 200L-SC IM-SC can work with various configuration frames. The configuration frame that can be read from the ET 200L-SC or ET 200L-SC IM-SC is described below. Possible changes to the frame are also described.

Note

SC function modules, such as the counter module, behave in the same way as analog SC modules.

Table C-3 Structure of the Configuration Frame

Configuration		Slot	Identifiers (Hexadecimal) in Bytes				
			0	1	2	3	4
Virtual slot		1	04	00	00	AD	C4
		2	04	00	00	9B	40
			04	00	00	8F	C0
ET 200L-SC (el	lectronics block)	4 to 5 or 7*	7* See Table C-4				
Smart Connect	SC digital modules	6 or 8*		See Table	C-5 and	Table C-6	5
(SC)	SC analog modules, if only analog modules are used	6 or 8*					
	SC analog modules, if analog and digital modules are used	7 or 9*					

Table C-3 Structure of the Configuration Frame, continued

Configuration		Slot	Identifiers (Hexadecimal) in Bytes						
			0	1	2	3	4		
ET 200L-SC IM-SC Smart Connect (SC)	SC digital modules	4	See Table C-7 and Table C-8						
	SC analog modules, if only analog modules are used	4							
	SC analog modules, if analog and digital modules are used	5							

^{*} The slot depends on the type of the ET 200L-SC electronics block; 8 bits of an electronic block occupy one slot

Slot Assignment

The slot assignment depends on the Smart Connect Modules used:

- Slot 6 or 8:
 - For digital modules
 - For analog modules when only analog modules are connected to the Smart Connect
- Slot 7 or 9:
 - For analog modules when analog and digital modules are connected to the Smart Connect

Contents of the Section

In the following section you will find all the information you need on the structure of the parameterization frame.

Section	Торіс	Page
C.3.1	Identifiers for the ET 200L-SC	C-6
C.3.2	Identifiers for the ET 200L-SC IM-SC	C-9
C.3.3	Configuration Frame Example	C-11

C.3.1 Identifiers for the ET 200L-SC

Identifiers for the The identifiers for configuration depend on the electronics block used. ET 200L-SC Table C-4 contains all the DP identifiers for the ET 200L-SC.

Table C-4 Identifiers for the ET 200L-SC

Electronics Block ET 200L-SC	Order Num- ber 6ES7	Manu- facturer ID	Slot	DP Identifiers (Hexadecimal) in Bytes					Con- sis- ten-	Address Length (Bytes) ¹	Ad- dress Area ²	
	-0XB0		ID		0	1	2	3	4	cy	(Dytes)	mica
L-SC 16 DI DC 24 V	131-0BH11	8027 _H	4	43	00	00	9F	41	Byte	66	Digital	
			5	43	00	00	9F	41				
L-SC 32 DI	131-1BL11	8029 _H	4	43	00	00	9F	41	Byte	68	Digital	
DC 24 V			5	43	00	00	9F	41				
			6	43	00	00	9F	41				
			7	43	00	00	9F	41				
L-SC 16 DO	132-1BH11	8028 _H	4	83	00	00	AF	48	Byte	66	Digital	
DC 24 V/0.5 A			5	83	00	00	AF	48				
L-SC 16 DI/	133-1BL10	802C _H	4	83	00	00	AF	48	Byte	68	Digital	
16 DO DC 24 V			5	83	00	00	AF	48				
			6	43	00	00	9F	41				
			7	43	00	00	9F	41				

Total address length of the ET 200L-SC

² The address area "Digital" and consistency "Byte" apply only to the electronic blocks. If you use analog modules on the Smart Connect, the address area is "Analog" and the consistency "Word".

Identifiers for the Smart Connect with Digital Modules

Table C-5 Identifiers for the Smart Connect with Digital ET 200L-SC Modules

Smart	Input	Output		Identifiers (Hexadecimal)				
Connect	Byte	Byte	0	1	2	3	4	
DI SC	1		43	00	00	42	45	
(SC configuration with	2		43	01	00	42	45	
SC input modules)	3 to 8*		43	02 to 07	00	42	45	
DO SC		1	83	00	00	42	45	
(SC configuration with		2	83	01	00	42	45	
SC output modules)		3 to 8*	83	02 to 07	00	42	45	
DI/DO SC	1	1	C2	00	00	42	45	
(SC config-	1	2	C2	00	01	42	45	
uration with SC input	2	1	C2	01	00	42	45	
and output	2	2	C2	01	01	42	45	
modules)	3 to 8*	3 to 8*	C2	02 to 07	02 to 07	42	45	

Identifiers for the Smart Connect with Analog Modules

Table C-6 Identifiers for the Smart Connect with Analog ET 200L-SC Modules

Smart Con-	Input	Output	Identifiers (Hexadecimal)					
nect	Word	Word	0	1	2	3	4	
DI SC	1		43	40	00	42	45	
(SC configuration with	2		43	41	00	42	45	
SC input modules)	3 to 16		43	42 to 4F	00	42	45	
DO SC		1	83	40	00	42	45	
(SC configuration with		2	83	41	00	42	45	
SC output modules)		3 to 16	83	42 to 4F	00	42	45	
DI/DO SC	1	1	C2	40	40	42	45	
(SC config-	1	2	C2	40	41	42	45	
uration with SC input	2	1	C2	41	40	42	45	
and output	2	2	C2	41	41	42	45	
modules)	3 to 16	3 to 16	C2	42 to 4F	42 to 4F	42	45	

Note

The byte size in the DP identifiers "1" and "2" becomes the word size when the Smart Connect is analog. The word size begins with the value $40_{\rm H}$ (for 1 word) and ends at $4F_{\rm H}$ (16 words).

If only input modules or only output modules are connected to the Smart Connect, the byte and word size is in the DP identifier "1".

If input and output modules are connected to the Smart Connect, the byte and word size of the outputs is in the DP identifier "1" and the byte and word size of the inputs is in the DP identifier "2".

For the Smart Connect with digital and analog modules, the total length of the input and output range is a maximum of 32 bytes in each case.

C.3.2 Identifiers for the ET 200L-SC IM-SC

Identifiers for the Smart Connect with Digital Modules

Table C-7 Identifiers for the Smart Connect with Digital ET 200L-SC IM-SC Modules

Smart	Input	Output		Identifie	rs (Hexade	cimal)	
Connect	Byte	Byte	0	1	2	3	4
DI SC	1		43	00	00	42	4A
(SC structure with SC	2		43	01	00	42	4A
input mod- ules)	3 to 16		43	02 to 0F	00	42	4A
DO SC		1	83	00	00	42	4A
(SC structure with SC		2	83	01	00	42	4A
output mod- ules)		3 to 16	83	02 to 0F	00	42	4A
DI/DO SC	1	1	C2	00	00	42	4A
(SC struc- ture with SC	1	2	C2	00	01	42	4A
input and	2	1	C2	01	00	42	4A
output mod- ules)	2	2	C2	01	01	42	4A
uiesj	3 to 16	3 to 16	C2	02 to 0F	02 to 0F	42	4A

Identifiers for the Smart Connect with Analog Modules

Table C-8 Identifiers for the Smart Connect with ET 200L-SC IM-SC Analog Modules

Smart	Input	Output	Identifiers (Hexadecimal)					
Connect	Word	Word	0	1	2	3	4	
AI SC	1		43	40	00	42	4A	
(SC structure with SC	2		43	41	00	42	4A	
input mod- ules)	3 to 32		43	42 to 5F	00	42	4A	
AO SC		1	83	40	00	42	4A	
(SC structure with SC		2	83	41	00	42	4A	
output mod- ules)		3 to 32	83	42 to 5F	00	42	4A	
AI/AO SC	1	1	C2	40	40	42	4A	
(SC struc- ture with SC	1	2	C2	40	41	42	4A	
input and	2	1	C2	41	40	42	4A	
output mod- ules)	2	2	C2	41	41	42	4A	
uies)	3 to 32	3 to 32	C2	42 to 5F	42 to 5F	42	4A	

Note

The byte size in the DP identifiers "1" and "2" becomes the word size when the Smart Connect is analog. The word size begins with the value $40_{\rm H}$ (for 1 word) and ends at $5F_{\rm H}$ (32 words).

If only input modules or only output modules are connected to the Smart Connect, the byte and word size is in the DP identifier "1".

If input and output modules are connected to the Smart Connect, the byte and word size of the outputs is in the DP identifier "1" and the byte and word size of the inputs is in the DP identifier "2".

For the Smart Connect with digital and analog modules, the total length of the input and output range is a maximum of 64 bytes in each case.

C.3.3 Configuration Frame Example

1st Example

The following example describes the structure of a configuration frame of an ET 200L-SC 16 DO DC 24V/0.5A with:

- 2 bytes DO
- A Smart Connect with 2 electronic modules (SC): 2DI and 2DO

The configuration frame thus consists of the 25 bytes described below:

Configuration Frame for Example 1

Configuration Frame	Slot	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
83-01-00-AF-48	4	2 bytes DO
C2-00-00-42-45	5	Smart Connect with electronic modules (SC): 2DI, 2DO. The inputs and outputs of the 2DI/2DO are distributed over 1 input and 1 output byte.

2nd Example

The following example describes the structure of a configuration frame of an ET 200L-SC 16 DI/16 DO DC 24V/0.5A with:

- 2 bytes DI, 2 bytes DO
- A Smart Connect with 4 digital electronic modules: $2 \times 2DI$ and $2 \times 2DO$ and with 3 analog electronic modules: $1 \times 2AI$, $1 \times 1AI$ and $1 \times 1AO$

The configuration frame thus consists of the following 30 bytes:

Configuration Frame for Example 2

Configuration Frame	Slot	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
C2-01-01-AF-48	4	2 bytes DO / 2 bytes DI
C2-01-01-42-45	5	SC with digital electronic modules: $2 \times 2DI$ and $2 \times 2DO$. The inputs and outputs of the $2 \times 2DI/2 \times 2DO$ are distributed over 2 input and 2 output bytes.
C2-40-42-42-45	6	SC with analog electronic modules: $1 \times 2AI$, $1 \times 1AI$ and $1 \times 1AO$. The inputs and outputs are distributed over 3 input words and 1 output word.

3rd Example

The following example describes the structure of a configuration frame of an ET 200L-SC 32 DI DC 24V with:

- 4 bytes DI
- No Smart Connect

The configuration frame thus consists of the 20 bytes described below:

Configuration Frame for Example 3

Configuration Frame	Slot	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-AF-C0	3	
43-03-00-9F-41	4	4 bytes DI

Note

- You must always transfer the complete configuration frame to the ET 200L-SC.
- If you have not inserted a Smart Connect module, a configuration frame is not sent for the SC section (slots 5 and 6).

4th Example

The following example describes the structure of a configuration frame of an ET 200L-SC IM-SC with:

• A Smart Connect with 7 digital electronic modules: $4 \times 2DI$ and $3 \times 2DO$ and with 6 analog electronic modules: $1 \times 2AI$, $2 \times 1AI$ and $3 \times 1AO$

The configuration frame thus consists of the 25 bytes described below:

Configuration Frame for Example 4

Configuration Frame	Slot	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
C2-04-03-42-4A	4	SC with digital electronic modules: 4×2DI and 3×2DO. The inputs and outputs are distributed over 4 input and 5 output bytes.
C2-48-44-42-4A	5	SC with analog electronic modules: $1 \times 2AI$, $2 \times 1AI$ and $3 \times 1AO$. The inputs and outputs are distributed over 5 input and 9 output words.

5th Example

The following example describes the structure of a configuration frame of an ET 200L-SC IM-SC with:

• A Smart Connect with 3 digital electronic modules: 2×2DI and 1×2DO and with 2 analog electronic modules: 1×2AI and 1×1AI and with one counter module (3 words I and O)

The configuration frame thus consists of the following 25 bytes:

Configuration Frame for Example 5

Configuration Frame	Slot	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-AF-C0	3	
C2-00-01-42-4A	4	SC with digital electronic modules: $2 \times 2DI$ and $1 \times 2DO$. The inputs and outputs are distributed over 2 input and 1 output byte.
C2-42-45-42-4A	5	SC with analog electronic modules: $1 \times 2AI$, $1 \times 1AI$ and $1 \times 1COUNT40kHz$. The inputs and outputs are distributed over 6 input nad 3 output words.

C.4 Parameterization Frame for the ET 200L-SC or ET 200L-SC IM-SC

ET 200L-SC Parameterization Frame

All the parameterizable values of the ET 200-SC are stored in the parameterization frame. The maximum length of the parameterization frame is 185 bytes.

The maximum length is required for the following Smart Connect module combination:

• 8×2AI

ET 200L-SC IM-SC Parameterization Frame

The structure of the ET 200L-SC IM-SC parameterization frame is identical to that of the ET 200L-SC. In the case of the ET 200L-SC IM-SC you can parameterize up to 16 SC modules. You must not exceed the maximum length of the parameterization frame, which is 244 bytes (see Section 2.4).

Structure of the Parameterization Frame

The following figure shows the basic structure of the parameterization frame of the ET 200L-SC or ET 200L-SC IM-SC:




Figure C-1 Structure of the Parameterization Frame of the ET 200L-SC and ET 200L-SC IM-SC

Contents of the Section

This section contains all the information you require on the structure of the parameterization frame.

Section	Торіс	Page
C.4.1	Standard Section and Parameters for the Status	C-16
C.4.2	Parameters for the Smart Connect Section	C-17
C.4.3	Data Record 0	C-19
C.4.4	Data Record 128	C-20
C.4.5	Data Record 130	C-22
C.4.6	Parameterization Frame Example	C-27

C.4.1 Standard Section and Parameters for the Status

Overview

The standard section is identical for all ET 200L modules. The parameters for the status have an identical structure for all ET 200L-SC and ET 200L-SC IM-SC modules.

Standard Section

The first 7 bytes of the parameterization frame are standardized in accordance with EN 50170 Volume 2, PROFIBUS and contain the following, for example:

Byte 0	88 _H	Station status
Byte 1	01 _H	Watchdog factor 1
Byte 2	06 _H	Watchdog factor 2
Byte 3	0B _H	Response delay T _{RDY}
Byte 4	80 _H	Manufacturer ID, high-byte
Byte 5	27 _H	Manufacturer ID, low-byte
Byte 6	00 _H	Group ID
Byte 5	27 _H	Manufacturer ID, low-byte

Figure C-2 Standard Section of the Parameterization Frame

ET 200L: Parameters for Status

ET 200L-SC and ET 200L-SC IM-SC: Parameters for Status The next 5 bytes contain the status bytes for the ET 200L. The default assignment for these 5 bytes is: 00_H 00_H 00_H 00_H 00_H .

The next 3 bytes are the status bytes. The default assignment for these 3 bytes is: $40_{\rm H}~20_{\rm H}~00_{\rm H}$. The meaning of the parameters is given in Figure C-3:




Figure C-3 Parameters for the Status

C.4.2 Parameters for the Smart Connect Section

Overview The parameters for the Smart Connect section are stored in various data re-

cords. Table 5-4 shows the composition of the records.

Configuration ET 200L-SC

The data records for the ET 200L-SC are arranged in the following order:

Table C-9 Data Records for the ET 200L-SC

Parameter		Slot		Length	Meaning
Record	Digital SC Modules Only	Analog SC Modules Only	Digital and Analog SC Modules		
DS0 SC digital	5		5	7 bytes	Diagnostic interrupt for the digital Smart Connect modules
DS128 SC digital	5		5	7 bytes + 7 bytes per SC module	Configuration data for the digital Smart Connect modules
DS0 SC analog		5	6	7 bytes	Diagnostic interrupt for the analog Smart Connect modules
DS128 SC analog		5	6	7 bytes + 7 bytes per SC module	Configuration data for the analog Smart Connect modules
DS130 SC analog		5	6	7 bytes + 2 bytes per SC module + 5 bytes per channel	Parameters for the analog Smart Connect modules

Configuration ET 200L-SC IM-SC

The data records for the ET 200L-SC IM-SC are arranged in the following order:

Table C-10 Data Records for the ET 200L-SC IM-SC

Parameter		Slot		Length	Meaning
Record	Digital SC Modules Only	Analog SC Modules Only	Digital and Analog SC Modules		
DS0 SC digital	4		4	7 bytes	Diagnostic interrupt for the digital Smart Connect modules
DS128 SC digital	4		4	7 bytes + 7 bytes per SC module	Configuration data for the digital Smart Connect modules
DS0 SC analog		4	5	7 bytes	Diagnostic interrupt for the analog Smart Connect modules
DS128 SC analog		4	5	7 bytes + 7 bytes per SC module	Configuration data for the analog Smart Connect modules
DS130 SC analog		4	5	7 bytes + 2 bytes per analog SC module + 5 bytes per channel + 11 bytes per counter module	Parameters for the analog Smart Connect modules Parameters for the counter module

Note

You must always transfer the complete parameterization frame for the configuration of the ET 200L-SC or ET 200L-SC IM-SC.

The information in records DS128 and DS130 for the analog Smart Connect modules must correspond.

C.4.3 Data Record 0

Data Record 0

Record 0 consists of 7 bytes (byte 0 to byte 6) and is generated separately for digital and analog Smart Connect modules. Record 0 has the same content for both modules.

The following figure describes the structure of DS0 for the ET 200L-SC:




Figure C-4 Structure of Data Record 0

C.4.4 Data Record 128

Overview

Data record 128 consists of a header with a length of 7 bytes and an additional 7 bytes per Smart Connect module. These are described below.

Data Record 128, Header

Figure C-5 describes the header of data record 128.




Figure C-5 Structure of the Header of Data Record 128

Data Record 128, Contents

Figure C-6 describes the contents of data record 128. These bytes are repeated for each Smart Connect electronic module that is connected.




Figure C-6 Structure of Data Record 128, Bytes 7 to 62

C.4.5 Data Record 130

Overview

Data record 130 consists of a header with a length of 7 bytes, an additional 2 bytes per SC module and 5 bytes per channel. They are described below.

Data Record 130, Header

Figure C-7 describes the header of data record 130.




Figure C-7 Structure of the Header of Data Record 128

Data Record 130, Contents

Figures C-8 and C-9 describe the contents of data record 130. A distinction is drawn between single- and two-channel modules.

Data Record 130, Single-Channel

You will find the contents of data record 130 for single-channel modules in the following figure.




Figure C-8 Structure of Data Record 130 for Single-Channel Modules

Data Record 130, Two-Channel

You will find the contents of data record 130 for two-channel modules in the following figure.




Figure C-9 Structure of Data Record 130 for Two-Channel Modules

Channel-Specific Parameters

The channel-specific parameters comprise 3 bytes. The third byte (byte 13 or byte 18) is reserved and preset with the value $00_{\rm H}$.

The remaining two bytes of the channel-specific parameters are assigned differently depending on the Smart Connect module. The assignment depends on whether the module is an input or output module.

Data Record 130, 1COUNT40kHz

The contents of the data record for the 1COUNT40kHz counter module are shown in the following figure:




Figure C-10 Structure of Data Record 130 for the 1COUNT40kHz Counter Module

Al Module – Byte 11 or Byte 16

The purpose of bytes 11 and 16 of data record 130 for analog input modules is indicated in Table C-11.

Table C-11 AI Parameters in Byte 11 and 16 of DS130

Smart Connect	Measurement Type Measurement Range		Bit ¹	
Module			7 4	3 0
_	Deactivated		0000	0000
2AI U	Voltage measurement	1 5 V	0001	0111
		+/- 10 V		1001
2AI I	Current measurement, 4-wire connection	0 20 mA	0010	0010
		4 20 mA		0011
		+/- 20 mA		0100
	Current measurement, 2-wire connection	4 20 mA	0011	0011
1AI RTD	Resistance measurement, 4-wire connection	0 600 Ω	0100	0110
	Thermal resistance measurement with lineariza-	Pt100 Kl (climatic range)	1000	0000
	tion and 4-wire connection	Pt100		0010
		NI100		1011
2AI TC	Voltage measurement	+/- 80 mV	0001	0001
	Temperature measurement with thermocouple	Type R	1011	0011
		Type J		0101
		Type K		1000

No other values or combinations are permissible

Al Module – Byte 12 or Byte 17

The purpose of bytes 12 and 17 of data record 130 for analog input modules is indicated in Figure C-11.




Figure C-11 AI Parameters in Byte 12 or 17 of DS130

Al Module – Byte 13 or Byte 18

The third byte (byte 13 or byte 18) of the channel-specific parameters is always assigned the value 00_H for input modules.

AO Module – Byte 11 or Byte 16

The purpose of bits 0 to 5 in bytes 11 and 16 of data record 130 for analog output modules is indicated in Table C-12.

Bit 6 is always assigned the value "0".

Bit 7 specifies the number format:

• Bit 7 = "0": S7 format

• Bit 7 = "1": S5 format

Table C-12 AO Parameters in Byte 11 or 16 of DS130

Smart Connect	Output	Measurement Range	Bit ¹	
Module			5, 4	3 0
-	Deactivated		00	0000
1AO U	Voltage output	1 5 V	01	0111
		+/- 10 V		1001
1AO I	Current output	0 20 mA	10	0010
		4 20 mA		0011

No other values or combinations are permissible

AO Module – Bytes 12 and 13 or Bytes 17 and 18

The second and third bytes (bytes 12 and 13 or bytes 17 and 18) of the channel-specific parameters are always assigned the value 00_H for output modules.

Counter Module – Bytes 11 to 17

The purpose of bytes 11 to 17 of data record 130 for the 1COUNT40kHz counter module indicated in Figure C-12.




Figure C-12 1COUNT40kHz Counter Module – Purpose of Bytes 11 to 17 of Data Record 130

C.4.6 Parameterization Frame Example

Example

The example below describes the parameterization of an ET 200L-SC IM-SC.

The Smart Connect contains the following electronic modules:

- 2DIDC24V (slot A)
- 2DODC24V0.5A (slot B)
- 2AI U (slot C)
- 1AO I (slot D)
- 1COUNT40kHz (slot F)

Table C-13 below shows the contents of the associated parameterization frame:

Table C-13 ET 200L-SC IM-SC Example

Byte	Value	Meaning		
0 to 6	See Figure C-2	Standard section		
7	40 _H	Status byte 0	Status bytes	
8	20 _H	Status byte 1; diagnostic interrupt enable: 21 _H		
9	00 _H	Status byte 2		
10	07 _H	Block length	Data record 0	
11	5F _H	S7 constant	(digital)	
12	04 _H	Slot		
13	00 _H	Data record number		
14	02 _H	Data record length		
15	00 _H	Diagnostics enable: 0		
16	00 _H	Not applicable		
17	15 _H	Block length	Data record 128	
18	5F _H	S7 constant	(digital)	
19	04 _H	Slot		
20	80 _H	Data record number		
21	10 _H	Data record length		
22	00 _H	Version identifier		
23	50 _H	Additional identifier/device type assignment		

Table C-13 ET 200L-SC IM-SC Example, continued

Byte	Value	Meaning			
24	01 _H	Channel module address: slot A	Channel module address: slot A		
25	01 _H	Channel module-specific identifier: 01 _H		(digital)	
26	00 _H	Byte offset, input range: 0	Smart Connect 2DIDC24V on		
27	0A _H	Bit offset: 2; number of channels: 1 (two-channel); input range	offset: 2; number of channels: 1 (two-chan-		
28	FF _H	Byte offset, output range: no output			
29	FF _H	Bit offset: 0; number of channels: 0; output range			
30	00 _H	Channel module-specific parameters			
31	02 _H	Channel module address: slot B			
32	02 _H	Channel module-specific identifier: 02 _H			
33	FF _H	Byte offset, input range: no input	Smart Connect 2DODC24V0.5A		
34	FF _H	Bit offset: 0; number of channels: 0; input range	on slot B		
35	00 _H	Byte offset, output range: 0			
36	0C _H	Bit offset: 4; number of channels 1 (two- channel); output range			
37	00 _H	Channel module-specific parameters			
38	07 _H	Block length	Block length		
39	5F _H	S7 constant	(analog)		
40	05 _H	Slot			
41	00_{H}	Data record number			
42	02 _H	Data record length			
43	00 _H	Diagnostics enable: 0 (as DS0 digital)			
44	00 _H	Not applicable			
45	1C _H	Block length	Data record 128		
46	17 _H	S7 constant		(analog)	
47	05 _H	Slot			
48	80 _H	Data record number			
49	17 _H	Data record length			
50	00 _H	Version identifier			
51	50 _H	Additional identifier/device type assignment			
52	03 _H	Channel module address: slot C	Smart Connect	1	
53	C5 _H	Channel module-specific identifier: C5 _H	2AI U +/– 10 V in slot C		
54	00 _H	Byte offset input range 0	in siot C		
55	88 _H	Bit offset: 0; channel number: 1 (two-channel); channel length: 2 bytes	Bit offset: 0; channel number: 1 (two-channel);		
56	FF _H	Byte offset output range: no output			
57	FF _H	Bit offset: 0; channel number: 0; output range			
58	00 _H	Channel module-specific parameters	1		

Table C-13 ET 200L-SC IM-SC Example, continued

Byte	Value	Meaning		
59	04 _H	Channel module address: slot D	Smart Connect	Data record 128
60	E6 _H	Channel module-specific identifier: E6 _H	1AO I 0 20 mA in slot D	(analog)
61	FF _H	Byte offset input range: no input	in siot B	
62	FF _H	Bit offset: 0; channel number: 0; input range		
63	00 _H	Byte offset output range: 0		
64	80 _H	Bit offset: 0; channel number: 0 (single-channel); length of the output channel: 2 bytes		
65	00 _H	Channel module-specific parameter		
66	06 _H	Channel module address: slot F	Smart Connect	Data record 128
67	D9 _H	Channel module-specific identifier: D9 _H 1COUNT40kHz counter module in		(analog)
68	04 _H	Byte offset input range: 4	slot F	
69	98 _H	Bit offset: 0; channel number: 2 (three-channel); input channel length: 2 bytes		
70	02 _H	Byte offset output range: 2		
71	98 _H	Bit offset: 0; channel number: 2 (three-channel); length of the output channels: 2 bytes		
72	00 _H	Channel module-specific parameters		
73	25 _H	Block length		Data record 130
74	5F _H	S7 constant		(analog)
75	05 _H	Slot		
76	82 _H	Data record number		
77	1F _H	Data record length		
78	00 _H	Version identifier		
79	50 _H	Additional identifier/device type assignment]	

Table C-13 ET 200L-SC IM-SC Example, continued

Byte	Value	Meaning				
80	0C _H	Block length for channel module	Smart Connect	Data record 130		
81	03 _H	Channel module address: slot C	2AI U +/- 10 V in slot C	(analog)		
82	05 _H	Block length for channel	in siot C			
83	00 _H	Channel address: 0 (one)				
84	19 _H	Voltage input: +/- 10 V				
85	80 _H	S5 format; interference frequency suppression: 50 Hz; no smoothing				
86	00 _H	Not relevant				
87	05 _H	Block length for channel				
88	01 _H	Channel address: 1 (two)				
89	19 _H	Voltage input: +/- 10 V				
90	80 _H	S5 format; interference frequency suppression: 50 Hz; no smoothing	1			
91	00 _H	Not relevant				
92	07 _H	Block length for channel module	Smart Connect	1		
93	04 _H	Channel module address: slot D	1AO I 0 20 mA in slot D			
94	05 _H	Block length for channel	III Slot D			
95	00 _H	Channel address: 0 (one)				
96	A3 _H	Power output: 0 20 mA, S5 format				
97	00 _H	Not relevant				
98	00 _H	Not relvant				
99	0B _H	Block length for channel module	Smart Connect			
100	06 _H	Channel module address: slot F	1COUNT40kHz in slot F			
101	09 _H	Block length for channel	in slot i			
102	00 _H	Channel address: 0 (one)				
103	00 _H	Lower count limit: 11				
104	0B _H					
105	08 _H	Upper count limit: 2222	1			
106	AE _H					
107	38 _H	Mode: continuous; count mode: upward; comparison value enabling: enable; activate digital output at: comparison value counting upward as pulse; digital output logic: 0;				
108	07 _H	Digital output pulse duration: 700 ms				
109	14 _H	Hysteresis: 20 pulses]			

C.5 Default Start-up

Introduction

The ET 200L-SC or ET 200L-SC IM-SC can carry out a default start-up. When it does this, the ET 200L-SC or ET 200L-SC IM-SC works with a default configuration.

The ET 200L-SC or ET 200L-SC IM-SC also runs with the digital default configuration when there are no SC modules connected.

The default configuration frame corresponds to the message of the ET 200L-SC or ET 200L-SC IM-SC when you read the configuration.



Warning

If an SC module fails, in a default start-up the addresses are read in such a way that the failed SC is not included.

A device master file provides security here. You can create this with COM PROFIBUS.

Contents of the Section

This section contains all the information you require on the default start-up.

Section	Торіс	Page
C.5.1	Default Start-up with Digital Smart Connect Modules	C-32
C.5.2	Default Start-up with Analog Smart Connect Modules	C-36

C.5.1 Default Start-up with Digital Smart Connect Modules

Type Files

A number of type files are available for the default start-up. You can obtain these via modem (dial +49 (911) 737972) or in CompuServe in AUTFORUM (GO AUTFORUM) in the SINEC library.

Table C-14 Type Files for the ET 200L-SC Default Start-up with Digital SC Modules

Electronics Block ET 200L-SC	Name of the Type File
L-SC 16 DI DC 24 V	SI8027ZX.200
L-SC 32 DI DC 24 V	SI8029ZX.200
L-SC 16 DO DC 24 V/0.5 A	SI8028ZX.200
L-SC 16 DI/16 DO DC 24 V/0.5 A	SI802CZX.200
L-SC IM-SC	SI802BZX.200

Configuration Frame

The following configuration frames are required for the default start-up of the ET 200L-SC or ET 200L-SC IM-SC with digital Smart Connect modules:

Note

When an ET 200L-SC or ET 200L-SC IM-SC receives a default configuration frame with 2/4 bytes DI and DO, the module still starts up when there are no SC modules connected.

L-SC 16 DI

Configuration frame for the ET 200L-SC 16 DI DC 24 V:

Configuration Frame	Slots	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
43-01-00-9F-42	4	2 bytes DI
C2-01-01-42-45	5	Smart Connect with electronic modules (SC): 2 input and 2 output bytes

L-SC 32 DI Configuration frame for the ET 200L-SC 32 DI DC 24 V:

Configuration Frame	Slots	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
43-03-00-9F-43	4	4 bytes DI
C2-01-01-42-45	5	Smart Connect with electronic modules (SC): 2 input and 2 output bytes

L-SC 16 DO Configuration frame for the ET 200L-SC 16 DO DC 24 V/0.5 A

Configuration Frame	Slots	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
83-01-00-AF-50	4	2 bytes DO
C2-01-01-42-45	5	Smart Connect with electronic modules (SC): 2 input and 2 output bytes

L-SC 16 DI/16 DO Configuration frame for the ET 200L-SC 16 DI/16 DO DC 24 V/ 0.5 A:

Configuration Frame	Slots	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
C2-01-01-BF-D2	4	2 bytes DO/2 bytes DI
C2-01-01-42-45	5	Smart Connect with electronic modules (SC): 2 input and 2 output bytes

L-SC IM-SC

Configuration frame for the ET 200L-SC IM-SC:

Configuration Frame	Slots	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
C2-01-01-42-4A	4	4 input and 4 output bytes

Parameterization Frame

The ET 200L-SC requires the following parameterization frame for the default start-up:




Figure C-13 Structure of the Parameterization Frame

Note

- A diagnostic interrupt enable is not possible in byte 1 (BIT 5).
- If you use a DP master for the default start-up that sends only the standard section of the parameterization frame, the start-up is carried out without status bytes (bytes 7 to 9).

Default Setting for Digital Smart Connect Modules

For the default setting of the ET 200L-SC, 2 bytes each are set in the process image for the digital Smart Connect modules for the input and output of the Smart Connect electronic modules.




Figure C-14 Default Setting for Digital SC Modules with the ET 200L-SC

Default Setting for the ET 200L-SC IM-SC

For the default setting of the ET 200L-SC IM-SC, 4 bytes each are set in the process image for the digital Smart Connect modules for the input and output of the Smart Connect electronics modules.





Figure C-15 Default Setting for Digital SC Modules with the ET 200L-SC IM-SC

Example

A default start-up is carried out with the following configuration:

• ET 200L-SC 16 DO DC 24 V/0.5A and Smart Connect:



Solution of the Example

Address assignment for the ET 200L-SC and Smart Connect

- ET 200L-SC 16 DO DC 24 V/0.5 A
 - On-board I/O device outputs 1 to 8: output byte 64.0 to 64.7
 - On-board I/O device outputs 9 to 16: output byte 65.0 to 65.7
- Smart Connect:

Slot	SC Module	Address	
A	2DIDC24V	Input	70.0 and 70.1
В	2DIDC24V	Input	70.2 and 70.3
С	2DODC24V0.5A	Output	80.4 and 80.5
D	2DODC24V0.5A	Output	80.6 and 80.7
Е	1DIAC120/230V	Input	71.0
F	1DIAC120/230V	Input	71.2
G	1DORel.AC230V	Output	81.4
Н	1DORel.AC230V	Output	81.6

C.5.2 Default Start-Up with Analog Smart Connect Modules

Type Files

There are no type files for the default start-up of the ET 200L-SC or ET 200L-SC IM-SC with analog Smart Connect modules. This is because there is such a wide range of configuration options.

Note

In the default start-up, the analog Smart Connect modules use the default parameters stored in each module (see Chapter 12).

Configuration Frame

For the default start-up of the ET 200L-SC or ET 200L-SC IM-SC with analog Smart Connect modules, an addition must be made to the configuration frame of the ET 200L-SC with digital Smart Connect modules. Use the configuration frame extension shown in Tables C-15 and C-16, and append it to the configuration frame of the ET 200L-SC or ET 200L-SC IM-SC with digital Smart Connect modules.

In addition to analog Smart Connect modules, at least one digital Smart Connect module must be plugged in.

Table C-15 ET 200L-SC: Configuration Frame Extension for Analog Smart Connect Modules

Configuration Frame Extension for the ET 200L-SC	Slot	Meaning
43-(40 to 4E)-00-42-45	6	Smart Connect with analog input modules; 1 to 8 modules with 1 to 16 channels, depending on the configuration
83-(40 to 43)-00-42-45	6	Smart Connect with analog output modules; 1 to 4 modules with 1 to 4 channels, depending on the configuration
C2-(40 to 43)-(40 to 4E)-42-45	6	Smart Connect with analog output and input modules; 1 to 4 output modules with 1 to 4 channels and 1 to 8 modules with 1 to 16 channels, depending on the configuration

Table C-16 ET 200L-SC IM-SC: Configuration Frame Extension for Analog Smart Connect Modules

Configuration Frame Extension for the ET 200L-SC IM-SC	Slot	Meaning
43-(40 to 5D)-00-42-4A	5	Smart Connect with analog input modules; 1 to 16 modules with 1 to 32 channels, depending on the configuration
83-(40 to 48)-00-42-4A	5	Smart Connect with analog output modules; 1 to 8 modules with 1 to 8 channels, depending on the configuration
C2-(40 to 48)-(40 to 5D)-42-4A	5	Smart Connect with analog output and input modules; 1 to 8 output modules with 1 to 8 channels and 1 to 16 input modules with 1 to 32 channels

Parameterization Frame

For the default start-up, the ET 200L-SC requires the following parameterization frame. The analog Smart Connect modules work with their default parameters:




Figure C-16 Structure of the Parameterization Frame

Note

- A diagnostic interrupt enable is not possible in byte 1 (BIT 5).
- If you use a DP master for the default start-up that sends only the standard section of the parameterization frame, the start-up is carried out without status bytes (bytes 7 to 9).

Default Setting for Analog Smart Connect Modules

For the default setting of the ET 200L-SC, 2 bytes each are set in the process image for the digital Smart Connect modules for the input and output channel of the Smart Connect electronic modules.

The identified analog channels are incorporated **seamlessly** in the slot sequence in the process image. Figure C-17 shows the assignment of the bytes in the process image to the individual channels.

Note

Unidentified analog channels are not inserted in the process image(because, for example, the SC analog module has been removed or is defective). As a result, the 3rd analog channel occupies bytes 2 and 3, for example.

The device master file gives you security about correct addressing. You can create this file with COM PROFIBUS.





Figure C-17 Default Setting for Analog Smart Connect Modules

Example

A default start-up is carried out with the following configuration:

• ET 200L-SC 16 DI DC 24 V and Smart Connect:



Configuration Frame of the Example

Configuration frame for the ET 200L-SC 16 DI DC 24 V:

Configuration Frame	Slot	Meaning
04-00-00-AD-C4	1	Virtual slots
04-00-00-9B-40	2	
04-00-00-8F-C0	3	
43-01-00-9F-42	4	2 bytes DI
C2-01-01-42-45	5	Smart Connect with digital electronic modules (SC): 2 input and 2 output bytes
C2-40-44-42-45	6	Smart Connect with analog electronic modules (SC): 1 input and 5 output words

Solution of the Example

Address assignment for the ET 200L-SC and Smart Connect

- ET 200L-SC 16 DI DC 24 V
 - On-board I/O device outputs 1 to 8: input byte 64.0 to 64.7
 - On-board I/O device outputs 9 to 16: input byte 65.0 to 65.7
- Smart Connect:

Slot	SC Module	Address
A	2DIDC24V	Input 70.0 and 70.1
В	2DODC24V/0.5A	Output 80.2 and 80.3
С	2AI U +/- 10V	Input word 130 and 132
D	2AI RTD	Input word 134
Е	1AO I4 20 mA	Output word 140
F	(double module width)	
G	2AI I4 20 mA	Input word 136 and 138
Н	2DODC24V/2A	Output word 81.6 and 81.7

Guidelines for Handling Electrostatically Sensitive Devices (ESD)



Summary of Sections

In Section	You will find	On Page
D.1	What is ESD?	D-2
D.2	Electrostatic Charging of Persons	D-3
D.3	General Protective Measures Against Electrostatic Discharge Damage	D-4

D.1 What is ESD?

Definition

All electronic modules are equipped with large-scale integrated ICs or components. Due to their design, these electronic elements are very sensitive to overvoltages and thus to any electrostatic discharge.

These Electrostatically Sensitive Devices are commonly referred to by the abbreviation ESD.

Electrostatically sensitive devices are labeled with the following symbol:





Caution

Electrostatically sensitive devices are subject to voltages that are far below the voltage values that can still be perceived by human beings. These voltages are present if you touch a component or the electrical connections of a module without previously being electrostatically discharged. In most cases, the damage caused by an overvoltage is not immediately noticeable and results in total damage only after a prolonged period of operation.

D.2 Electrostatic Charging of Persons

Charging

Every person with a non-conductive connection to the electrical potential of its surroundings can be electrostatically charged.

Figure D-1 shows you the maximum values for electrostatic voltages which can build up on a person coming into contact with the materials indicated in the figure. These values are in conformity with the specifications of IEC 801-2.




Figure D-1 Electrostatic Voltages which can Build up on a Person

D.3 General Protective Measures Against Electrostatic Discharge Damage

Ensure Sufficient Grounding

Make sure the personnel, working surfaces and packaging are sufficiently grounded when handling electrostatically sensitive devices. You can thus avoid electrostatic charging.

Avoid Direct Contact

You should touch electrostatically sensitive devices only if it is unavoidable (for example, during maintenance work). Hold modules without touching the pins of components or printed conductors. In this way, the discharged energy cannot affect the sensitive devices.

If you have to carry out measurements on a module, you must discharge your body before you start the measurement by touching grounded metallic parts. Use grounded measuring devices only.

Glossary

Α

Aggregate current The aggregate of the currents of all the output channels of a digital output

module.

В

Baud rate The baud rate is the speed at which data is transmitted. It specifies the num-

ber of bits transmitted per second (baud rate = bit rate).

Baud rates of 9.6 kbps to 1.5 Mbps are possible with the ET 200L.

Bus The common transmission path to which all nodes are connected. It has two

defined ends.

In the case of the ET 200, the bus is a two-wire cable or a fiber-optic cable.

Bus connector The physical link between the bus nodes and the bus cable.

In the case of the ET 200, there is a bus connector with and without connections for the programming unit and with IP 20 and IP 65 degrees of protec-

tion.

C

Chassis ground The chassis ground is the totality of all the interconnected inactive parts of a

piece of equipment that cannot carry hazardous contact voltage even in the

event of a fault.

Configuration This refers to the configuration of individual modules in a distributed I/O

system.

Consistent data

Data that belongs together by content is referred to as consistent data.

The data must not be corrupted by being read at different times.

D

Default setting

The default setting is a basic setting that applies unless another value is set (i.e. parameterized).

Device master file

All the properties of a DP slave are stored in a device master file. The format of the device master file is stored in the EN 50170 Volume 2, PROFIBUS standard.

Distributed I/O devices

These are input/output units that are installed in a distributed configuration at some distance from the CPU rather than in the central rack. For example:

- ET 200L
- ET 200B
- ET 200M
- Other DP slaves manufactured by Siemens or another company

The distributed I/O devices are connected to the DP master via the PROFIBUS-DP bus.

Diagnostics

Diagnostics is the detection, localization, categorization, indication and analysis of errors, faults, malfunctions and messages.

Diagnostics provides monitoring functions that run automatically while a plant is operating. This enhances the availability of a plant by reducing setup and stoppage times.

DP master

A → master whose behavior complies with EN 50170 Volume 2, PROFIBUS is referred to as a DP master.

DP slave

 $A \rightarrow$ slave that runs on the PROFIBUS using the PROFIBUS-DP protocol and whose behavior complies with EN 50170 Volume 2, PROFIBUS is referred to as a DP slave.

DP standard

The DP standard is the bus protocol of the ET 200 distributed I/O system. It complies with EN 50170 Volume 2, PROFIBUS.

Ε

Electromagnetic compatibility

Electromagnetic compatibility is the capacity of electrical equipment to work correctly in a specified environment without negatively affecting the functioning of other equipment in the vicinity.

Equipotential bonding

An electrical connection (equipotential bonding conductor) that brings the bodies of electrical apparatus and extraneous conductive bodies to the same or approximately the same potential to prevent interfering or hazardous voltages between these bodies.

ET 200

The ET 200 distributed I/O system with the PROFIBUS-DP protocol is a bus for connecting distributed I/O devices to a CPU or an adequate DP master. A feature of ET 200 are its short response times, since only a small volume of data (bytes) is transmitted.

ET 200 complies with the PROFIBUS standard, EN 50170 Volume 2, PROFIBUS.

ET 200 operates on the master/slave principle. The IM 308-C master interface module or the CPU 315-2 DP can be DP masters, for example.

The distributed I/O devices ET 200B, ET 200C, ET 200M, ET 200L or ET 200U can be DP slaves, as can other DP slaves made by Siemens or other manufacturers.

F

Floating

In the case of input/output modules, the reference potentials of control and load circuits are isolated (e.g. by means of an optocoupler, a relay contact or a transformer). Input/output circuits can be connected to common potential.

FREEZE

This is a control command of the DP master to a group of DP slaves.

When a DP slave receives the FREEZE control command, it freezes the current status of the **inputs** and transfers them at intervals to the DP master.

The DP slave freezes the status of the **inputs** again after each subsequent FREEZE control command.

The input data is not transmitted from the DP slave to the DP master at intervals again until the DP master sends the UNFREEZE control command.

Function grounding

Grounding with the sole purpose of ensuring that the electrical equipment functions properly. By means of function grounding, interference voltages that would otherwise result in inadmissible interference to the equipment are short-circuited.

G

Ground The conductive earth whose electrical potential can be set to zero at any

point.

Around grounding electrodes, the earth may have a potential other than zero.

The term "reference ground" is frequently used in this connection.

Grounding Grounding means to connect an electrically conductive part to the grounding

electrode by means of a grounding system.

I

IP 20 DIN 40050 degree of protection: Protection against finger contact and against

solid foreign matter more than 12 mm in diameter.

L

Load power supply unit

A power supply unit for the ET 200L distributed I/O device and the process

devices connected to it.

M

Master When it is in possession of the token, a master can send data to other nodes

and request data from other nodes (synonymous with active node).

The CPU 315-2 DP and the IM 308-C can be \rightarrow DP masters, for example.

Ν

Node A device that can send, receive or amplify data via the bus (e.g. a DP master,

DP slave, RS 485 repeater or active star coupler).

Non-isolated In the case of non-isolated input/output modules, the reference potentials of

control and load circuits are electrically connected.

Ρ

Parameterization

Parameterization is the passing of slave parameters from the DP master to the DP slave.

Parameters, dynamic

In contrast to static parameters, the dynamic parameters of modules can be changed during operation by calling an SFC in the application program (e.g. limit values of an analog signal input module).

Parameters, static

In contrast to dynamic parameters, the static parameters of modules cannot be changed by means of the application program; they can only by changed by means of STEP 7 (not in RUN mode). An example is the input delay of a digital signal input module.

Programmable logic controller

A programmable logic controller consists of at least one CPU, a number of input and output modules, and operating and monitoring equipment.

PROFIBUS

PROcess FIeld BUS, the German process and field bus standard defined in the PROFIBUS standard (EN 50170 Volume 2, PROFIBUS). It specifies functional, electrical and mechanical characteristics for a bit-serial field bus system.

PROFIBUS is available with the following protocols: DP (= distributed I/O), FMS (= Fieldbus Message Specification), PA (= Process Automation) or TF (= Technological Functions).

PROFIBUS address

Each bus node must have a PROFIBUS address (station number) so that it can be identified uniquely on the PROFIBUS.

PC/PG or the ET 200-Handheld have the PROFIBUS address "0".

The PROFIBUS addresses 1 to 99 are permissible for the ET 200L distributed I/O device.

PROFIBUS-DP

A draft standard (EN 50170 Volume 2, PROFIBUS) on which the ET 200 distributed I/O system is based.

R

Reference potential

The potential on the basis of which the voltages of the circuits involved can be observed and/or measured.

S

Slave

A slave cannot exchange data with a \rightarrow master unless requested by the latter to do so.

Examples of slaves are all DP slaves, such as ET 200B, ET 200L and ET 200M.

Smart Connect SC

The Smart Connect SC enables the fine adjustment of input and output channels to the process. The ET 200L-SC can be upgraded by means of a Smart Connect.

SYNC

SYNC is a control command of the DP master to a group of DP slaves.

By means of the SYNC control command, the DP master causes the DP slave to freeze the statuses of the **outputs** at their current value. In the subsequent frames, the DP slave saves the output data, but the statuses of the outputs remain unchanged.

After each SYNC control command, the DP slave sets the outputs it has saved as output data.

The outputs are not periodically updated again until the DP master sends the UNSYNC control command.

T

Type file

A file required by the configuration software (e.g. COM ET 200 Windows) for configuring a DP slave. The type file contains definitions of the slave-specific properties, such as the number of inputs and outputs, the number of diagnostic bytes, and SYNC capability.

U

Ungrounded

Not having a conductive connection to \rightarrow ground.

Index

Numbers	Bus, Glossary-1
24 VDC supply, 3-4	Bus connector, Glossary-1
24 VDC supply, 5-4	clipping on, 3-12
Α	С
Actuators on the SC, connecting, 11-26	C
Address	Cable cross-sections, 3-9
for queries, v	Cables
for training, v	insulation stripping length, 3-9
Aggregate current, Glossary-1	number, 3-9
Analog value representation of the SC, 11-29	CE marking, 6-2
for input modules, 11-1-11-3, 11-32-11-54	Certification, 6-2
for resistance thermometers, 11-35, 11-48	Changes, since the previous versions of the
for thermocouples, 11-36–11-37,	manual, iii
11-49–11-50	Characteristics
Analog/digital conversion, 11-8	electronics block, 1-7
Applicability of the manual, iii	terminal block, 1-7
Applications, 1-3	Chassis ground, Glossary-1
Assignment, slot module, 2-9	Circuit schematic, 2-13
Assignment of EB to TB, 8-1, 9-1	Climatic environmental conditions, 6-7
	COM PROFIBLE 4.2
	COM PROFIBUS, 4-2
В	Compensating box, 11-12
Pandrata P 2 Classers 1	Components SC 1 10
Baud rate, B-3 , Glossary-1 BF, 5-2, 5-3	Components, SC, 1-10 Configuration, Glossary-1
Block diagram, 1COUNT40kHz, 13-3	Configuration frame, C-4
Block diagram of the analog modules	Configuration frame for the ET 200L-SC, struc-
1 AI RTD, 12-45	ture, C-4
1 AO I, 12-55	Configuration software, 4-2
1 AO U, 12-51	Connect, terminal block, 3-11
2 AI HS U, 12-9	Connecting cables, tightening torque, 3-9
2 AI U, 12-3	Connecting to the SC, loads/actuators, 11-26
2AI HS I, 12-27, 12-33	Connection rules, SC, 2-13, 2-15
2AI I, 12-15, 12-21	Consistent data, Glossary-2
Block diagram, electronic module, SC	Conversion time
1DIAC120/230V, 10-12	analog input channel, 11-8
1DOAC120/230V1A, 10-15	analog output channel, 11-24
1DORel.AC230V, 10-18	Counter module, 13-1
2DIDC24V, 10-3	functions, 13-4
2DODC24V0.5A, 10-6	parameters, 13-17
2DODC24V2A, 10-9	technical data, 13-25
Block I/O device, ET 200L, 1-3	wiring, 13-14
Bridging voltage drops, 6-9	CSA certification, 6-3

Current sensor, 11-15	E
Customer Support, vi	EB L 16 DI AC 120 V, 8-18
Cycle time	block diagram, 8-19
in a module, 11-8, 11-24	characteristics, 8-18
of the system, 11-24	technical data, 8-20
to the system, 11-8	EB L 16 DI DC 24 V, 8-3, 9-4
	block diagram, 8-4
	technical data, 8-5, 9-6
D	
Data exchange, 4-4	view, 8-3 EB L 16 DI/16 DO DC 24 V/0.5 A, 8-15
Default parameters, SC, 11-6	block diagram, 8-16
of the analog output module, 11-22	technical data, 8-16
Default setting for the Smart Connect, C-34,	view, 8-15
C-35, C-38	EB L 16 DO AC 120V/1.0A, 8-21
Default start-up, C-31	block diagram, 8-22
Definition	characteristics, 8-21
electromagnetic compatibility, 6-4	technical data, 8-23
grounded supply, 3-5	EB L 16 DO DC 24 V/0.5 A, 8-6
manufacturer ID, 5-9	block diagram, 8-7
master PROFIBUS address, 5-9	technical data, 8-7
ET 200L, 1-3	view, 8-6
station status, 5-8	EB L 16 DO DC 24 V/AC 120V/2.0 A, 8-24
Degree of protection, 6-8	EB L 32 DI DC 24 V, 8-9
Device master file, B-1 , Glossary-2	block diagram, 8-10
Diagnostics, 5-1, Glossary-2	technical data, 8-11
default start-up for ET 200L-SC, 5-15	view, 8-9
definition, 5-5	EB L 32 DO DC 24 V/0.5 A, 8-12
DP slave, 5-7	block diagram, 8-13
general remarks, 5-6	technical data, 8-13
station for ET 200L-SC, 5-13	view, 8-12
module for ET 200L-SC, 5-10	EB L 8 DI/8 DO AC 120 V/1.0 A, 8-28
using LEDs, 5-2	block diagram, 8-29
Disassemble	characteristics, 8-28
electronics block, 2-6	technical data, 8-29
supplementary terminal, 2-4	EB L 8DI AC 120V/8 DO DC 24V/AC
terminal block, 2-5	120V/2.0A, 8-31
Display	EB L-SC 16 DI/16 DO DC 24 V/0.5 A, 9-13
LED, 5-2, 5-3	block diagram, 9-14
status, 5-2	technical data, 9-14
Disposal, iv	view, 9-13
Distributed I/O device, Glossary-2	EB L-SC 16 DI DC 24 V
DP master, Glossary-2	block diagram, 9-5
DP slave, Glossary-2	view, 9-4
DP standard, Glossary-2	v10 w, 7- 1
DP identifier, C-2	
D1 1001101101, C 2	

EB L-SC 16 DO DC 24 V/0.5 A, 9-7	ET 200, Glossary-3
block diagram, 9-8	components, 1-2
technical data, 9-8	incorporated modules, 1-8
view, 9-7	what is the ET 200, 1-2
EB L-SC 32 DI DC 24 V, 9-10	ET 200 distributed I/O system, 1-2
block diagram, 9-11	ET 200L
technical data, 9-12	block I/O device, 1-3
view, 9-10	characteristics
Electrical installation, configuring, 3-5	electronics block, 1-7
Electrical phenomena, protection against, 3-4	terminal block, 1-7
Electromagnetic compatibility, 6-4	components, 1-9
Electronic module, SC, 1-11, 1-14	definition, 1-3
1 AI RTD, 12-44	view, 1-8
1 AO I, 12-54	wiring, 3-11
1 AO U, 12-50	ET 200L and Smart Connect, what is the ET
1COUNT40kHz, 13-1	200L and Smart Connect, 1-3
1DIAC120/230V, 10-11	ET 200L terminal block, wiring, 3-16
1DOAC120/230V1A, 10-14	ET 200L-SC
1DORel.AC230V, 10-17	modular I/O device, 1-4
2 AI HS I, 12-26, 12-32	modules, 1-10
2 AI HS U, 12-8	ET 200L-SC IM-SC
2 AI I, 12-14, 12-20	components, 1-14
2 AI TC, 12-38	features, 1-13
2 AI U, 12-2	fine-step modular I/O device, 1-5
2DIDC24V, 10-2	IM-SC interface module, 1-13
2DODC24V0.5A, 10-5	Expansion, 4-5
2DODC24V0.5A, 10-5 2DODC24V2A, 10-8	Expansion, 4-3
connecting additional, 4-5	
installing, 2-13	F
Electronics block	Г
characteristics, 1-7	Fine-step modular I/O device, ET 200L-SC IM-
disassembling, 2-6	SC, 1-5
L 16 DI AC 120 V, 8-18	Floating, Glossary-3
L 16 DI DC 24 V, 8-18	FM approval, 6-3
	FREEZE, Glossary-3
L 16 DI/16 DO DC 24 V/0.5 A, 8-15	Function grounding, Glossary-3
L 16 DO AC 120V/1.0A, 8-21	Functioning, of thermocouples, 11-9
L 16 DO DC 24 V/0.5 A, 8-6 L 16 DO DC 24 V/AC 120 V/2.0 A, 8-24	
L 32 DI DC 24 V, 8-9	
	G
L 32 DO DC 24 V/0.5 A, 8-12 L 8 DI AC 120V/8 DO DC 24 V/AC	Constal technical data ET 2001 6 1
	General technical data, ET 200L, 6-1
120V/2.0A, 8-31	Ground, Glossary-4
L 8 DI/8 DO AC 120 V/1.0 A, 8-28	Grounded supply, 3-5
L-SC 16 DI DC 24 V, 9-4	Grounding, Glossary-4
L-SC 16 DI/16 DO DC 24 V/0.5 A, 9-13	
L-SC 32 DI DC 24 V, 9-10	11
L-SC 16 DO DC 24 V/0.5 A, 9-7	Н
EMC, 3-6	Hotline, vi
EMERGENCY STOP devices, 3-3	
Emission of radio interference, 6-5	
Equalizing circuit, 11-12	
Equipotential bonding, Glossary-3	

1	IVI
Identifier, C-6	Mailbox, vi
Identifiers for the ET 200L, C-2	Maintenance, 4-5
Identifiers for the ET 200L-SC, C-6	Manual
IEC 1131, 6-2	aids to using, v
IM-SC, 9-2	electronic, iv
block diagram, 9-3	other, iv
characteristics, 9-2	purpose of, iii
technical data, 9-3	Manufacturer ID, C-2
view, 9-2	definition, 5-9
IM-SC interface module, 1-13	structure, 5-9
installing on the terminal block, 2-17	Master, Glossary-4
wiring, 3-18	Master PROFIBUS address
Input ranges, SC	definition, 5-9
bipolar, 11-30, 11-43	structure, 5-9
life-zero, 11-31, 11-44	Measurement type/measurement range, 11-4
unipolar, 11-30, 11-43	Measuring sensor, floating, 11-18
Installation, 2-1	Mechanical environmental conditions, 6-7
electronics block, 2-6	Modular I/O device, ET 200L-SC, 1-4
requirements, 2-3	Modules of the ET 200L-SC, 1-10
supplementary terminal, 2-4	
terminal block, 2-4	
Installation dimensions, SC, 2-7	N
Installation, ET 200L, sequence, 2-1	Node, Glossary-4
Installing	Non-isolated, Glossary-4
terminal block for the Smart Connect, 2-8	, ,
the IM-SC interface module, 2-17	
Insulation stripping length, ET 200L, 3-9	0
Insulation test, 6-8	ON 5 2 5 2
Interface module IM-SC, 9-2	ON, 5-2, 5-3 Operating regulations, 3-3
Interference frequency suppression, SC, 11-5 Internet, vi	Output ranges, SC
IP 20, Glossary-4	bipolar, 11-37, 11-50
11 20, Glossary-4	life-zero, 11-38, 11-51
	unipolar, 11-37, 11-50
L	Output type/output range, 11-21
L	Overall installation in TN system, 3-7
Label, 3-12	Overall installation in 114 system, 5 7
Labeling sheet, SC, 1-12, 1-15	
Labeling strips, SC, 2-9, 2-15	Р
LED, 5-2, 5-3	-
BF, 5-2, 5-3	Parameterization, Glossary-5
ON, 5-2, 5-3	tool for, 11-2, 11-20
LEDs on the ET 200L-SC, 5-3	Parameterization frame, C-14
Load circuit, 3-6	Parameters for the Smart Connect, C-17
Load current power supply, characteristics, 3-6	Plug-in rules, SC, 2-14
Load power supply unit, Glossary-4	Power supply, 1-6
Loads on the SC, connecting, 11-26	connecting, 3-17
Local ground, 3-14	Preface, iii

Previous version, of the manual, iii Product overview, 1-1 PROFIBUS, Glossary-5 address, Glossary-5 location of rotary switch, 2-18 address modifying, 2-18 address validity, 2-18 PROFIBUS address, setting, 2-18 PROFIBUS-DP terminal connection, 3-13 PROFIBUS-DP, 1-2, Glossary-5	Smart Connect connecting, 3-24 connecting cable, 1-11 wiring, 3-14 Smart Connect SC, 1-10 Smoothing, SC, 11-5 Standards, 6-2 Standards and certification, 6-2 Start-up, 4-4 of plant, 3-3
Programmable logic controller, Glossary-5 Protection against electrical phenomena, 3-4 Protective measures, 3-5 PS. <i>See</i> Power supply Pulse-shaped interference, 6-4	Start-up types, C-3 Static parameters, of the analog output modules, 11-20 Station diagnosis, 5-13 Station status
Q Queries, v	definition, 5-8 structure Part 1, 5-8 Part 2, 5-9 Part 3, 5-9 STEP 7, 4-2
Rail, 1-6 Rated voltage, 6-9 Recycling, iv Reference junction, 11-5, 11-12 Reference potential, Glossary-5 Reference temperature, 11-5 Resistance thermometer, 11-17 Resistors, 11-17 Resolution, 11-29 Response time of the SC, analog output, 11-25 Rotary switch, 2-18 Rules for electronic modules, 2-13 general, 3-3	Storage conditions, 6-6 Structure, of thermocouples, 11-9 Structure of the slave diagnosis, 5-7 Supplementary terminal, 7-18 dimension drawing, 7-19, 7-20 disassembling, 2-4 for TB 16SC and TB 16IM-SC, 7-20 installing, 2-4 versions supplied, 7-18, 7-20 Supplementary terminal ET 200L, SC, 1-15 Supplementary terminal, ET 200L, SC securing, 2-19 using, 3-22 Supplementary terminal, SC, 1-11 Supply isolating switch, 3-3 Supply voltage, 3-3 SYNC, Glossary-6 System designation, note on labeling strip, 2-12
Safety class, 6-8 Safety regulations, 3-3 Settling time, SC, analog output, 11-25 Shield terminal, SC, 1-12, 1-15 Shipping conditions, 6-6 SIMATIC Customer Support, vi Sine-shaped interference, 6-5 Slave, 5-5, Glossary-6 diagnosis, structure, 5-7 requesting, 5-7 Slot, SC, 2-13	T TB 16IM-SC, 7-14 block diagram, 7-17 characteristics, 7-14 dimension drawing, 7-16 terminal designation, 3-17 wiring, 3-16

TB 16L, 7-2	Terminal connection model, 3-12
dimension drawing, 7-2	Terminal designation, TB 16SC, TB 16IM-SC
pinout, 7-3	3-17
technical data, 7-3, 7-13, 7-17	Test voltage, 6-8
TB 16L AC, 7-7	Thermocouple types, 11-9
dimension drawing, 7-8	Thermocouple, SC, 11-9
pinout, 7-9	how it works, 11-9
technical data, 7-9	structure, 11-9
TB 16SC, 7-10	with compensating box, 11-13
dimension drawing, 7-12	Tightening torque, connecting cables, 3-9
wiring, 3-14	TN system, 3-7
TB 32L, 7-4	Training, v
dimension drawing, 7-5	Type file, B-1 , Glossary-6
pinout, 7-6	Type files for the default start-up, C-32
technical data, 7-6	Type files, device master files, B-1
Technical data	-JF,
1AI RTD, 12-48	
1AO I, 12-57	U
1AO U, 12-53	
1COUNT40kHz, 13-25	UL recognition, 6-3
1DIAC120/230V, 10-13	Ungrounded, Glossary-6
1DOAC120/230V1A, 10-16	
1DORel.AC230V, 10-19	
2AI I, 12-18, 12-24	V
2AI HS I, 12-30, 12-36	View of ET 200L, 1-8
2AI TC, 12-42	Voltage drop, 6-9
2AI HS U, 12-12	Voltage sensor, non-isolated, 11-14
2AI U , 12-6	voltage sensor, non isolated, 11 11
2DIDC24V , 10-4	
2DODC24V0.5A, 10-7	W
2DODC24V2A, 10-10	
climatic environmental conditions, 6-7	Wiring
data of the individual components, 8-1, 9-1	ET 200L and Smart Connect, 3-1
electromagnetic compatibility, 6-4	ET 200L terminal block, 3-16
general, ET 200L, 6-1	IM-SC interface module, 3-18
mechanical environmental conditions, 6-7	Smart Connect, 3-14
transport and storage conditions, 6-6	TB 16IM-SC, 3-16
Temperature measurement, 11-9	TB 16SC, 3-14
Terminal block	terminal block (spring terminal), 3-10
(spring terminal) wiring, 3-10	Wiring rules, SC, 3-9
characteristics, 1-7	
connecting, 3-11	
disassembling, 2-5	
installing, 2-4	
snapping onto, SC, 2-8	
TB 16IM-SC, 1-14, 7-14	
TB 16L, 7-2	
TB 16L, 7-2 TB 16L AC, 7-7	
TB 16SC, 7-10	
TB 32L, 7-4	
TB16-SC, 1-11	
111000, 111	

Sie	mens AG		
A&	ED AS E 148		
Pos	etfach 1963		
D-9	92209 Amberg		
Fed	leral Republic of Germany		
Fro	m:		
You	ır Name:		
Coı	mpany Name:		
	~		
	City, Zip Code:		
Ple	ase check any industry that applies to you	:	
	Automotive		Pharmaceutical
	Chemical		Plastic
	Electrical Machinery		Pulp and Paper
	Food		Textiles
	Instrument and Control		Transportation

□ Nonelectrical Machinery □ Other _ _ _ _ _ _

Petrochemical

Remarks Form

Your comments and recommendations will help us to improve the quality and usefulness of our publications. Please take the first available opportunity to fill out this questionnaire and return it to Siemens.

	e give each of the following questions your own personal mark within the range 1 (very good) to 5 (poor).					
1.	Do the contents meet your requirements?					
2.	Is the information you need easy to find?					
3.	Is the text easy to understand?					
4.	Does the level of technical detail meet your requirements?					
5.	Please rate the quality of the graphics/tables:					
6.						
7.						
8.						
Addi	tional comments:					
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				

Sie	mens AG		
A&	ED AS E 148		
Pos	etfach 1963		
D-9	92209 Amberg		
Fed	leral Republic of Germany		
Fro	m:		
You	ır Name:		
Coı	mpany Name:		
	~		
	City, Zip Code:		
Ple	ase check any industry that applies to you	:	
	Automotive		Pharmaceutical
	Chemical		Plastic
	Electrical Machinery		Pulp and Paper
	Food		Textiles
	Instrument and Control		Transportation

□ Nonelectrical Machinery □ Other _ _ _ _ _ _

Petrochemical

Remarks Form

Your comments and recommendations will help us to improve the quality and usefulness of our publications. Please take the first available opportunity to fill out this questionnaire and return it to Siemens.

	e give each of the following questions your own personal mark within the range 1 (very good) to 5 (poor).					
1.	Do the contents meet your requirements?					
2.	Is the information you need easy to find?					
3.	Is the text easy to understand?					
4.	Does the level of technical detail meet your requirements?					
5.	Please rate the quality of the graphics/tables:					
6.						
7.						
8.						
Addi	tional comments:					
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				
		_				