


**Features** 60.62 60.63

### Flange mount 10 A General purpose relay

- Flange mount (Faston 187, 4.8x0.8 mm termination)
- 2 & 3 pole changeover contacts
- AC coils & DC coils
- Cadmium Free contacts (preferred version)
- Contacts material options


Approvals (according to type)








• 3 pole - 10 A power contacts • Flange mount/Faston 187





Contact specification  Contact configuration			
Contact configuration			
Contact configuration	2 CO (DPDT)	3 CO (3PDT)	
Rated current/Maximum peak current	10/20	10/20	
Rated voltage/Maximum switching voltage V AC	250/400	250/400	
Rated load AC1	2,500	2,500	
Rated load AC15 (230 V AC)	500	500	
Single phase motor rating (230 V AC) $$	0.37	0.37	
Breaking capacity DC1: 30/110/220 V	10/0.4/0.15	10/0.4/0.15	
Minimum switching load mW (V/mA	500 (10/5)	500 (10/5)	
Standard contact material	AgNi	AgNi	
Coil specification			
Nominal voltage ( $U_N$ ) V AC (50/60 Hz	6 - 12 - 24 - 48 - 60 - 110 - 120 - 230 - 240 - 400		
V DO	6 - 12 - 24 - 48 - 60 - 110 -125 - 220		
Rated power AC/DC VA (50 Hz)/W	2.2/1.3	2.2/1.3	
Operating range AC	(0.81.1)U <sub>N</sub>	(0.81.1)U <sub>N</sub>	
DC	(0.81.1)U <sub>N</sub>	(0.81.1)U <sub>N</sub>	
Holding voltage AC/DC	0.8 U <sub>N</sub> /0.5 U <sub>N</sub>	0.8 U <sub>N</sub> /0.5 U <sub>N</sub>	
Must drop-out voltage AC/DC	0.2 U <sub>N</sub> /0.1 U <sub>N</sub>	0.2 U <sub>N</sub> /0.1 U <sub>N</sub>	
Technical data			
Mechanical life AC/DC cycle	20 · 106/50 · 106	20 · 106/50 · 106	
Electrical life at rated load AC1 cycle	200 · 10³	200 · 10³	
Operate/release time m.	9/9	9/9	
Insulation between coil and contacts (1.2/50 $\mu s)$ $kV$	3.6	3.6	
Dielectric strength between open contacts VAC	1,000	1,000	
Ambient temperature range °C	_40+70	-40+70	
Environmental protection	RT I	RT I	

B & @ \

IRAM

N

RINA

CE ABS

CAL US VDE

(DC, polarity positive to pin 2) +


mechanical indicator

(finder

# 60

## **Ordering information**

Example: 60 series plug-in relay, 3 CO (3PDT), 12 V DC coil, test button and mechanical indicator.




## Selecting features and options: only combinations in the same row are possible.

Preferred selections for best avaliability are shown in **bold**.

Туре	Coil version	Α	В	С	D
60.12/13	AC	<b>0</b> - 2	0	0 - 2 - 3 - <b>4</b> - 5	0
	AC	0 - 2	0	54	/
	AC	5	0 - 2	0 - 2 - 3 - 4 - 5	0
	AC	5	0 - 2	54	/
	DC	<b>0</b> - 2	0	0 - 2 - <b>4</b> - 6 - 7	0
	DC	0 - 2	0	74	/
	DC	5	0 - 2	0 - 2 - 4 - 6 - 7	0
	DC	5	0 - 2	74	/
	current sensing	0	0	4	0
60.62/63	AC-DC	<b>0</b> - 2 - 5	0	0	0

#### **Descriptions: Options and Special versions**







#### Lockable test button and mechanical flag indicator (0040)

The dual-purpose Finder test button can be used in two ways:

<u>Case 1</u>) The plastic pip (located directly above the test button) remains intact. In this case, when the test button is pushed, the contacts operate. When the test button is released the contacts return to their former state.

<u>Case 2</u>) The plastic pip is broken-off (using an appropriate cutting tool). In this case, (in addition to the above function), when the test button is pushed and rotated, the contacts are latched in the operating state, and remain so until the test button is rotated back to its former position. In both cases ensure that the test button actuation is swift and decisive.