The PSU 206 is a 'Eurocard' sized power supply unit designed primarily for OEM use. The linear regulator Ics used have over-current and over-temperature protection.

Stock Number

Max.

70

5.25

1000

-15

-250

PSU 206

Unit

% mV

mΑ

mΑ

mΑ

VAC

- **⚠** Simple Screw-Terminal Connection
- Encapsulated Mains Transformer
- Fixed 5V Output

Standard Unit

pecification

Load regulation

Line regulation

Operating temperature

Positive Adjustable

Negative Adjustable

Input (50-60Hz)

link selectable

Output (D.C.) at 25°C

Ripple


5V Fixed

Separate, Fully Adjustable Split Rail Outputs



Derating Curve

The hotter the unit becomes the lower the current that may be taken from it. Enclosures should be adequately ventilated if necessary and power supplies should not be mounted upside down.



240V 120V 1240 240 240 240 240 2

240V 120V 240 240 28 28 28		Output	Terminal	
		5V Fixed	5V & 02	
		Adjust. Pos	V+ & 01	
		Adjust. Neg	V- & 01	

Selecting Mains I/P Voltage

The unit is normally supplied connected for 240V operation. For 120V operation remove 240V link and insert BOTH 120V links.

120

240

Min.

4.75

0


5

220

Safety

For safe operation the unit must be installed in an enclosure which prevents accidental contact. If the enclosure is made of a conducting material or the internal surfaces have a conductive coating, ensure that no part of the power supply will come into contact with it. The unit need not be earthed but two terminals (E) are provided as a convenient anchorage for earth leads. The mains lead to the unit must be fused with a 160mA (240V operation) or a 315mA (120V operation) fuse. Fuses should be IEC 127 part 2, sheet 3, DIN 41662 anti-surge spiral. In general, it is the responsibility of the user to ensure that the incorporation of the power supply unit into the OEM equipment conforms to the relevant sections of EN 60742, in accordance with the Low Voltage Directive (LVD93/68/EEC).

IF IN DOUBT CONTACT AN APPLICATIONS ENGINEER.



Applies to PSU 206/4 Specifications liable to change without prior warning PSU 206 Issue 14 06/2010 S.L.

LASCAR ELECTRONICS LTD. MODULE HOUSE, WHITEPARISH, WILTSHIRE SP5 2ST UK TEL: +44 (0)1794 884567 FAX: +44 (0)1794 884616 E-mail: sales@lascar.co.uk

LASCAR ELECTRONICS INC. 4258 WEST 12th Street, ERIE, PA 16505 USA TEL: +1 (814) 835 0621 FAX: +1 (814) 838 8141 E-mail: us-sales@lascarelectronics.com

No: 716 - Page 1 of 1 LASCAR ELECTRONICS (HK) LTD. 8th FLOOR, CHINA AEROSPACE CENTRE, 143 HOI BUN ROAD, KWUN TONG, KOWLOON,HK TEL: +852 2389 6502 FAX: +852 2389 6535 E- mail: saleshk@lascar.com.hk



The PSU 206 is a 'Eurocard' sized power supply unit designed primarily for OEM use. The linear regulator Ics used have over-current and over-temperature protection.

- Simple Screw-Terminal Connection
- **Encapsulated Mains Transformer**
- Fixed 5V Output
- Separate, Fully Adjustable Split Rail Outputs





Derating Curve

1009

40%

Output

Current

The hotter the unit becomes the lower the current that may be taken from it. Enclosures should be adequately ventilated if necessary and power supplies should not be mounted upside down.


1111111111

111111111

TITLIBLE

Ambient Temperature °C

KELLER



Standard Unit					PSU 206
Specification		Min.	Тур.	Max.	Unit
Load regulation				1	%
Line regulation				1	%
Ripple				10	mV
Operating temperature		0		70	°C
Output (D.C.) at 25°C					
5V Fixed	V	4.75	5	5.25	V
	1	0		1000	mA
Positive Adjustable	V	5		15	V
	1			250	mA
Negative Adjustable	V	-5		-15	V
				-250	mA
Input (50-60Hz)		110	120	125	VAC
- link selectable		220	240	250	VAC

Selecting Mains I/P Voltage


The unit is normally supplied connected for 240V operation. For 120V operation remove 240V link and insert BOTH 120V links.

Output	Terminals
5V Fixed	5V & 02
Adjust. Pos	V+ & 0 ₁
Adjust. Neg	V- & 01

Safety

For safe operation the unit must be installed in an enclosure which prevents accidental contact. If the enclosure is made of a conducting material or the internal surfaces have a conductive coating, ensure that no part of the power supply will come into contact with it. The unit need not be earthed but two terminals (E) are provided as a convenient anchorage for earth leads. The mains lead to the unit must be fused with a 160mA (240V operation) or a 315mA (120V operation) fuse. Fuses should be IEC 127 part 2, sheet 3, DIN 41662 anti-surge spiral. In general, it is the responsibility of the user to ensure that the incorporation of the power supply unit into the OEM equipment conforms to the relevant sections of EN 60742, in accordance with the Low Voltage Directive (LVD93/68/EEC).

IF IN DOUBT CONTACT AN APPLICATIONS ENGINEER.



Applies to PSU 206/4 Specifications liable to change without prior warning **PSU 206** Issue 14 06/2010 S.L.

LASCAR ELECTRONICS LTD. MODULE HOUSE, WHITEPARISH, WILTSHIRE SP5 2SI UK

LASCAR ELECTRONICS INC. 4258 WEST 12th Street, ERIE, PA 16505 USA TEL: +1 (814) 835 0621 FAX: +1 (814) 838 8141 E-mail: us-sales@lascarelectronics.com

No: 716 - Page 1 of 1 LASCAR ELECTRONICS (HK) LTD. 8th FLOOR, CHINA AEROSPACE CENTRE, 143 HOI BUN ROAD, KWUN TONG, KOWLOON,HK TEL: +852 2389 6502 FAX: +852 2389 6535 E- mail: sales hk@lascar.com.hk

TEL: +44 (0) 1794 884567 FAX: +44 (0) 1794 884616 E-mail: sales@lascar.co.uk